



SV680-INT Series Servo Drive Communication Guide



Industrial
Automation



Intelligent
Elevator



New Energy
Vehicle



Industrial
Robot



Rail
Transit



Data code PS00015535A01

Preface

Introduction

The SV680-INT series servo drive is a high-end servo drive designed based on global-leading standards and high-end application needs. It is featured with high speed, high precision, high performance, and tuning-free function. Compliant with CE, UL, KC, EAC, UKCA and TUV certification requirements and top international quality standards, it is specially suitable for high-end applications.

Its power ranges from 0.05 kW to 7.5 kW. It supports Modbus, CANopen and EtherCAT communication protocols and carries necessary communication interfaces to work with the host controller for implementing a networked operation of multiple servo drives. The servo drive supports adaptive stiffness level setting, inertia auto-tuning, and vibration suppression for easy use. The drive, together with an MS1 series high-response servo motor (with ultra-low, low or medium inertia) equipped with a 23- or 26-bit single-turn/multi-turn absolute encoder, any third party servo motor, linear motor or DDR motor, serves to deliver a quiet and stable operation and accurate process control through features like fully closed-loop, internal process segment and gantry synchronization.

The drive also comes with features like safe torque off, dynamic braking, and brake output (external relay not needed) as standard and supports extension of seven kinds of functional safety and bus functional safety FSoE (the PINT version further offers 24V backup power) for continuous safe production. The drive aims to achieve quick and accurate position control, speed control, and torque control through high-performance solutions for automation equipment in such industries as electronic manufacturing, lithium batteries, manipulators, packaging, and machine tools.

This manual introduces the communication of the drive, including configuration of Modbus, CANopen, and EtherCAT communication and application cases.

Note

The speed of a servo motor and DDR motor is in RPM and DDL motor is in mm/s. RPM is used throughout the manual. Unless otherwise specified, an RPM value is equivalent to the mm/s one.


Abbreviation

The following abbreviations will be used herein to refer to the corresponding servo drives.

| Abbreviation | Servo drive |
|--------------|-------------|
| [P] | SV680P***** |
| [N] | SV680N***** |

More documents

The documents related to the drive are shown in the following figure and table.



| No. | Name | Data Code | Description |
|-----|---|------------|--|
| ① | SV680-INT series flagship servo drive | 19120347 | Provides instructions on product selection, including the list of supporting components, technical data on the drive, and the selection guide of cables. |
| ② | SV680-INT Series Servo Drive Installation and Commissioning Quick Guide | PS00015536 | Describes the model number, installation, terminals and quick commissioning and operation of the drive. |
| ③ | SV680-INT Series Servo Drive Hardware Guide | PS00015494 | Describes technical data, installation, terminals, required certificates and standards and solutions to common EMC problems of the drive. |
| ④ | SV680-INT Series Servo Drive Function Guide | PS00015554 | Introduces the functions and faults of the drive, including function overview, adjustment, basic servo functions and fault handling. |
| ⑤ | SV680-INT Series Servo Drive Communication Guide | PS00015535 | Introduces the communication of the drive, including configuration of Modbus, CANopen, and EtherCAT communication. |
| ⑥ | SV680P-INT Series Servo Drive Safety Guide | PS00009740 | Describes the safety function and related certifications and standards, wiring, commissioning process, troubleshooting and parameters of the drive. |
| | SV680N-INT Series Servo Drive Safety Guide | PS00009768 | |
| ⑦ | SV680-INT Series Servo Drive Parameter Guide | PS00015555 | Introduces the parameters of the drive, including a parameter list and description of parameters. |

| No. | Name | Data Code | Description |
|-----|--|------------|---|
| ⑧ | MS1-R Series Servo Motor Selection Guide | PS00004605 | Introduces the product information, general specifications, motor selection, cable selection, and required certificates and standards of the servo motor. |
| | MS1-R Series Servo Motor Installation Guide | PS00005407 | Describes installation of the motor, including an installation flowchart, unpacking and transportation, mechanical installation, and electrical installation. |
| | Direct drive motor module platform and drive | 19120011 | Introduces the product information, general specifications, motor selection, cable selection, and required standards of the motor. |

Revision History

| Date | Version | Description |
|---------|---------|-------------------------|
| 2024-03 | A01 | Made minor corrections. |
| 2024-02 | A00 | First release |

Access to the Guide

This guide is not delivered with the product. You can obtain the PDF version in the following way:

- Visit <http://www.inovance.com>, go to Support > Download, search by keyword, and then download the PDF file.
- Scan the QR code on the product with your mobile phone.
- Scan the QR code below to install the app, where you can search for and download manuals.



Warranty

Inovance provides warranty service within the warranty period (as specified in your order) for any fault or damage that is not caused by improper operation of the user. You will be charged for any repair work after the warranty period expires.

Within the warranty period, maintenance fee will be charged for the following damage:

- Damage caused by operations not following the instructions in the user guide
- Damage caused by fire, flood, or abnormal voltage
- Damage caused by unintended use of the product

- Damage caused by use beyond the specified scope of application of the product
- Damage or secondary damage caused by force majeure (natural disaster, earthquake, and lightning strike)

The maintenance fee is charged according to the latest Price List of Inovance. If otherwise agreed upon, the terms and conditions in the agreement shall prevail.

For details, see the Product Warranty Card.

Table of Contents

| | |
|--|----|
| Preface | 1 |
| Fundamental Safety Instructions | 7 |
| 1 Communication Protocols | 14 |
| 2 Modbus Communication [P] | 15 |
| 2.1 Communication | 15 |
| 2.1.1 Communication technical data | 15 |
| 2.1.2 Protocols | 15 |
| 2.2 Hardware Configuration | 15 |
| 2.2.1 Terminal Layout | 15 |
| 2.2.2 RS485 Communication Connection Example | 16 |
| 2.3 Communication Transmission Mode | 18 |
| 2.4 Data Frame Structure | 19 |
| 2.5 Communication Parameters | 27 |
| 3 CANopen Communication [P] | 29 |
| 3.1 Communication | 29 |
| 3.1.1 Communication Technical Data | 29 |
| 3.1.2 Protocols | 30 |
| 3.2 Hardware Configuration | 30 |
| 3.2.1 Terminal Layout | 30 |
| 3.2.2 CAN Communication Connection Example | 30 |
| 3.3 Communication Transmission Mode | 33 |
| 3.4 Data Frame Structure | 34 |
| 3.4.1 Network Management System (NMT) | 34 |
| 3.4.2 Service data object (SDO) | 39 |
| 3.4.3 Process Data Object (PDO) | 39 |
| 3.4.4 Synchronization Object (SYNC) | 45 |
| 3.4.5 Emergency (EMCY) Object Service | 48 |
| 3.4.6 SDO Transmission Message | 49 |
| 3.4.7 SDO transmission framework | 51 |
| 3.5 Communication Parameters | 52 |
| 3.6 PN-to-CANopen bridge | 53 |
| 4 EtherCAT Communication [N] | 56 |
| 4.1 Communication | 56 |
| 4.1.1 Communication technical data | 56 |
| 4.1.2 Communication Specifications | 57 |
| 4.1.3 Protocols | 57 |
| 4.2 Hardware Configuration | 59 |

| | |
|--|-----|
| 4.2.1 Terminal Layout | 59 |
| 4.2.2 EtherCAT Communication Connection Example | 60 |
| 4.3 Communication Transmission Mode | 62 |
| 4.3.1 Structure of EtherCAT Communication | 62 |
| 4.3.2 Communication State Machine. | 63 |
| 4.3.3 Distributed clock. | 64 |
| 4.3.4 Status Indication. | 65 |
| 4.4 Data Frame Structure | 68 |
| 4.4.1 Process data | 68 |
| 4.4.2 Service Data Object (SDO) | 73 |
| 4.5 Communication Parameters | 73 |
| 5 Communication Configuration Instance. | 75 |
| 5.1 Modbus Communication Configuration Case [P] | 75 |
| 5.1.1 Communication Overview | 75 |
| 5.1.2 Wiring of Modbus RTU Communication Between SV680P-INT and Third-Party PLCs | 75 |
| 5.1.3 Servo Parameter Settings | 77 |
| 5.1.4 PLC Program Examples | 77 |
| 5.2 CANopen Communication Configuration Case [P] | 78 |
| 5.2.1 Connecting SV680P-INT to Schneider 3S Master | 78 |
| 5.2.2 Connecting SV680P-INT to Beckhoff CANopen Master. | 97 |
| 5.2.3 Connecting SV680P-INT to Inovance H3U CANopen Master | 117 |
| 5.2.4 Connecting SV680P-INT to Inovance EASY CANopen Master. | 128 |
| 5.3 EtherCAT Communication Configuration Case [N]. | 138 |
| 5.3.1 SV680N-INT and AM600 Controller | 138 |
| 5.3.2 SV680N-INT and Omron Controller. | 147 |
| 5.3.3 SV680N-INT and Beckhoff Controller | 162 |
| 5.3.4 SV680N-INT and KEYENCE KV7500 Controller. | 179 |
| 5.3.4.1 Configuring the Servo Drive. | 179 |
| 5.3.4.2 Configuring KEYENCE KV7500 Software Tool | 179 |
| 5.3.4.3 Trial Run. | 194 |
| 5.3.5 SV680N-INT and EASY Controller | 196 |

Fundamental Safety Instructions

Safety Precautions

- This chapter presents essential safety instructions for a proper use of the equipment. Before operating the equipment, read through the guide and comprehend all the safety instructions. Failure to comply with the safety precautions may result in death, serious injury, or equipment damage.
- "CAUTION", "WARNING", and "DANGER" items in the guide only indicate some of the precautions that need to be followed; they just supplement the safety precautions.
- Use this equipment according to the designated environment requirements. Damage caused by improper use is not covered by warranty.
- Inovance shall take no responsibility for any personal injuries or property damage caused by improper usage.

Safety Levels and Definitions



Indicates that failure to comply with the notice will result in death or severe personal injuries.



Indicates that failure to comply with the notice may result in death or severe personal injuries.



Indicates that failure to comply with the notice may result in minor or moderate personal injuries or equipment damage.

Fundamental Safety Instructions

- Drawings in the guide are sometimes shown without covers or protective guards. Remember to install the covers or protective guards as specified first, and then perform operations in accordance with the instructions.
- The drawings in the guide are shown for illustration only and may be different from the product you purchased.
- Users must take mechanical precautions to protect personal safety and wear protective equipment, such as anti-smashing shoes, safety clothing, safety glasses, protective gloves, and protective sleeves.

Unpacking

 WARNING

- Do not install the equipment if you find damage, rust, or signs of use on the equipment or accessories upon unpacking.
- Do not install the equipment if you find water seepage or missing or damaged components upon unpacking.
- Do not install the equipment if you find the packing list does not conform to the equipment you received.

 CAUTION

- Check whether the packing is intact and whether there is damage, water seepage, dampness, and deformation before unpacking.
- Unpack the package by following the unpacking sequence. Do not strike the package violently.
- Check whether there is damage, rust, or injuries on the surface of the equipment and equipment accessories before unpacking.
- Check whether the package contents are consistent with the packing list before unpacking.

Storage and Transportation

 WARNING

- Large-scale or heavy equipment must be transported by qualified professionals using specialized hoisting equipment. Failure to comply may result in personal injuries or equipment damage.
- Before hoisting the equipment, ensure the equipment components such as the front cover and terminal blocks are secured firmly with screws. Loosely-connected components may fall off and result in personal injuries or equipment damage.
- Never stand or stay below the equipment when the equipment is being hoisted by the hoisting equipment.
- When hoisting the equipment with a steel rope, ensure the equipment is hoisted at a constant speed without suffering from vibration or shock. Do not turn the equipment over or let the equipment stay hanging in the air. Failure to comply may result in personal injuries or equipment damage.

 CAUTION

- Handle the equipment with care during transportation and mind your steps to prevent personal injuries or equipment damage.
- When carrying the equipment with bare hands, hold the equipment casing firmly with care to prevent parts from falling. Failure to comply may result in personal injuries.
- Store and transport the equipment based on the storage and transportation requirements. Failure to comply will result in equipment damage.
- Avoid storing or transporting the equipment in environments with water splash, rain, direct sunlight, strong electric field, strong magnetic field, and strong vibration.
- Avoid storing the equipment for more than three months. Long-term storage requires stricter protection and necessary inspections.
- Pack the equipment strictly before transportation. Use a sealed box for long-distance transportation.
- Never transport the equipment with other equipment or materials that may harm or have negative impacts on this equipment.

Installation DANGER

- The equipment must be operated only by professionals with electrical knowledge. Non-professionals are not allowed.

 WARNING

- Read through the guide and safety instructions before installation.
- Do not install this equipment in places with strong electric or magnetic fields.
- Before installation, check that the mechanical strength of the installation site can bear the weight of the equipment. Failure to comply will result in mechanical hazards.
- Do not wear loose clothes or accessories during installation. Failure to comply may result in an electric shock.
- When installing the equipment in a closed environment (such as a cabinet or casing), use a cooling device (such as a fan or air conditioner) to cool the environment down to the required temperature. Failure to comply may result in equipment over-temperature or a fire.
- Do not retrofit the equipment.
- Do not fiddle with the bolts used to fix equipment components or the bolts marked in red.
- When the equipment is installed in a cabinet or final assembly, a fireproof enclosure providing both electrical and mechanical protections must be provided. The IP rating must meet IEC standards and local laws and regulations.
- Before installing equipments with strong electromagnetic interference, such as a transformer, install a shielding equipment for the equipment to prevent malfunction.
- Install the equipment onto an incombustible object such as a metal. Keep the equipment away from combustible objects. Failure to comply will result in a fire.

 CAUTION

- Cover the top of the equipment with a piece of cloth or paper during installation. This is to prevent unwanted objects such as metal chippings, oil, and water from falling into the equipment and causing faults. After installation, remove the cloth or paper on the top of the equipment to prevent over-temperature caused by poor ventilation due to blocked ventilation holes.
- Resonance may occur when the equipment operating at a constant speed executes variable speed operations. In this case, install the vibration-proof rubber under the motor frame or use the vibration suppression function to reduce resonance.

Wiring

 DANGER

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Before wiring, cut off all the power supplies of the equipment. and wait for at least the time designated on the equipment warning label before further operations because residual voltage still exists after power-off. After waiting for the designated time, measure the DC voltage in the main circuit to ensure the DC voltage is within the safe voltage range. Failure to comply will result in an electric shock.
- Do not perform wiring, remove the equipment cover, or touch the circuit board with power ON. Failure to comply will result in an electric shock.
- Check that the equipment is grounded properly. Failure to comply can result in electric shock.

 WARNING

- Do not connect the input power supply to the output end of the equipment. Failure to comply can result in equipment damage or even a fire.
- When connecting a drive to the motor, check that the phase sequences of the drive and motor terminals are consistent to prevent reverse motor rotation.
- Cables used for wiring must meet cross sectional area and shielding requirements. The shield of the cable must be reliably grounded at one end.
- Fix the terminal screws with the tightening torque specified in the user guide. Improper tightening torque may overheat or damage the connecting part, resulting in a fire.
- After wiring is done, check that all cables are connected properly and no screws, washers or exposed cables are left inside the equipment. Failure to comply may result in an electric shock or equipment damage.

 CAUTION

- Follow the proper electrostatic discharge (ESD) procedure and wear an anti-static wrist strap to perform wiring. Failure to comply may result in damage to the equipment or to the internal circuit of the product.
- Use shielded twisted pairs for the control circuit. Connect the shield to the grounding terminal of the equipment for grounding purpose. Failure to comply will result in equipment malfunction.

Power-on

**DANGER**

- Before power-on, check that the equipment is installed properly with reliable wiring and the motor can be restarted.
- Check that the power supply meets equipment requirements before power-on to prevent equipment damage or a fire.
- After power-on, do not open the cabinet door or protective cover of the equipment, touch any terminal, or disassemble any unit or component of the equipment. Failure to comply will result in an electric shock.

**WARNING**

- Perform a trial run after wiring and parameter setting to ensure the equipment operates safely. Failure to comply may result in personal injuries or equipment damage.
- Before power-on, check that the rated voltage of the equipment is consistent with that of the power supply. Failure to comply may result in a fire.
- Before power-on, check that no one is near the equipment, motor, or machine. Failure to comply may result in death or personal injuries.

Operation

**DANGER**

- The equipment must be operated only by professionals. Failure to comply will result in death or personal injuries.
- Do not touch any connecting terminals or disassemble any unit or component of the equipment during operation. Failure to comply will result in an electric shock.

**WARNING**

- Do not touch the equipment casing, fan, or resistor with bare hands to feel the temperature. Failure to comply may result in personal injuries.
- Prevent metal or other objects from falling into the equipment during operation. Failure to comply may result in a fire or equipment damage.

Maintenance

**DANGER**

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Do not maintain the equipment with power ON. Failure to comply will result in an electric shock.
- Before maintenance, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.
- In case of a permanent magnet motor, do not touch the motor terminals immediately after power-off because the motor terminals will generate induced voltage during rotation even after the equipment power supply is off. Failure to comply will result in an electric shock.

| |
|---|
| <div data-bbox="180 132 325 177" style="border: 1px solid black; padding: 2px;">  WARNING </div> <ul style="list-style-type: none"> • Perform routine and periodic inspection and maintenance on the equipment according to maintenance requirements and keep a maintenance record. |
| Repair |
| <div data-bbox="180 304 325 349" style="border: 1px solid black; padding: 2px;">  DANGER </div> <ul style="list-style-type: none"> • Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals. • Do not repair the equipment with power ON. Failure to comply will result in an electric shock. • Before inspection and repair, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label. |
| <div data-bbox="180 544 325 588" style="border: 1px solid black; padding: 2px;">  WARNING </div> <ul style="list-style-type: none"> • Submit the repair request according to the warranty agreement. • When the fuse is blown or the circuit breaker or earth leakage current breaker (ELCB) trips, wait for at least the time designated on the equipment warning label before power-on or further operations. Failure to comply may result in death, personal injuries or equipment damage. • When the equipment is faulty or damaged, the troubleshooting and repair work must be performed by professionals that follow the repair instructions, with repair records kept properly. • Replace quick-wear parts of the equipment according to the replacement instructions. • Do not use damaged equipment. Failure to comply may result in death, personal injuries, or severe equipment damage. • After the equipment is replaced, check the wiring and set parameters again. |
| Disposal |
| <div data-bbox="180 983 325 1027" style="border: 1px solid black; padding: 2px;">  WARNING </div> <ul style="list-style-type: none"> • Dispose of retired equipment in accordance with local regulations and standards. Failure to comply may result in property damage, personal injuries, or even death. • Recycle retired equipment by observing industry waste disposal standards to avoid environmental pollution. |

Additional Precautions

Precautions for the dynamic brake

- Dynamic braking can only be used for emergency stop in case of failure and sudden power failure. Do not trigger failure or power failure frequently.
- Ensure that the dynamic braking function has an operation interval of more than 5 minutes at high speed, otherwise the internal dynamic braking circuit may be damaged.

- Dynamic braking is commonly used in rotating mechanical structures. For example, when a motor has stopped running, it keeps rotating due to the inertia of its load. In this case, this motor is in the regenerative state and short-circuit current passes through the dynamic brake. If this situation continues, the drive, and even the motor, may be burned.

Safety label

For safe equipment operation and maintenance, comply with the safety labels on the equipment. Do not damage or remove the safety labels. The following table describes the meaning of the safety labels.

| Safety label | Description |
|---|---|
|  <p>危険 DANGER 高压注意 Hazardous Voltage 高温注意 High Temperature</p> | <ul style="list-style-type: none"> • Never fail to connect the protective earth (PE) terminal. Read through the guide and follow the safety instructions before use. • Do not touch terminals within 15 minutes after disconnecting the power supply to prevent the risk of electric shock. • Do not touch the heatsink with power ON to prevent the risk of burn. |

1 Communication Protocols

| Supported Protocol | SV680P-INT | SV680N-INT |
|--------------------|------------|------------|
| Modbus | ✓ | × |
| CANopen | ✓ | × |
| EtherCAT | × | ✓ |

2 Modbus Communication [P]

2.1 Communication

2.1.1 Communication technical data

| Item | | Specification |
|--|----------------------------|--|
| Modbus Basic perform ance of slave | Link layer protocol | RS485 |
| | Application layer protocol | Modbus-RTU, GBT 19582.2-2008, custom command areas |
| | Baud rate | 115200bps |
| | Duplex mode | Half-duplex |
| | Data format | 8-N-1 ((1) 8-bit data, (2) check, (3) stop bit) |

2.1.2 Protocols

The Modbus protocol is a common language applied to electronic controllers. Through this protocol, the controllers can communicate with each other and other devices. It has become a general industry standard. Thanks to this communication protocol, control devices produced by different manufacturers can be connected into an industrial network for centralized monitoring.

2.2 Hardware Configuration

2.2.1 Terminal Layout




Figure 2-1 Communication Terminal pin layout of the servo drive

Table 2-1 Description of communication terminal pins

| Pin No. | Description | Description |
|-----------|-------------|--------------------------|
| 1 and 9 | CANH | CAN communication port |
| 2 and 10 | CANL | |
| 3 and 11 | CGND | CAN communication GND |
| 4 and 12 | RS485+ | RS485 communication port |
| 5 and 13 | RS485- | |
| 6 and 14 | - | - |
| 7 and 15 | - | - |
| 8 and 16 | GND | Ground |
| Enclosure | PE | Shield |

2.2.2 RS485 Communication Connection Example

RS485 communication connection with PLC

The following figure shows the cable used for 485 communication between the servo drive and PLC.




Figure 2-2 Outline drawing of cable used for CAN communication between the servo drive and PLC

Use a three-conductor shielded cable to connect the RS485 bus, with three conductors connected to 485+, 485-, and GND (GND represents non-isolated RS485 circuit) respectively. Connect RS485+ and RS485- with two conductors twisted together and connect the remaining conductor to the RS485 reference ground (GND). Connect the shield to the device ground (PE). Connect a 120Ω termination resistor on each end of the bus to prevent RS485 signal reflection.

Table 2-2 Pin connection relation of the cable used for CAN communication between the servo drive and PLC

| RJ45 on the Drive (A) | | | PLC Side (B) | | |
|-----------------------|-----------|-------------------|--------------------|-----------|-------------------|
| Communication Type | Pin No. | Description | Communication Type | Pin No. | Description |
| RS485 | 4 | 485+ | RS485 | 4 | 485+ |
| | 5 | 485- | | 5 | 485- |
| | 8 | GND | | 8 | GND |
| - | Enclosure | PE (shield layer) | - | Enclosure | PE (shield layer) |

RS485 communication connection for multi-drive applications

The following figure shows the cable used for parallel connection of multiple servo drives during RS485 communication.




Figure 2-3 Outline drawing of multi-drive communication cable

Table 2-3 Pin connection relation of the cable used for multi-drive RS485 communication (pins in 485 group used only)

| RJ45 on the Drive (A) | | | RJ45 on the Drive Side (B) | | |
|-----------------------|-----------|-------------------|----------------------------|-----------|-------------------|
| Communication Type | Pin No. | Description | Communication Type | Pin No. | Description |
| RS485 | 4 | 485+ | RS485 | 4 | 485+ |
| | 5 | 485- | | 5 | 485- |
| | 8 | GND | | 8 | GND |
| - | Enclosure | PE (shield layer) | - | Enclosure | PE (shield layer) |

In case of a large number of nodes, use the daisy chain mode for RS485 communication. Connect the reference grounds of RS485 signals of all the nodes (up to 128 nodes) together.




Figure 2-4 RS485 bus topology



Caution

Do not connect ⊕ (GND) terminal to the CGND terminal of the drive. Failure to comply may damage the machine.




Figure 2-5 Daisy chain mode

The following table lists the maximum number of nodes and transmission distance supported by the standard RS485 circuit at different transmission rate.


Table 2-4 Transmission distance and number of nodes

| No. | Transmission Rate (kbps) | Transmission Distance (m) | Number of Nodes | Cable Size |
|-----|--------------------------|---------------------------|-----------------|------------|
| 1 | 115.2 | 100 | 128 | AWG26 |
| 2 | 19.2 | 1000 | 128 | AWG26 |

2.3 Communication Transmission Mode

In an RS485 communication network, data is transmitted in the asynchronous serial and half-duplex transmission mode. Data is sent frame by frame in the message

format specified by the Modbus-RTU protocol. The idle time longer than 3.5-byte transmission time marks the start of a new communication frame.



The built-in communication protocol of the drive is the Modbus-RTU slave communication protocol, which allows the drive to respond to the query command from the master or execute the action according to query command from the master and respond with communication data.

The master can be a PC, an industrial control device, or a PLC, etc. The master can separately communicate with a slave or issue broadcast information to all slaves. When the master sends a query command to a single slave, the slave needs to return a response frame. For a broadcast message sent by the master, the slaves do not need to return a response to the master.

2.4 Data Frame Structure

Parameters of the SV680P-INT servo drive are divided into 16-bit and 32-bit parameters based on the data length. You can read and write parameters through the Modbus RTU protocol.

The command codes for reading/writing parameters vary with the data length.

| Operation | Command code |
|-------------------------------|--------------|
| Read 16-bit/32-bit parameters | 0x03 |
| Write 16-bit parameters | 0x06 |
| Write 32-bit parameters | 0x10 |

Command code for reading parameter: 0x03

In Modbus RTU protocol, command code 0x03 is used to read both 16-bit and 32-bit parameters.

Request frame format:

| Value | Description |
|-------|---|
| START | Equal to or larger than 3.5-character idle time, indicating the start of a frame |
| ADDR | Servo axis address: 1 to 247 Note: 1 to 247 are decimal values which need to be converted into hexadecimal equivalents. |
| CMD | Command code: 0x03 |

| Value | Description |
|---------|---|
| DATA[0] | Register start address (eight high bits): parameter group number of the start register Take H06.11 as an example, "06" is the group number, which means DATA[0] = 0x06. Note: In this example, "06" is a hexadecimal value that needs no conversion. |
| DATA[1] | Register start address (eight low bits): offset within the parameter group of the start register Take H06.11 as an example, "11" is the offset within the parameter group. That is, DATA [1] = 0x0B. Note: In this example, "11" is a decimal value that needs to be converted into the hexadecimal equivalent 0x0B. |
| DATA[2] | Read the eight high bits N (H) of the number of parameters (hexadecimal) |
| DATA[3] | Read the eight low bits N (L) of the number of parameters (hexadecimal) |
| CRCL | CRC valid byte (low 8 bits). |
| CRCH | CRC valid byte (high 8 bits). |
| END | Equal to or larger than 3.5-character idle time, indicating the end of a frame |

Response frame format:

| Value | Description |
|-------------|---|
| START | Equal to or larger than 3.5-character idle time, indicating the start of a frame |
| ADDR | Servo axis address, hexadecimal |
| CMD | Command code: 0x03 |
| DATALENGTH | Number of parameter bytes, equal to reading the number of parameters $N \times 2$ |
| DATA[0] | Parameter data in the first register (eight high bits) |
| DATA[1] | Parameter data in the first register (eight low bits) |
| DATA[...] | ... |
| DATA[N*2-2] | Parameter data in the Nth register (eight high bits) |
| DATA[N*2-1] | Parameter data in the Nth register (eight low bits) |
| CRCL | CRC valid byte (low 8 bits). |
| CRCH | CRC valid byte (high 8 bits). |
| END | Equal to or larger than 3.5-character idle time, indicating the end of a frame |

In Modbus RTU protocol, command code 0x06 is used to write 16-bit parameters.
Command code for writing 32-bit parameters: 0x10

Communication example

- To read data with a length of two words by taking H02.02 as the start register in the drive whose servo axis address is 01:

Master request frame

| | | | | | | | |
|----|----|----|----|----|----|------|------|
| 01 | 03 | 02 | 02 | 00 | 02 | CRCL | CRCH |
|----|----|----|----|----|----|------|------|

Slave response frame:

| | | | | | | | | |
|----|----|----|----|----|----|----|------|------|
| 01 | 03 | 04 | 00 | 01 | 00 | 00 | CRCL | CRCH |
|----|----|----|----|----|----|----|------|------|

The response frame indicates the slave returns data with a length of two words (four bytes), the content of which is 0x0001 and 0x0000.

If the slave response frame is as follows:

| | | | | |
|----|----|----|------|------|
| 01 | 83 | 02 | CRCL | CRCH |
|----|----|----|------|------|

This response frame indicates a communication error occurs and the error code is 0x02. (0x83 indicates an error.)

- To read H05.07 (32-bit) in the drive whose servo axis address is 01:

Master request frame

| | | | | | | | |
|----|----|----|----|----|----|------|------|
| 01 | 03 | 05 | 07 | 00 | 02 | CRCL | CRCH |
|----|----|----|----|----|----|------|------|

Slave response frame:

| | | | | | | | | |
|----|----|----|----|----|----|----|------|------|
| 01 | 03 | 04 | 00 | 01 | 00 | 00 | CRCL | CRCH |
|----|----|----|----|----|----|----|------|------|

The preceding response frame indicates the value of H05.07 is 0x00000001.

Command code for writing 16-bit parameters: 0x06



Caution

Do not write 32-bit parameters with the command code 0x06. Failure to comply can result in unexpected error.

Request frame format:

| Value | Description |
|-------|--|
| START | Equal to or larger than 3.5-character idle time, indicating the start of a frame |
| ADDR | Servo axis address 1 to 247 Note: 1 to 247 are decimal values which need to be converted into hexadecimal equivalents. |
| CMD | Command code: 0x06 |

| Value | Description |
|---------|---|
| DATA[0] | Register start address (eight high bits): parameter group number of the start register Take H06.11 as an example, "06" is the group number, which means DATA[0] = 0x06. Note: In this example, "06" is a hexadecimal value that needs no conversion. |
| DATA[1] | Register start address (eight low bits): offset within the parameter group of the start register Take H06.11 as an example, "11" is the offset within the parameter group, which means DATA[1] = 0x0B. Note: In this example, "11" is a decimal value that needs to be converted into the hexadecimal equivalent 0x0B. |
| DATA[2] | Write the 8 high bits of register data (hexadecimal) |
| DATA[3] | Write the 8 low bits of register data (hexadecimal) |
| CRCL | CRC valid byte (low 8 bits). |
| CRCH | CRC valid byte (high 8 bits). |
| END | Equal to or larger than 3.5-character idle time, indicating the end of a frame |

Response frame format:

| Value | Description |
|---------|---|
| START | Equal to or larger than 3.5-character idle time, indicating the start of a frame |
| ADDR | Servo axis address, hexadecimal |
| CMD | Command code: 0x06 |
| DATA[0] | Register start address (eight high bits): parameter group number of the start register Take H06.11 as an example, "06" is the group number, which means DATA[0] = 0x06. Note: In this example, "06" is a hexadecimal value that needs no conversion. |
| DATA[1] | Register start address (eight low bits): offset within the parameter group of the start register Take H06.11 as an example, "11" is the offset within the parameter group, which means DATA[1] = 0x0B. Note: In this example, "11" is a decimal value that needs to be converted into the hexadecimal equivalent 0x0B. |
| DATA[2] | Write the 8 high bits of register data (hexadecimal) |
| DATA[3] | Write the 8 low bits of register data (hexadecimal) |
| CRCL | CRC valid byte (low 8 bits). |
| CRCH | CRC valid byte (high 8 bits). |
| END | Equal to or larger than 3.5-character idle time, indicating the end of a frame |

Communication example

To write data 0x0001 to H02.02 in the drive whose servo axis address is 01:

Master request frame

| | | | | | | | |
|----|----|----|----|----|----|------|------|
| 01 | 06 | 02 | 02 | 00 | 01 | CRCL | CRCH |
|----|----|----|----|----|----|------|------|

Slave response frame:

| | | | | | | | |
|----|----|----|----|----|----|------|------|
| 01 | 06 | 02 | 02 | 00 | 01 | CRCL | CRCH |
|----|----|----|----|----|----|------|------|

This response frame indicates 0x0001 has been written to H02.02 in the drive whose servo axis address is 01.

If the slave response frame is as follows:

| | | | | |
|----|----|----|------|------|
| 01 | 86 | 02 | CRCL | CRCH |
|----|----|----|------|------|

This response frame indicates a communication error occurs and the error code is 0x02. (0x86 indicates an error.)

Command code for writing 32-bit parameters: 0x10



Caution

Do not write 16-bit parameters with the command code 0x10. Failure to comply can result in unexpected error.

Request frame format:

| Value | Description |
|---------|---|
| START | Equal to or larger than 3.5-character idle time, indicating the start of a frame |
| ADDR | Servo axis address 1 to 247 Note: 1 to 247 are decimal values which need to be converted into hexadecimal equivalents. |
| CMD | Command code: 0x10 |
| DATA[0] | Register start address (eight high bits): parameter group number of the start register Take H11.12 as an example, "11" is the group number, which means DATA[0] = 0x11. Note: In this example, "11" is a hexadecimal value that needs no conversion. |

| Value | Description |
|---------|---|
| DATA[1] | Register start address (eight low bits): offset within the parameter group of the start register Take H11.12 as an example, "12" is the offset within the parameter group, which means DATA[1] = 0x0C. Note: In this example, "12" is a decimal value that needs to be converted into the hexadecimal equivalent 0x0C. |
| DATA[2] | Write the eight high bits M (H) of the number of parameters (hexadecimal) Take H05.07 as an example, DATA[2] is 00, DATA[3] is 02, and M is H0002. For 32-bit parameters, each parameter is calculated as two words. |
| DATA[3] | Write the eight low bits M (L) of the number of parameters (hexadecimal) |
| DATA[4] | Write the number of bytes (M x 2) corresponding to the register data Take H05.07 as an example, DATA[4] is H04. |
| DATA[5] | Write the eight high bits of the start register data (hexadecimal) |
| DATA[6] | Write the eight low bits of the start register data (hexadecimal) |
| DATA[7] | Write the eight high bits of the start register address +1 (hexadecimal) |
| DATA[8] | Write the eight low bits of the start register address +1 (hexadecimal) |
| CRCL | CRC valid byte (low 8 bits). |
| CRCH | CRC valid byte (high 8 bits). |
| END | Equal to or larger than 3.5-character idle time, indicating the end of a frame |

Response frame format:

| Value | Description |
|---------|---|
| START | Equal to or larger than 3.5-character idle time, indicating the start of a frame |
| ADDR | Servo axis address, hexadecimal |
| CMD | Command code: 0x10 |
| DATA[0] | Register start address (eight high bits): offset within the parameter group of the start register Take H11.12 as an example, DATA[0] = 0x11. |
| DATA[1] | Register start address (eight low bits): offset within the parameter group of the start register Take H11.12 as an example, DATA[1] = 0x0C. |
| DATA[2] | Write the eight high bits M (H) of the number of parameters (hexadecimal) |
| DATA[3] | Write the eight low bits M (L) of the number of parameters (hexadecimal) |

| Value | Description |
|-------|--|
| CRCL | CRC valid byte (low 8 bits). |
| CRCH | CRC valid byte (high 8 bits). |
| END | Equal to or larger than 3.5-character idle time, indicating the end of a frame |

Error response frame

Error frame response format:

| Value | Description |
|---------------|--|
| START | Equal to or larger than 3.5-character idle time, indicating the start of a frame |
| ADDR | Servo axis address, hexadecimal |
| CMD | Command code: 0x80 |
| DATA[0]...[3] | DATA error code. |
| CRCL | CRC valid byte (low 8 bits). |
| CRCH | CRC valid byte (high 8 bits). |
| END | Equal to or larger than 3.5-character idle time, indicating the end of a frame |

Error code:

| Error code | Description |
|------------|----------------------|
| 0x0001 | Invalid command code |
| 0x0002 | Illegal data address |
| 0x0003 | Illegal data |
| 0x0004 | Slave device fault |

32-bit parameter addressing

When 32-bit parameters are read/written through Modbus commands, the communication address is determined by the address of the parameter with lower offset number. Two offset numbers are operated in one operation.

Note

In the following examples, the servo axis address is 01 by default.

- The Modbus command for reading H11.12 (Displacement 1) is as follows:

| | | | | | | | |
|----|----|----|----|----|----|------|------|
| 01 | 03 | 11 | 0C | 00 | 02 | CRCL | CRCH |
|----|----|----|----|----|----|------|------|

If the "1st displacement" is 0x40000000 (decimal equivalent: 1073741824), then the following response frames apply:

- When H0E.84 is set to 1 (Low 16 bits before high 16 bits), the response frame is as follows.

| | | | | | | | | |
|----|----|----|----|----|----|----|------|------|
| 01 | 03 | 04 | 00 | 00 | 40 | 00 | CRCL | CRCH |
|----|----|----|----|----|----|----|------|------|

- When H0E.84 is set to 0 (High 16 bits before low 16 bits), the response frame is as follows.

| | | | | | | | | |
|----|----|----|----|----|----|----|------|------|
| 01 | 03 | 04 | 40 | 00 | 00 | 00 | CRCL | CRCH |
|----|----|----|----|----|----|----|------|------|

- For example, the Modbus command for writing 0x12345678 to H11.12 (Displacement 1) is as follows.

- If H0E.84 = 1 (Low 16 bits before high 16 bits):

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|------|------|
| 01 | 10 | 11 | 0C | 00 | 02 | 04 | 56 | 78 | 12 | 34 | CRCL | CRCH |
|----|----|----|----|----|----|----|----|----|----|----|------|------|

- If H0E.84 = 0 (High 16 bits before low 16 bits):

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|------|------|
| 01 | 10 | 11 | 0C | 00 | 02 | 04 | 12 | 34 | 56 | 78 | CRCL | CRCH |
|----|----|----|----|----|----|----|----|----|----|----|------|------|

- For example, to write 0x00100000 (decimal: 1048576) to the 32-bit parameter H05-07:

When H0E.84 is set to 0 (High 16 bits before low 16 bits), the response frame is as follows.

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|------|------|
| 01 | 10 | 05 | 07 | 00 | 02 | 04 | 00 | 00 | 00 | 10 | CRCL | CRCH |
|----|----|----|----|----|----|----|----|----|----|----|------|------|

CRC check

The host controller and the drive must use the same CRC algorithm during communication. Otherwise, a CRC error can occur. The servo drive uses 16-bit CRC with low byte before high byte. The CRC function is as follows: The polynomial used for CRC is $X^{16} + X^{15} + X^2 + 1$ (0xA001).

```

Uint16 COMM_CrcValueCalc(const Uint8 *data, Uint16 length)
{
    Uint16 crcValue = 0xffff;
    int16 i;
    while (length--)
    {
        crcValue ^= *data++;
        for (i = 0; i < 8; i++)
        {
            if (crcValue & 0x0001)
            {
                crcValue = (crcValue >> 1) ^ 0xA001;
            }
            else
            {
                crcValue = crcValue >> 1;
            }
        }
    }
    return (crcValue);
}

```

2.5 Communication Parameters

| Parameter | Default Value | Description | Remarks |
|-----------|---------------|------------------------------|---------------|
| HOE.00 | 1 | Drive axis address | - |
| HOE.80 | 9 | Baud rate of the serial port | 9: 115200 bps |

| Parameter | Default Value | Description | Remarks |
|-----------|---------------|------------------------------------|--|
| HOE.81 | 3 | Modbus communication data format | 3: No parity, 1 stop bit (8-N-1) |
| HOE.84 | 1 | Modbus communication data sequence | 0: High bits before low bits 1: Low bits before high bits |

3 CANopen Communication [P]

3.1 Communication

3.1.1 Communication Technical Data

| Item | Name | Description |
|------------------------------|--|--|
| Parameter setting | Node address switching | The node address can only be set manually. The maximum value is 127. |
| | Baud rate switching | The baud rate can only be set manually. |
| Description of state machine | State description/display of communication layer | Initializing, Pre-Operational, Operational, Stopped |
| | Description/display of emergency error codes | Time-Out, State-Switch-Err, PTO-Lend-Err |
| Error frame recording | Reception error frames can be recorded. | Count of NMT frames with incorrect length |
| | | Count of NMT frames with incorrect command |
| | | Count of heartbeat/node protection frames with incorrect length |
| Sync deviation detection | Multi-quantile sync deviation detection | 1/4-period deviation |
| | | 1/2-period deviation |
| | | 3/4-period deviation |
| | | 1-period deviation |
| | | 2-period deviation |
| Baud rate | 20K-1M baud rate | 20Kbps, 50Kbps, 100Kbps, 125Kbps, 250Kbps, 500Kbps, 1Mbps |
| SYNC | SYNC Producer | Synchronous frame production |
| | SYNC Consumer | Synchronous signal consumption with deviation detection |
| SDO | Start domain upload/download | Transmit data \leq 4 bytes |
| | SDO abort error | Report an SDO error code contextually |
| PDO | Synchronous TPDO | The sync number is 1–240. The default number of TPDOs/RPDOs is 4, which can be configured. |
| | Asynchronous TPDO | Time-triggered by time. The default number of TPDOs/RPDOs is 4, which can be configured. |

| Item | Name | Description |
|-------------|--|--|
| EMCY | Emergency message | Heartbeat timeout, PDO length error, node state switching error, application layer error |
| NMT | Bootup Service | Support for node online message transmit |
| NMTErrCtl | Life Guard | Optional node protection (cannot be used with heartbeat production) |
| | Heartbeat Consumer | Node heartbeat consumption |
| | Heartbeat Producer | Node heartbeat production |
| Expert mode | PDO communication parameters and their mapping are set through parameters. | PDO communication parameters and their mapping are set manually. |

3.1.2 Protocols

CANopen is a protocol for the application layer of the network transmission system based on CAN serial bus. It complies with the ISO/OSI standard model. Different devices in the network exchange data through the object dictionary or objects. The master node obtains or modifies data in the object dictionary of other nodes through PDO or SDO. The CANopen device model is shown in the following figure.




Figure 3-1 CANopen device model

3.2 Hardware Configuration

3.2.1 Terminal Layout

For details, see ["2.2.1 Terminal Layout" on page 15](#).

3.2.2 CAN Communication Connection Example

CAN communication with PLC

The following figure shows the cable used for the communication between the servo drive and PLC in CAN communication networking.




Figure 3-2 Outline drawing of cable used for CAN communication between the servo drive and PLC

Use a three-conductor shielded cable to connect the CAN bus, with the three conductors connected to CANH, CANL, and CGND (CGND represents isolated RS485 circuit) respectively. Connect CANH and CANL with twisted pairs. Connect CGND to the CAN reference ground. Connect the shield to the device ground. Connect a 120Ω termination resistor on each end of the bus to prevent CAN signal reflection.

Table 3-1 Pin connection relation of the cable used for CAN communication between the servo drive and PLC

| RJ45 on the Drive Side (A) | | | PLC Side (B) | | |
|----------------------------|-----------|-------------------|--------------------|-----------|-------------------|
| Communication Type | Pin No. | Description | Communication Type | Pin No. | Description |
| CAN | 1 | CANH | CAN | 1 | CANH |
| | 2 | CANL | | 2 | CANL |
| | 3 | CGND | | 3 | CGND |
| - | Enclosure | PE (shield layer) | - | Enclosure | PE (shield layer) |

CAN communication connection for multi-CAN applications

The following figure shows the cable used for parallel connection of multiple servo drives during CAN communication.




Figure 3-3 Outline drawing of multi-drive communication cable

Table 3-2 Pin connection relation of multi-drive communication cable (pins in CAN group used only)

| RJ45 on the Drive (A) | | | RJ45 on the Drive Side (B) | | |
|-----------------------|-----------|-------------------|----------------------------|-----------|-------------------|
| Communication Type | Pin No. | Description | Communication Type | Pin No. | Description |
| CAN | 1 | CANH | CAN | 1 | CANH |
| | 2 | CANL | | 2 | CANL |
| | 3 | CGND | | 3 | CGND |
| - | Enclosure | PE (shield layer) | - | Enclosure | PE (shield layer) |

Use the daisy chain mode for CAN bus, as shown in the following figure.

- Shielded twisted pair cables are recommended for connecting the CAN bus. Twisted pairs are recommended for connecting CANH and CANL.
- Connect a 120Ω termination resistor on each end of the bus to prevent signal reflection.
- Connect the reference grounds of CAN signals of all the nodes together.
- Up to 64 nodes can be connected.




Figure 3-4 CAN bus topology



Do not connect the CGND terminal of the host controller to the GND terminal of the servo drive. Otherwise, the servo drive may be damaged.

3.3 Communication Transmission Mode

CANopen provides multiple communication objects. Every communication object has different features. You can select a communication object according to different applications. The predefined COB-ID is used. Specific rules are as follows:

- NMT object: 0x000
- SYNC object: 0x080
- SDO object:
 - Transmit SDO — 0x600+Node-Id
 - Receive SDO — 0x580+Node-Id
- PDO object:
 - RPDO1 — 0x200+Node-Id
 - RPDO1 — 0x300+Node-Id
 - RPDO1 — 0x400+Node-Id
 - RPDO1 — 0x500+Node-Id
 - RPDO1 — 0x180+Node-Id
 - RPDO1 — 0x280+Node-Id
 - RPDO1 — 0x380+Node-Id
 - RPDO1 — 0x480+Node-Id
- EMCY object: 0x80+Node-Id

Communication objects are defined as follows:

- NMT

A network management object (NMT) includes Boot-up messages, Heartbeat protocol, and NMT messages. Based on the master-slave mode, an NMT is used to manage and monitor nodes in the network and implements three functions: node status control, error control, and node activation.
- SDO

By using indexes and sub-indexes, SDOs enable clients to access entries in the object dictionary of devices. An SDO is achieved through a CMS object of the multi-element domain in CAL and transmitting data in any length is allowed. When the data exceeds four bytes, the data is divided into several packets. The SDO protocol produces a response for every message. SDO request and response packets always contain eight bytes.
- PDO

A PDO is used to transmit real-time data from one creator to one or multiple receivers. The length of transmitted data ranges from one to eight bytes. Every CANopen device contains eight default PDO channels, four PDO sending channels and four PDO receiving channels. The PDO supports synchronous and asynchronous transmission modes, which are determined by the communication

parameter corresponding to the PDO. The content of a PDO message is pre-defined and is determined by the mapping parameter corresponding to the PDO.

- SYNC object
An SYNC object is a packet that is broadcast to the CAN bus periodically by the CANopen master. It is used to achieve basic network clock signals. Every device can determine whether to perform synchronous communication with other network devices using this event according to its own configurations.

3.4 Data Frame Structure

3.4.1 Network Management System (NMT)

The NMT initializes, starts, and stops the network and devices in the network. It belongs to the master-slave system. There is only one NMT master in the CANopen network. A CANopen network that includes the master can be configured.

NMT Service

CANopen works according to the state machine specified by the protocol. Some states are converted automatically and some must be converted through NMT messages transmitted by the NMT master, as shown below.




Figure 3-5 Execution process of NMT state machine

In the figure above, conversion marked with a letter is implemented through NMT messages and only the NMT master can send NMT control messages. The message format is shown in "Table 3-3 " on page 35.

Table 3-3 NMT message format

| COB-ID | RTR | Data/Byte | |
|--------|-----|--------------|---------|
| | | 0 | 1 |
| 0x000 | 0 | Command word | Node_ID |

The COB-ID of the NMT message is fixed to "0x000".

The data area contains two bytes. The first byte is a command word indicating this frame is for control purpose. See "Table 3-4 " on page 35 for details.

The second byte (Node_ID) is the CANopen node address. The byte value 0 indicates it is a broadcast message and all slave devices in the network are active.

Table 3-4 NMT message command

| Command word | Conversion Code | Description |
|--------------|-----------------|---|
| 0x01 | A | Instruction for starting a remote node |
| 0x02 | B | Instruction for stopping a remote node |
| 0x80 | C | Instruction for entering the pre-operational status |
| 0x81 | D | Instruction for resetting a node |
| 0x82 | E | Instruction for resetting communication |

After power-on, the device automatically enters the initialization state, including initializing, node reset, and communication reset. During initializing, parameters of each mode is loaded. During node reset, the manufacturer-defined area and profile area of the object dictionary are restored to values saved last time. During communication reset, communication parameters in the object dictionary are restored to values saved last time.

Next, the device sends Boot-up and enters the pre-operation status, which is the status of the main configuration nodes.

After configuration is done, the node can enter the operational status only after the NMT master sends the NMT message. When CANopen is working properly, it is in the operation status. All modules should work properly.

When the NMT master sends a node stop message, the device enters the stop state and only the NMT module works normally during CANopen communication.

The following table lists CANopen services available in various NMT status.

Table 3-5 Services supported in different NMT states

| Service | Pre-operational | Operation | Stop |
|---------------------------------|-----------------|-----------|------|
| Process Data Object (PDO) | No | Yes | No |
| Service data object (SDO) | Yes | Yes | No |
| Synchronization Object (SYNC) | Yes | Yes | No |
| Emergency message (EMCY) | Yes | Yes | No |
| Network Management System (NMT) | Yes | Yes | Yes |
| Error control | Yes | Yes | Yes |

NMT error control

NMT error control is used to detect whether devices in the network are online and the device status, including node guarding, life guarding, and heartbeat.

Note

- Life guarding and heartbeat cannot be used at the same time.
- Set the node guarding, life guarding, and heartbeat time to large values to prevent excessive network load.

- **Node/life guarding**

In node guarding, the NMT master periodically check the NMT slave state through remote frames. In life guarding, the slave monitors the master state indirectly through the remote frame interval used to monitor the slave. Node guarding complies with the master/slave model. A response must be provided for each remote frame.

Objects related to node/life guarding include the protection time 100Ch and life factor 100Dh. The value of 100Ch is the remote frame interval (ms) of node guarding under normal conditions. The product of 100Ch multiplied by 100Dh determines the latest time of master query. Node guarding is available normally. When 100Ch and 100Dh of a node are non-zero values and a node guarding request frame is received, life guarding will be activated.




Figure 3-6 Description of node protection

As shown in the figure above, the master sends a node guarding remote frame at the interval defined by 100Ch, and the slave must respond to the remote frame. Otherwise, the slave is considered to be offline.

If the node guarding remote frame is not received by the slave within the time defined by $100Ch \times 100Dh$, the master is considered to be offline.

The following table describes the remote frame sent by the NMT master node.

Table 3-6 Node guarding remote frame message

| COB-ID | RTR |
|---------------|-----|
| 0x700+Node_ID | 1 |

The following table describes the response message returned by NMT from the slave. The data segment is a status word consisting of one byte.

Table 3-7 Response message of node guarding

| COB-ID | RTR | Data |
|-----------------|-----|-------------|
| 0x700 + Node-ID | 0 | Status word |

Table 3-8 Description of response message state

| Data bits | Description |
|----------------|--|
| bit7 | It must be set to 0 or 1 alternatively. |
| Bit 6 to bit 0 | 4: Stopped 5: Operation status 127: Pre-operation status |



Caution

It is recommended that the guarding time (100Ch) be at least 10 ms. The life factor must be greater than or equal to 2.

● Heartbeat

The heartbeat mode adopts the producer—consumer model. The CANopen device can send heartbeat messages based on the cycle (ms) defined by the producer heartbeat interval object (1017h). In the network, there is always a node configured with the consumer heartbeat function, which monitors the producer based on the consumer time defined by object 1016h. Once the producer heartbeat is not received from the corresponding node within the consumer heartbeat time, a fault occurs on the node.

After the producer heartbeat interval (1017h) is configured, the node heartbeat function is activated and a heartbeat message starts to be generated. After a valid sub-index is configured for consumer heartbeat (1016h) and a heartbeat frame is received from the corresponding node, monitoring starts.




Figure 3-7 Heartbeat diagram

The master sends a heartbeat message based on the producer time. If the slave that monitors the master does not receive the heartbeat message within the time defined by the sub-index of 1016h, the master is considered to be offline. The time of the sub-index of 1016h must be longer than or equal to the master producer

time multiplied by 1.8. Otherwise, a false report indicating the master is offline may occur.

The slave sends a heartbeat message at the interval defined by 1017h. If the master (or other slave) that monitors the slave does not receive the heartbeat message within the consumer time, the slave is considered to be offline. If 1017h multiplied by 1.8 is smaller than or equal to the consumer time of the master (or other slaves) that monitors the slave, a false report indicating the slave is disconnected may be reported.

The following table describes the format of a heartbeat message. The data segment contains only one byte. The most significant bit is permanently set to 0 and other bits are consistent with the response message status of node guarding, as shown in the following table.

Table 3-9 Heartbeat message

| COB-ID | RTR | Data |
|-----------------|-----|-------------|
| 0x700 + Node-ID | 0 | Status word |

The SV680P-INT series servo drive is both a heartbeat producer and a heartbeat consumer. It can serve as the heartbeat consumer for five different nodes. It is recommended that the heartbeat producer time be set to a value not lower than 20 ms and the consumer heartbeat time be set to a value not lower than 40 ms (Consumer heartbeat time > 1.8 x Producer heartbeat time).


3.4.2 Service data object (SDO)

The SDO is associated with the object dictionary through object index and sub-index. Based on the SDO can read the object content in the object dictionary or modify the object data if allowed.

3.4.3 Process Data Object (PDO)

The PDO is used to transmit real-time data, which is the major data transmission mode in CANopen. PDO transmission features high speed as no response is required and the PDO may consist of less than eight bytes.

The following figure shows the PDO mapping configuration flowchart.



PDO transmission framework

PDO transmission complies with the producer-consumer model, that is, in the CAN bus network, the TPDO generated by the producer may be received by one or multiple consumers in the network based on the COB-ID. The transmission model is shown in the following figure.




Figure 3-8 PDO transmission model

CANopen communication in SV680P-INT series servo drives only supports point-to-point PDO transmission.

PDO object

PDO can be divided into RPDO (Receive PDO) and TPDO (Transmitted PDO). The final PDO transmission mode and content are determined by communication parameters

and mapping parameters. The SV680P-INT series servo drive uses four RPDOs and four TPDOs to transmit the PDO. The following table lists the related objects.

Table 3–10 PDOs of SV680P-INT servo drives

| Name | | COB-ID | Communication Object | Mapping Object |
|------|---|----------------|----------------------|----------------|
| RPDO | 1 | 200h + Node_ID | 1400h | 1600h |
| | 2 | 300h + Node_ID | 1401h | 1601h |
| | 3 | 400h + Node_ID | 1402h | 1602h |
| | 4 | 500h + Node_ID | 1403h | 1603h |
| TPDO | 1 | 180h + Node_ID | 1800h | 1A00h |
| | 2 | 280h + Node_ID | 1801h | 1A01h |
| | 3 | 380h + Node_ID | 1802h | 1A02h |
| | 4 | 480h + Node_ID | 1803h | 1A03h |

PDO Communication Parameters

● CAN Identifier for PDO

The CAN identifier of a PDO, namely COB-ID, includes a control bit and identifier data and determines the bus priority of the PDO.

The COB-ID is in the sub-index 01 of communication parameters (RPDO: 1400h to 1403h; TPDO: 1800h to 1803h). The most significant bit decides whether the PDO is valid.




Figure 3-9 Description of PDO validity

The SV680P-INT servo drive only supports point-to-point PDO transmission. Therefore, the seven least significant bits of the COB-ID must be the station address of the node.

Example:

For the node whose station No. is 4, when TPDO3 is invalid, its COB-ID should be 8000384h. When 384h is written for the COB-ID, it indicates the PDO is activated.

● Transmission type of PDO

The PDO transmission type parameter is in the sub-index 02h of communication parameters (RPDO: 1400h–1403h, TPDO: 1800h–1803h). It determines the transmission type of the PDO.




Figure 3-10 Supported PDO transmission mode

Communication parameters (RPDO: 1400h–1403h, TPDO: 1800H–1803h) Different values of the sub-index 02 stand for different transmission types and define the methods for triggering TPDO transmission or methods for processing received RPDOs. Table 3-26 lists methods for triggering TPDO and RPDO.

Table 3–11 Triggering Methods of TPDO and RPDO

| Value of Communication Type | Synchronous | | Asynchronous |
|-----------------------------|-------------|---------|--------------|
| | Cyclic | Acyclic | |
| 0 | - | ✓ | - |
| 1–240 | ✓ | - | - |
| 241–253 | - | | |
| 254, 255 | - | - | ✓ |

- When the transmission type of a TPDO is 0, if mapping data is changed and a synchronous frame is received, the TPDO is sent.
 - When the transmission type of a TPDO is a value in the range 1 to 240 and a corresponding number of synchronous frames are received, the TPDO is sent.
 - When the transmission type of a TPDO is 254 or 255, if mapping data is changed or the event timer expires, the TPDO is sent.
 - When the transmission type of an RPDO is a value in the range 0 to 240, once a synchronous frame is received, the latest data of the RPDO is updated to the application; when the transmission RPDO of an RPDO is 254 or 255, the received data is directly updated to the application.
- **Disabled time**
The disabled time is set for TPDOs and is stored on the sub-index 03h of communication parameters (1800h to 1803h) to prevent the CAN from being continuously occupied by PDO with lower priorities. After the parameter (unit: 100 us) is set, the transmission interval of one TPDO must be longer than or equal to the time corresponding to this parameter.

Example: If the inhibit time of TPDO2 is 300 ms, the transmission interval of TPDOs is no shorter than 30 ms.

- **Event timer**

For TPDO transmitted in asynchronous mode (transmission types 254 or 255), the event timer is defined in sub-index 05 of communication parameters (1800h–1803h). The event timer can be considered as a trigger event. It also triggers corresponding TPDO transmission. If another event, for example, data change, occurs in the operation cycle of the event timer, the TPDO is triggered and the event timer is reset immediately.

PDO mapping parameter

PDO mapping parameters include pointers of process data that corresponds to PDO and that is to be sent or received by PDO, including index, sub-index, and mapping object length. The length of each PDO data can be up to eight bytes and one or multiple objects can be mapped. The sub-index 00 records the number of objects mapped by the PDO and the sub-indices 01...08 are the mapping content.

The following takes 1600h as an example.

Table 3–12 Description of PDO mapping relation

| Index | Sub-index | Description |
|-------|-----------|------------------------------|
| 1600h | 00 | Number of mapped objects |
| | 01 | Content of mapping parameter |
| | ... | |
| | 08 | |

Table 3–13 Definition of PDO mapping parameters

| Places | 31 | ... | 16 | 15 | ... | 8 | 7 | ... | 0 | |
|-------------|-------|-----|----|-----------|-----|---|---------------|-----|---|--|
| Description | Index | | | Sub-index | | | Object Length | | | |

The index and sub-index together define the position of an object in the object dictionary. The object length indicates the bit length of the object in hexadecimal, as shown below.

Table 3–14 Relation between object length and object bit length

| Object Length | Bit Length |
|---------------|------------|
| 08h | 8-bit |
| 10h | 16-bit |
| 20h | 32-bit |

For example: the mapping parameter of the 16-bit command word 6040.00h is 60400010h.

The following example describes the PDO mapping relation.

Example:

RPDO1 maps the following three parameters.




Figure 3-11 Example of PDO1 mapping

Then, the mapping length is seven bytes (2+1+4), namely there are seven bytes in the data segment of RPDO1 during transmission. The mapping relation is shown in the following figure.




Figure 3-12 Example of RPDO mapping relation

The mapping mode of TPDO is the same as that of RPDO, but in the opposite direction. The RPDO decodes the input based on the mapping relation. The TPDO encodes the output based on the mapping relation.

Example:

TPDO2 maps the following two parameters.




Figure 3-13 Example of TPDO2 mapping relation

Then, the mapping length is four bytes (2+2), namely there are four bytes in the data segment of TPDO2 during transmission. The mapping relation is shown in the following figure.




Figure 3-14 Example of TPDO mapping relation

3.4.4 Synchronization Object (SYNC)

The SYNC object is a special mechanism that controls harmony and synchronization between transmission and reception of multiple nodes. It is used for synchronous transmission of the PDO.

The following figure shows the configuration flowchart of the Sync generator.




Figure 3-15 Synchronization generator configuration flowchart

Note

The SV680P-INT series does not support the Sync generator with cycle lower than 500 μ s. Synchronization cycles lower than 1 ms are not recommended.

Sync generator

The SV680P-INT servo drive is both a synchronization consumer and a synchronization producer. The objects related to synchronization are synchronization object COB-ID (1005h) and synchronization cycle (1006h).




Figure 3-16 Description of supported objects related to synchronization

The second most significant bit of the synchronization object COB-ID determines whether to activate the Sync generator.




Figure 3-17 Activating the synchronization generator

The synchronization cycle (unit: us) is only used for the Sync generator. It indicates the interval of the node in generating the synchronization object.

Synchronization object transmission framework

Synchronization objects are transmitted based on the producer-consumer model, which is similar to PDO transmission. The synchronization producer sends a synchronous frame, and other nodes in the CAN network can receive this frame as consumers, without the need to provide any feedback. Only one Sync generator is allowed to be activated in one CAN network. The following figure shows the transmission framework of synchronization objects.




Figure 3-18 Synchronization transmission framework

Transmission of synchronous PDO is closely related to the synchronous frame.

- For an RPDO, so long as the PDO is received, the received PDO is updated to the application in the next synchronization.
- A synchronization TPDO can be transmitted in cyclic synchronization mode or acyclic synchronization mode.




Figure 3-19 Description of synchronization TPDO

The following figure shows the synchronous transmission model.




Figure 3-20 Synchronous transmission model

Example:

RPDO1 has a transmission type of 0, RPDO2 has a transmission type of 5, TPDO1 has a transmission type of 0, and TPDO2 has a transmission type of 20. Once RPDO1 and RPDO2 receive the PDO, the latest PDO data will be updated to the corresponding application in the next synchronization. Once the mapping data of TPDO1 changes, TPDO1 will be transmitted in the next synchronization. After TPDO2 experiences 20 SYNC, the PDO will be transmitted no matter whether the data changes.

3.4.5 Emergency (EMCY) Object Service

When an error occurs in a CANopen node, the node sends an emergency message according to the standard mechanism. The emergency message complies with the producer-consumer model. After the node fault is sent, other nodes in the CAN network may handle the fault. The SV680P-INT series servo drive only serves as the emergency message producer, which means it does not process emergency messages of other nodes.




Figure 3-21 Description of objects related to emergency messages

When a fault occurs on the node, the error register and the pre-defined error field must be updated no matter whether the emergency object is activated. The content of the emergency message follows the following specifications.

Table 3-15 Specifications of the content of an emergency message

| COB-ID | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---------------|------------|---|----------------|-----------|----------------|---|---|---|
| 80h + Node_ID | Error code | | Error register | Re served | Auxiliary byte | | | |

- The error register is always consistent with 1001h.
- When a communication error occurs, the error code is consistent with the one required by DS301 and the auxiliary byte is 0.
- When the error described in the DSP402 sub-protocol occurs on the servo drive, the error code is consistent with DS402 requirements and corresponds to the object 603Fh. The auxiliary byte is extra descriptions.
- When an error specified by the user occurs on the servo drive, the error code is 0xFF00 and the auxiliary byte displays the error code specified by the user.

3.4.6 SDO Transmission Message

SDO transmission include transmission of object data with no more than four bytes and those with more than four bytes. Object data with no more than four bytes are transmitted in the expedited SDO mode. Object data with more than four bytes are transmitted in the segmented SDO mode or block mode.

The SV680P-INT supports expedited SDO transfer and segmented SDO transfer only.

An SDO transmission message consists of a COB-ID and a data segment. As shown in the following table, the COB-ID of T_SDO and R_SDO messages are different.

The data segment adopts the little endian mode, in which least significant bits are arranged in front of most significant bits. The data segment of all SDO messages must consist of eight bytes. The following table describes the format of SDO transmission message.

Table 3-16 Description of SDO transmission message format

| COB-ID | Data (data segment) | | | | | | | |
|--------------|---------------------|-------|---|-----------|------|---|---|---|
| 580h+Node_ID | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 600h+Node_ID | Command code | Index | | Sub-index | Data | | | |

The command code specifies the transmission type and transmission data length of the SDO. The index and sub-index indicate the position of the SDO in the list; the data indicates the value of the SDO.

Message written in expedited SDO mode

Expedited SDO transfer is used for reading/writing the object message with no more than four bytes. The transmission message varies the read/write mode and data length. The following table describes the message written in the expedited SDO mode.

Table 3-17 Description

| | | COB-ID | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---------|----------|--------------|-----|-------|---|-----------|------------|---|---|---|
| Client→ | | 600h+Node_ID | 23h | Index | | Sub-index | Data | | | |
| | | | 27h | | | | Data | | | - |
| | | | 2bh | | | | Data | | - | - |
| | | | 2fh | | | | Data | - | - | - |
| ←Server | Normal | 580h+Node_ID | 60h | Index | | Sub-index | - | - | - | - |
| | Abnormal | | 80h | | | | Abort Code | | | |

Note

"-" indicates that data exists but is not considered. It is recommended that value 0 be written for the data. The same rule applies to the following descriptions in this section.

Example:

If the slave station No. is 4 and SDO is used to write the speed value (60FF.00h) in the speed mode, write 1000 (namely 0x3E8). The message sent by the master is shown in the following table. (All data are in hexadecimal format.)

Table 3-18 Example of a message sent by the master

| COB-ID | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|--------|----|----|----|----|----|----|----|----|
| 604 | 23 | FF | 60 | 00 | E8 | 03 | 00 | 00 |

If the value is written successfully, the servo drive returns the following message.

Table 3-19 Example of a message returned by the servo drive upon normal write operation

| COB-ID | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|--------|----|----|----|----|----|----|----|----|
| 584 | 60 | FF | 60 | 00 | 00 | 00 | 00 | 00 |

If the type of the data written does not match, the fault code 0x06070010 is returned. The message is as follows.

Table 3-20 Example of a message returned upon mismatch of the written data type

| COB-ID | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|--------|----|----|----|----|----|----|----|----|
| 584 | 80 | FF | 60 | 00 | 10 | 00 | 07 | 06 |

Message written in expedited SDO mode

Object message with no more than four bytes are read in the expedited SDO mode. The following table describes the message written in the expedited SDO mode.

Table 3–21 Structure of an SDO start packet transmitted

| | | COB-ID | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---------|----------|--------------|-----|-------|---|-----------|-------------|---|---|---|
| Client→ | | 600h+Node_ID | 40h | Index | | Sub-index | - | - | - | - |
| ←Server | Normal | 580h+Node_ID | 41h | Index | | Sub-index | Data Length | | | |
| | Abnormal | | 80h | | | | Abort Code | | | |

During transmission, the trigger bit (bit6) of the command code sends 0 or 1 alternatively. This rule must be maintained so that the slave can respond to the message. The structure of the process message is shown in the following table.

Table 3–22 Structure of a message during SDO transmission

| | | COB-ID | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---------|----------|--------------|-----|-------------|---|-----------|------------|---|---|---|
| Client→ | | 600h+Node_ID | 60h | - | - | - | - | - | - | - |
| ←Server | Normal | 580h+Node_ID | 00h | Data Length | | | | | | |
| | Abnormal | | 80h | Index | | Sub-index | Abort Code | | | |
| Client→ | | 600h+Node_ID | 70h | - | - | - | - | - | - | - |
| ←Server | Normal | 580h+Node_ID | 10h | Data Length | | | | | | |
| | Abnormal | | 80h | Index | | Sub-index | Abort Code | | | |

The response packet of the end frame transmitted in segmented mode includes the end frame identifier and valid data length of the end frame. The structure of its transmission message is shown in the following table.

Table 3–23 Message structure of the last frame in SDO segmented transmission

| | | COB-ID | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---------|----------|--------------|---------|-----------|------------|-----------|---|---|---|---|
| Client→ | | 600h+Node_ID | 60h/70h | Index | | Sub-index | - | - | - | - |
| ←Server | Normal | 580h+Node_ID | 01h/11h | Data | | | | | | |
| | | | 03h/13h | Data | | | | | | - |
| | | | 05h/15h | Data | | | | | - | - |
| | | | 07h/17h | Data | | | | - | - | - |
| | | | 09h/19h | Data | | | - | - | - | - |
| | | | 0Bh/1Bh | Data | - | - | - | - | - | |
| | | | 0Dh/1Dh | Data | - | - | - | - | - | |
| | Abnormal | 80h | Index | Sub-index | Abort Code | | | | | |

3.4.7 SDO transmission framework

SDO transmission complies with the client-server mode, that is, one initiates a request and the other responds to the request. The SDO client in the CAN bus network initiates a request and the SDO server responds to the request. Therefore,

data exchange between SDOs requires at least two CAN messages with different CAN identifiers. The SDO transmission model is shown in the following figure.




Figure 3-22 Object word in the SDO server read/written by the SDO client

3.5 Communication Parameters

To connect the servo drive to the CANopen fieldbus network, set related parameters of the servo drive properly.

CANopen parameters:

| Parameter | Communication Address | Name | Value | Default | Unit | Change Mode |
|-----------|-----------------------|--|---|---------|------|-------------|
| H02.00 | 2002-01h | Control mode | 0: Speed control mode 1: Position control mode 2: Torque control mode 3: Torque/Speed control mode 4: Speed/Position control mode 5: Torque/Position control mode 6: Torque/Speed/Position compound mode 7: Process segment 8: CANopen mode | 1 | - | At stop |
| H0E.00 | 200E-01h | Node address | 1 to 127 | 1 | - | At stop |
| H0E.01 | 200E-02h | Save objects written through communication to e2prom | 0: Not save 1: Save parameters written through communication to e2prom 2: Save object dictionaries written through communication to e2prom 3: Save parameters and object dictionaries written through communication to e2prom 4: Save object dictionaries written before communication (OP) to e2prom | 1 | - | Real-time |

| Parameter | Communication Address | Name | Value | Default | Unit | Change Mode |
|-----------|-----------------------|---------------|--|---------|------|-------------|
| H0E.10 | 200E-0Bh | CAN selection | 0: Pulse/Axis control command 1: Enhanced axis control command 2: CANopen | 0 | - | At stop |
| H0E.11 | 200E-0Ch | CAN baud rate | 0: 20kbps 1: 50kbps 2: 100kbps 3: 125kbps 4: 250kbps 5: 500kbps 6: 1Mbps 7: 1Mbps | 5 | - | At stop |

3.6 PN-to-CANopen bridge

H0E.11 sets the baud rate and H0E.10 sets the CAN station number. The SV680P-INT supports 4 RPDOs/TPDOs and 8-bit/16-bit/32-bit data structures. Related parameter:

| | | 2D address | | | | 2E address | |
|--------------------------|--------------------------|---------------------------|--------------------------|-------|-------|---------------------------|-------|
| OUT | RPDO1 | Number of Mapping Objects | 2D-20 | INPUT | TPDO1 | Number of Mapping Objects | 2E-14 |
| | | Mapped object 1 in RPDO1 | 2D-21 | | | Mapped object 1 in TPDO1 | 2E-15 |
| | | Mapped object 2 in RPDO1 | 2D-23 | | | Mapped object 2 in TPDO1 | 2E-17 |
| | | Mapped object 3 in RPDO1 | 2D-25 | | | Mapped object 3 in TPDO1 | 2E-19 |
| | | Mapped object 4 in RPDO1 | 2D-27 | | | Mapped object 4 in TPDO1 | 2E-1B |
| | | Mapped object 5 in RPDO1 | 2D-29 | | | Mapped object 5 in TPDO1 | 2E-1D |
| | | Mapped object 6 in RPDO1 | 2D-2B | | | Mapped object 6 in TPDO1 | 2E-1F |
| | | Mapped object 7 in RPDO1 | 2D-2D | | | Mapped object 7 in TPDO1 | 2E-21 |
| | Mapped object 8 in RPDO1 | 2D-2F | Mapped object 8 in TPDO1 | | 2E-23 | | |
| | RPDO2 | Number of Mapping Objects | 2D-31 | | TPDO2 | Number of Mapping Objects | 2E-25 |
| | | Mapped object 1 in RPDO2 | 2D-32 | | | Mapped object 1 in TPDO2 | 2E-26 |
| | | Mapped object 2 in RPDO2 | 2D-34 | | | Mapped object 2 in TPDO2 | 2E-28 |
| | | Mapped object 3 in RPDO2 | 2D-36 | | | Mapped object 3 in TPDO2 | 2E-2A |
| | | Mapped object 4 in RPDO2 | 2D-38 | | | Mapped object 4 in TPDO2 | 2E-2C |
| | | Mapped object 5 in RPDO2 | 2D-3A | | | Mapped object 5 in TPDO2 | 2E-2E |
| | | Mapped object 6 in RPDO2 | 2D-3C | | | Mapped object 6 in TPDO2 | 2E-30 |
| Mapped object 7 in RPDO2 | | 2D-3E | Mapped object 7 in TPDO2 | 2E-32 | | | |
| Mapped object 8 in RPDO2 | 2D-40 | Mapped object 8 in TPDO2 | 2E-34 | | | | |

| | | 2D address | | | | 2E address | |
|-----|-------|---------------------------|-------|-------|-------|---------------------------|-------|
| OUT | RPDO3 | Number of Mapping Objects | 2D-42 | INPUT | TPDO3 | Number of Mapping Objects | 2E-36 |
| | | Mapped object 1 in RPDO3 | 2D-43 | | | Mapped object 1 in TPDO3 | 2E-37 |
| | | Mapped object 2 in RPDO3 | 2D-45 | | | Mapped object 2 in TPDO3 | 2E-39 |
| | | Mapped object 3 in RPDO3 | 2D-47 | | | Mapped object 3 in TPDO3 | 2E-3B |
| | | Mapped object 4 in RPDO3 | 2D-49 | | | Mapped object 4 in TPDO3 | 2E-3D |
| | | Mapped object 5 in RPDO3 | 2D-4B | | | Mapped object 5 in TPDO3 | 2E-3F |
| | | Mapped object 6 in RPDO3 | 2D-4D | | | Mapped object 6 in TPDO3 | 2E-41 |
| | | Mapped object 7 in RPDO3 | 2D-4F | | | Mapped object 7 in TPDO3 | 2E-43 |
| | | Mapped object 8 in RPDO3 | 2D-51 | | | Mapped object 8 in TPDO3 | 2E-45 |
| | RPDO4 | Number of Mapping Objects | 2D-53 | | TPDO4 | Number of Mapping Objects | 2E-47 |
| | | Mapped object 1 in RPDO4 | 2D-54 | | | Mapped object 1 in TPDO4 | 2E-48 |
| | | Mapped object 2 in RPDO4 | 2D-56 | | | Mapped object 2 in TPDO4 | 2E-4A |
| | | Mapped object 3 in RPDO4 | 2D-58 | | | Mapped object 3 in TPDO4 | 2E-4C |
| | | Mapped object 4 in RPDO4 | 2D-5A | | | Mapped object 4 in TPDO4 | 2E-4E |
| | | Mapped object 5 in RPDO4 | 2D-5C | | | Mapped object 5 in TPDO4 | 2E-50 |
| | | Mapped object 6 in RPDO4 | 2D-5E | | | Mapped object 6 in TPDO4 | 2E-52 |
| | | Mapped object 7 in RPDO4 | 2D-60 | | | Mapped object 7 in TPDO4 | 2E-54 |
| | | Mapped object 8 in RPDO4 | 2D-62 | | | Mapped object 8 in TPDO4 | 2E-56 |

Note

- Ensure that the number of bytes in each PDO is no more than 8 bytes.
- For a PDO that does not involve communication, you must clear the value of the parameter so that the device can run normally.
- The number of mappings must match the actual number.

4 EtherCAT Communication [N]

4.1 Communication

4.1.1 Communication technical data


| Item | | Specification |
|-------------------------------------|--|--|
| EtherCAT Basic performance of slave | Communication protocol | EtherCAT protocol |
| | Service supported | CoE (PDO, SDO) |
| | Synchronization mode | DC - Distributed clock FreeRun |
| | Physical layer | 100BASE-TX |
| | Baud rate | 100 Mbit/s (100Base-TX) |
| | Duplex mode | Full duplex |
| | Topology | Ring and linear |
| | Transmission medium | Shielded cables of Cat 5e or higher |
| | Transmission distance | Less than 100 m between two nodes (with proper environment and cables) |
| | Number of slaves | Up to 65535 by protocol, not exceeding 100 in actual use |
| | EtherCAT frame length | 44 bytes to 1498 bytes |
| | Process data | Max. 1,486 bytes per Ethernet frame |
| | Synchronous jitter of two slaves | < 1 us |
| EtherCAT Configuration unit | Update time | About 30 us for 1000 DI/DOs About 100 μs for 100 servo axes Define different update time for different interfaces. |
| | Bit error rate | 10 ⁻¹⁰ Ethernet standard |
| | Number of FMMU units | 8 |
| | Number of storage synchronization management units | 8 |
| | Process data RAM | 8 kB |
| Distributed Clock | 64-bit | |
| EEPROM capacity | 32 kbits | |

4.1.2 Communication Specifications

| Item | | Specification | |
|--------------------------------------|-----------------------|--|--|
| Communication protocol | | IEC 61158 Type 12, IEC 61800-7 CiA 402 Drive Profile | |
| Application layer | SDO | SDO request, SDO response | |
| | PDO | Variable PDO mapping | |
| | CiA402 | Profile position mode (PP) | |
| | | Profile velocity mode (PV) | |
| | | Profile torque mode (PT) | |
| | | Homing mode (HM) | |
| | | Cyclic synchronous position mode (CSP) | |
| | | Cyclic synchronous velocity mode (CSV) | |
| Cyclic synchronous torque mode (CST) | | | |
| Physical layer | Transmission protocol | 100BASE-TX (IEEE802.3) | |
| | Maximum distance | 100 m | |
| | Interface | RJ45 × 2 (IN, OUT) | |

4.1.3 Protocols

EtherCAT is an industrial Ethernet-based fieldbus system that features high performance, low cost, easy use and flexible topology. It is applicable to industrial applications requiring ultra-high speed I/O network. EtherCAT adopts standard Ethernet physical layer with twisted pairs or optical fibers (100Base-TX or 100Base-FX) used as the transmission media.



An EtherCAT system includes the master and the slave. The master requires a common network adapter, and the slave requires a special slave control chip, such as ET1100, ET1200, and FPGA.

EtherCAT can process data at the I/O layer,

- without any sub-bus
- or gateway delay
- One system covers all devices, including input/output devices, sensors, actuators, drives, and displays.....
- Transmission rate: 2×100 Mbit/s (high-speed Ethernet, full duplex mode).
- Synchronization: synchronization jitter $< 1 \mu\text{s}$ (number of nodes up to 300, cable length within 120 m)

Update time:

256 DI/DOs: 11 μs

1000 DI/DOs distributed in 100 nodes: 30 μs = 0.03 ms

200 AI/AOs (16-bit): 50 μs , sampling rate: 20 kHz

100 servo axes (8 bytes IN + 8 bytes OUT for each): 100 μs = 0.1 ms

12000 digital I/Os: 350 μs

To support more types of devices and applications, EtherCAT establishes the following application protocols:

- CANopen over EtherCAT (CoE)
- Safety over EtherCAT (SoE, compliant with IEC 61800-7-204)
- Ethernet over EtherCAT (EoE)
- File over EtherCAT (FoE)

The slave only needs to support the suitable application protocol.

Note

EtherCAT[®] is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

4.2 Hardware Configuration

4.2.1 Terminal Layout




Table 4-1 EtherCAT communication terminal pins

| Pin No. | Name | Description |
|-----------|------|------------------------|
| 1 | TD+ | Data transmit positive |
| 2 | TD- | Data transmit negative |
| 3 | RD+ | Data reception+ |
| 4 and 5 | - | - |
| 6 | RD- | Data reception- |
| 7 and 8 | - | - |
| 9 | TD+ | Data transmit positive |
| 10 | TD- | Data transmit negative |
| 11 | RD+ | Data reception+ |
| 12 and 13 | - | - |
| 14 | RD- | Data reception- |
| 15 and 16 | - | - |

4.2.2 EtherCAT Communication Connection Example

CN3 and CN4 are EtherCAT connectors. Connect CN4 (IN) to the communication port of the master and CN3 (OUT) to the next slave. For assignment of CN3/CN4 terminal pins, see *"Table 4-1 EtherCAT communication terminal pins"* on page 59.




Figure 4-1 Wiring of communication cables

Topology

The communication topology of EtherCAT is flexible without any limit, as shown in *"Figure 4-2 Communication network topology"* on page 61. The drive carries IN and OUT ports.






Figure 4-2 Communication network topology

Linear topology



Redundant ring topology



Note

When using the redundant ring, set H0E.36 (EtherCAT AL enhanced link) to 1 (Enable), then power on the drive again.

4.3 Communication Transmission Mode

4.3.1 Structure of EtherCAT Communication

Multiple kinds of application protocols are available for EtherCAT communication. The IEC 61800-7 (CiA 402)-CANopen motion control profile is used for SV680N-INT series servo drives. The following figure shows the EtherCAT communication structure at the CANopen application layer.




Figure 4-3 EtherCAT communication structure at CANopen application layer

The object dictionary in the application layer includes communication parameters, application process data and PDO mapping data. The process data object (PDO) includes the real-time data generated during operation, which is read and written cyclically. In the SDO mailbox communication, the communication objects and PDO objects are being accessed and modified non-cyclically.

4.3.2 Communication State Machine

The following figure shows the status transition diagram of EtherCAT state machine.




Figure 4-4 EtherCAT state machine

The EtherCAT state machine must support the following four states and coordinate the states between the master and slave application program during initialization and operation.

- Init: initialization, shortened as I
- Pre-Operational: pre-operational, shortened as P
- Safe-Operational: safe-operational, shortened as S
- Operational: operational, shortened as O

Transition from Init state to Operational state must be in the sequence of Init→Pre-Operational→Safe→Operational, and then Operational step by step. In transition from the Operational state to the Init state, certain steps can be skipped. The following table lists the state transition and the initialization process.

| Status | SDO | RPDO | TPDO | Description |
|----------------------|-----|------|------|---|
| Init (I) | No | No | No | Communication initialization No communication available in the application layer, EtherCAT slave controller (ESC) register can only be read/written by the master |
| IP | No | No | No | The master configures the slave addresses, mailboxes, and distributed clocks (DCs). Request the Pre-Operational state. |
| Pre-Operational (P) | Yes | No | No | Mailbox data communication in the application layer (SDO). |
| PS | Yes | No | No | The master uses process data mapping of SDO initialization. The master configures the Sync Manager channel used during process data communication. The master configures the FMMU. Request the Safe-Operational state. |
| Safe-Operational (S) | Yes | No | Yes | SDO, TPDO, and distributed clock mode can be used. |
| SO | Yes | No | Yes | The master sends valid output data. to request the Operational state. |
| Operational (O) | Yes | Yes | Yes | Normal operational state Both input and output are valid. Mailbox communication can still be used. |

4.3.3 Distributed clock

The distributed clock (DC) enables all EtherCAT devices to use the same system time and allows synchronous execution of slave tasks. A slave produces the

synchronization signal according to the synchronized system time. The SV680N-INT drive only supports the DC sync mode. The synchronization period, which is controlled by SYNC0, varies with different motion modes.

Note

- The SYNC signal can be used to synchronize all the slaves with an error less than 1 us. The master must synchronize all the slaves to the same clock and continues doing so during operation to prevent clock skew caused by difference in the crystal oscillator. This is usually done by synchronizing the 0x910 register in ESC.
- SYNC starting time = 0x990 register (with ESC) - 0x920
Note that the DC mode (0x981 = 0x03) can be enabled only before 0x910 reaches the starting time. If the starting time of SYNC is set improperly, the 0x134 status register of ESC will report the error code of 0x2D.

4.3.4 Status Indication




Figure 4-5 Status indication diagram

If the value 0 is displayed, it indicates no value is written or the value 0 is written to 6060h, or H02.00 is set to 0, 1 or 2.

Communication connection status

For the SV680N-INT, the connection status of the two RJ45 ports are indicated by "-" on the upper and lower part of the first LED on the keypad. The upper "-" indicates the status of CN3:PORT1, and the lower "-" indicates the status of CN4:PORT0.

OFF: no communication connection is detected in the physical layer.

ON: communication connection is detected in the physical layer.

Communication status

The 2nd LED indicates the status of the EtherCAT state machine of the slave in the form of characters, as described in the following table.

State of EtherCAT state machine

| Status | SDO | RPDO | TPDO | Description | Panel Display |
|--------------------------|-----|------|------|---|---|
| Initializa tion | No | No | No | Communication initialization | 1: Solid ON |
| Pre- operation al | Yes | No | No | Network configuration initialized SDO is available | 2: Blinks at an interval of 400 ms |
| Safe- operation al | Yes | No | Yes | SDO, TPDO, and distributed clock mode are available | 4: Blinks with a period of 1200 ms, on for 200 ms and off for 1000 ms |
| Operation | Yes | Yes | Yes | Normal operation state | 8: Solid ON |

Display of control modes

The 3rd LED indicates the operation mode of the servo drive in the form of hexadecimal without blinking, as described in the following table.

The operation modes include the following:

| Modes of operation (6060h) | Panel Display |
|-------------------------------------|---------------|
| 1: Profile position mode | 1 |
| 3: Profile velocity mode | 3 |
| 4: Profile torque mode | 4 |
| 6: Homing mode | 6 |
| 8: Cyclic synchronous position mode | 8 |
| 9: Cyclic synchronous velocity mode | 9 |
| 10: Cyclic synchronous torque mode | A |

Display of servo status

The 4th and 5th LEDs indicate the servo status of the slave.

The statuses include the following:

| Status | Description | Panel Display |
|-----------|--|--|
| Reset | Initialization | reset |
| Not ready | Initialization is done. The control circuit is switched on but the main circuit is not switched on. Not ready | nr |
| Ready | The main circuit is switched on, but the S-ON signal is inactive. Ready | ry The character "y" blinks when the motor speed is not 0 RPM. When the communication layer is in the pre-operational or safe-operational state, the blinking frequency is the same as that of characters "2" or "4" (see "communication status" in the previous page for details). When the communication layer is in Init or Operational state, the blinking frequency is 2 Hz. |
| Operation | The S-ON signal is active and the motor is energized. Run | rn The letter "n" blinks when the motor speed is not 0 RPM. When the communication layer is in the pre-operational or safe-operational state, the blinking frequency is the same as that of characters "2" or "4" (see "communication status" in the previous page for details). When the communication layer is in Init or Operational state, the blinking frequency is 2 Hz. |

Description of indicators





Figure 4-6 Description of indicators

| Indicator | Status | Status Indication |
|--|---|--|
| RUN | OFF | Initialization. |
| | Blinking (on for 200 ms and off for another 200 ms) | Pre-Operational. |
| | Single flash (on for 200 ms and off for 1000 ms) | Safe-Operational. |
| | ON | Operational. |
| ERR | OFF | No Network error. |
| | Blinking (on for 200 ms and off for another 200 ms) | Communication setting error. |
| | Single flash (on for 200 ms and off for 1000 ms) | Sync event error. |
| | Double flash (on for 200 ms and off for 200 ms, and then on for 200 ms and off for 1000 ms) | Watchdog timeout. |
| L/A IN indicator ^[1] L/A OUT indicator | OFF | Link is not established. |
| | Flickering (on for 50 ms and off for another 50 ms) | Link is established. A data transceiving signal is present. |
| | ON | Link is established. No data transceiving signal is present. |

4.4 Data Frame Structure

4.4.1 Process data

The real-time data transmission of EtherCAT is achieved through PDO. PDOs can be divided into RPDOs (Receive PDO) and TPDOs (Transmit PDO) based on the data transmission direction. RPDOs transmit the master data to the slave, and TPDOs returns the slave data to the master.



The SV680N-INT series servo drive allows users to assign the PDO list and define the PDO mapping objects.

PDO mapping

PDO mapping is used to establish the mapping relation between the object dictionary and the PDO. 1600h to 17FFh are RPDOs, and 1A00h to 1BFFh are TPDOs. The SV680N-INT provides 7 RPDOs and 6 TPDOs, as listed in the following table.

| | | |
|-------------|------------------|------------------|
| RPDO (7) | 1600h, 1601h | Variable mapping |
| | 1701h to 1705h | Fixed mapping |
| TPDO (6) | 1A00h, 1A01h | Variable mapping |
| | 1B01h to 0x1B04h | Fixed mapping |

Fixed PDO mapping

SV680N-INT provides five fixed RPDOs and four fixed TPDOs.

The following table lists the typical instances of RPDOs and TPDOs.

| | |
|--------------------|---|
| Control Mode | PP/CSP |
| 1701h (Outputs) | Mapping objects (4 mapping objects, 12 bytes) |
| | 6040h (Control word) |
| | 607Ah (Target position) |
| | 60B8h (Touch probe function) 60FEh sub-index 1 (forced physical outputs) |
| 1B01h (Inputs) | Mapping objects (9 mapping objects, 28 bytes) |
| | 603Fh (error code) |
| | 6041h (status word) |
| | 6064h (position actual value) |
| | 6077h (torque actual value) |
| | 60F4h (following error actual value) |
| | 60B9h (touch probe status) |
| | 60BAh (probe 1 positive edge) |
| | 60BCh (probe 2 positive edge) |
| | 60FDh (Digital inputs) |

| | |
|--------------------|---|
| Control Mode | PP/PV/PT/CSP/CSV/CST |
| 1702h (Outputs) | Mapping objects (7 mapping objects, 19 bytes) |
| | 6040h (Control word) |
| | 607Ah (Target position) |
| | 60FFh (Target velocity) |
| | 6071h (Target torque) |
| | 6060h (Modes of operation) |
| | 60B8h (Touch probe function) |
| | 607Fh (Max. profile velocity) |

| | |
|-------------------|---|
| 1B02h (Inputs) | Mapping objects (9 mapping objects, 25 bytes) |
| | 603Fh (error code) 6041h (status word) 6064h (position actual value) 6077h (torque actual value) 6061h (modes of operation display) 60B9h (touch probe status) 60BAh (probe 1 positive edge) 60BCh (probe 2 positive edge) 60FDh (Digital inputs) |

| | |
|--------------------|--|
| Control Mode | PP/PV/CSP/CSV |
| 1703h (Outputs) | Mapping objects (7 mapping objects, 17 bytes) |
| | 6040h (Control word) 607Ah (Target position) 60FFh (Target velocity) 6060h (Modes of operation) 60B8h (Touch probe function) 60E0h (Positive torque limit value) 60E1h (Negative torque limit value) |
| 1B03h (Inputs) | Mapping objects (10 mapping objects, 29 bytes) |
| | 603Fh (error code) 6041h (status word) 6064h (position actual value) 6077h (torque actual value) 60F4 (following error actual value) 6061h (modes of operation display) 60B9h (touch probe status) 60BAh (probe 1 positive edge) 60BCh (probe 2 positive edge) 60FDh (Digital inputs) |

| | |
|--------------------|--|
| Control Mode | PP/PV/PT/CSP/CSV/CST |
| 1704h (Outputs) | Mapping objects (9 mapping objects, 23 bytes) |
| | 6040h (Control word) 607Ah (Target position) 60FFh (Target velocity) 6071h (Target torque) 6060h (Modes of operation) 60B8h (Touch probe function) 607Fh (Max. profile velocity) 60E0h (Positive torque limit value) 60E1h (Negative torque limit value) |

| | |
|-----------------------|---|
| Control Mode | PP/PV/CSP/CSV |
| 1705h (Outputs) | Mapping objects (8 mapping objects, 19 bytes) |
| | 6040h (Control word) |
| | 607Ah (Target position) |
| | 60FFh (Target velocity) |
| | 6060h (Modes of operation) |
| | 60B8h (Touch probe function) |
| | 60E0h (Positive torque limit value) |
| | 60E1h (Negative torque limit value) |
| 60B2h (Torque offset) | |

Variable PDO mapping

SV680N-INT provides two variable RPDOs and two variable TPDOs.

| Variable PDO | Index | Max. Length of the Byte | Default Mapping Object |
|--------------|----------------|-------------------------|--|
| RPDO1 | 1600h 1601h | 40 | 6040h (Control word) 607Ah (Target position) 60B8h (Touch probe function) |
| TPDO1 | 1A00h 1A01h | 40 | 603Fh (error code) 6041h (status word) 6064h (position actual value) 60BCh (probe 2 positive edge) 60B9h (touch probe status) 60BAh (probe 1 positive edge) 60FDh (Digital inputs) |

Sync Manager PDO assignment

The process data can contain multiple PDO mapping data objects during cyclic EtherCAT data communication. The CoE protocol defines the PDO mapping object list of the Sync Manager using data objects 1C10 to 1C2Fh. Multiple PDOs can be mapped to different sub-indexes. The SV680N-INT series servo drive supports assignment of one RPDO and one TPDO, as described in the following table.

| Index | Sub-index | Description |
|-------|-----------|---|
| 1C12h | 01h | One of 1600h, 1601h and 1701h to 1705h used as the actual RPDO. |
| 1C13h | 01h | One of 1A00h, 1A01h and 1B01h to 1B04h used as the actual TPDO. |

PDO configuration

PDO mapping parameters contain indicators of the process data for PDOs, including the index, subindex and mapping object length. The sub-index 0 indicates the number (N) of mapping objects in the PDO, and the maximum length of each PDO is 4 x N

bytes. One or multiple objects can be mapped simultaneously. Sub-indexes 1 to N indicate the mapping content. Table 3-27 defines mapping parameters.

| | | | | | | | | | |
|-------------|-------|-----|----|-----------|-----|---|---------------|-----|---|
| Places | 31 | ... | 16 | 15 | ... | 8 | 7 | ... | 0 |
| Description | Index | | | Sub-index | | | Object Length | | |

The index and sub-index together define the position of an object in the object dictionary. The object length indicates the bit length of the object in hexadecimal, as shown below.

| Object Length | Bit Length |
|---------------|------------|
| 08h | 8-bit |
| 10h | 16-bit |
| 20h | 32-bit |

For example, the mapping parameter of the 16-bit control word 6040.00h is 60400010h.

- PDO mapping steps:

Abide by the following procedures for PDO mapping:

1. Configure the mapping group of PDO. Write 0 to sub-index 00h of 1C12h (or 1C13h).
 - a. Clear the original mapping group. Write 0 to sub-index 00h of 1C12h (or 1C13h) to clear the original mapping group.
 - b. Write the PDO mapping group. Write the mapping group according to application needs. Pre-write values of 1600h/1701h...1705h to 1C12h and values of 1A00h/1B01h...1B04h to 1C13h. Note: Only 1600h and 1A00h, and 1601h and 1A01h are configurable mapping groups.
 - c. Write the total number of this PDO mapping group to sub-index 0 of 1C12h (or 1C13h).
2. Configure the mapping objects of PDO. Write 0 to sub-index 00h of 1600h (or 1A00h) and 1601h(or 1A01h).
 - a. Clear the original mapping objects. Write 0 to sub-index 00h of 1600h (or 1A00h), and 1601h (or 1A01h) to clear the original mapping objects.
 - b. Write the PDO mapping content. Write the mapping content to sub-index 1...10 of the mapping parameter based on object parameter definitions in XML file. Only mappable objects can be configured as PDO mapping content.
 - c. Write the total number of mapping objects. Write the number of mapping objects in step b to sub-index 0.

Note

- Configure the PDO only when the EtherCAT state machine is in pre-operational state ("2" displayed on the keypad). Otherwise, an error will be reported.
- Do not save the PDO configuration parameters to EEPROM. Configure the mapping objects again each time upon power-on. Otherwise, the mapping objects are the default parameters of the servo drive.

An SDO fault code will be returned when the following operations are under execution:

- Modify PDO parameters in status other than pre-operational.
- Write a value outside the range of 1600h/1601h/1701h...1705h to 1C12h. Write a value outside the range of 1A00h/ 1A01h/1B01h...1B04h to 1C13h.

4.4.2 Service Data Object (SDO)

The EtherCAT SDO is used to transfer non-cyclic data, such as communication parameter configuration and servo drive parameter configuration. The CoE service types of EtherCAT include:

- Emergency message
- SDO request:
- SDO response:
- TxPDO
- RxPDO
- Remote TxPDO transmission request
- Remote RxPDO transmission request
- SDO information.

The SV680N-INT series supports SDO request and SDO response.

4.5 Communication Parameters

Parameter address structure

Parameter access address: index+subindex, both of which are in hexadecimal.

CiA402 establishes the following restrictions on the parameter address:

| Index (Hex) | Description |
|----------------|------------------------------|
| 0000h to 0FFFh | Data type |
| 1000h to 1FFFh | CoE communication object |
| 2000h to 5FFFh | Manufacturer-specific object |
| 6000h to 9FFFh | Profile object |
| A000h–FFFFh | Reserved |

System parameter setting

Set related parameters to allow the SV680N-INT servo drive to be connected to the EtherCAT fieldbus network.

☆ Related parameters:

| Parameter | Communication Address | Name | Value | Default | Unit | Change Mode |
|-----------|-----------------------|--|---|---------|------|-------------|
| H02.00 | 2002-01h | Control mode | 0: Velocity mode 1: Position mode 2: Torque mode 7: Technology segment 9: EtherCAT mode | 9 | - | At stop |
| H0E.01 | 200E-02h | Save objects written through communication to e2prom | 0: Not save 1: Save parameters written through communication to e2prom 2: Save object dictionaries written through communication to e2prom 3: Save parameters and object dictionaries written through communication to e2prom 4: Save object dictionaries written before communication (OP) to e2prom | 4 | - | Real-time |
| H0E.21 | 200E-16h | EtherCAT slave alias | 0 to 65535 | 0 | - | At stop |

Note

Before saving parameters to EEPROM, set H0E.01h to a proper value. Otherwise, parameters will be restored to default values at next power-on. It is recommended to set H0E.01 to 0 after parameters are set properly. This is to prevent damage to the EEPROM device caused by prolonged writing process.

5 Communication Configuration Instance

5.1 Modbus Communication Configuration Case [P]

5.1.1 Communication Overview

The following describes the Modbus RTU communication connection between Inovance H2U and the SV680P-INT series servo drive. It can be achieved by a configuration table or program. In this case, H06.03 (Write speed) and H0b.00 (Read speed) are used for illustration.




Figure 5-1 Schematic and wiring

5.1.2 Wiring of Modbus RTU Communication Between SV680P-INT and Third-Party PLCs

Inovance H2U and SV680P-INT

| Name | Model | Quantity | Remarks |
|---|--------------------------------|----------|---------|
| PLC | H2U-1616MT/MR | 1 piece | - |
| Inovance SV680P-INT series servo drive and applicable motor | SV680PT012I-INT MS1H3-***** | 1 set | - |

| COM1 Terminal Layout on PLC Side | | CN3/CN4 Terminal Layout on Drive Side | |
|----------------------------------|---------|---------------------------------------|-----------|
| Signal Name | Pin No. | Signal Name | Pin No. |
| RS485+ | 1 | RS485+ | 4 |
| RS485- | 2 | RS485- | 5 |
| - | - | PE (shield layer) | Enclosure |

Siemens PLC and SV680P-INT

| Siemens S7200 PLC | | CN3/CN4 Terminal Layout on Drive Side | |
|-------------------|-----------|---------------------------------------|-----------|
| PLC PORT0-RS485 | Pin No. | Signal Name | Pin No. |
| Data+ | 3 | RS485+ | 4 |
| Data- | 8 | RS485- | 5 |
| PE (shield layer) | Enclosure | PE (shield layer) | Enclosure |

Mitsubishi FX3U and SV680P-INT

| Mitsubishi FX3U PLC | | CN3/CN4 Terminal Layout on Drive Side | |
|---------------------|-----------|---------------------------------------|-----------|
| FX3U-485-BD | Pin No. | Signal Name | Pin No. |
| SDA | Short | RS485+ | 4 |
| RDA | | | |
| SDB | Short | RS485- | 5 |
| RDB | | | |
| SG | Enclosure | PE (shield layer) | Enclosure |

Setting communication parameters through GX PLC software (initialization of communication port 1):

1. Communication port 1 parameter setting (RS485, 19200, 7, N, 1)
2. LD M8002
3. Initial ON
4. MOV H0C91 D8120
5. Communication port 1 setting
6. SET M8161
7. Communication format: 8-bit

Using two major commands (See the user guide for FX3U communication.)

- RS D100 K8 D120 K8
 - D100: station No. being "?"
 - D120: starting address for data receiving (8 bytes)
- CRC D100 D106 K6
 - D100: station No. being "?"
 - D106: CRC checked address

Omron PLC and SV680P-INT

| Omron CP1L | | CN3/CN4 Terminal Layout on Drive Side | |
|-------------------|-----------|---------------------------------------|-----------|
| PLC PORT0-RS485 | Pin No. | Signal Name | Pin No. |
| SDB+ | - | RS485+ | 4 |
| SDA- | - | RS485- | 5 |
| PE (shield layer) | Enclosure | PE (shield layer) | Enclosure |

Note


Set 2, 3, 5, and 6 on the DIP switch to ON, and others to OFF. The DIP switch is on the back of PLC communication card.

5.1.3 Servo Parameter Settings



| Para. | Setting | Description | Remarks |
|--------|---------|------------------------------------|--|
| H0E.00 | 1 | Drive axis address | - |
| H0E.80 | 5 | Modbus baud rate | 5: 9600 bps |
| H0E.84 | 1 | Modbus communication data sequence | 0: High 16 bits before low 16 bits 1: Low 16 bits before high 16 bits |

5.1.4 PLC Program Examples

Communication connection implemented through programming



Communication connection implemented through configuration table



5.2 CANopen Communication Configuration Case [P]

5.2.1 Connecting SV680P-INT to Schneider 3S Master

The following takes the position control mode as example. For details on the position control mode, see section "Position Control Mode" in SV680-INT Series Servo Drive Function Guide.

In the position control mode, assignment of objects used as PDO are listed in the following table.


Table 5-1 PDO mapping allocation

| PDO | Object | Description | Bit Length |
|-------|----------|------------------------|------------|
| RPDO1 | 6040.00h | Control word | Uint16 |
| | 6060.00h | Mode selection | Int8 |
| RPDO2 | 6081.00h | Profile velocity | Uint32 |
| | 607A.00h | Target position | Int32 |
| TPDO1 | 6041.00h | Status word | Uint16 |
| | 6061.00h | Operation mode display | Int8 |
| TPDO2 | 606C.00h | Speed feedback | Int32 |
| | 606A.00h | Position actual value | Int32 |
| TPDO3 | H0b.26 | Phase current feedback | Uint16 |


SDO is used to write acceleration 6083h, deceleration 6084h and emergency stop 605Ah.

SoMachine is the software tool of Schneider 3S series master. This section describes how to connect the SV680P-INT servo drive to Schneider M238.


1. Start SoMachine and click **Create new machine** based on a standard project.
Select a master device, for example, TM238LFDC24DT, modify the device name, and click **Create Project**, as shown below.




2. Enter the file name and click **Save** in the dialog box displayed.




3. The following interface appears.




4. Choose **Tools > Device Repository** in the toolbar. The **Device Repository** dialog box is displayed. (If the EDS file is imported, steps Step 4 to 6 can be omitted.)




5. As shown in the preceding interface, select **System Repository** and click **Install**. Select a directory for saving the EDS file, as shown below.




6. Click **Open**. The EDS file of the SV680P-INT servo drive is imported into SoMachine. In the **Device Repository** dialog box, you can choose **Field Bus > CANopen > Remote Device** to view devices..




9. Now, the CANOpen gateway appears in the interface. Click the position indicated by **2**.




10. The **Add device** dialog box appears again. Select **Inovance** as the vendor and **SV680** as the device, and then click **Add and close**.




11. Now, the SV680P-INT servo drive appears in the interface.




12. Click **Program** and double-click **CAN** on the left to select a proper baud rate. 500 Kbps is selected here.




13. Double-click **SV680P_INT_Servo_Driver** on the left. The node ID can be modified. Check **Enable Expert Settings**.




14. Click **PDO Mapping** and check two RPDO and three TPDO.




15. Double-click **RPDO1**. The **PDO Properties** dialog box is displayed. Modify **Transmission Type** to **Type 255**. Perform the same operation for other PDOs.




16. Select **Receive PDO Mapping** and click **receive PDO parameter**. Click **Add Mapping** or select a mapping and click **Edit**.




17. Select the proper mapping object in the dialog box displayed according to "Table 5-1" on page 79.




18. After the mapping object is added, the RPDO mapping is shown as follows.




19. Similarly, click **Send PDO Mapping** and perform configuration according to "Table 5-1" on page 79, as shown below.




20. Click the **Service Data Object** and click **New** to add a required SDO. (Optional) (If default values are used, steps 20 to 22 can be omitted)




21. Select the corresponding SDO in the list. You can modify the value and click **OK**. (Optional)




22. The newly added SDO is shown as below. (Optional)




23. Double-click **POU** on the left. Add variable definitions in **2** and add PLC program logic in **3**. Click **Edit** or press "F11". If no error occurs, go to the next step.




24. Double-click **MAST** to add the PDO, and set the program circulation interval.




25. Select the POU added based on the following dialog box and click **OK**.




26. Select **CANopen I/O Mapping** under **SV680P_INT...** and double-click the variable to display the ... button, and then click the ... button.




27. Select the PLC-defined variable based on the following steps.




28. Add other variables in the similar way, and the mapping is shown below.




29. Double-click the master name on the left. Select **MyController** and click **Set active path** on the right.




30. The following warning displays. Press Alt+F according to the instructions.




31. Click the icon circled out or select **Online > Login** or press Alt+F8.



32. Click **Yes** in the dialog box displayed.




33. After download is done, click the ► circled out or click **Online > Start** or press F5 to start the PLC program written by the user. The motor operates in the mode defined by the user.



34. You can also perform motor commissioning manually according to the following steps.

Select **CANopen I/O Mapping** under **SV680P_INT...** and enter the value needed in the **Prepared V...** column. Next, click **Debug/Watch > Forced Value** or press F7 to modify the variable manually.


35. Write 1 to 6060h, 100 to 6081h, and 10485760 (10 revolutions) to 607Ah. Write 6 (0x06), 7 (0x07), 47 (0x2f), and 63 (0x3f) to 6040h in sequence to make the motor run.



Note

- When writing multiple values for one variable, execute the "Forced value" command every time a value is written. When writing values for multiple variables, you can execute the "Forced value" command once for all after all the values are written.
- When a new position or speed reference is required, write the new reference and set 6040h to 47(0x2f) and 63(0x3f) in turn. The motor runs to the position according to the new reference regardless of whether the previous reference is executed.
- To stop the motor, set 6040h to 0.
- To terminate manual writing of values, go to the toolbar and choose Debug/Watch > Release Values, or press Alt+F7. Then, variables will be executed according to the PLC program logic instead of manually written values.

36. Execute **1** marked in the following figure, or select **Online > Stop** in the toolbar and press Shift + F8 to stop the PLC program. Click **2** marked in the following figure, or select **Online > Exit** or press Ctrl + F8 to exit from the online function.



5.2.2 Connecting SV680P-INT to Beckhoff CANopen Master

Assign PDO according to "Table 5-2" on page 98 in the position control mode.


1. Configuring PDO mapping is complex on a Beckhoff master node. Therefore, before connecting the network, manually configure the PDO mapping. Based on the

following table and the appendix, change the mapping by modifying parameters. The parameters to be modified are as follows:


Table 5-2 Example of PDO mapping of Beckhoff master

| Parameter | Object | Mapping Object | Input |
|-----------|----------|-----------------------------------|-----------|
| H2d.32 | 1600.00h | Number of mapped objects in RPDO1 | 2 |
| H2d.33 | 1600.01h | 6040.00h | 60400010h |
| H2d.35 | 1600.02h | 6060.00h | 60600008h |
| H2d.49 | 1601.00h | Number of mapped objects in RPDO2 | 2 |
| H2d.50 | 1601.01h | 6081.00h | 60810020h |
| H2d.52 | 1601.02h | 607A.00h | 607A0020h |
| H2E.20 | 1A00.00h | Number of mapped objects in TPDO1 | 2 |
| H2E.21 | 1A00.01h | 6041.00h | 60410010h |
| H2E.23 | 1A00.02h | 6061.00h | 60610008h |
| H2E.37 | 1A01.00h | Number of mapped objects in TPDO2 | 2 |
| H2E.38 | 1A01.01h | 606C.00h | 606C0020h |
| H2E.40 | 1A01.02h | 6064.00h | 60640020h |
| H2E.54 | 1A02.00h | Number of mapped objects in TPDO3 | 1 |
| H2E.55 | 1A02.01h | 200B.19h | 200B1910h |
| H2E.57 | 1A02.02h | - | 0 |


2. Connect Beckhoff CX9020, as a master node, to the CANopen module of EL6751 and perform the test. Ensure that the IP address of CX9020 is in the same network segment as the IP address of the PC and the first four bytes of AMS Net (**Properties > AMS Router > AMS Net**) of Beckhoff TwinCAT software are the same as the IP address of the PC.




3. Open TwinCAT System Manager and create an empty project. Click **SYSTEM - Configuration** on the left and click **Choose Target...** on the right.




4. In the dialog box that is displayed, select **...local...** and click **Search (Ethernet)**.




5. Select the **IP Address** as indicated by **1** and click **Broadcast Search**.




6. The master is displayed. Select the master and click **Add Route**.




7. In the dialog box displayed, the account is the same with the **Host Name** and the password is empty. Click **OK**.




8. Click **Close** in the interface shown in Step 6, then you can click + in the **Choose Target System** dialog box to select the master. Finally, click **OK**.




9. The master (in red background) can be seen in the lower right corner of the window, which is in the configuration status (in blue background). If the master is in the operating status (in green background), click the icon indicated by **4** to switch to the configuration status, and then proceed to the next step. Select **I/O Devices** on the left and click the icon indicated by **3** or right-click **I/O Devices** and select **Scan Devices**.




10. Click **OK** in the warning dialog box displayed.




11. Check **Device EtherCAT** and click **OK** in the dialog box displayed.




12. Click **Yes** in the dialog box asking whether to scan for boxes.




13. Click **Yes** in the dialog box asking whether to create 6751 master.



14. Select the baud rate (defaulted to 500 kbps) and click **OK**. The master starts device searching, which may take a while.




15. After device searching is done, click **OK** in the warning dialog box displayed.



16. Click **Yes** in the dialog box asking whether to activate free run.




17. The Box of SV680P-INT series servo drive is now displayed on the left. Right-click to insert three TPDOs and 2 RPDOs. Right click **Disabled** to **uncheck it**.




Note

Only servo drives equipped with termination resistors can be scanned by the master.


18. The following figure shows the result after the previous operation is complete. Choose **TPDO1 > Inputs**, right-click, and choose **Insert Variable**.




19. Map different variables in each PDO according to ["Table 5-2 Example of PDO mapping of Beckhoff master"](#) on page 98. TPDO1 maps 6041.00h and 6061.00h. To insert the first variable 6041h, select **UINT16** in the **Variable Type** first, and then enter a proper name in the field **Name** and click **OK**.



20. Now 6041h has been added to TPDO1. Select **Inputs** again, right-click, choose **Insert Variable**, and insert the second variable.




21. For the inserted variable 6061h, select **INT8** (the object dictionary can be queried) for **Variable Type**, enter a large value for **Byte** of **Start Address** to prevent 6061h from being inserted in front of 6041h, enter a proper name, Click **OK**.




22. You can see that two objects are added to TPDO1. Note that the sequence of the two variables must be the same as that in *"Table 5-2 Example of PDO mapping of Beckhoff master"* on page 98. Otherwise, the second variable must be deleted and inserted again and a large value must be entered in **2** marked in the figure in Step 21.


After making sure that the variable sequence is correct, choose **TPDO1 > Inputs**, right-click, and choose **Recalc Address** to allocate addresses. This step must be performed. Otherwise, addresses will be in mess.




23. Repeat steps 18 to 22 for other PDOs. Add corresponding mapping variables according to "Table 5-2 Example of PDO mapping of Beckhoff master" on page 98. The interface after variables are added is shown below.




24. Click the icon circled out in the following figure or press Shift + F4.




25. Click **Yes** in the following dialog box.




26. Click **Yes** in the dialog box asking whether to activate free run.




27. Select the Box of SV680P-INT and select **Inputs > NodeState**. The node state in **Online** is 0, indicating the node is in a normal state.




28. Open TwinCAT PLC Control, create a new project and select **CX (ARM)** in the dialog box displayed.




29. In the dialog box that is displayed, select the following options:




30. Enter corresponding variable definition and the PLC logic.




31. In the toolbar, select **Online > Choose Run-Time System**. Select the corresponding master port in the dialog box displayed and click **OK**.




32. In TwinCAT System Manager, select **PLC** → **Configuration** on the left, and then right-click to display the short-cut menu. Select **Append PLC Project...** in the short-cut menu to select the PLC program (.tpy), created.



33. After the PLC program is added, select the PDO variable and click **Linked to** or double-click the variable to link the variable to the PLC program.



34. Select the corresponding PLC variable and click **OK**.




35. After the variable is linked, a small arrow pointing upper right appears at the bottom left of the variable name icon. As shown in the following figure, the name of


the variable not linked is displayed on the left and the name of the linked variable is displayed on the right.



36. Click **Generate mapping**, **Check Configuration**, and **Activate Configuration** in sequence, as circled out by **1**, **2**, and **3** in the following figure.




37. Click **OK** to activate configuration.




38. Click **OK** to restart TwinCAT system with the run mode.




39. Open the project created by TwinCAT PLC Control software before, and click **Online > Login** or press F11 to display the dialog box asking whether to download the new program.




40. Select **Online > Run** or press F5 to run the user PLC program.



41. You can perform write commissioning forcibly through the manual mode. The commissioning method is similar to that of the Schneider master. Double-click variables circled out in the following figure and enter values.



42. Enter the value and click **OK**.



The value entered is displayed in the square brackets behind the original variable. Click **Online** → **Forced Value** or press F7 to write the value forcibly.

Write 1 to 6060h, 100 to 6081h, and 10485760 (10 revolutions) to 607Ah. Write 6 (0x06), 7 (0x07), 47 (0x2f), and 63 (0x3f) to 6040h in sequence to make the motor run.


Note

- When writing multiple values for one variable, execute the "Forced value" command every time a value is written. When writing values for multiple variables, you can execute the "Forced value" command once for all after all the values are written.
- When a new position or speed reference is required, write the new reference and set 6040h to 47(0x2f) and 63(0x3f) in turn. The motor runs to the position according to the new reference regardless of whether the previous reference is executed.
- To stop the motor, set 6040h to 0.
- To terminate manual writing of values, go to the toolbar and choose Online > Release Force, or press Shift+F7. Then, variables will be executed according to the PLC program logic instead of manually written values.


43. In the toolbar, choose **Online > Stop** to stop executing the PLC program. Choose **Online > Logout** to continue editing the PLC program or exit.

5.2.3 Connecting SV680P-INT to Inovance H3U CANopen Master

1. Open AutoShop, double-click "CAN" in Communication Port of the project management interface or right-click "Open" to pop up the "CAN Config" window. Select the CANopen master as the protocol and set **Station No.** and **Baud Rate** of the master.




2. Right-click **CAN (CANopen)** and select **Add CAN Config** in the short-cut menu.




3. Double click CANopen Config.

You can see the H3U master icon in the CANopen configuration interface. Double-click this icon to open the master configuration interface, in which you can set parameters such as synchronization and heartbeat.


H3U axis-control commands control the servo drive through PDO communication. The PDO adopts synchronization mode by default when the drive is working with an H3U master. Therefore, you need to check **Enable Synchronous Production** in this interface and set the synchronization period (15ms for 8 axes generally) as needed. For other servo drive models, this option also needs to be checked if the PDO also adopts synchronization mode.



4. If the EDS files needed is not in the CANopen device list, add the device EDS file.
 - a. Click **CANopen device list** and right-click on it to display the short-cut menu. In the short-cut menu, select **Import EDS**.




b. In the dialog box displayed, select the EDS file needed and click **Open**.




c. The device added will be displayed in the CANopen device list on the right.

- Double-click the **SV680P** in the **CANopen device list** to add CANopen slaves. Then, double-click the **SV680P-INT** icon in the configuration to open the slave configuration parameter list.




- The **axis parameters setting** interface is shown as follows, which include **axis parameter setting** and **homing parameter setting**.
Setting axis parameters



- For devices without reducers, set the gear ratio to 1:1. Set the pulses per motor revolution and distance per motor revolution correctly. The calculation formula is as follows.

$$\text{Pulses} = \frac{\text{Pulses of one circle on the motor (1)}}{\text{Distance of one circle on the working gear (3)}} \times \text{Distance (in displayed unit)}$$


- Applications with reducers are shown as follows.



The calculation formula for devices with reducers is as follows.

$$\text{Pulses} = \frac{\text{Pulses of one circle on the motor (1)} \times \text{Working gear ratio (5)}}{\text{Distance of one circle on the working gear (3)} \times \text{Working gear ratio (4)}} \times \text{Distance (in displayed unit)}$$

Setting axis homing parameters



The range of the homing method is 1 to 35. The calculation formula for parameters and object dictionaries of the homing speed, homing acceleration, and homing proximity speed is shown as follows.

$$\text{Object dictionary value} = \frac{\text{Pulses of one circle on the motor (1)} \times \text{Working gear ratio (5)}}{\text{Distance of one circle on the working gear (3)} \times \text{Working gear ratio (4)}} \times \text{Setpoint in the software tool (in displayed unit)}$$

The relation between preceding parameters and object dictionaries is as follows.

| Index | Sub-index | Data type | Description | Unit |
|-------|-----------|-----------|--------------------------------|------------------|
| 6098h | 00 | SINT | Homing method | - |
| 6099h | 01 | UDINT | Speed during search for switch | Reference unit/s |

| Index | Sub-index | Data type | Description | Unit |
|-------|-----------|-----------|------------------------------|-------------------------------|
| 6099h | 02 | UDINT | Speed during search for zero | Reference unit/s |
| 609Ah | 00 | UDINT | Homing acceleration | Reference unit/s ² |
| 60E6h | 00 | USINT | Homing method | - |


7. The object dictionaries involved in CANopen CiA402 motion control commands interact with the slave in the PDO mode. These object dictionaries, which include 6040h (Control word), 6041h (Status word), 6060h (Modes of operation), 6061h (Modes of operation display), 6081h (Profile velocity), 607Ah (Target position), 60FFh (Target velocity), 6064h (Position actual value), and 606Ch Velocity actual value), must be configured as required below. Otherwise, axis configuration failure may occur during calling axis control commands.

Note

It is recommended to configure the PDO communication to synchronous mode to prevent frame loss caused by interference during communication. The synchronous mode requires synchronous production to be enabled in the master configuration. To ensure communication stability, the network load rate must be lower than 70%.

$$\text{Network load rate} = \frac{328 \times \text{Number of axes} + 79}{\text{Baud rate} \times \text{SYNC cycle}} \times 100\%$$

Configuring the RPDOs




Configure the RPDOs in the following sequence.

| Index | Sub-index | Name |
|----------------------|-----------|--------------------|
| 6040h | 00 | Control word |
| 60FFh ^[1] | 00 | Target velocity |
| 6060h | 00 | Modes of operation |
| 607Ah | 00 | Target position |
| 6081h | 00 | Profile velocity |

Note

[1]: The object dictionary can be replaced by other object dictionaries with a length of 0x20.

It is recommended to use synchronous mode for PDO communication. The method for setting synchronous PDO communication of the slave is as follows.



Note

When MCMOVVEL and MCJOG are not in use, this object dictionary can be replaced by other object dictionaries with a length of 0x20.

Steps:

- 1. Double-click the group No. and a dialog box appears.
- 2. Set "Transmission Type" to "Type1-240".
- 3. Set "Synchronization NO." to "1".

Configuring TPDOs:

Configure the TPDOs in the following sequence.

| Index | Sub-index | Name |
|----------------------|-----------|-----------------------|
| 6041h | 00 | Status word |
| 60FDh ⁽¹⁾ | 00 | Digital inputs |
| 6061h | 00 | Modes of operation |
| 6064h | 00 | Position actual value |
| 606Ch | 00 | Velocity actual value |

Note

[1]: The object dictionary can be replaced by other object dictionaries with a length of 0x20.


The mode for setting TPDOs is similar to that for RPDOs.



Caution


The EDS must be configured based on the preceding sequence by default. Observe the preceding configuration sequence when adding new objects. A wrong sequence will cause failure of H3U axis control commands. The preceding configuration sequence does not necessarily apply to PLCs from other manufacturers.

- Download the CANopen configuration to H3U. The H3U starts slave configuration based on the previous configurations. Configuration is performed based on the object dictionaries listed in the **Servo Data Object** interface. To view this list, check **Enable Expert setting** in the **Slave Node** interface first.



| NO. | Index | Sub-Index | Name | Value | Bit NO. | Download |
|-----|---------|-----------|-------------------|------------|---------|----------|
| 1 | 16#1000 | 16#00 | Device type | 0x00020192 | 32 | * |
| 2 | 16#1018 | 16#01 | Vendor ID | 0x000003B9 | 32 | |
| 3 | 16#1018 | 16#02 | Product code | 0x000D0107 | 32 | |
| 4 | 16#1018 | 16#03 | Revision number | 0x19203800 | 32 | |
| 5 | 16#1400 | 16#01 | Disable PDO | 0x80000201 | 32 | * |
| 6 | 16#1401 | 16#01 | Disable PDO | 0x80000301 | 32 | * |
| 7 | 16#1402 | 16#01 | Disable PDO | 0x80000401 | 32 | * |
| 8 | 16#1403 | 16#01 | Disable PDO | 0x80000501 | 32 | * |
| 9 | 16#1600 | 16#00 | Clear PDO mapping | 0x00 | 8 | * |
| 10 | 16#1601 | 16#00 | Clear PDO mapping | 0x00 | 8 | * |
| 11 | 16#1602 | 16#00 | Clear PDO mapping | 0x00 | 8 | * |
| 12 | 16#1603 | 16#00 | Clear PDO mapping | 0x00 | 8 | * |
| 13 | 16#1800 | 16#01 | Disable PDO | 0xC0000181 | 32 | * |

During commissioning, you can monitor the device status online and read/write the object dictionary of the slave through H3U, as shown below.




Where:


- 1. Click **Start Monitor**.
- 2. Write the index of the object dictionary to be operated in **Index** and the sub-index in **Subindex**.
- 3. Click **Read SDO** or **Write SDO** as needed.


5.2.4 Connecting SV680P-INT to Inovance EASY CANopen Master

1. Open Autoshop and click **New Project**. In the popup dialog box, first select the editor type, and then select Easy300 as the PLC type. Enter the project name and select the save path, and then click "OK" to create a new project and enter the project main interface.




3. Double-click **CAN** in **Configuration** of **Project Management**, select CANopen in the pop-up window, set the station number and baud rate, and click OK. At this time, CAN is configured as a CANopen slave station,. Configure it as a CANopen master station by right-clicking **CAN** in **Configuration** of **Project Management** and selecting **Add CAN Configuration** in the pop-up menu, as shown in the following figure.






4. Double click CANOpen Config to open the CANOpen Configuration interface, as shown below:



5. If the EDS files needed is not in the CANOpen device list, add the device EDS needed. Click **CANOpen device list** and right-click on it to display the short-cut menu. In the short-cut menu, select **Import EDS**. In the dialog box displayed, select the EDS device file needed and click **Open**. The device added will be displayed in the CANOpen device list on the right.



6. Double-click the EASY master station to open the master configuration interface, in which you can set parameters such as synchronization and heartbeat.

Easy302

Master Information Network State

Network Management

Node ID: 63

Baud Rate(bit/s): 500Kbps

The program is running prohibited SDO, NMT access Ignore any errors continue to configure SDO

Synchronous

Enable Synchronous Production

COB-ID: 16# 80

Synchronization Cycle(ms): 200

Window Length(ms): 0

Heartbeat

Enable Heartbeat Production

Production Time(ms): 300

SDO Timeout

Timeout: 500 ms

Node Status Monitor

Enable Site Monitor

Monitor Register Start Address(D):

Automatic Allocation PDO Map Register

Automatic Allocation


Slaves receives the map registers start address (D): 7000

Slaves send the map register start address(D): 7400

Reset PDO Map register

OK Cancel

7. Double-click the **SV680P_INT** in the **CANopen device list** to add CANopen slaves. Then, double-click the **SV680P_INT** icon in the configuration to open the slave configuration parameter list.
8. The **axis parameters setting** interface is shown as follows, which include **axis parameter setting** and **homing parameter setting**.




- **Setting axis parameters**

For devices without reducers, set the gear ratio to 1:1. Set the pulses per motor revolution and distance per motor revolution correctly. The calculation formula is as follows.

$$\text{Number of pulses} = \frac{\text{Number of pulses per revolution (1)}}{\text{Distance per revolution (3)}} \times \text{Moving distance (displayed unit)}$$

Applications with reducers are shown as follows.



The calculation formula is as follows.

$$\text{Number of pulses} = \frac{\text{Pulses per revolution (1)} \times \text{Motor gear ratio (5)}}{\text{Distance per revolution (3)} \times \text{Working gear ratio (4)}} \times \text{Moving distance (displayed unit)}$$

- **Homing**

The range of homing modes is 1-35. For details of each mode, see *SV680P-INT Series Servo Drive Function Guide*.

SV680P_INT_V1.0

| Service Data Objects | Debug | I/O Mapping | Module information |
|-------------------------|------------------------------|-------------|--------------------|
| Slave Node | Set The Axis Parameters | Receive PDO | Send PDO |
| Axis Parameter Settings | Axis Zero Parameter Settings | | |

Set the homing

Homing method: Zero-back mode 26 Homing mode: Absolute Return to Zero

Homing velocity: 10 Millimeter/s Homing acceleration: 100 Millimeter/s²


Homing dosing velocity: 2 Millimeter/s Homing timeout: 50000 10ms

The timing diagram shows the relationship between four signals during a homing process:

- Homing switch Signal:** A pulse that occurs when the homing switch is triggered.
- Positive limit switch:** A signal that transitions from low to high when the limit is reached.
- Deceleration point signal is invalid, Positive limit switch is not met:** This signal is active (high) before the limit switch is triggered.
- Deceleration point signal is invalid, Encountered a positive limit switch:** This signal is active (high) after the limit switch is triggered but before deceleration begins.
- Deceleration point signal is valid:** This signal becomes active (high) once deceleration has started.

OK Cancel

9. Click **Receive PDO** or **Transmit PDO**. The following interface is displayed.



Receive PDO Parameter: Indicates the data sent by the master station to a slave station.

Send PDO Parameter: Indicates the data sent by a slave station to the master station.

You can check the box in front of the number to enable a PDO. The PDOs in the EDS file that take effect by default are already checked. You can click **Add PDO mapping**, **Edit**, or **Delete** to edit PDO mapping.

10. Download the CANopen configuration to EASY. The EASY starts slave configuration based on the previous configurations. Configuration is performed based on the service object list. To view this list, check **Enable Expert setting** in the **Slave Node** interface first.

SV680P_INT_V1.0

×

| | | | |
|----------------------|-------------------------|-------------|--------------------|
| Service Data Objects | Debug | I/O Mapping | Module information |
| Slave Node | Set The Axis Parameters | Receive PDO | Send PDO |

Convention

Node ID:

Enable Expert setting

Ignore error and continue configuring SDO Create All SDO

Not Initialized Factory Setting

During commissioning, you can monitor the device status online and read/write the object dictionary of the slave through EASY, as shown below.

SV680P_INT_V1.0

×

| | | | |
|----------------------|-------------------------|-------------|--------------------|
| Slave Node | Set The Axis Parameters | Receive PDO | Send PDO |
| Service Data Objects | Debug | I/O Mapping | Module information |

NMT Command

Start Node Stop Node Pre-run **1** Start Monitor

Reset Node Reset Communication

Service Data Object (SDO)

Index 16#: **2** Subindex 16#:

Value: Hex Bit Length:

Result:

3 Read SDO Write SDO

Diagnosis

Online status: SDO error steps:

Error code:

Diagnostic string:

Emergency Error

| Creation Time | Error Code ... | Error Register (16#) | Manufacturer Error ... |
|---------------|----------------|----------------------|------------------------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

OK Cancel

5.3 EtherCAT Communication Configuration Case [N]

5.3.1 SV680N-INT and AM600 Controller

This section describes how to configure the SV680N-INT series servo drive for cooperation with the AM600 series controller.






Figure 5-2 Configuration flowchart


Open the software and create an AM600 project.

Select **AM600-CPU1608TP**, as shown in the following interface.




Adding the SV680N-INT servo drive as slave


Open the network configuration and import the ECT file of SV680N-INT. Add an SV680N-INT as a slave, as shown in the following interface.



Configuring PDO


Select **Enable Expert Settings** and configure PDOs in the process data as needed. In this case, CSP is used as the operation mode and the default values of 1600 and 1A00 are used for PDO parameters.






Configuring axis parameters


1. Set the software position limit and the operation mode in basic axis settings.



2. Select 16#4000000 for the 26-bit encoder, 16#800000 for the 23-bit encoder and 16#100000 for the 20-bit encoder during unit conversion. In this case, the single-turn travel distance is set to 60 mm and 1 mm/s equals to 1 RPM of the motor.




3. Select the homing mode according to actual needs. For details, see section "Homing Mode" in SV680-INT Series Servo Drive Function Guide for details.




Adding a program

Add a program to control the servo axis position, as shown by the following interface. See the following figure.



- Implement basic functions such as enabling, homing and positioning through adding function blocks.



- To implement directed motion through the logic program, some variables may need to be called to different POU. Therefore, set the variables as global variables.


CASE iStatus OF

```

10:|
gb_powerOn:=TRUE;
IF gb_powerok THEN
iStatus:=20;
END_IF
20:
gd_MoveAbsPos:=1000;gd_MoveAbsVel:=200;gd_MoveAbsVelacc:=200;gd_MoveAbsVeldec:=200;gb_moveAbs:=TRUE;
IF gb_moveAbsOK THEN
gb_moveAbs:=FALSE;iStatus:=30;
END_IF
30:
gd_MoveAbsPos:=2000;gd_MoveAbsVel:=400;gd_MoveAbsVelacc:=400;gd_MoveAbsVeldec:=400;gb_moveAbs:=TRUE;
IF gb_moveAbsOK THEN
gb_moveAbs:=FALSE;iStatus:=40;
END_IF
40:
gd_MoveAbsPos:=0;gd_MoveAbsVel:=1000;gd_MoveAbsVelacc:=1000;gd_MoveAbsVeldec:=1000;gb_moveAbs:=TRUE;
IF gb_moveAbsOK THEN
gb_moveAbs:=FALSE;iStatus:=50;
END_IF
50:
gb_powerOn:=FALSE;
iStatus:=0;

```


END_CASE



The screenshot shows the 'Auto Declare' dialog box. The 'Scope' is set to 'VAR_STAT', the 'Name' is 'gd_setTorqueV', and the 'Type' is 'LREAL'. The 'Object' is set to 'GVL [Application]'. There are fields for 'Initialization' and 'Address'. The 'Flags' section includes 'CONSTANT', 'RETAIN', and 'PERSISTENT' checkboxes. 'OK' and 'Cancel' buttons are at the bottom.


Compiling

After compiling the program, click the icon indicated by the red square box to check whether the program is correct.




Downloading and commissioning

1. After checking that the program is correct, download the program to PLC. The program can be activated after running. Before downloading, scan the PLCs first to select the PLC to be downloaded, and then click the download icon, as shown in the following interface.



2. After log-in, ensure the servo drive and the axis are in normal state.



3. Monitor critical parameters through the monitoring function. Start the testing program to perform basic tests such as enabling, homing and positioning.

The screenshot shows a ladder logic program with four main blocks: MC_Power_1, MC_Home_0, MC_Halt_0, and MC_Stop_0. The MC_Power_1 block has inputs gb_test, gb_powerOn, and gb_powerOn, and outputs Status (gb_powerok), bRegulatorRealState (TRUE), bDriveStartRealState (TRUE), Busy (TRUE), Error (FALSE), and ErrorID (SMC_NO_E). The MC_Home_0 block has inputs Axis and Execute (gb_home), and outputs Done (FALSE), Busy (FALSE), CommandAborted (FALSE), Error (FALSE), and ErrorID (SMC_NO_E). The MC_Halt_0 block has inputs Axis and Execute (qb_halt), and outputs Done (FALSE) and Busy (FALSE). The MC_Stop_0 block has inputs Axis and Execute (qb_stop), and outputs Done (FALSE) and Busy (FALSE). A Watch 1 table is visible at the bottom of the screenshot.

| Expression | Application | Type | Value | Prepared value | Execution point |
|-------------------|--------------------|----------------|--------------------|----------------|-------------------|
| Axis.FactPosition | Device.Application | REAL | 881.408793926239 | | Cyclic Monitoring |
| Axis.nAxisState | Device.Application | SMC_AXIS_STATE | continuous_motion | | Cyclic Monitoring |
| Axis.FactVelocity | Device.Application | REAL | 99.334723949432373 | | Cyclic Monitoring |

4. After the testing is done, perform directed running program.

The screenshot shows a PLC program with a CASE statement. The CASE statement is labeled 'CASE iStatus' with a value of 20 and an output of 'OF'. The program includes several conditional statements and assignments for motion control parameters. The CASE statement is followed by a series of assignments and conditional checks for motion parameters like gd_MoveAbsPos, gd_MoveAbsVel, and gb_moveAbs. The program ends with a RETURN statement.

```

1 CASE iStatus 20 OF
2   10:
3   gb_powerOk TRUE :=TRUE;
4   IF gb_powerOk TRUE THEN
5     iStatus 20 :=20;
6   END_IF
7   20:
8   gd_MoveAbsPos 1E+03 :=1000;gd_MoveAbsVel 200 :=200;gd_MoveAbsVelacc 200 :=200;gd_MoveAbsVeldec 200 :=200;
9   IF gb_moveAbsOk FALSE THEN
10    gb_moveAbs TRUE :=FALSE;iStatus 20 :=30;
11  END_IF
12  30:
13  gd_MoveAbsPos 1E+03 :=2000;gd_MoveAbsVel 200 :=400;gd_MoveAbsVelacc 200 :=400;gd_MoveAbsVeldec 200 :=400;
14  IF gb_moveAbsOk FALSE THEN
15    gb_moveAbs TRUE :=FALSE;iStatus 20 :=40;
16  END_IF
17  40:
18  gd_MoveAbsPos 1E+03 :=0;gd_MoveAbsVel 200 :=1000;gd_MoveAbsVelacc 200 :=1000;gd_MoveAbsVeldec 200 :=1000;
19  IF gb_moveAbsOk FALSE THEN
20    gb_moveAbs TRUE :=FALSE;iStatus 20 :=50;
21  END_IF
22  50:
23  gb_powerOk TRUE :=FALSE;
24  iStatus 20 :=0;
25  END_CASERETURN
    
```

5.3.2 SV680N-INT and Omron Controller

This section describes how to configure the SV680N-INT series servo drive for working with an Omron NX701 controller.




Figure 5-3 Configuration flowchart

Note

When more than 25 drives are networked with Omron NX701, you need to modify the cable length defined in the Omron master station. The cable length is calculated based on the fact that one drive needs a length of 36 m.

Installing the Sysmac Studio software

Install the Sysmac Studio software.

It is recommended to install V1.10 or above.

Importing the xml device description file


Importing the device description file (V2.5 or later recommended).

It is recommended to import the device description file of "SV680_INT_EOE_1Axis_02002_240110.xml" or later version. The file path is as follows: OMRON\Sysmac Studio\IODeviceProfiles\EsiFiles\UserEsiFiles.

If the xml file is saved under this path for the first time, the Sysmac Studio software must be restarted.

Setting the network connection attribute

- If the PC is connected to the controller through an USB, skip this step.
- If the PC is connected to the controller through Ethernet, set the TCP/IP attribute of the PC, as shown below.



Configuring the servo drive

Recommended version:


Use MCU software version (H01.00) of 0900.1 or later for SV680N-INT series servo drives.

Use FPGA software version (H01.01) of 0902.1 or later for SV680N-INT series servo drives.

Pay attention to the setting of H0E.21.

| Parameter | Name | Value range | Unit | Initial Value | Mode | Setting Condition | Effective Time | Value |
|-----------|----------------------|-------------|------|---------------|------|-------------------|----------------|----------|
| H0E.21 | EtherCAT slave alias | 0-65535 | - | 0 | - | Stop setting | At once | Non-zero |


When an Omron controller is used, set the EtherCAT communication station number in H0E.21. It is recommended to set the station number according to the actual connection sequence for the convenience of configuration management.



Create a project.

Device: Set a device according to the actual controller model.


Version: Use V1.09 or later versions. For NX1P2-1140DT, only V1.13 is supported.



Communication setting

After entering the main interface, set the connection mode between the PC and the controller in Controller → Connection type.


- Select Remote connection via USB to perform USB Communication Test directly. If the test is succeeded, proceed to the next step.
- Select Ethernet connection via a hub, in this case, set the IP address to 192.168.250.1 (controlled by NX), and then perform Ethernet Communication Test. If the test is succeeded, proceed to the next step.



Scanning the device




Switch the controller to the online and running mode.

1. Check that the controller status in the lower right corner is online and running.



2. A prompt window appears if it is a new controller.
3. Click Yes in the window. The name shown in the window is the project name. Scan the device and add the slave station.

Right click Configurations and Setup→EtherCAT→Master, and select Compare and Merge with Actual Network Configuration. The controller scans all the slaves in the network (an error will be reported if the station number is 0). After scanning, click Apply actual network configuration in the pop-up window to add the slave. You can view the added slave station in the main page.




Parameter settings


Switch the controller to the offline mode and set PDO mapping, axis parameters, and distributed clock.

Setting PDO mapping

1. Setting the PDO mapping.



2. Select the editable RPDO and TPDO provided by the drive for configuration.




3. Modify the PDO mapping object through Add PDO Entry and Delete PDO Entry. The frequently used mapping parameters are shown in the following interface.


| Index | Size | Data type | PDO entry name |
|-----------|----------|-----------|------------------------------|
| 0x603F:00 | 16 [bit] | UINT | Error code |
| 0x6041:00 | 16 [bit] | UINT | Statusword |
| 0x6064:00 | 32 [bit] | DINT | Position actual value |
| 0x6077:00 | 16 [bit] | INT | Torque actual value |
| 0x60F4:00 | 32 [bit] | DINT | Following error actual value |
| 0x60B9:00 | 16 [bit] | UINT | Touch Probe Status |
| 0x60BA:00 | 32 [bit] | DINT | Touch Probe pos 1 pos value |
| 0x60BC:00 | 32 [bit] | DINT | Touch Probe pos 2 pos value |
| 0x60FD:00 | 32 [bit] | UDINT | Digital inputs |

Setting axis parameters

1. Right click Motion Control Setup→Axis settings →Add→Motion Control Axis, as shown in the following interface.



2. MC_Axis000 can be renamed through a simple click. For example, if it is named as "Rewind axis", the axis variable "Rewind axis" used in the NX program represents control on this SV680N-INT servo axis.
3. Double-click **MC_Axis000** and configure an SV680N-INT device at the corresponding station in a corresponding **Axis Basic Settings** interface.
 - a. Axis assignment



- Axis number: Represents the Ethernet communication station No. of the servo drive, which is also the value of H0E.21.
- Axis use: Represents the axis in use.
- Axis type: Represents the servo axis.
- Output device 1: Select the servo drive.

b. Detailed settings

- Select the PDO mapping objects according to step 8, which is to assign the output parameters (controller to device) and input parameters (device to controller). Note that the object name, node number, and index number must be set correctly. Each mapping object selected in step 8 must be assigned correctly. Otherwise, an error will be reported.

| Function Name | Device | Process Data |
|--|--------------------------|------------------------|
| - Output (Controller to Device) | | |
| ★ 1. Controlword | Node : 1 InoSV680I(E001) | 6040h-00.0(259th rece) |
| ★ 3. Target position | Node : 1 InoSV680I(E001) | 607Ah-00.0(259th rece) |
| 5. Target velocity | <Not assigned> | <Not assigned> |
| 7. Target torque | <Not assigned> | <Not assigned> |
| 9. Max profile Velocity | <Not assigned> | <Not assigned> |
| 11. Modes of operation | Node : 1 InoSV680I(E001) | 6060h-00.0(259th rece) |
| 15. Positive torque limit value | <Not assigned> | <Not assigned> |
| 16. Negative torque limit value | <Not assigned> | <Not assigned> |
| 21. Touch probe function | Node : 1 InoSV680I(E001) | 6088h-00.0(259th rece) |
| 44. Software Switch of Encoder's Input | <Not assigned> | <Not assigned> |
| + Input (Device to Controller) | | |
| + Digital inputs | | |

⚠ The combinations of MC Function Module functions and process data are changed. When changing the combinations, please confirm that they behave as intended. Invalid combinations may cause unexpected operations of the equipment and machines.

| | | |
|-------------------------------------|------------------------|------------------------|
| ★ 22. Statusword | Node:1 InoSV680I(E001) | 6041h-00.0(Inputs_Sta |
| ★ 23. Position actual value | Node:1 InoSV680I(E001) | 6064h-00.00(Inputs_Pos |
| 24. Velocity actual value | <Not assigned> | <Not assigned> |
| 25. Torque actual value | <Not assigned> | <Not assigned> |
| 27. Modes of operation display | <Not assigned> | <Not assigned> |
| 40. Touch probe status | Node:1 InoSV680I(E001) | 60B9h-00.0(Inputs_Tot |
| 41. Touch probe pos1 pos value | Node:1 InoSV680I(E001) | 60BAh-00.0(Inputs_Tot |
| 42. Touch probe pos2 pos value | <Not assigned> | <Not assigned> |
| 43. Error code | Node:1 InoSV680I(E001) | 603Fh-00.0(Inputs_Err |
| 45. Status of Encoder's Input Slave | <Not assigned> | <Not assigned> |
| 46. Reference Position for csp | <Not assigned> | <Not assigned> |

- 60FDh must be mapped to the same as that in the Omron controller, as shown in the following interface. bit0...bit2 of SV680-INT indicate the negative position limit, positive position limit, and the home respectively. bit16...bit20 indicate the status of DI1...DI5.


| | | |
|-------------------------------|--------------------------|---|
| 28. Positive limit switch | Node : 1 InoSV680I(E001) | 60FDh-00.1(Inputs_Digital inputs_60FD_00) |
| 29. Negative limit switch | Node : 1 InoSV680I(E001) | 60FDh-00.0(Inputs_Digital inputs_60FD_00) |
| 30. Immediate Stop Input | <Not assigned> | <未分配> |
| 32. Encoder Phase Z Detection | <Not assigned> | <未分配> |
| 33. Home switch | <Not assigned> | 60FDh-00.2(Inputs_Digital inputs_60FD_00) |
| 37. External Latch Input 1 | Node : 1 InoSV680I(E001) | <未分配> |
| 38. External Latch Input 2 | <Not assigned> | <未分配> |

Note

The Omron software tool only allows you to configure axes for the SV680N-INT series manually.

Setting unit conversion

Set Command pulse count per motor rotation based on the resolution of the motor encoder (example: 67108864 PPR for motor equipped with 26-bit encoder). For the convenience of commissioning, set the **Work travel distance per motor rotation** to 60 mm/rev, indicating 1 mm/s equals to 1 RPM of the motor.



Select the Display Unit based on the actual running unit when setting the gear ratio. All the position-type parameters in the host controller will be displayed in this unit.

Operation settings

Operation Settings

▼ Velocity/Acceleration/Deceleration

| | | | |
|----------------------|---------------------|----------------------------|-----|
| Maximum velocity | 600 mm/s | Velocity warning value | 0 % |
| Start velocity | 0 mm/s | | |
| Maximum jog velocity | 600 mm/s | | |
| Maximum acceleration | 0 mm/s ² | Acceleration warning value | 0 % |
| Maximum deceleration | 0 mm/s ² | Deceleration warning value | 0 % |

Acceleration/deceleration over Operation selection at Reversing: Use rapid acceleration/deceleration (Blending is changed to Buffered) ▼
Deceleration stop ▼

▼ Torque


| | | | |
|-------------------------------|-----|-------------------------------|-----|
| Positive torque warning value | 0 % | Negative torque warning value | 0 % |
|-------------------------------|-----|-------------------------------|-----|

▼ Monitor

| | | | |
|--------------------------------------|-------|------------------------|-------|
| In-position range | 10 mm | In-position check time | 0 ms |
| Actual velocity filter time constant | 0 ms | Zero position range | 10 mm |


- Velocity/Acceleration/Deceleration: Set the maximum speed of the load (if the motor speed converted exceeds 1900 RPM, a parameter setting error) which is marked by a red box, will be reported by the host controller software) according to actual conditions. If the acceleration/deceleration rate is 0, the motion profile will be generated based on the maximum acceleration/deceleration rate (there is no need to set the acceleration/deceleration rate in general cases).
- Torque: If the warning value is 0, no warning will be reported. There is no need to set the warning value in general cases.
- Monitor: Set Positioning Range and Zero Position Range based on actual motor and mechanical conditions. If the set value is too small, positioning or homing may not be completed.

Position limit



You can use the function of software position limit. The software position limit will be activated after homing.

Homing



The homing mode involves cooperation between the servo drive and host controller. Set the homing mode according to the following table.

| Description of NX Software | Servo Drive Function | Terminal Configuration |
|----------------------------|------------------------|------------------------|
| Home proximity signal | Home switch (FunIN.31) | - |
| Positive limit input | P-OT (FunIN.14) | DI1 |
| Negative limit input | N-OT (FunIN.15) | DI2 |

Select the homing mode of the host controller and set the homing speed, acceleration, and home offset based on actual mechanical conditions.

- Introduction to homing

Function block: MC_Home and MC_HomeWithParameter

1. Set MC_Home in the preceding figure and MC_HomeWithParameter in the function block.
2. The two function blocks both include 10 types of homing modes.

| MC_Home | MC_HomeWithParameter |
|---|--|
| <p>Proximity reverse turn/home proximity input OFF Proximity reverse turn/home proximity input ON Home proximity input OFF Home proximity input ON Limit input OFF Proximity reverse turn/home input mask distance Limit inputs only Proximity reverse turn/holding time No home proximity input/holding home input Zero position preset</p> | <p>Designate the homing action to be modified. 0: Proximity reverse turn/home proximity input OFF 1: Proximity reverse turn/home proximity input ON 4: Home proximity input OFF 5: Home proximity input ON 8: Limit input OFF 9: Proximity reverse turn/home input mask distance 11: Limit inputs only 12: Proximity reverse turn/holding time 13: No home proximity input/holding home input 14: Zero position preset</p> |


- Home proximity input OFF: The search for the home signal starts after the falling edge of the home proximity switch is reached.
- Home proximity input ON: The search for the home signal starts after the rising edge of the home proximity switch is reached.
- Proximity reverse turn: The home proximity signal is ON when homing starts, and reverse running applies after the falling edge of the home proximity signal is reached.
- Home input mask distance: The home signal is masked by the host controller within the set distance after receiving the homing signal (for example, edge change of home proximity signal), and the home signal is received only after the set distance passes.
- Holding time: The home signal is masked by the host controller within the set period of time after receiving the homing signal (for example, edge change of home proximity signal), and home signal is received only after the set period of time elapses.
- Zero position preset: The home offset is being written to the position reference/ position feedback in the host controller with current position as the home and motor at a standstill.

Note

In all the homing modes, the home signal is searched at low speed. In case of operations at high speed, the home signal is hidden during decelerating from high speed to low speed.

Distributed clock


The default clock is 1 ms. The synchronization clock (cycle of primary fixed-cycle tasks) named "PDO communication cycle" can be modified in Task Settings. The modification will be activated after switching to the online status at next power-on.



Program-controlled servo operations

1. After configurations are done, you can control the servo operations through the PLC program.

If the MC_POWER module is used, it is recommended to add the servo status bit MC_Axis000.DrvStatus. Ready (MC_Axis000 is the axis name). Where MC_Axis000 is the axis name. This is to prevent the situation where the PLC program is running but the communication configuration is not done.





2. After all the settings and programming are done, switch to the online state, and

click  to download the program to the controller.

Click  to use the synchronization function. This function serves to compare the difference between the current program and the program in the controller, allowing users to determine whether to download the program to the controller, upload it from the controller  or leave it unchanged based on the differences.

You can monitor the data through the monitoring list or collect the data waveform by using the data tracking function during operation.



5.3.3 SV680N-INT and Beckhoff Controller

This section describes how to configure the SV680N-INT servo drive for working with Beckhoff TwinCAT3.




Figure 5-4 Configuration flowchart



Installing the TwinCAT software

The TwinCAT3 software, which supports Windows7 32-bit or 64-bit systems, can be downloaded from the official website of Beckhoff.

Note

The Ethernet card must be 100 M Ethernet card equipped with Intel chip. If other brands are used, the EtherCAT operation may fail.


1. Copy the SV680N-INT EtherCAT configuration file (SV680_1Axis_V0.04-0506) to the TwinCAT installation directory: TwinCAT\3.1\Config\Io\EtherCAT.
2. Open TwinCAT3 and create a New Twincat3 Project.




Installing the network adapter driver

Install the TwinCAT network adapter driver.

1. Open Show Real Time Ethernet Compatible Devices... in the menu shown in the preceding figure to display the following dialog box. Select local connection under Incompatible devices, and click Install.




2. After installation is done, the network adapter installed will be displayed under Installed and ready to use devices(realtime capable).




Search for devices.


1. Create a project and start searching for devices. Select

 **Devices**, and click  as shown below.


See the following figure:




2. Click **OK**.




3. Click **OK**.




4. Click **OK**.




5. Click **OK**.



6. Click **Cancel**.




7. The search for the device is done, as shown below.



Configuring servo drive parameters

Configure parameters through SDO communication in CoE - Online interface. When H0E.01(200E-02h) is set to 3, the parameter values modified through SDO communication will be saved upon power failure. To modify 6060h to the CSP mode (8), follow the procedure shown in the following figure.





Note

This operation is available only when H02.00 (Control mode) is set to 9 (EtherCAT mode).

Configuring PDO


Select 0x1600 and 0x1A00 as shown in the following figure. Change the current PDO only if it does not fulfill your needs. To modify the PDO, right-click on the PDO

Content window, click Delete to delete the redundant PDO or click Insert to add the PDO needed.




Activate the configuration and switch to the operation mode.


1. Click 



2. Click OK.



3. After you click OK, the device enters OP status as shown in the Online interface. Meanwhile, the 3rd LED on the keypad displays "8", and the keypad displays _88RY.




Controlling servo drive operation

Control the servo drive through NC or PLC programs.


1. For operating in CSP mode

a. Set the unit.

Set the unit to "mm" during the test.




b. Set the scaling factor.



Scaling factor: Indicates the distance corresponding to the encoder pulses per position feedback.

For example, 67108864 PPR corresponds to a distance of 60 mm, and the scaling factor is: $60/67108864 = 0.0000089406967163$ mm/Inc.

c. Set the encoder feedback mode to PosVelo.





Descriptions for Other Settings:

Encoder mode: There are three encoder modes: POS, POSVELO, and POSVELOACC.


- POS: The encoder only calculates the position, which is used when the position loop is in the servo drive.
- POSVELO: The encoder only calculates the position, which is used when the position loop is in TwinCAT NC.
- POSVELOACC: The TwinCAT NC uses the encoder to determine the position, speed, and acceleration.

d. Jogging test

Hide the system deviation temporarily.





Click Set to display a dialog box and then click All to enable the servo drive. Perform jogging through F1 to F4. The jog speed is set as follows.




2. Controlling the servo drive operations through the PLC


a. Create a PLC program.




- b. Add a motion control library for calling the motion control function blocks.




- c. Create a POU program.





- d. Call the motion module to implement some simple actions and input the final program to PLCTask.




e. Link the axis to the variable defined in the PLC.




f. Compile the program. If there is not fault, activate the configuration and log onto the PLC.



g. Click Start to make the servo drive run.





- Controlling the servo drive operations through the HMI
Add the HMI interface to control the servo drive through the HMI interface.




Use the scope view function.

- Add a scope view project as shown in the following figure.



2. Add parameters to be monitored and monitor these parameters during operation of the PLC.



5.3.4 SV680N-INT and KEYENCE KV7500 Controller

5.3.4.1 Configuring the Servo Drive

- Servo drive version
It is recommended to use the device description file "SV680N-INT-Ecat_v0.09.xml" or above for trial run of SV680N-INT series servo drives. It is recommended to use the MCU software of version 901.4 (H01.00 = 901.4) or later for the drive.
- Related Parameters
The definition of 60FDh of the SV680N-INT series differs from that of IS620N: bit0: negative limit; bit1: positive limit; bit2: home switch; bit16...bit20 correspond to DI1...DI5 respectively.

5.3.4.2 Configuring KEYENCE KV7500 Software Tool

As software tool versions earlier than KV STUDIO 9.45 do not support extension of KEYENCE EtherCAT module "KV-XH16EC", the version of the KEYENCE software tool used must be KV STUDIO 9.45 or later.





Figure 5-5 Configuration flowchart


Unit configuration setting

Create a project and click OK to display the following window.




Click Yes, No, or Read unit setting as needed.

- Click Read unit setting when the physical PLC unit is connected properly and able to communicate with the software tool. The software tool obtains unit configurations automatically according to the physical connection.
- If you click Yes, the Unit editor window opens, allowing you to select units for configuration through dragging or double-clicking.




- If you click No, you can click Tool > Unit editor or double-click [0] KV7500 under Unit configuration.



Axis configuration setting

1. Enter "Axis configuration setting".
2. Double-click "Register ESI file".




3. Find the storage directory of the device description file ".xml" and open it.
4. Importing the ". XML" file.


| | | | |
|--------------------------------------|------------------|--------|--------|
| 03023980-SV820N-3Axis-V3.03.xml | 2019/8/30 20:34 | XML 文档 | 427 KB |
| 03024278-IS620N-Ecat_v2.6.8.xml | 2019/9/16 9:18 | XML 文档 | 441 KB |
| SV680_INT_EOE_1Axis_02002_240110.xml | 2019/12/30 15:04 | XML 文档 | 317 KB |
| SV820N_ECAT.xml | 2018/3/21 8:47 | XML 文档 | 881 KB |

5. After the device description file is imported, you can start to add axes. You can also set the control period in "Axis configuration setting". The default control cycle is 1 ms and the minimum control cycle is 250 us.


- You can add the axes needed through dragging or double-clicking. Select the corresponding axis and set critical information such the Encoder resolution, Max. motor speed, and Max. motor torque for this axis.



- You can add PDO setting in detailed setting of the slave.




- If extension setting is needed, set Extension setting to Enable.




- For motion function settings, you can double-click or click on the combo box (small triangle icon) to select the PDO configuration needed from the dropdown list. You can also right-click > Automatic assignment > Yes, in this way the assigned contents will correspond to preceding PDO contents automatically.


During manual assignment, do not neglect any contents in the PDO mapping. Otherwise, a pop-up window will be displayed to remind you of the missing contents when you click OK. For Communication command at initialization, DC setting, and Advanced settings, use the default values. After settings are done, click OK.




- After Slave detailed setting is done, the exclamation symbol disappears.




11. After adding the axes, click OK, and the following dialog box opens, asking you whether to set up coordinate (namely electronic gear ratio) transformation.



- Click Yes and the coordinate transformation dialog box opens. Set mechanical parameters and the coordinate unit based on actual conditions and click Execute calculation. The software calculates the denominator and numerator for coordinate transformation automatically and writes parameters to Axis control setting automatically.




- If you click No, you can click Tool > Coordinate transformation calculation > KV-XH setting > Coordinate transformation calculation.



Axis control setting

1. To open axis control setting, click Tool > Axis configuration setting > KV-XH setting > Axis control setting, or click Axis control setting under Project.
2. In axis control setting, you can set items including Unit coordinate transformation, Software limit coord, Axis error, Axis control function, Common in position control, Operation speed, and JOG.




Running setting

Homing

Before homing, assign (+) limit switch, (-) limit switch, and Origin sensor in Motion function setting under Axis configuration setting to each bit of 60FDh. 60FDh is defined as follows:

bit0: negative limit; bit1: positive limit; bit2: home switch; bit16...bit20 correspond to DI1...DI5 respectively.

In automatic assignment, you need to assign (+) limit switch, (-) limit switch, and origin sensor manually, you can assign them to corresponding bits of 60FDh based on the relation shown in the following figure or to bit16...bit20, in this case, you also need to assign them to corresponding DI's of the servo drive.



Set the restriction parameters for homing in Axis control setting > Origin return. The following homing methods are available. For detailed trajectories, see KEYENCE instruction manual for positioning/motion control unit KV-XH16EC.

| Default | Value range | Description |
|-------------------------------|--|--|
| DOG type (with phase Z) | DOG type (with phase Z) | Decelerating upon DOG signal input and homing through phase Z signal |
| | DOG type (without phase Z) | Decelerating upon DOG signal input and homing through falling edge of DOG signal |
| | DOG-type jogging (with phase Z) | Pausing after moving based on Dog ON upon DOG signal input. Then moving to the homing direction through position-type speed control and homing with phase Z signal. |
| | DOG-type jogging (without phase Z) | Moving based on Dog ON upon DOG signal input before homing |
| | DOG type (contact) | Homing executed when the ON duration of the torque limit signal keeps longer than the compression torque time upon DOG signal input |
| | Origin sensor and phase Z | Homing executed in the initial phase Z position after the origin sensor is ON |
| | Rising edge of origin sensor | Homing executed through the rising edge of the origin sensor |
| | Middle point of origin sensor (without phase Z) | Taking the middle point of the ON range of origin sensor as the origin and comparing it with that in "Rising edge of origin sensor". Even if the light-receptive performance of the origin sensor degrades, the homing position can hardly change with the time. |
| | Rising edge of limit switch | Homing executed with the limit switch in the negative direction (direction where the current coordinate decreases) acting as the origin sensor |
| | Immediate homing of phase Z | Homing executed with phase Z signal |
| Data setting type | Taking current coordinate as the origin coordinate | |

The following homing methods are available in IS620N and SV680N-INT series servo drives.


| No. | Homing mode | IS620N | SV680N-INT |
|-----|------------------------------------|--------|------------|
| 1 | DOG-type (with phase Z) | OK | OK |
| 2 | DOG-type (without phase Z) | OK | OK |
| 3 | DOG-type jogging (with phase Z) | No | No |
| 4 | DOG-type jogging (without phase Z) | No | No |

| | | | |
|----|-------------------------------|--|---|
| 5 | DOG-type (contact) | OK | Homing is available, but the reference coordinate after homing is not 0. Updating to the xml coordinate of IS620N zeros out the reference coordinate. |
| 6 | Origin sensor and phase Z | OK | OK |
| 7 | Rising edge of origin sensor | OK | OK |
| 8 | Middle point of origin sensor | No | No |
| 9 | Rising edge of limit switch | Homing is available, but the reference coordinate after homing is not 0. | Homing is available, but the reference coordinate after homing is not 0. |
| 10 | Immediate homing of phase Z | OK | OK |

Positioning


Set the unit coordinate transformation properly before positioning. The unit coordinate transformation is "PLS" by default, which allows no modification on the numerator or denominator. Assume N revolutions are required by the servo drive, in this case, the number of commands that need to be sent by the host controller is N x Pulses per revolution. If coordinate transformation calculation has been executed, the unit coordinate transformation parameters will correspond to the unit transformation results automatically.

1. To set the motion profile of the servo drive, click Tool > Point parameter.




Set the target coordinate and speed per positioning segment as needed. After settings are done, you can call the corresponding point number through the program to start operation.

2. You can preview the parameter trajectory through the following short-cut.




3. You can write ladder diagrams through regular methods. You can also use the following short-cut method provided by KEYENCE.

a. Drag down the Point parameter window with the left mouse button, and zoom out the window to put it in a proper place.




b. Move the mouse to the point parameter, such as "No.1-Axis1", and wait until the mouse icon to change from an arrow to a small hand. Then drag towards the

program edit interface with the right mouse button, and the following short-cut pops out.



c. Select the desired function.

If the operation is enabled, click it to automatically generate a DEMO program. Then designate the part in red as the relay needed. After these actions are done, this function is done compiling.




4. Unit monitor


The unit monitor supports monitoring on the operating state of KV-XH16EC or the internal data.

a. Open “Unit monitor”. There are three ways:

- Select the unit to be monitored and right-click to select Unit monitor in the short-cut menu.




- Double-click with left mouse button to open the Unit monitor.
- Right-click the blank section in the main program to select Unit monitor in the pop-up menu.




b. The unit monitor displays the operating state of each axis.

- 1). To change the operating state of the monitor item, click Monitor item setting on the top right corner.



- 2). To check whether I/O signals such as limit switch signals and origin sensor signals are normal, open Unit monitor and find the corresponding monitoring position.

If corresponding message is received, a small black circle will be displayed.



The error state of the unit can also be displayed in the Unit monitor. The axis error can be cleared using the Error clear button in the bottom right.

5.3.4.3 Trial Run


In trial run, actions can be acknowledged directly, without the need for programming ladder diagrams.

1. You can find the Trial run button at the bottom right of the unit monitor interface.
2. Select the control mode from positioning control, speed control, and torque control.
3. Then, select the object axis for trial run.

Note

If trial run is executed in the speed control mode or torque control mode, a warning will be reported. To execute trial run, set the control mode to position control.

The following introduces trial run → positioning control.



1. OP enable/Servo ON.
 - Unrelated to the status of the ladder diagram program. OP enable and Servo ON can be executed through Commissioning. After operations are done, the Operation ready and Servo ready indicators turn green. To ensure safety, set the CPU unit to PROG mode and execute operations again after stopping ladder diagram program.
 - Confirm the following items when the Servo ready indicator is not in green.
 - No error occurs on the axis.
 - No warning occurs on the servo drive.
 - The main circuit power supply of the servo drive is switched on.
 - The Ethernet cable is connected.

2. Axis error/Error clear

Check the error details and clear the error. After rectifying the error cause, click the Clear button to clear the error.

3. JOG.

Click the "FWD" and "REV" buttons to perform JOG operation in forward/reverse directions respectively. The jogging speed is the value in General Axis Control Settings→JOG High Speed multiplied by a ratio. You can set the ratio at a 1% increment between 10% and 100%.

4. Inching.

Click the "FWD" and "REV" buttons to perform inching in forward/reverse directions respectively. The inching runs at the speed specified in General Axis Control Settings→JOG Start Speed. The inching runs with the movement specified in General Axis Control Settings→JOG Inch Movement.

5. Origin return

Click the Origin return button to execute homing.

6. Teaching


Click the Acquire button to save current command coordinate value to the buffer memory of the target coordinate of the designated point number. The teaching function is available only in the online edit mode. The teaching value will also be reflected to the buffer memory and the point parameter.

7. Trial run

Designate a point number and click the Start button to execute point positioning. To stop operation, click the **Stop** button. Clicking the 1 point operation button makes the servo drive execute positioning of one point. Clicking the Cont. operation button makes the servo drive execute positioning of ten points at most. Clicking the Repeat button makes the servo drive return to the point in the first row and execute positioning repeatedly after positioning of the point in the last row is done. The time interval between points can be set to a value within 0.1s to 20.0s.


8. Changing current coordinate

Click Command coordinate and the Changing current coordinate dialog box opens. Enter the coordinate needing to be changed and click the Change button to change the current coordinate of the axis in trial run, and then close the Changing current coordinate dialog box. If you click the Close button after changing current coordinate, the Changing current coordinate dialog box will be closed with current coordinate unchanged.




5.3.5 SV680N-INT and EASY Controller

This section describes how to configure the SV680N-INT series servo drive for cooperation with the EASY series controller.




1. Open the software, and create an EASY project.

- a. Open Autoshop and click "New Project". In the popup dialog box, first select the editor type, and then select Easy500 as the PLC type.
- b. Enter the project name and select the save path, and then click "OK" to create a new project and enter the project main interface.





2. Importing device XML

a. Open the toolbox and find the EtherCAT Devices list.




b. Right-click on EtherCAT Devices, and in the pop-up dialog box, select the desired XML file and import it.





c. You need to restart the application to let the imported xml take effect.



After clicking "OK", you need to restart the application manually to let the newly added device take effect.


d. After reopening the application, you can see the newly added device.



3. Adding a slave station

First, connect the PLC through Ethernet.

- a. Select the target host.



- b. Set whether to automatically associate motion control axes as needed.
 If you select "Auto create axis and associate slave station when creating new slave station" in EtherCAT Settings, a motion control axis will be automatically added for each drive-type EtherCAT slave station.

System Options ×

Project Properties

Default Editor: ▾

Default PLC Series: ▾

Default PLC model: ▾

Default Open: ▾

Ladder Chart

Variable display maximum width: (Cells)

Comment display Cascaded m

Compile

Allow multiple networks in a network block

Format ladder display when compiling: ▾

Automatically generate CANlink Axis Communication Config

CANlink Axis Control Instruction Enhancement

Double coil check Check SET directives

Debug

Check Variable Consistency

Procedure check before monitoring

Download procedure after start simulation

Ladder chart monitoring data display format: ▾


Language

▾ NOTE: Effective after restart


Ethercat settings

Automatically create axes and associate slaves when creating new slaves

c. Right click the EtherCAT tab and select Auto Scan.



- d. Select Start Scan in the pop-up dialog box. After the scan completes, you can see all scanned slave devices. Click Update Configuration to update the scanned devices to the configuration list.




- e. The configuration list is as follows. The SV6801 in the configuration will be automatically associated with the motion control axis.

the process data sent by the EtherCAT slave station to the master station. Each slave station may have multiple groups of PDOs or a single group of PDOs, as shown in the above figure. Some PDOs can be added and deleted.


PDO control according to control requirements in process data.

5. Configuring axis parameters


a. In Genera Setting, you can set the axis type and select the physical driving device.. The interface is as shown below.




b. In Scaling, select 16#400000 for the 26-bit encoder and 16#800000 for the 23-bit encoder.



c. In General Setting, you can set the software position limit and the operation mode. The interface is as follows. Note that the parameter lists displayed vary with different axis types you select.




- d. Select the homing mode according to actual needs. For details, see section "Homing Mode" in SV680-INT Series Servo Drive Function Guide for details.




6. Controlling servo drive operation

After configurations are done, you can control the servo drive operations through the PLC program.




7. Compiling

After compiling the program, click the icon indicated by the red square box to check whether the program is correct.



8. Downloading and commissioning

After checking that the program is correct, download the program to PLC. The program can be activated after running. Click  to switch the PLC to operation state.





PS00015535A01

Copyright © Shenzhen Inovance Technology Co., Ltd.

Shenzhen Inovance Technology Co., Ltd.

www.inovance.com

Add.: Inovance Headquarters Tower, High-tech Industrial Park,
Guanlan Street, Longhua New District,
Shenzhen 518000, P.R. China

Tel: (0755) 2979 9595

Fax: (0755) 2961 9897

Suzhou Inovance Technology Co., Ltd.

www.inovance.com

Add.: No.52, Tian'e Dang Road, Wuzhong District,
Suzhou 215104, P.R. China

Tel: (0512) 6637 6666

Fax: (0512) 6285 6720