



## SV680N Series Servo Drive Communication Guide



Industrial  
Automation



Intelligent  
Elevator



New Energy  
Vehicle



Industrial  
Robot



Rail  
Transit



Data code 19011537 A00

# Preface

## Introduction

Thank you for purchasing the SV680N series servo drive developed by Inovance.

The SV680N series servo drive is a high-end servo drive designed based on global-leading standards and high-end application needs. It is featured with high speed, high precision, high performance, and tuning-free function.

Covering a power range from 0.05 kW to 7.5 kW, the SV680N series servo drive carries EtherCAT communication interfaces to work with the host controller for a networked operation of multiple servo drives. It is equipped with the latest ITune function that allows adaptive stiffness level setting, inertia auto-tuning, and vibration suppression for easy control. The SV680N series servo drive, together with an MS1 series high-response servo motor (with ultra-low, low or medium inertia) and a 26-bit single-turn/multi-turn absolute encoder, aims to deliver a quiet and stable operation and accurate process control through the fully closed-loop function and internal process segment function.

In addition, the SV680N series servo drive provides a five-year warranty and carries the functions of safe torque off, dynamic braking, and brake output (external relay not needed) as standard. It supports extension of seven kinds of safety functions and bus functional safety FSoE for continuous safe production. The SV680N series servo drive is applicable to quick and accurate position control, speed control, and torque control of automation equipment in such industries as electronic manufacturing, lithium batteries, manipulators, packaging, and machine tools.

This guide introduces functions and parameters of the servo drive, including EtherCAT communication configuration, troubleshooting, parameter descriptions, and communication cases.

## More Documents

Name	Data Code	Description
SV680N Series Servo Drive Selection Guide	19011540	Presents technical data and dimensions of the servo drive, and specifications and models of optional parts (installation accessories, cables, and periphery electrical parts).
SV680N Series Servo Drive Hardware Guide	19011539	Presents installation and wiring of the servo drive, including preparations before installation, unpacking inspection and transport, wiring, and routine maintenance.
SV680N Series Servo Drive Commissioning Guide	19011536	Presents servo commissioning, parameter descriptions, troubleshooting, including the operating panel, commissioning software, and commissioning process and procedure.

Name	Data Code	Description
SV680N Series Servo Drive Function Guide	19011538	Presents functions and parameters of the servo drive, including function overview, basic servo functions, adjustment, and parameter descriptions.
SV680 Series Servo Drive Safety Guide	19011489	Presents the safety function and related certifications and standards, wiring, commissioning process, troubleshooting, and functions.

### Revision History

Date of Revision	Version	Revision
December 2021	A00	First release

### Document Acquisition

This guide is not delivered along with the product. To download the PDF version, visit <http://en.inovance.cn/support/download.html>.

# Table of Contents

Preface .....	1
Fundamental Safety Instructions .....	6
1 Product Information .....	13
1.1 Nameplate and Model of the Servo Drive .....	13
1.2 Technical Data of EtherCAT Communication .....	15
2 EtherCAT Communication .....	16
2.1 Wiring .....	16
2.1.1 Description of EtherCAT Communication Terminals (CN3/CN4) .....	16
2.1.2 Connecting EtherCAT Communication Signals (CN3/CN4) .....	17
2.2 Communication Configuration .....	20
2.2.1 Overview of EtherCAT Protocol .....	20
2.2.2 System Parameter Setting .....	22
2.2.3 Specifications of EtherCAT Communication .....	24
2.2.4 Structure of EtherCAT Communication .....	24
2.2.5 Communication State Machine .....	25
2.2.6 Process Data .....	26
2.2.7 Service Data Object (SDO) .....	32
2.2.8 Distributed Clock .....	32
2.2.9 State Indication .....	33
3 Troubleshooting .....	37
3.1 Fault and Warning Levels .....	37
3.2 List of Fault and Warning Codes .....	39
3.3 Solutions to Faults .....	44
3.4 Solutions to Warnings .....	109
3.5 Internal Faults .....	124
4 List of Parameters .....	125
4.1 Parameter Group H00 .....	125
4.2 Parameter Group H01 .....	125
4.3 Parameter Group H02 .....	127
4.4 Parameter Group H03 .....	131
4.5 Parameter Group H04 .....	136
4.6 Parameter Group H05 .....	137
4.7 Parameter Group H06 .....	141
4.8 Parameter Group H07 .....	143
4.9 Parameter Group H08 .....	145

4.10	Parameter Group H09	150
4.11	Parameter Group H0A	154
4.12	Parameter Group H0b	157
4.13	Parameter Group H0d	162
4.14	Parameter Group H0E	163
4.15	Parameter Group H0F	166
4.16	Parameter Group H11	168
4.17	Parameter Group H12	173
4.18	Parameter Group H17	180
4.19	Parameter Group H18	201
4.20	Parameter Group H19	203
4.21	Parameter Group H1F	242
4.22	Parameter Group H30	243
4.23	Parameter Group H31	243
4.24	Parameter Group 1000h	244
4.25	Parameter Group 6000h	247
5	Parameter Descriptions	254
5.1	H00: Servo Motor Parameters	254
5.2	H01: Servo Drive Parameters	256
5.3	H02: Basic Control Parameters	259
5.4	H03: Terminal Input Parameters	268
5.5	H04: Terminal Output Parameters	276
5.6	H05: Position Control Parameters	280
5.7	H06: Speed Control Parameters	290
5.8	H07: Torque Control Parameters	297
5.9	H08: Gain Parameters	304
5.10	H09: Gain Auto-tuning Parameters	320
5.11	H0A: Fault and Protection Parameters	333
5.12	H0b: Monitoring Parameters	346
5.13	H0d: Auxiliary Function Parameters	362
5.14	H0E: Communication Function Parameters	366
5.15	H0F: Fully Closed Loop Parameters	375
5.16	H11: Multi-position Parameters	382
5.17	H12: Multi-speed Parameters	402
5.18	H17: VDI/VDO Parameters	419

---

5.19	H18: Position Comparison Output Parameters .....	446
5.20	H19: Target Position Parameters.....	451
5.21	H1F: Software Tool Parameters.....	491
5.22	H30: Variables Read Through Communication .....	493
5.23	H31: Communication Setting.....	494
5.24	1000h Object Dictionaries.....	496
5.25	6000h Object Dictionaries.....	511
6	Application Cases .....	537
6.1	AM600 Series Controller as the Host Controller.....	537
6.2	Omron NX1P2 Controller as the Host Controller .....	545
6.3	Beckhoff TwinCAT3 as the Host Controller .....	559
6.4	KEYENCE KV7500 Controller as the Host Controller .....	577
6.4.1	Configuring the Servo Drive.....	577
6.4.2	Configuring KEYENCE KV7500 Software Tool .....	577
6.4.3	Trial Run.....	592

# Fundamental Safety Instructions

## Safety Precautions

- This chapter presents essential safety instructions for a proper use of the equipment. Before operating the equipment, read through the guide and comprehend all the safety instructions. Failure to comply with the safety instructions may result in death, severe personal injuries, or equipment damage.
- "CAUTION", "WARNING", and "DANGER" items in the guide only indicate some of the precautions that need to be followed; they just supplement the safety precautions.
- Use this equipment according to the designated environment requirements. Damage caused by improper use is not covered by warranty.
- Inovance shall take no responsibility for any personal injuries or property damage caused by improper use.

## Safety Levels and Definitions



Indicates that failure to comply with the notice will result in death or severe personal injuries.



Indicates that failure to comply with the notice may result in death or severe personal injuries.



Indicates that failure to comply with the notice may result in minor or moderate personal injuries or equipment damage.

## General Safety Instructions

- Drawings in the guide are sometimes shown without covers or protective guards. Remember to install the covers or protective guards as specified first, and then perform operations in accordance with the instructions.
- The drawings in the guide are shown for illustration only and may be different from the product you purchased.

<b>Unpacking</b>	
	<ul style="list-style-type: none"><li>• Do not install the equipment if you find damage, rust, or signs of use on the equipment or accessories upon unpacking.</li><li>• Do not install the equipment if you find water seepage or missing or damaged components upon unpacking.</li><li>• Do not install the equipment if you find the packing list does not conform to the equipment you received.</li></ul>

 CAUTION

- Check whether the packing is intact and whether there is damage, water seepage, dampness, and deformation before unpacking.
- Unpack the package by following the unpacking sequence. Do not strike the package violently.
- Check whether there is damage, rust, or injuries on the surface of the equipment and equipment accessories before unpacking.
- Check whether the package contents are consistent with the packing list before unpacking.

**Storage and Transportation** WARNING

- Large-scale or heavy equipment must be transported by qualified professionals using specialized hoisting equipment. Failure to comply may result in personal injuries or equipment damage.
- Before hoisting the equipment, ensure the equipment components such as the front cover and terminal blocks are secured firmly with screws. Loosely-connected components may fall off and result in personal injuries or equipment damage.
- Never stand or stay below the equipment when the equipment is being hoisted by the hoisting equipment.
- When hoisting the equipment with a steel rope, ensure the equipment is hoisted at a constant speed without suffering from vibration or shock. Do not turn the equipment over or let the equipment stay hanging in the air. Failure to comply may result in personal injuries or equipment damage.

 CAUTION

- Handle the equipment with care during transportation and mind your steps to prevent personal injuries or equipment damage.
- When carrying the equipment with bare hands, hold the equipment casing firmly with care to prevent parts from falling. Failure to comply may result in personal injuries.
- Store and transport the equipment based on the storage and transportation requirements. Failure to comply will result in equipment damage.
- Avoid storing or transporting the equipment in environments with water splash, rain, direct sunlight, strong electric field, strong magnetic field, and strong vibration.
- Avoid storing the equipment for more than three months. Long-term storage requires stricter protection and necessary inspections.
- Pack the equipment strictly before transportation. Use a sealed box for long-distance transportation.
- Never transport the equipment with other equipment or materials that may harm or have negative impacts on this equipment.

**Installation** DANGER

- The equipment must be operated only by professionals with electrical knowledge.



 WARNING

- Read through the guide and safety instructions before installation.
- Do not install this equipment in places with strong electric or magnetic fields.
- Before installation, check that the mechanical strength of the installation site can bear the weight of the equipment. Failure to comply will result in mechanical hazards.
- Do not wear loose clothes or accessories during installation. Failure to comply may result in an electric shock.
- When installing the equipment in a closed environment (such as a cabinet or casing), use a cooling device (such as a fan or air conditioner) to cool the environment down to the required temperature. Failure to comply may result in equipment over-temperature or a fire.
- Do not retrofit the equipment.
- Do not fiddle with the bolts used to fix equipment components or the bolts marked in red.
- When the equipment is installed in a cabinet or final assembly, a fireproof enclosure providing both electrical and mechanical protections must be provided. The IP rating must meet IEC standards and local laws and regulations.
- Before installing devices with strong electromagnetic interference, such as a transformer, install a shielding device for the equipment to prevent malfunction.
- Install the equipment onto an incombustible object such as a metal. Keep the equipment away from combustible objects. Failure to comply will result in a fire.

 CAUTION

- Cover the top of the equipment with a piece of cloth or paper during installation. This is to prevent unwanted objects such as metal chippings, oil, and water from falling into the equipment and causing faults. After installation, remove the cloth or paper on the top of the equipment to prevent over-temperature caused by poor ventilation due to blocked ventilation holes.
- Resonance may occur when the equipment operating at a constant speed executes variable speed operations. In this case, install the vibration-proof rubber under the motor frame or use the vibration suppression function to reduce resonance.

**Wiring**

 DANGER

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Before wiring, cut off all the power supplies of the equipment, and wait for at least the time designated on the equipment warning label before further operations because residual voltage still exists after power-off. After waiting for the designated time, measure the DC voltage in the main circuit to ensure the DC voltage is within the safe voltage range. Failure to comply will result in an electric shock.
- Do not perform wiring, remove the equipment cover, or touch the circuit board with power ON. Failure to comply will result in an electric shock.
- Check that the equipment is grounded properly. Failure to comply will result in an electric shock.

 **WARNING**

- Do not connect the input power supply to the output end of the equipment. Failure to comply will result in equipment damage or even a fire.
- When connecting a drive to the motor, check that the phase sequences of the drive and motor terminals are consistent to prevent reverse motor rotation.
- Cables used for wiring must meet cross sectional area and shielding requirements. The shield of the cable must be reliably grounded at one end.
- Fix the terminal screws with the tightening torque specified in the user guide. Improper tightening torque may overheat or damage the connecting part, resulting in a fire.
- After wiring is done, check that all cables are connected properly and no screws, washers or exposed cables are left inside the equipment. Failure to comply may result in an electric shock or equipment damage.

 **CAUTION**

- During wiring, follow the proper electrostatic discharge (ESD) procedure, and wear an antistatic wrist strap. Failure to comply will damage the equipment or the internal circuits of the equipment.
- Use shielded twisted pairs for the control circuit. Connect the shield to the grounding terminal of the equipment for grounding purpose. Failure to comply will result in equipment malfunction.

**Power-on** **DANGER**

- Before power-on, check that the equipment is installed properly with reliable wiring and the motor can be restarted.
- Check that the power supply meets equipment requirements before power-on to prevent equipment damage or a fire.
- After power-on, do not open the cabinet door or protective cover of the equipment, touch any terminal, or disassemble any unit or component of the equipment. Failure to comply will result in an electric shock.

 **WARNING**

- Perform a trial run after wiring and parameter setting to ensure the equipment operates safely. Failure to comply may result in personal injuries or equipment damage.
- Before power-on, check that the rated voltage of the equipment is consistent with that of the power supply. Failure to comply may result in a fire.
- Before power-on, check that no one is near the equipment, motor, or machine. Failure to comply may result in death or personal injuries.

**Operation**



- The equipment must be operated only by professionals. Failure to comply will result in death or personal injuries.
- Do not touch any connecting terminals or disassemble any unit or component of the equipment during operation. Failure to comply will result in an electric shock.



- Do not touch the equipment casing, fan, or resistor with bare hands to feel the temperature. Failure to comply may result in personal injuries.
- Prevent metal or other objects from falling into the equipment during operation. Failure to comply may result in a fire or equipment damage.

### Maintenance



- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Do not maintain the equipment with power ON. Failure to comply will result in an electric shock.
- Before maintenance, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.
- In case of a permanent magnet motor, do not touch the motor terminals immediately after power-off because the motor terminals will generate induced voltage during rotation even after the equipment power supply is off. Failure to comply will result in an electric shock.



- Perform routine and periodic inspection and maintenance on the equipment according to maintenance requirements and keep a maintenance record.

### Repair



- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Do not repair the equipment with power ON. Failure to comply will result in an electric shock.
- Before inspection and repair, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.

**WARNING**

- When the fuse is blown or the circuit breaker or earth leakage current breaker (ELCB) trips, wait for at least the time designated on the equipment warning label before power-on or further operations. Failure to comply may result in death, personal injuries or equipment damage.
- When the equipment is faulty or damaged, the troubleshooting and repair work must be performed by professionals that follow the repair instructions, with repair records kept properly.
- Replace quick-wear parts of the equipment according to the replacement instructions.
- Do not use damaged equipment. Failure to comply may result in death, personal injuries, or severe equipment damage.
- After the equipment is replaced, check the wiring and set parameters again.

**Disposal****WARNING**


- Dispose of retired equipment in accordance with local regulations and standards. Failure to comply may result in property damage, personal injuries, or even death.
- Recycle retired equipment by observing industry waste disposal standards to avoid environmental pollution.

**Other Precautions****Dynamic brake**

- The dynamic brake can only be used for emergency stop upon fault or power failure. Do not trigger faults or power failure frequently.
- The action interval of the dynamic brake function must be above 5 min during high-speed operation. Failure to comply may damage the internal dynamic braking circuit.
- A motor being driven by the load axis is in the generating state, which is common in rotary mechanical structures during dynamic braking stop. Under such state, a short circuit current will pass through the dynamic brake. If the motor keeps being driven by the load axis, smoke or flame may be generated from the drive, resulting in motor damage.

**Safety Labels**

For safe equipment operation and maintenance, comply with the safety labels on the equipment. Do not damage or remove the safety labels. See the following table for descriptions of the safety labels.

Safety Label	Description
 <p>危险 DANGER 高压注意 Hazardous Voltage 高温注意 High Temperature</p>	<ul style="list-style-type: none"><li>• Never fail to connect protective earth (PE) terminal. Read through the guide and follow the safety instructions before use.</li><li>• Do not touch terminals within 15 minutes after disconnecting the power supply to prevent the risk of electric shock.</li><li>• Do not touch heatsink with power ON to prevent the risk of burn.</li></ul>

# 1 Product Information

## 1.1 Nameplate and Model of the Servo Drive

### Nameplate and model of the servo drive

SV680 N S 2R8 I  
 ① ② ③ ④ ⑤

<b>① Product series</b> SV680: SV680 series general-purpose servo drive SV680L: SV680 series servo drive for direct-drive motors	<b>④ Rated output current</b> S: 220 V    1R6: 1.6 A 2R8: 2.8 A 5R5: 5.5 A 7R6: 7.6 A 012: 12.0 A 018: 18.0 A 022: 22.0 A 027: 27.0 A T: 380 V    3R5: 3.5 A 5R4: 5.4 A 8R4: 8.4 A 012: 12.0 A 017: 17.0 A 021: 21.0 A 026: 26.0 A	<b>⑤ Model configuration</b> I: Standard type S: Functional safety type ...
<b>② Product type</b> N: Network type P: Pulse type F: Profinet (upcoming)		
<b>③ Voltage class</b> S: 220 V T: 380 V		




Figure 1-1 Servo drive nameplate

## Encryption of the production serial number

01050202 4 H 7 00001  
 ①                    ② ③ ④                    ⑤

① <b>Internal code</b> Material code	③ <b>Year</b> 9: 2009 A: 2010 ... N: 2021 ... Note: I/L/O/Q is not used.	⑤ <b>Lot number</b> 00001: 1st in current month 00002: 2nd in current month 00003: 3rd in current month ... Range: 00001 to 99999
② <b>Manufacturer code</b> 4: Suzhou Inovance	④ <b>Month</b> 1: January 2: February ... A: October B: November C: December	

Example: The S/N 010502024H700001 indicates the drive is manufactured in July, 2017.

## 1.2 Technical Data of EtherCAT Communication

Item		Specifications
Basic performance of EtherCAT slave	Communication protocol	EtherCAT protocol
	Available services	CoE (PDO, SDO)
	Synchronization mode	DC - Distributed clock FreeRun
	Physical layer	100BASE-TX
	Baud rate	100 Mbit/s (100Base-TX)
	Duplex mode	Full duplex
	Topology	Ring and linear
	Transmission medium	Shielded cables of Cat 5e or higher
	Transmission distance	Less than 100 m between two nodes (with proper environment and cables)
	Number of slaves	Up to 65535 in protocol, not exceeding 100 in actual use
	EtherCAT frame length	44 bytes to 1498 bytes
	Process data	A maximum of 1486 bytes per Ethernet frame
	Synchronous jitter of two slaves	< 1 us
	Refresh time	About 30 us for 1000 DI/DOs About 100 us for 100 servo axes Different refresh time can be set for different interfaces.
Communication code error rate	10 <sup>-10</sup> Ethernet standard	
EtherCAT configuration unit	Number of FMMU units	8
	Number of storage synchronization management units	8
	Process data RAM	8 kB
	Distributed Clock	64-bit
	EEPROM capacity	32 kbit



## 2 EtherCAT Communication

### 2.1 Wiring

#### 2.1.1 Description of EtherCAT Communication Terminals (CN3/CN4)




Table 2-1 EtherCAT communication terminal pins

Pin No.	Name	Description
1	TD+	Transmit data (+)
2	TD-	Transmit data (-)
3	RD+	Receive data (+)
4 and 5	-	-
6	RD-	Receive data (-)
7 and 8	-	-
9	TD+	Transmit data (+)
10	TD-	Transmit data (-)
11	RD+	Receive data (+)
12 and 13	-	-
14	RD-	Receive data (-)
15 and 16	-	-

## 2.1.2 Connecting EtherCAT Communication Signals (CN3/CN4)

### 2.1.2.1




Figure 2-1 Network topology




Figure 2-2 Wiring of communication cables

CN3 and CN4 are EtherCAT connectors. Connect CN3 (IN) to the communication port of the master and CN4 (OUT) to the next slave. For assignment of CN3/CN4 terminal pins, see ["2.1.1 Description of EtherCAT Communication Terminals \(CN3/CN4\)" on page 16](#).

### Communication cable selection

Table 2-2 Instructions for communication cable selection

Cable Length	Price	Supplier
0.2 m to 10 m	See <a href="#">"Table 2-3 Information for ordering the communication cable" on page 18</a> .	Inovance, Haituo and others
More than 10 m	The cable price is added by RMB 5 for every additional 1 m based on the price of S6-L-T04-10.0. The cable price is also related to the magnitude of the order.	

Table 2-3 Information for ordering the communication cable

Material Code	Cable Model	Length (m)
15040261	S6-L-T04-0.3	0.3
15040262	S6-L-T04-3.0	3.0
15041960	S6-L-T04-0.2	0.2
15041961	S6-L-T04-0.5	0.5
15041962	S6-L-T04-1.0	1.0

Material Code	Cable Model	Length (m)
15041963	S6-L-T04-2.0	2.0
15041964	S6-L-T04-5.0	5.0
15041965	S6-L-T04-10.0	10.0


Table 2-4 Specifications

Item	Description
UL	Compliant with UL certification
Cat 5e cable	Cat 5e cable
Double-shielded	Braided shield (coverage: 85%), aluminum foil shield (coverage: 100%)
Environmental worthiness	Ambient temperature: -30°C to +60°C, resistant to industrial oil, corrosive acid and alkali

## Basic features

- Interfaces

EtherCAT cables are connected to the network ports (IN and OUT) equipped with metal shield. The electrical characteristics comply with standards IEEE 802.3 and ISO 8877.




Pin No.	Assignment	Description
1	TX+	Transmit data (+)
2	TX-	Transmit data (-)
3	RX+	Receive data (+)
4	NULL	Not connected
5	NULL	Not connected
6	RX-	Receive data (-)
7	NULL	Not connected
8	NULL	Not connected


- Topology

The communication topology of EtherCAT is flexible without any limit, as shown in the following figures. The SV680N series servo drive carries IN and OUT ports.

- Linear topology



- Redundancy ring topology



## Note

When using the redundant ring, set H0E.36 (EtherCAT AL enhanced link) to 1 (Enable), then power on the servo drive again.


- Communication cables
  - The EtherCAT communication cable must be Ethernet Category 5 (100BASE-TX) network cable or high-strength shielded network cable. The network cables used for the servo drive must also be shielded, with cable length not exceeding 100 m.
  - The shielded network cable enhances the anti-interference capacity of the system.

## 2.2 Communication Configuration

### 2.2.1 Overview of EtherCAT Protocol

EtherCAT is an industrial Ethernet-based fieldbus system that features high performance, low cost, easy use and flexible topology. It is applicable to industrial applications requiring ultra-high speed I/O network. EtherCAT adopts standard

Ethernet physical layer with twisted pairs or optical fibers (100Base-TX or 100Base-FX) used as the transmission media.



An EtherCAT system includes the master and the slave. The master requires a common network adapter, and the slave requires a special slave control chip, such as ET1100, ET1200, and FPGA.

EtherCAT can process data at the I/O layer without sub-bus or gateway delay.

- One system covers all devices, including input/output devices, sensors, actuators, drives, and display devices.
- Transmission rate: 2 x 100 Mbit/s (high-speed Ethernet, full duplex mode).
- Synchronization: synchronization jitter < 1 us (number of nodes up to 300, cable length within 120 m)
- Refresh time:

256 DI/DOs: 11 us

1000 DI/DOs distributed in 100 nodes: 30 us = 0.03 ms

200 AI/AOs (16-bit): 50 us, sampling rate: 20 kHz

100 servo axes (8 bytes IN + 8 bytes OUT for each): 100 us = 0.1 ms

12000 digital I/Os: 350 us

To support more types of devices and application layers, EtherCAT establishes the following application protocols:

- CANopen over EtherCAT (CoE)

- Safety over EtherCAT (SoE, compliant with IEC 61800-7-204)
- Ethernet over EtherCAT (EoE)
- File over EtherCAT (FoE)

The slave only needs to support the most suitable application protocol.




Figure 2-3 EtherCAT networking

## Note

EtherCAT<sup>®</sup> is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

## 2.2.2 System Parameter Setting

### Parameter address structure

Parameter access address: index+subindex, both of which are in hexadecimal.

CiA402 establishes the following restrictions on the parameter address:

Index (Hex)	Description
0FFFh to 0000h	Data type
1FFFh to 1000h	CoE communication object
2000h to 5FFFh	Manufacturer-specific object
6000h to 9FFFh	Profile object
A000h to FFFFh	Reserved

## System parameter setting

Set related parameters to allow the SV680N servo drive to be connected to the EtherCAT fieldbus network.

Param. No.	Name	Value Range	Default
H02.00h	Control mode	0: Speed control mode 1: Position control mode 2: Torque control mode 9: EtherCAT mode	9
H0E.02h	Saving objects written through communication to EEPROM	0: Neither parameters nor object dictionaries written through communication saved to EEPROM 1: Only parameters written through communication saved to EEPROM 2: Only object dictionaries written through communication saved to EEPROM 3: Both parameters and object dictionaries written through communication saved to EEPROM	3
H0E.16h	EtherCAT slave alias	0 to 65535	0

## Note

Before saving parameters to EEPROM, set H0E.01h to a proper value. Otherwise, parameters will be restored to default values at next power-on. It is recommended to set H0E.01 to 0 after parameters are set properly. This is to prevent damage to the EEPROM device caused by prolonged writing process.



## 2.2.3 Specifications of EtherCAT Communication

Item		Specifications	
Communication protocol		IEC 61158 Type 12, IEC 61800-7 CiA 402 Drive Profile	
Application layer	SDO	SDO request, SDO response	
	PDO	Variable PDO mapping	
	CiA402	Profile position mode (PP)	
		Profile velocity mode (PV)	
		Profile torque mode (PT)	
		Homing mode (HM)	
		Cyclic synchronous position mode (CSP)	
		Cyclic synchronous velocity mode (CSV)	
Cyclic synchronous torque mode (CST)			
Physical layer	Transmission protocol	100BASE-TX (IEEE802.3)	
	Maximum distance	100 m	
	Interface	RJ45 x 2 ( IN/OUT)	

## 2.2.4 Structure of EtherCAT Communication

Multiple kinds of application protocols are available for EtherCAT communication. The IEC 61800-7 (CiA 402)-CANopen motion control profile is used for SV680N series servo drives. The following figure shows the EtherCAT communication structure in the CANopen application layer.




Figure 2-4 EtherCAT communication structure in the CANOpen application layer

The object dictionary in the application layer includes communication parameters, application process data and PDO mapping data. The process data object (PDO) includes the real-time data generated during operation, which is read and written cyclically. In the SDO mailbox communication, the communication objects and PDO objects are being accessed and modified non-cyclically.

## 2.2.5 Communication State Machine

The following figure shows the state transition diagram of EtherCAT state machine.




Figure 2-5 EtherCAT state machine

The EtherCAT state machine must support the following four states and coordinate the states between the master and slave application program during initialization and operation.

- Init: Initializing (abbreviated as I)
- Pre-operational: abbreviated as P
- Safety-operational: abbreviated as S
- Operational: abbreviated as O


Transition from Init state to Operational state must be in the sequence of Init, Pre-Operational, Safe-Operational, and Operational step by step. In transition from Operational state to Init state, certain steps can be skipped. The following table lists the state transition and the initialization process.

State	SDO	RPDO	TPDO	Description
Init (I)	No	No	No	Communication initialization No communication available in the application layer, EtherCAT slave controller (ESC) register can only be read/written by the master
IP	No	No	No	Configuring the slave address by master; Configuring the mailbox channel; Configuring the distributed clock (DC); Request for Pre-Operational state
Pre-Operational (P)	Yes	No	No	Mailbox data communication in the application layer (SDO)
PS	Yes	No	No	The master uses process data mapping of SDO initialization. The master configures the Sync Manager channel used during process data communication. The master configures the FMMU. Request for Safe-Operational state
Safe-Operational (S)	Yes	No	Yes	SDO, TPDO, and distributed clock mode can be used.
SO	Yes	No	Yes	The master sends valid output data to make a request for the Operational state.
Operational (O)	Yes	Yes	Yes	Normal operational state Both the input and output are valid. Mailbox communication can still be used.

## 2.2.6 Process Data

The real-time data transmission of EtherCAT is achieved through PDO. PDOs can be divided into RPDOs (Receive PDO) and TPDOs (Transmit PDO) based on the data

transmission direction. RPDOs transmit the master data to the slave, and TPDOs return the slave data to the master.



The SV680N series servo drive allows users to assign the PDO list and define the PDO mapping objects.

## PDO mapping

PDO mapping is used to establish the mapping relationship between the object dictionary and PDO. 1600h to 17FFh are RPDOs, and 1A00h to 1BFFh are TPDOs. The SV680N series servo drive provides six RPDOs and five TPDOs, as listed in the following table.

RPDO (seven)	1600h, 1601h	Variable mapping
	1701h to 1705h	Fixed mapping
TPDO (six)	1A00h, 1A01h	Variable mapping
	1B01h to 0x1B04h	Fixed mapping

## Fixed PDO mapping

SV680N provides five fixed RPDOs and four fixed TPDOs.

The following table lists the typical instances of RPDOs and TPDOs.

Control Mode	PP/CSP
1701h (Outputs)	Mapping objects (4 mapping objects, 12 bytes)
	6040h (Control word)
	607Ah (Target position)
	60B8h (Touch probe function) 60FEh sub-index 1 (Physical outputs)
1B01h (Inputs)	Mapping objects (9 mapping objects, 28 bytes)
	603Fh (Error code)
	6041h (Status word)
	6064h (Position actual value)
	6077h (Torque actual value)
	60F4h (Following error actual value)
	60B9h (Touch probe status)
	60BAh (Touch probe 1 positive edge)
	60BCh (Touch probe 2 positive edge)
60FDh (Digital inputs)	

Control Mode	PP/PV/PT/CSP/CSV/CST
1702h (Outputs)	Mapping objects (7 mapping objects, 19 bytes)
	6040h (Control word) 607Ah (Target position) 60FFh (Target velocity) 6071h (Target torque) 6060h (Modes of operation) 60B8h (Touch probe function) 607Fh (Max. profile velocity)
1B02h (Inputs)	Mapping objects (9 mapping objects, 25 bytes)
	603Fh (Error code) 6041h (Status word) 6064h (Position actual value) 6077h (Torque actual value) 6061h (Modes of operation display) 60B9h (Touch probe status) 60BAh (Touch probe 1 positive edge) 60BCh (Touch probe 2 positive edge) 60FDh (Digital inputs)

Control Mode	PP/PV/CSP/CSV
1703h (Outputs)	Mapping objects (7 mapping objects, 17 bytes)
	6040h (Control word) 607Ah (Target position) 60FFh (Target velocity) 6060h (Modes of operation) 60B8h (Touch probe function) 60E0h (Positive torque limit value) 60E1h (Negative torque limit value)
1B03h (Inputs)	Mapping objects (10 mapping objects, 29 bytes)
	603Fh (Error code) 6041h (Status word) 6064h (Position actual value) 6077h (Torque actual value) 60F4 (Following error actual value) 6061h (Modes of operation display) 60B9h (Touch probe status) 60BAh (Touch probe 1 positive edge) 60BCh (Touch probe 2 positive edge) 60FDh (Digital inputs)

Control Mode	PP/PV/PT/CSP/CSV/CST
1704h (Outputs)	Mapping objects (9 mapping objects, 23 bytes)
	6040h (Control word) 607Ah (Target position) 60FFh (Target velocity) 6071h (Target torque) 6060h (Modes of operation) 60B8h (Touch probe function) 607Fh (Max. profile velocity) 60E0h (Positive torque limit value) 60E1h (Negative torque limit value)
1B02h (Inputs)	Mapping objects (9 mapping objects, 25 bytes)
	603Fh (Error code) 6041h (Status word) 6064h (Position actual value) 6077h (Torque actual value) 6061h (Modes of operation display) 60B9h (Touch probe status) 60BAh (Touch probe 1 positive edge) 60BCh (Touch probe 2 positive edge) 60FDh (Digital inputs)

Control Mode	PP/PV/CSP/CSV
1705h (Outputs)	Mapping objects (8 mapping objects, 19 bytes)
	6040h (Control word) 607Ah (Target position) 60FFh (Target velocity) 6060h (Modes of operation) 60B8h (Touch probe function) 60E0h (Positive torque limit value) 60E1h (Negative torque limit value) 60B2h (Torque offset)
1B04h (Inputs)	Mapping objects (10 mapping objects, 29 bytes)
	603Fh (Error code) 6041h (Status word) 6064h (Position actual value) 6077h (Torque actual value) 6061h (Modes of operation display) 60F4h (Following error actual value) 60B9h (Touch probe status) 60BAh (Touch probe 1 positive edge) 60BCh (Touch probe 2 positive edge) 606Ch (Velocity actual value)

## Variable PDO mapping

SV680N provides two variable RPDOs and two variable TPDOs.

Variable PDO	Index	Max. Length of the Byte	Default Mapping Object
RPDO1	1600h 1601h	40	6040h (Control word) 607Ah (Target position) 60B8h (Touch probe function)
TPDO1	1A00h 1A01h	40	603Fh (Error code) 6041h (Status word) 6064h (Position actual value) 60BCh (Touch probe 2 positive edge) 60B9h (Touch probe status) 60BAh (Touch probe 1 positive edge) 60FDh (Digital inputs)

### Sync Manager PDO assignment

The process data can cover multiple PDO mapping data objects during cyclic EtherCAT data communication. The CoE protocol defines the PDO mapping object list of the Sync Manager using data objects 1C10 to 1C2Fh. Multiple PDOs can be mapped to different sub-indexes. The SV680N series servo drive supports assignment of one RPDO and one TPDO, as described in the following table.

Index	Sub-index	Description
1C12h	01h	Take one from 1600h, 1601h, and 1701h to 1705h as the RPDO for actual use.
1C13h	01h	Take one from 1A00h, 1A01h, and 1B01h to 1B04h as the TPDO for actual use.

### PDO configuration

PDO mapping parameters contain indicators of the process data for PDOs, including the index, sub-index and mapping object length. The sub-index 0 indicates the number (N) of mapping objects in the PDO, and the maximum length of each PDO is 4 x N bytes. One or multiple objects can be mapped simultaneously. Sub-indexes 1 to N indicate the mapping content, as defined below:

Bit	31	...	16	15	...	8	7	...	0
Meaning	Index			Sub-index			Object length		

The index and sub-index together define the position of an object in the object dictionary. The object length indicates the bit length of the object in hexadecimal, as shown below:

Object Length	Bit Length
08h	8 bits
10h	16 bits
20h	32 bits

For example, the mapping parameter of the 16-bit control word 6040.00h is 60400010h.

- Observe the following procedure for PDO mapping:
  1. Configure the mapping group of PDO. Write 0 to sub-index 00h of 1C12h (or 1C13h).
    - a. Clear the original mapping group. Write 0 to sub-index 00h of 1C12h ( or 1C13h) to clear the original mapping group.
    - b. Write the PDO mapping group. Write the mapping group according to application needs. Pre-write values of 1600h/1701h...1705h to 1C12h and values of 1A00h/1B01h...1B04h to 1C13h. Note: Only 1600h, 1A00h, 1601h, and 1A01h are configurable mapping groups. Others are fixed mapping configurations.
    - c. Write the total number of this PDO mapping group to sub-index 0 of 1C12h (or 1C13h).
  2. Configure the mapping objects of PDO. Write 0 to sub-index 00h of 1600h (or 1A00h) and 1601h (or 1A01h).
    - a. Clear the original mapping objects. Write 0 to sub-index 00h of 1600h ( or 1A00h) and 1601h (or 1A01h) to clear the original mapping objects.
    - b. Write the PDO mapping content. Write the mapping content to sub-index 1...10 of the mapping parameter based on object parameter definitions in XML file. Only mappable objects can be configured as PDO mapping content.
    - c. Write the total number of mapping objects. Write the number of mapping objects in step b to sub-index 0.

---

## Note

- Configure the PDO only when the EtherCAT state machine is in pre-operational state ("2" displayed on the keypad). Otherwise, an error will be reported.
- Do not save the PDO configuration parameters to EEPROM. Configure the mapping objects again each time upon power-on. Otherwise, the mapping objects are the default parameters of the servo drive.

---

A SDO fault code will be returned when the following operations are under execution:

- Modify PDO parameters in status other than pre-operational.
- Write a value outside the range of 1600h/1601h/1701h...1705h to 1C12h. Write a value outside the range of 1A00h/1A01h/1B01h...1B04h to 1C13h.



## 2.2.7 Service Data Object (SDO)

The EtherCAT SDO is used to transfer non-cyclic data, such as communication parameter configuration and servo drive parameter configuration. The CoE service types of EtherCAT include:

- Emergency message
- SDO request
- SDO response
- TxPDO
- RxPDO
- Remote TxPDO transmission request
- Remote RxPDO transmission request
- SDO message

SV680N series servo drives support SDO request and SDO response.

## 2.2.8 Distributed Clock

The distributed clock (DC) enables all EtherCAT devices to use the same system time and allows synchronous execution of slave tasks. A slave can generate synchronous signals according to the synchronized system time. SV680N series servo drives support DC synchronization mode only. The synchronization cycle, which is controlled by SYNC0, varies with different motion modes.

---

### Note

- The SYNC signal can be used to synchronize all the slaves with an error less than 1 us. The master must synchronize all the slaves to the same clock and continues doing so during operation to prevent clock skew caused by difference in the crystal oscillator. This is usually done by synchronizing the 0x910 register in ESC.
  - SYNC starting time = 0x990 register (with ESC) - 0x920  
Note that the DC mode (0x981 = 0x03) can be enabled only before 0x910 reaches the starting time. If the starting time of SYNC is set improperly, the 0x134 status register of ESC will report the error code of 0x2D.
-

## 2.2.9 State Indication




Figure 2-6 State indication diagram

If the value 0 is displayed, it indicates no value is written or the value 0 is written to 6060h, or H02.00 is set to 0, 1, and 2.

### Communication connection state

The connection state of the two RJ45 ports are indicated by "-" on the upper and lower part of the first LED on the keypad. The upper "-" indicates the state of CN3: PORT1, and the lower "-" indicates the state of CN4: PORT0.

Solid OFF: No communication connection is detected in the physical layer.

Solid ON: Communication connection is detected in the physical layer.

### Communication operation state

The 2nd LED indicates the state of the EtherCAT state machine of the slave in the form of characters, as described in the following table.

State of EtherCAT state machine

State	SDO	RPDO	TPDO	Description	Keypad Display
Initialization	No	No	No	Communication initialization	1: Solid ON
Pre-operational	Yes	No	No	Network configuration initialized SDO available	2: LED blinking at an interval of 400 ms
Safe-operational	Yes	No	Yes	SDO, TPDO, and distributed clock mode available	4: LED blinking at an interval of 1200 ms (ON for 200 ms and OFF for 1000 ms)
Operational	Yes	Yes	Yes	Normal operational state	8: Solid ON

### Display of operation modes

The 3rd LED indicates the operation mode of the servo drive in hexadecimal without blinking, as described in the following table.

Modes of Operation (6060h)	Keypad Display
1: Profile position mode	1
3: Profile velocity mode	3
4: Profile torque mode	4
6: Homing mode	6
8: Cyclic synchronous position mode	8
9: Cyclic synchronous velocity mode	9
10: Cyclic synchronous torque mode	A

### Display of servo state

The 4th and 5th LEDs indicate the servo (slave) state, as described in the following table.

State	Description	Keypad Display
Reset	Initialization	reset
Not ready	Initialization is done. The control circuit is switched on but the main circuit is not switched on. Not ready	nr

State	Description	Keypad Display
Ready	The main circuit is switched on, but the S-ON signal is inactive. Ready	ry The character "y" blinks when the motor speed is not 0 rpm. When the communication layer is in the pre-operational or safe-operational state, the blinking frequency is the same as that of characters "2" or "4" (see "communication status" in the previous page for details). When the communication layer is in Init or Operational state, the blinking frequency is 2 Hz.
Operational	The S-ON signal is active and the motor is energized. Run	rn The character "n" blinks when the motor speed is not 0 rpm. When the communication layer is in the pre-operational or safe-operational state, the blinking frequency is the same as that of characters "2" or "4" (see "communication status" in the previous page for details). When the communication layer is in Init or Operational state, the blinking frequency is 2 Hz.

### Description of state indicator




Figure 2-7 Description of state indicator

Indicator	State	State Indication
RUN indicator	OFF	Init state
	Blinking (ON for 200 ms/OFF for 200 ms)	Pre-operational
	Single-flashing (ON for 200 ms/OFF for 1000 ms)	Safe-operational
	ON	Operational
ERR indicator	OFF	No network fault
	Blinking (ON for 200 ms/OFF for 200 ms)	Communication setting error
	Single-flashing (ON for 200 ms/OFF for 1000 ms)	Sync event error
	Double-flashing (ON for 200 ms, OFF for 200 ms, ON for 200 ms, and OFF for 1000 ms)	Application program watchdog timeout
L/A IN indicator <sup>[1]</sup> L/A OUT indicator	OFF	Link not established
	Flickering (ON for 50 ms/OFF for 50 ms)	Link established, with data transceiving signal
	ON	Link established, without data transceiving signal

## 3 Troubleshooting

### 3.1 Fault and Warning Levels

Faults and warnings of the servo drive are divided into three levels based on severity: No. 1 > No. 2 > No. 3, as shown below.

- No. 1 non-resettable fault
- No. 1 resettable fault
- No. 2 resettable fault
- No. 3 resettable warning

---

#### Note

"Resettable" means the keypad stops displaying the fault/warning once a "Reset signal" is input.

---

Operating procedure:

- To stop the keypad from displaying the fault/warning, set H0d.01 to 1 or activate the logic of the DI assigned with FunIN.2 (ALM-RST, fault and warning reset).
- Set the rising edge of bit 7 of the control word 0x6040 through the host controller.

To reset No. 1 and No. 2 resettable faults, switch off the S-ON signal first and then set H0d.01 to 1 or use FunIN.2 (ALM-RST).

To reset No. 3 warnings, set H0d.01 to 1 or use FunIN.2 (ALM-RST).

---

#### Note

- Some faults and warnings can be reset only after the fault causes are rectified by modifying the settings. However, a reset operation does not necessarily activate the modifications to settings.
- For modifications activated at next power-on (R, S, T/L1C, L2C powered on again), perform a power cycle.
- For modifications activated after stop, switch off the S-ON signal. The servo drive can operate normally only after modifications are activated.

---

☆Related parameters

See "[H0d.01](#)" on page 363 for details.

☆Related function No.

Start Process	Fault Symptom	Cause	Confirming Method
FunIN.2	ALM-RST	Fault/Warning reset signal	<p>The servo drive may, depending on the warning types, continue running after warning reset. When FunIN.2 is assigned to a low-speed DI, the effective level change of this DI must be kept for more than 3 ms. Otherwise, fault reset will be inactive. Do not assign FunIN.2 to a high-speed DI. Otherwise, fault/warning reset will be inactive.</p> <ul style="list-style-type: none"> <li>• Inactive: Not resetting the fault/warning</li> <li>• Active: Resetting the fault/warning</li> </ul>

### Fault and warning log

The servo drive can record the latest 20 faults and warnings and values of status parameters upon fault/warning. Among the latest 5 faults/warnings, if a fault/warning occurs repetitively, the servo drive records the fault/warning code and the drive status only once.

A fault/warning will still be saved in the fault log after reset. To remove the fault/warning from the fault log, set H02.31 to 1.

Read the value of H0b.34 to get the fault/warning code. See examples in the following table.

H0b.34 (Hexadecimal)	Description
0101	0: No. 1 non-resettable fault 101: Fault code
2130	2: No. 1 resettable fault 130: Fault code
6121	6: No. 2 resettable fault 121: Fault code
E110	E: No. 3 resettable warning 110: Warning code

## 3.2 List of Fault and Warning Codes

### No. 1 non-resettable faults:

Table 3-1 List of No. 1 non-resettable faults

Fault Code	Display	Fault Name	Fault Type	Resettable
E101	E101.0	Abnormal parameters in groups H02 and above	No. 1	No
	E101.1	Abnormal parameters in group H00/H01	No. 1	No
	E101.2	Address error in read/write operation after the number of parameters changes	No. 1	No
E102	E102.0	FPGA communication initialization error	No. 1	No
	E102.8	FPGA and MCU version mismatch	No. 1	No
E104	E104.1	MCU operation timeout (MCU crashed)	No. 1	No
	E104.2	FPGA operation timeout (FPGA crashed)	No. 1	No
	E104.4	MCU command update timeout	No. 1	No
E120	E120.0	Unknown encoder model	No. 1	No
	E120.1	Unknown motor model	No. 1	No
	E120.2	Unknown drive model	No. 1	No
	E120.5	Motor and drive current mismatch	No. 1	No
	E120.6	FPGA and motor model mismatch	No. 1	No
	E120.7	Model check error	No. 1	No
E136	E120.8	Junction temperature parameter check error	No. 1	No
	E136.0	Motor parameter check error in encoder ROM	No. 1	No
E201	E136.1	Motor parameter read error in encoder ROM	No. 1	No
	E201.0	Phase-P overcurrent	No. 1	No
	E201.1	Phase-U overcurrent	No. 1	No
	E201.2	Phase-V overcurrent	No. 1	No
E210	E201.4	Phase-N overcurrent	No. 1	No
	E210.0	Output short-circuited to ground	No. 1	No
E234	E234.0	Runaway	No. 1	No
E740	E740.0	Absolute encoder communication timeout	No. 1	No
	E740.2	Absolute encoder error	No. 1	No
	E740.3	Absolute encoder single-turn calculation error	No. 1	No
	E740.6	Encoder write error	No. 1	No



Fault Code	Display	Fault Name	Fault Type	Resettable
E750	E750.0	Master/Slave initial position deviation of safety encoder too large	No. 1	No
	E750.1	Master/Slave position difference of safety encoder too large	No. 1	No
	E750.3	Master/Slave analog deviation of safety encoder too large	No. 1	No
E765	E765.0	Nikon encoder overtemperature or overspeed	No. 1	No
EA33	EA33.0	Encoder read/write check error	No. 1	No
EE12	EE12.0	EtherCAT initialization failure	No. 1	No
EE16	EE16.0	MCU and ESC communication error	No. 1	No

## No. 1 resettable faults

Table 3-2 List of No. 1 resettable faults

Fault Code	Fault subcode	Fault Name	Fault Type	Resettable
E150	E150.0	STO safety state applied	No. 1	Yes
	E150.1	STO input state error	No. 1	Yes
	E150.2	Buffer 5 V voltage detection error	No. 1	Yes
	E150.3	STO input circuit hardware diagnosis failure	No. 1	Yes
	E150.4	PWM Buffer hardware diagnosis failure	No. 1	Yes
E208	E208.2	Encoder communication timeout	No. 1	Yes
	E208.4	FPGA current loop operation timeout	No. 1	Yes
E320	E320.0	Regenerative resistor overload	No. 1	Yes
E400	E400.0	Main circuit overvoltage	No. 1	Yes
E410	E410.0	Main circuit undervoltage	No. 1	Yes
	E410.1	Main circuit power-off	No. 1	Yes
E500	E500.0	Motor overspeed	No. 1	Yes
	E500.1	Speed feedback overflow	No. 1	Yes
	E500.2	FPGA position feedback pulse overspeed	No. 1	Yes
E602	E602.0	Angle auto-tuning failure	No. 1	Yes
	E602.2	U/V/W phase sequence reversed	No. 1	Yes
E605	E605.0	Speed too fast upon S-ON	No. 1	Yes
E620	E620.0	Motor overload	No. 1	Yes
E625	E625.0	Brake release error	No. 1	Yes
E626	E626.0	Brake apply error	No. 1	Yes
E630	E630.0	Motor stall overtemperature protection	No. 1	Yes

Fault Code	Fault subcode	Fault Name	Fault Type	Resettable
E631	E631.1	24 V or brake not connected	No. 1	Yes
	E631.2	P-MOS disconnected	No. 1	Yes
	E631.3	N-MOS disconnected	No. 1	Yes
E640	E640.0	IGBT overtemperature	No. 1	Yes
	E640.1	Flywheel diode overtemperature	No. 1	Yes
E650	E650.0	Heatsink overtemperature	No. 1	Yes
E660	E660.0	Motor overtemperature	No. 1	Yes
E770	E770.0	Phase-A input disconnected in fully-closed loop mode	No. 1	Yes
	E770.1	Phase- B input disconnected in fully-closed loop mode	No. 1	Yes
	E770.2	Phase- Z input disconnected in fully-closed loop mode	No. 1	Yes
	E770.3	BiSS communication protocol timeout	No. 1	Yes
	E770.4	BiSS communication CRC error	No. 1	Yes
	E770.5	BiSS response data error	No. 1	Yes
	E770.6	2nd encoder initialization communication error in fully closed-loop mode	No. 1	Yes
E770.7	2nd encoder communication error in fully closed-loop mode	No. 1	Yes	
E939	E939.0	Motor power cables disconnected	No. 1	Yes
	E939.1	Phase-U power cable disconnected	No. 1	Yes
	E939.2	Phase-V power cable disconnected	No. 1	Yes
	E939.3	Phase-W power cable disconnected	No. 1	Yes

## No. 2 resettable faults

Table 3-3 List of No. 2 resettable faults

Fault Code	Display	Fault Name	Fault Type	Resettable
E122	E122.0	Multi-turn absolute encoder setting error	No. 2	Yes
	E122.1	DI function assignment error	No. 2	Yes
	E122.2	Different DOs assigned with the same function	No. 2	Yes
	E122.3	Upper limit in the rotation mode too high	No. 2	Yes
	E122.4	VDI function assignment fault	No. 2	Yes
	E122.5	VDI and DI assigned with the same function	No. 2	Yes
	E122.6	Absolute function setting fault of the 2nd encoder	No. 2	Yes
	E122.7	Fully closed loop parameter setting error	No. 2	Yes
E420	E420.0	Main circuit phase loss	No. 2	Yes
	E420.1	Main circuit PL signal detection error	No. 2	Yes
E430	E430.0	Control power supply undervoltage	No. 2	Yes
E661	E661.0	STune failure	No. 2	Yes
E662	E662.0	ETune failure	No. 2	Yes
E663	E663.0	ITune failure	No. 2	Yes
E664	E664.0	Resonance too strong	No. 2	Yes
E731	E731.0	Encoder battery failure	No. 2	Yes
E733	E733.0	Encoder multi-turn counting error	No. 2	Yes
E735	E735.0	Encoder multi-turn counting overflow	No. 2	Yes
E760	E760.0	Encoder overtemperature	No. 2	Yes
EB00	EB00.0	Position deviation too large	No. 2	Yes
	EB00.1	Position deviation overflow	No. 2	Yes
EB01	EB01.0	Position reference increment too large	No. 2	Yes
	EB01.1	Individual position reference increment too large	No. 2	Yes
	EB01.3	Reference overflow	No. 2	Yes
EB02	EB02.0	Position deviation too large in fully closed-loop mode	No. 2	Yes
EB03	EB03.0	Electronic gear ratio beyond the limit - H05.02	No. 2	Yes
	EB03.1	Electronic gear ratio beyond the limit - Electronic gear ratio 1	No. 2	Yes
	EB03.2	Electronic gear ratio beyond the limit -Electronic gear ratio 2	No. 2	Yes

Fault Code	Display	Fault Name	Fault Type	Resettable
EE08	EE08.0	Synchronization (SYNC) signal loss	No. 2	Yes
	EE08.1	Status switchover error	No. 2	Yes
	EE08.3	Network cable connected improperly	No. 2	Yes
	EE08.4	Data frame loss protection error	No. 2	Yes
	EE08.5	Data frame transfer error	No. 2	Yes
	EE08.6	Data update timeout	No. 2	Yes
EE09	EE09.0	Software position limit setting error	No. 2	Yes
	EE09.1	Home setting error	No. 2	Yes
	EE09.2	Gear ratio beyond the limit	No. 2	Yes
	EE09.3	Homing method setting error	No. 2	Yes
	EE09.5	PDO mapping beyond the limit	No. 2	Yes
EE10	EE10.0	Mailbox setting error protection (pre-op)	No. 2	Yes
	EE10.1	SM2 configuration error	No. 2	Yes
	EE10.2	SM3 configuration error	No. 2	Yes
	EE10.3	PDO watchdog setting error	No. 2	Yes
	EE10.4	PLL error protection not completed (no sync signal)	No. 2	Yes
EE11	EE11.0	ESI check error	No. 2	Yes
	EE11.1	EEPROM cannot be read by the bus	No. 2	Yes
	EE11.2	EEPROM cannot be updated by the bus	No. 2	Yes
	EE11.3	ESI and drive model mismatch	No. 2	Yes
EE13	EE13.0	Synchronization cycle setting error	No. 2	Yes
EE15	EE15.0	Synchronization cycle error too large	No. 2	Yes

## Resettable warnings

Table 3-4 List of resettable warnings

Fault Code	Display	Name	Fault Type	Resettable
E108	E108.0	Storage parameter write error	No. 3	Yes
	E108.1	Storage parameter read error	No. 3	Yes
	E108.2	Check on data written in EEPROM failed	No. 3	Yes
	E108.3	Check on data read in EEPROM failed	No. 3	Yes
E110	E110.0	Frequency-division pulse output setting error	No. 3	Yes
E121	E121.0	Invalid S-ON command	No. 3	Yes
E510	E510.0	Frequency division pulse output overspeed	No. 3	Yes
E600	E600.0	Inertia auto-tuning failure	No. 3	Yes

Fault Code	Display	Name	Fault Type	Resettable
E601	E601.0	Homing warning	No. 3	Yes
	E601.1	Homing switch error	No. 3	Yes
	E601.2	Homing mode setting error	No. 3	Yes
E631	E631.4	P-MOS short circuit	No. 1	Yes
	E631.5	N-MOS short circuit	No. 1	Yes
E730	E730.0	Encoder battery warning	No. 3	Yes
	E730.1	2nd encoder battery voltage too low	No. 3	Yes
E831	E831.0	A11 zero offset too large	No. 3	Yes
E834	E834.1	A11 overvoltage	No. 3	Yes
	E834.2	A12 input current too high	No. 3	Yes
E900	E900.0	DI emergency braking	No. 3	Yes
E902	E902.0	DI setting invalid	No. 3	Yes
	E902.1	DO setting invalid	No. 3	Yes
	E902.2	Torque reach setting invalid	No. 3	Yes
E908	E908.0	Model identification failure	No. 3	Yes
E909	E909.0	Motor overload	No. 3	Yes
E910	E910.0	Control circuit overvoltage	No. 3	Yes
E920	E920.0	Regenerative resistor overload	No. 3	Yes
E922	E922.0	Resistance of the external regenerative resistor too small	No. 3	Yes
E924	E924.0	Regenerative transistor over-temperature	No. 3	Yes
E941	E941.0	Modified parameters activated at next power-on	No. 3	Yes
E942	E942.0	Parameters saved frequently	No. 3	Yes
E950	E950.0	Forward overtravel warning	No. 3	Yes
E952	E952.0	Reverse overtravel warning	No. 3	Yes
E954	E954.0	Position reference overflow	No. 3	Yes
E971	E971.0	Undervoltage warning of voltage drop protection	No. 3	Yes
E980	E980.0	Encoder algorithm error	No. 3	Yes
EA41	EA41.0	Torque ripple compensation failure	No. 3	Yes

### 3.3 Solutions to Faults

- E101.0: Abnormal parameters in groups H02 and above  
Cause:

The total number of parameters changes, which generally occurs after software update.

Values of parameters in groups H02 and above exceed the limit, which generally occurs after software update.

Cause	Confirming Method	Solution
<p>1. The voltage of the control circuit power supply drops instantaneously.</p>	<p>1. Check whether the control circuit (L1C, L2C) is in the process of power-off or instantaneous power failure occurs.</p>	<p>1. Restore system parameters to default settings (H02.31 = 1), and write parameters again. 2. Enlarge the power capacity or replace with a power supply of higher capacity, restore system parameters to default settings (H02.31 = 1) and write parameters again.</p>
	<p>2. Measure whether the input voltage of the control circuit cable on the non-drive side is within the following range: 220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: -10% to +10% (198 V to 264 V) 380 V servo drive: Effective value: 380 V to 440 V Allowable deviation: -10% to +10% (342 V to 484 V)</p>	<p>Increase the power supply capacity or replace with a power supply of higher capacity. Restore system parameters to default settings (H02.31 = 1), and write parameters again.</p>
<p>2. Instantaneous power failure occurs when saving parameters.</p>	<p>Check whether instantaneous power failure occurs when saving parameters.</p>	<p>Power on the system again, restore system parameters to default settings (H02.31 = 1), and write parameters again.</p>
<p>3. The number of write operations within a certain period of time exceeds the limit.</p>	<p>1. Check whether instantaneous power failure occurs during parameter-saving. 2. Check whether parameters are updated frequently through the host controller.</p>	<p>1. If the servo drive is faulty, replace it. 2. Change the write mode and write parameters again.</p>
<p>4. The software is updated.</p>	<p>Check whether parameter values in groups H02 and above exceed the upper/lower limit due to software update.</p>	<p>Reset the servo drive model and motor model, and restore system parameters to default settings (H02.31 = 1).</p>
<p>5. The servo drive is faulty.</p>	<p>If the fault persists though parameters are restored to default settings and the servo drive is powered off and on repeatedly, the servo drive is faulty.</p>	<p>Replace the servo drive.</p>

- E101.1: Abnormal parameters in group H00/H01

Cause:

The total number of parameters changes, which generally occurs after software update.

Values of parameters in group H00 or H01 exceed the limit, which generally occurs after software update.

Cause	Confirming Method	Solution
The servo drive detects whether parameter values in groups H00 and H01 exceed the upper/lower limit during initialization upon power-on. If yes, the keypad displays E101.1. Motor parameters in group H00 are read from the encoder. Servo drive parameters in group H01 are mapped based on the servo drive model defined by H01.10.	Check which parameter in group H00 and H01 exceeds the limit. Check whether this parameter is set to an improper value.	Replace the motor or servo drive.

- E101.2: Address error in read/write operation after the number of parameters changes

Cause	Confirming Method	Solution
The total number of parameters changes after software update, leading to address error in read/write operation.	Read H0b.90 and H0b.91 to check the parameter group that the abnormal parameter belongs to.	Set this parameter to a proper value. Restore default settings.

- E102.0: FPGA communication initialization error

Cause:

The software versions of MCU and FPGA do not match.

Cause	Confirming Method	Solution
1. The software versions of the FPGA the MCU do not match.	View the MCU software version (H01.00) and FPGA software version (H01.01) through the keypad or the software tool. Check whether the non-zero bits in the most significant bits of these two versions are consistent.	Contact Inovance for technical support. Update the FPGA or MCU software to make them match.
2. The FPGA is faulty.	The fault persists after the servo drive is powered off and on repeatedly.	Replace the servo drive.

- E102.8: FPGA and MCU version mismatch

Cause:

The software versions of MCU and FPGA do not match.

Cause	Confirming Method	Solution
The software versions of MCU and FPGA do not match.	<ol style="list-style-type: none"> <li>1. Check whether the MCU version (H01.00) is 9xx.x (the fourth digit displayed on the keypad is 9).</li> <li>2. Check whether the FPGA version (H01.01) is 9xx.x (the fourth digit displayed on the keypad is 9).</li> </ol>	Contact Inovance for technical support. Update the FPGA or MCU software to make them match.

- E104.1: MCU operation timeout (MCU crashed)

Cause:

The access to MCU times out.

Cause	Confirming Method	Solution
1. The FPGA is faulty.	The fault persists after the servo drive is powered off and on repeatedly.	Replace the servo drive.
2. The communication handshake between FPGA and HOST is abnormal.		
3. Access timeout occurs between HOST and the coprocessor.		

- E104.2: FPGA operation timeout (FPGA crashed)

Cause:

The MCU torque interrupt scheduling time is abnormal. This fault is reported only during commissioning.



Cause	Confirming Method	Solution
1. The FPGA is faulty.	The fault persists after the servo drive is powered off and on repeatedly.	Replace the servo drive.
2. The communication handshake between FPGA and MCU is abnormal.		

- E104.4: MCU command update timeout

Cause:

Take the moment when interrupt starts as the starting time, if the time when commands are written to MCU is longer than the time when position and speed regulators are started by FPGA, a warning will be reported.

Cause	Confirming Method	Solution
The system reports that the encoder communication time is set improperly or the command calculation time is too long.	The fault persists after the servo drive is powered off and on repeatedly.	1. Hide unnecessary functions. 2. Replace the servo drive.

- E120.0: Unknown encoder model

Cause:

The servo drive detects the encoder model during initialization upon power-on. If the encoder model does not comply with the requirement, E120.0 occurs.

Cause	Confirming Method	Solution
1. The product (motor or servo drive) code does not exist.	Read the nameplates of the servo drive and motor to check whether SV680N series servo drive and motor with a 26-bit encoder are used. Meanwhile, check whether H00.00 (Motor code) is set to 14102.	If the motor code is unknown, set H00.00 to 14102 when SV680N series servo drive and the motor equipped with a 26-bit encoder are used.
	Check the servo drive model (H01.02) to see whether this model exists.	If the servo drive model is unknown, set the model correctly according to the nameplate.
2. The power rating of the motor does not match that of the servo drive.	Check whether the servo drive model (H01.02) matches the serial-type motor model (H00.05).	Replace the device that does not match.

- E120.1: Unknown motor model

Cause:

The servo drive detects the motor model defined by H00.00 during initialization upon power-on. If the motor model does not exist, E120.1 occurs.

Cause	Confirming Method	Solution
The motor model defined by H00.00 is abnormal.	Check whether the motor code (H00.00) matches the model of the motor used.	Set H00.00 to a proper value.

- E120.2: Unknown drive model

Cause:

The servo drive detects the servo drive model defined by H01.10 during initialization upon power-on. If the servo drive model does not exist, E120.2 occurs.

Cause	Confirming Method	Solution
The servo drive model (H01.10) is set improperly.	Check whether H01.10 (Servo drive model) is set properly.	Disable servo drive model auto-tuning and set H01.10 to a proper value manually.

- E120.5: Motor and drive current mismatch

Cause:

The rated output of the servo drive is far higher than the rated current of the motor. Replace with a servo drive of lower rated output or a motor with higher rated current.

Cause	Confirming Method	Solution
The internal scaling value is abnormal.	Check whether the servo drive model is correct. If the set current sampling coefficient is too large, calculation overflow will occur.	Replace the servo drive.

- E120.6: FPGA and motor model mismatch

Cause:

- The motor model is set improperly, causing mismatch and malfunction of the servo drive.
- The motor model is set properly, but the motor encoder is not supported by the servo drive.

Cause	Confirming Method	Solution
The FPGA software version does not match the motor model defined by H00.00.	Check whether the FPGA software version (H01.01) supports the motor model defined by H00.00.	Update the FPGA software to enable the FPGA to support the motor model defined by H00.00, or replace the motor.

- E120.7: Model check error

Cause:

The servo drive model parameter cannot be identified.

Cause	Confirming Method	Solution
The model parameter does not pass CRC.	Check whether the model parameter is not programmed or is lost.	Program the model parameter again.

- E120.8: Junction temperature parameter CRC error

Cause:

The auto-tuned junction temperature parameter is wrong.

Cause	Confirming Method	Solution
The CRC on the junction temperature parameter fails.	Check whether the junction parameter is not programmed or is lost.	Program the junction temperature parameter again.

- E122.0: Multi-turn absolute encoder setting error

Cause:

The motor does not match the absolute position mode or the motor code is set improperly.

Cause	Confirming Method	Solution
The motor does not match the absolute position mode or the motor code is set incorrectly.	<ol style="list-style-type: none"> <li>1. Check the motor nameplate to see whether the motor is configured with a multi-turn absolute encoder.</li> <li>2. Check whether H00.00 (Motor code) is set properly.</li> </ol>	Reset H00.00 (Motor code) according to the motor nameplate or replace with a matching motor.

- E122.1: DI function assignment fault

Cause:

The same function is assigned to different DIs.

The DI function No. exceeds the maximum setting number allowed for DI functions.

Cause	Confirming Method	Solution
1. Different DIs are assigned with the same function.	Check whether parameters in groups H03 (H03.02, H03.04...H03.20) and H17 (H17.00, H17.02...H17.30) are assigned with the same non-zero DI function No..	Assign different DI function numbers to parameters in groups H03 or H17, and then restart the control circuit to activate the assignment, or switch off the S-ON signal and send a "RESET" signal to activate the assignment.
2. The DI function No. exceeds the number of DI functions.	Check whether the MCU program is updated.	Restore system parameters to default values (H02.31 = 1) and restart the servo drive.

- E122.2: DO function assignment fault

Cause	Confirming Method	Solution
The DO function No. exceeds the maximum number allowed for DO functions.	Check whether DO function numbers defined by H04.00 and H04.02 are abnormal.	Set the correct DO function No..

- E122.3: Upper limit in the rotation mode invalid  
Cause:

The upper limit (reference range) of the mechanical single-turn position exceeds  $2^{31}$  in the absolute rotation mode.

Cause	Confirming Method	Solution
The upper limit of the mechanical single-turn position exceeds $2^{31}$ .	Check the setting of the mechanical gear ratio, the upper limit of mechanical single-turn position, and the electronic gear ratio when the servo drive operates in the absolute rotation mode (H02.01 = 2).	Reset the mechanical gear ratio, the upper limit of mechanical single-turn position, and the electronic gear ratio to ensure the upper limit of the mechanical single-turn position (reference range) does not exceed $2^{31}$ .

- E122.4: VDI function assignment fault  
Cause:

The same function is assigned to different VDIs. The VDI function No. exceeds the maximum number allowed for VDI functions.

Cause	Confirming Method	Solution
1. The same function is assigned to different VDIs.	Check whether parameters in groups H03 (H03.02, H03.04...H03.20) and H17 (H17.00, H17.02...H17.30) are assigned with the same non-zero DI function No..	Assign different DI function numbers to parameters in groups H03 or H17, and then restart the control circuit to activate the assignment, or switch off the S-ON signal and send a "RESET" signal to activate the assignment.
2. The VDI function No. exceeds the maximum number allowed for VDI functions.	Check whether the MCU program is updated.	Restore system parameters to default values (H02.31 = 1) and restart the servo drive.

- E122.5: VDI and DI assigned with the same function

Cause:

The same function is assigned to different VDIs. The VDI function No. exceeds the maximum number allowed for VDI functions.

Cause	Confirming Method	Solution
At least two DIs/VDIs are assigned with the same function.	Check whether the same DI function No. is set in groups H03 and H17.	Ensure the DI and VDI are set with different function No..

- E122.6: Absolute function setting fault of the 2nd encoder

Cause:

The motor does not match the absolute mode.

Cause	Confirming Method	Solution
The motor does not match the absolute mode.	Check the motor nameplate to see whether the motor is configured with a multi-turn absolute encoder.	Set H0F.02 to 0 (Incremental mode).

- E122.7: Fully closed loop parameter setting error

Cause:

Cause	Confirming Method	Solution
H02.01 is set to 2 (Absolute position rotation mode) when H0F.00 is not 0.	Check the value of H02.01 when using the fully closed loop function.	Set H02.01 to a value other than 2 when using the fully closed loop function.

- E136.0: Motor parameter check error in encoder ROM

Cause:

When reading parameters in the encoder ROM, the servo drive detects that no parameters are saved there or parameter values are inconsistent with the setpoints.

Cause	Confirming Method	Solution
1. The motor model does not match the servo drive model.	View the nameplates of the servo drive and motor to check whether the devices used are SV680N series servo drive and motor.	Replace with the mutually-matching servo drive and motor.
2. A parameter check error occurs or no parameter is saved in the ROM of the serial incremental encoder.	<ol style="list-style-type: none"> <li>1. Check whether the encoder cable provided by Inovance is used. For cable specifications, see "Matching Cables". The cable must be connected securely without scratching, breaking or poor contact.</li> <li>2. Measure signals PS+, PS-, +5V and GND on both ends of the encoder cable and observe whether signals at both ends are consistent. For signal assignment, see Chapter "Wiring" in SV680N Series Servo Drive Hardware Guide.</li> </ol>	<ol style="list-style-type: none"> <li>1. Use the encoder cable provided by Inovance. Ensure motor terminals and servo drive screws are connected securely. Use a new encoder cable if necessary.</li> <li>2. Route encoder cables and power cables (R/S/T, U/V/W) through different routes.</li> </ol>
3. The servo drive is faulty.	The fault persists after the servo drive is restarted.	Replace the servo drive.

● E136.1: Motor parameter read error in encoder ROM

Cause:

- The encoder cable is disconnected.
- A communication error occurs on the encoder due to interference.

Cause	Confirming Method	Solution
1. The encoder cable is connected improperly or loosely.	Check the encoder cable connection. Check whether ambient vibration is too strong, which loosens the encoder cable and even damages the encoder.	<ol style="list-style-type: none"> <li>1. Connect the encoder cables according to the correct wiring diagram.</li> <li>2. Re-connect encoder cables and ensure encoder terminals are connected securely.</li> </ol>
2. The servo drive is faulty.	The fault persists after the servo drive is restarted.	Replace the servo drive.

- E150.0: STO safety state applied

Cause:

The STO input protection (safety state) applies.

Cause	Confirming Method	Solution
Two 24 V inputs are disconnected simultaneously, triggering the STO function.	1. Check whether the STO function is activated.	There is no need to take any corrective actions. After the STO terminal is back to normal, clear the fault using the fault reset function.
	2. Check whether the STO power supply is normal.	Check whether the 24 V power supply for the STO is stable. Tighten the cables that are loose or disconnected.
	3. The fault persists after preceding causes are rectified.	Replace the servo drive.

- E150.1: STO input state error

Cause:

The single-channel input of STO is invalid.

Cause	Confirming Method	Solution
1. The STO power supply is abnormal.	Check whether the STO power supply is normal.	Check whether the 24 V power supply for the STO is stable. Tighten the cables that are loose or disconnected.
2. The STO input resistor is abnormal.	After STO is triggered, only one STO signal is sent to MCU after the 24 V power supply is cut off due to input resistor drift.	Replace the servo drive.
3: The STO function fails.	The fault persists after preceding causes are rectified.	Replace the servo drive.

- E150.2: Buffer 5 V voltage detection error

Cause:

The MCU monitors the 5 V power supply of the PWM Buffer to detect whether overvoltage or undervoltage occurs. If the voltage is abnormal, E150.2 occurs.

Cause	Confirming Method	Solution
The 5 V voltage supplied to the STO Buffer is abnormal due to undervoltage or overvoltage.	Check whether the fault can be removed by a restart. If not, the 5 V voltage supplied to the Buffer is abnormal.	Replace the servo drive.

- E150.3: STO input circuit hardware diagnosis failure

Cause:

Short circuit occurs on the optocoupler of the upstream hardware circuit of STO.

Cause	Confirming Method	Solution
Short circuit occurs on the upstream optocoupler of STO1 or STO2.	The fault persists and the keypad displays E150.3 after restart.	Replace the servo drive.

- E150.4: PWM buffer hardware detection failure

Cause:

An error occurs on the PWM Buffer integrated circuit during initialization detection upon power-on (the PWM signal cannot be blocked).

Cause	Confirming Method	Solution
A STO Buffer error is detected upon power-on.	The fault persists and the keypad displays E150.4 after restart.	Replace the servo drive.

- E165.0: SLS1 slope beyond the limit

Cause:

Cause	Confirming Method	Solution
The SLS1 deceleration slope monitored exceeds the upper limit.	Check whether the slope in which SLS1 ramp decelerates to the SLS1 limit exceeds the allowable upper limit.	<ol style="list-style-type: none"> <li>1. Set a proper upper limit of SLS1 deceleration slope.</li> <li>2. Set a proper SLS1 deceleration slope for stop to ensure the slope in which SLS1 ramps to the limit value is lower than the upper limit.</li> </ol>

- E165.1: SLS2 slope beyond the limit

Cause:

Cause	Confirming Method	Solution
The SLS2 deceleration slope monitored exceeds the upper limit.	Check whether the slope in which SLS2 ramps to the SLS2 limit exceeds the allowable upper limit.	<ol style="list-style-type: none"> <li>1. Set a proper upper limit of SLS2 deceleration slope.</li> <li>2. Set a proper SLS2 deceleration slope for stop to ensure the slope in which SLS2 ramps to the limit value is lower than the upper limit.</li> </ol>

- E165.2: SLS3 slope beyond the limit

Cause:



Cause	Confirming Method	Solution
The SLS3 deceleration slope monitored exceeds the upper limit.	Check whether the slope in which SLS3 ramps to the SLS3 limit exceeds the allowable upper limit.	<ol style="list-style-type: none"> <li>1. Set a proper upper limit of SLS3 deceleration slope.</li> <li>2. Set a proper SLS3 deceleration slope for stop to ensure the slope in which the SLS3 ramps to the limit value is lower than the upper limit.</li> </ol>

- E165.3: SLS4 slope beyond the limit

Cause:

Cause	Confirming Method	Solution
The SLS4 deceleration slope monitored exceeds the upper limit.	Check whether the slope in which SLS4 ramps to the SLS4 limit exceeds the allowable upper limit.	<ol style="list-style-type: none"> <li>1. Set a proper upper limit of SLS4 deceleration slope.</li> <li>2. Set a proper SLS4 deceleration slope for stop to ensure the slope in which SLS4 ramps to the limit value is lower than the upper limit.</li> </ol>

- E201.0: Phase-P overcurrent

Cause:

An excessively high current flows through the positive pole of the DC-AC circuit.

Cause	Confirming Method	Solution
<p>1. Gains are set improperly, leading to motor oscillation.</p>	<p>Check whether vibration or sharp noise occurs during start and operation of the motor, or view "Current feedback" in the software tool.</p>	<ol style="list-style-type: none"> <li>1. Motor parameters are set improperly, modify motor parameter values.</li> <li>2. Current loop parameters are set improperly, modify current loop parameter values.</li> <li>3. Speed loop parameters are set improperly, leading to motor oscillation.</li> <li>4. If the servo drive operates improperly, replace it.</li> </ol>
<p>2. The encoder is wired improperly, aging, or connected loosely.</p>	<p>Check whether the encoder cable provided by Inovance is used and whether the cable is aging, corroded, or connected loosely. Switch off the S-ON signal and rotate the motor shaft manually. Check whether the value of H0b.17 changes as the motor shaft rotates.</p>	<p>Re-solder, tighten or replace the encoder cable.</p>

Cause	Confirming Method	Solution
3. The servo drive is faulty.	<ol style="list-style-type: none"> <li>1. Switch off the S-ON signal and rotate the motor shaft manually. Check whether the value of H0b.17 changes as the motor shaft rotates.</li> <li>2. Disconnect the motor cable and power on the servo drive again, but the fault persists.</li> <li>3. Check whether resistance of the external regenerative resistor is too small or the regenerative resistor is short-circuited (between terminals P⊕ and C).</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace with a regenerative resistor with matching resistance and perform wiring again.</li> <li>2. Replace the servo drive.</li> </ol>
4. Overcurrent occurs on the regenerative resistor.	Check whether the resistance of the external regenerative resistor is too small or the regenerative resistor is short-circuited (terminals P and C in the main circuit).	Select new resistance value and model of the bleeder resistor. Perform wiring again.

- E201.1: Phase-U overcurrent  
Cause:

A current higher than the threshold is collected in the phase-U current.

Cause	Confirming Method	Solution
<ol style="list-style-type: none"> <li>1. Motor cables are in poor contact.</li> <li>2. Motor cables are grounded.</li> <li>3. U/V/W cables of the motor are short-circuited.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check whether the servo drive power cables and motor cables on the U, V, and W sides of the servo drive are loose.</li> <li>2. After confirming the servo drive power cables and motor cables are connected properly, measure whether the insulation resistance between the servo drive U/V/W side and the PE cable is at MΩ level.</li> </ol>	<ol style="list-style-type: none"> <li>1. Tighten the cables that are loose or disconnected.</li> <li>2. Replace the motor in case of poor insulation.</li> </ol>
<ol style="list-style-type: none"> <li>4. The motor is damaged.</li> </ol>	<ol style="list-style-type: none"> <li>1. Disconnect motor cables and check whether short circuit occurs among motor U/V/W cables and whether burrs exist in the wiring.</li> <li>2. Disconnect the motor cables and measure whether the resistance among U, V, and W phases of motor cables is balanced.</li> </ol>	<ol style="list-style-type: none"> <li>1. Connect the motor cables correctly.</li> <li>2. Replace the motor if the resistance is unbalanced.</li> </ol>

- E201.2: Phase-V overcurrent

Cause:

A current higher than the threshold is collected in the phase-V current.

Cause	Confirming Method	Solution
<ol style="list-style-type: none"> <li>Motor cables are in poor contact.</li> <li>Motor cables are grounded.</li> <li>U/V/W cables of the motor are short-circuited.</li> </ol>	<ol style="list-style-type: none"> <li>Check whether the servo drive power cables and motor cables on the U, V, and W sides of the servo drive are loose.</li> <li>After confirming the servo drive power cables and motor cables are connected properly, measure whether the insulation resistance between the servo drive U/V/W side and the PE cable is at MΩ level.</li> </ol>	<ol style="list-style-type: none"> <li>Tighten the cables that are loose or disconnected.</li> <li>Replace the motor in case of poor insulation.</li> </ol>
<ol style="list-style-type: none"> <li>The motor is damaged.</li> </ol>	<ol style="list-style-type: none"> <li>Disconnect motor cables and check whether short circuit occurs among motor U/V/W cables and whether burrs exist in the wiring.</li> <li>Disconnect the motor cables and measure whether the resistance among U, V, and W phases of motor cables is balanced.</li> </ol>	<ol style="list-style-type: none"> <li>Connect the motor cables correctly.</li> <li>Replace the motor if the resistance is unbalanced.</li> </ol>

● E201.4: Phase-N overcurrent

Cause:

An excessively high current flows through the negative pole of the DC-AC circuit.

Cause	Confirming Method	Solution
<ol style="list-style-type: none"> <li>Gains are set improperly, leading to motor oscillation.</li> </ol>	<p>Check whether vibration or sharp noise occurs during start and operation of the motor, or view "Current feedback" in the software tool.</p>	<p>Adjust the gains.</p>
<ol style="list-style-type: none"> <li>The encoder is wired improperly, aging, or connected loosely.</li> </ol>	<p>Check whether the encoder cable provided by Inovance is used and whether the cable is aging, corroded, or connected loosely.</p>	<p>Re-solder, tighten or replace the encoder cable.</p>

Cause	Confirming Method	Solution
3. Overcurrent occurs on the regenerative resistor.	Check whether resistance of the external regenerative resistor is too small or the regenerative resistor is short-circuited (between terminals P⊕ and C).	Replace with a regenerative resistor of matching resistance. Perform wiring again.
4. The servo drive is faulty.	Switch off the S-ON signal and rotate the motor shaft manually. Check whether the value of H0b.17 (Electrical angle) changes as motor shaft rotates. Disconnect the motor cable but the fault persists after the servo drive is powered off and on again.	Replace the servo drive.

- E201.4: Phase-N overcurrent

Cause:

An excessively high current flows through the negative pole of the DC-AC circuit.

Cause	Confirming Method	Solution
1. Gains are set improperly, leading to motor oscillation.	Check whether vibration or sharp noise occurs during start and operation of the motor, or view "Current feedback" in the software tool.	Adjust the gains.
2. The encoder is wired improperly, aging, or connected loosely.	Check whether the encoder cable provided by Inovance is used and whether the cable is aging, corroded, or connected loosely.	Re-solder, tighten or replace the encoder cable.

Cause	Confirming Method	Solution
3. Overcurrent occurs on the regenerative resistor.	Check whether resistance of the external regenerative resistor is too small or the regenerative resistor is short-circuited (between terminals P⊕ and C).	Replace with a regenerative resistor of matching resistance. Perform wiring again.
4. The servo drive is faulty.	Switch off the S-ON signal and rotate the motor shaft manually. Check whether the value of H0b.17 (Electrical angle) changes as motor shaft rotates. Disconnect the motor cable but the fault persists after the servo drive is powered off and on again.	Replace the servo drive.

- E208.2: Encoder communication timeout

Cause:

Cause	Confirming Method	Solution
The servo drive fails to receive the data fed back by the encoder in three consecutive cycles.	Check bit12 of H0b.30. The encoder is wired incorrectly. The encoder cable is loosened. The encoder cable is too long. The encoder communication suffers from interference. The encoder is faulty.	1. Check whether the motor model is correct. 2. Check whether the encoder cable is proper. 3. Check whether the encoder version (H00.04) is proper. 4. Check whether the servo drive is faulty. If yes, replace it.

- E208.4: FPGA current loop operation timeout

Cause:

The operating time of the current loop exceeds the interval threshold.

Cause	Confirming Method	Solution
The FPGA operation times out.	Internal fault code H0b.45 = 4208: Current loop operation timeout	Disable some unnecessary functions to reduce the operating load of the current loop.

- E210.0: Output short-circuited to ground

Cause:

An abnormal motor phase current or bus voltage is detected during auto-inspection upon power-on.

- The DC bus voltage exceeds the discharge threshold.

- Phase-U current of servo drives in size C/D/E exceeds 25% of the setpoint of H01.07.
- Overcurrent occurs on phase-P and phase-N of servo drives in sizes A and B.

Cause	Confirming Method	Solution
1. The servo drive power cables (U/V/W) are short-circuited to ground.	Disconnect the motor cables and measure whether the servo drive power cables (U/V/W) are short-circuited to ground (PE).	Connect cables again or replace the servo drive power cables.
2. The motor is short-circuited to ground.	After confirming the servo drive power cables and motor cables are connected properly, measure whether the insulation resistance between the servo drive U/V/W side and the PE cable is at MΩ level.	Replace the motor.
3. The servo drive is faulty.	Disconnect the power cables from the servo drive, but the fault persists after the servo drive is powered off and on repeatedly.	Replace the servo drive.
4. The motor speed is too high during phase-to-ground detection.	Check whether the motor is in the generating status during power-on.	Reduce the motor speed.

● E234.0: Runaway

Cause:

The torque reference direction is opposite to the speed feedback direction in the torque control mode.

The speed feedback direction is opposite to the speed reference direction in the position or speed control mode.

Cause	Confirming Method	Solution
1. The U/V/W cables are connected in the wrong phase sequence.	Check whether the servo drive power cables are connected in the correct sequence at both ends.	Connect the U/V/W cables in the correct phase sequence.
2. An error occurs on the initial phase detection of the motor rotor due to disturbing signals upon power-on.	The U/V/W phase sequence is correct. But E234.0 occurs when the servo drive is enabled.	Power off and on the servo drive again.



Cause	Confirming Method	Solution
3. The encoder model is wrong or the encoder is wired improperly.	View the nameplates of the servo drive and motor to check whether SV680N series servo drive and the motor equipped with a 26-bit encoder are used.	Replace with a mutually-matching servo drive and motor. For use of SV680N series servo drive and the motor equipped with a 26-bit encoder, set H00.00 to 14102. Check the motor model, encoder type, and encoder cable connection again.
4. The encoder is wired improperly, aging, or connected loosely.	<ol style="list-style-type: none"> <li>1. Check whether the encoder cable provided by Inovance is used and whether the cable is aging, corroded, or connected loosely.</li> <li>2. Switch off the S-ON signal and rotate the motor shaft manually. Check whether the value of H0b.10 (Electrical angle) changes as motor shaft rotates.</li> </ol>	Re-solder, tighten or replace the encoder cable.
5. The gravity load in vertical axis applications is too large.	Check whether the load of the vertical shaft is too large. Adjust brake parameters H02.09...H02.12 and check whether the fault is cleared.	Reduce the load of the vertical axis, increase the stiffness level, or hide this fault without affecting the safety performance and normal use.
6. Improper parameter settings lead to excessive vibration.	The stiffness level is set to an excessively high value, leading to excessive vibration.	Set a proper stiffness level to avoid excessive vibration.

- E320.0: Regenerative resistor overload

Cause:

The regenerative resistor is overloaded.

Cause	Confirming Method	Solution
<p>The accumulative heat of the regenerative resistor exceeds the maximum thermal capacity of the regenerative resistor.</p>	<p>Check whether the value of H0b.67 exceeds 100%.</p>	<ol style="list-style-type: none"> <li>1. Check whether the bus voltage is too high, leading to excessive high bleeder current.</li> <li>2. To avoid excessively high bleeder current, take measures to prevent the motor from being driven by external force.</li> <li>3. Replace the servo drive.</li> </ol>



In applications where the motor drives a vertical axis or is driven by the load, set H0A.12 to 0 to hide the runaway fault.

- E400.0: Main circuit overvoltage

Cause:

The DC bus voltage between P $\oplus$  and N $\ominus$  exceeds the overvoltage threshold.

220 V servo drive: Normal value: 310 V Overvoltage threshold: 420 V

380 V servo drive: Normal value: 540 V Overvoltage threshold: 760 V

Cause	Confirming Method	Solution
<p>1. The voltage input to the main circuit is too high.</p>	<p>Check the power input specifications of the servo drive and measure whether the voltage input to main circuit cables (R/S/T) on the drive side is within the following range:                      220 V servo drive:                      Effective value: 220 V to 240 V                      Allowable deviation: -10% to +10% (198 V to 264 V)                      380 V servo drive:                      Effective value: 380 V to 440 V                      Allowable deviation: -10% to +10% (342 V to 484 V)</p>	<p>Replace or adjust the power supply according to the specified range.</p>
<p>2. The power supply is unstable or affected by lightning.</p>	<p>Check whether the power supply is unstable, affected by lightning, or complies with the preceding range.</p>	<p>Connect a surge protection device and then switch on the main circuit and control circuit power supplies again. If the fault persists, replace the servo drive.</p>

Cause	Confirming Method	Solution
<p>3. The regenerative resistor fails.</p>	<p>If the built-in regenerative resistor is used (H02.25 = 0), check whether terminals P ⊕ and D are jumpered. If yes, measure the resistance between terminals C and D. If an external regenerative resistor is used (H02.25 = 1 or 2), measure the resistance of the external regenerative resistor connected between terminals P ⊕ and C. For details, See table "Specifications of the regenerative resistor" in SV680N Series Servo Drive Commissioning Guide.</p>	<ol style="list-style-type: none"> <li>1. If the resistance is "∞" (infinite), the regenerative resistor is disconnected internally.</li> <li>2. If a built-in regenerative resistor is used, change to use an external regenerative resistor (H02.25 = 1 or 2) and remove the jumper between terminals P ⊕ and D. Select an external regenerative resistor of the same resistance and equal or higher power than the built-in one.</li> <li>3. If an external regenerative resistor is used, replace with a new one and connect it between P ⊕ and C.</li> <li>4. Set H02.26 (Power of external regenerative resistor) and H02.27 (Resistance of external regenerative resistor) to values consistent with the specifications of the external regenerative resistor used.</li> </ol>

Cause	Confirming Method	Solution
<p>4. The resistance of the external regenerative resistor is too large, resulting in insufficient energy absorption during braking.</p>	<p>Measure the resistance of the external regenerative resistor connected between terminals P⊕ and C, and compare the measured value with the recommended value.</p>	<p>1. Replace with a new external regenerative resistor that carries the recommended resistance, and connect it between P⊕ and C. 2. Set H02.26 (Power of external regenerative resistor) and H02.27 (Resistance of external regenerative resistor) to values consistent with the specifications of the external regenerative resistor used.</p>
<p>5. The motor is in abrupt acceleration/deceleration status and the maximum braking energy exceeds the energy absorption value.</p>	<p>Confirm the acceleration/deceleration time during operation and measure whether the DC bus voltage between P⊕ and N⊖ exceeds the overvoltage threshold during deceleration.</p>	<p>After confirming the input voltage of the main circuit is within the specified range, increase the acceleration/deceleration time if the operating conditions allow.</p>
<p>6. The bus voltage sampling value deviates greatly from the measured value.</p>	<p>Check whether H0b.26 (Bus voltage) is within the following range: 220 V servo drive: H0b.26 &gt; 420 V 380 V servo drive: H0b.26 &gt; 760 V Measure whether the DC bus voltage detected between terminals P⊕ and N⊖ is lower than the value of H0b.26.</p>	<p>Contact Inovance for technical support.</p>
<p>7. The servo drive is faulty.</p>	<p>The fault persists after the main circuit is powered off and on repeatedly.</p>	<p>Replace the servo drive.</p>

- E410.0: Main circuit undervoltage

Cause:

The DC bus voltage between P⊕ and N⊖ is lower than the undervoltage threshold.

220 V servo drive: Normal value: 310 V Undervoltage threshold: 200 V (180 V for S5R5 models)

380 V servo drive: Normal value: 540 V Undervoltage threshold: 380 V

Cause	Confirming Method	Solution
1. The power supply of the main circuit is unstable or power failure occurs.	Check the specifications of the power supply. Measure whether the input voltage of the main circuit on the power supply side and the drive side (R/S/T) is within the following range: 220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: -10% to +10% (198 V to 264 V) Measure the voltages of all the three phases.	Increase the capacity of the power supply.
2. Instantaneous power failure occurs.		
3. The power supply voltage drops during operation.		
4. A three-phase servo drive is connected to a single-phase power supply, leading to phase loss.	Check whether the main circuit is wired correctly and whether phase loss detection (H0A.00) is hidden.	Replace the cables and connect the main circuit cables correctly. Three-phase: R, S, T
5. The servo drive is faulty.	Check whether H0b.26 (Bus voltage) is within the following range: 220 V servo drive: H0b.26 < 200 V 380 V servo drive: H0b.26 < 380 V The fault persists after the main circuit is powered off and on repeatedly.	Replace the servo drive.

- E410.1: Main circuit power-off

Cause:

Phase loss occurs on the three-phase servo drive.

Cause	Confirming Method	Solution
<p>The power supply is disconnected during operation.</p>	<p>Check the specifications of the power supply. Measure whether the input voltage of the main circuit on the power supply side and the drive side (R/S/T) is within the following range:                      220 V servo drive:                      Effective value: 220 V to 240 V                      Allowable deviation: -10% to +10%                      380 V servo drive:                      Effective value: 380 V to 440 V                      Allowable deviation: -10% to +10%                      Measure the voltages of all the three phases.</p>	<p>Increase the capacity of the power supply.</p>
	<p>Monitor the power supply voltage and check whether the main circuit power supply is applied to other devices, resulting in insufficient power capacity and voltage drop.</p>	
	<p>Check whether 200B.1Bh (Bus voltage) is within the following range: 220 V servo drive: <math>H0b.27 &lt; 200</math> V; 380 V servo drive: <math>H0b.27 &lt; 380</math> V                      The fault persists after the main circuit (RST) is powered off and on several times.</p>	<p>Replace the servo drive.</p>
	<p>Check whether the main circuit is wired correctly.</p>	<p>Replace the cables and connect the main circuit cables correctly.                      Three-phase: R, S, T                      Single-phase: L1, L2</p>

- E410.1: Main circuit power-off

Cause:

Phase loss occurs on the three-phase servo drive.

Cause	Confirming Method	Solution
<p>The power supply is disconnected during operation.</p>	<p>Check the specifications of the power supply. Measure whether the input voltage of the main circuit on the power supply side and the drive side (R/S/T) is within the following range:                      220 V servo drive:                      Effective value: 220 V to 240 V                      Allowable deviation: -10% to +10%                      380 V servo drive:                      Effective value: 380 V to 440 V                      Allowable deviation: -10% to +10%                      Measure the voltages of all the three phases.</p>	<p>Increase the capacity of the power supply.</p>
	<p>Monitor the power supply voltage and check whether the main circuit power supply is applied to other devices, resulting in insufficient power capacity and voltage drop.</p>	
	<p>Check whether 200B.1Bh (Bus voltage) is within the following range: 220 V servo drive: <math>H0b.27 &lt; 200</math> V; 380 V servo drive: <math>H0b.27 &lt; 380</math> V                      The fault persists after the main circuit (RST) is powered off and on several times.</p>	<p>Replace the servo drive.</p>
	<p>Check whether the main circuit is wired correctly.</p>	<p>Replace the cables and connect the main circuit cables correctly.                      Three-phase: R, S, T                      Single-phase: L1, L2</p>

- E420.0: Main circuit phase loss  
Cause:



Cause	Confirming Method	Solution
1. The three-phase input cables are connected improperly.	Check whether RST cables on the drive side and non-drive side are in good condition and connected properly.	Replace the cables and connect the main circuit cables properly.
2. A single-phase power supply is used for a three-phase servo drive.  3. The three-phase power supply is unbalanced or the voltages of the three phases are too low.	Check the specifications of the power supply and measure whether the voltage input to the main circuit is within the following range: 220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: -10% to +10% (198 V to 264 V) 380 V servo drive: Effective value: 380 V to 440 V Allowable deviation: -10% to +10% (342 V to 484 V) Measure the voltages of all the three phases.	Servo drives of 0.75 kW (H01.10 = 5) can be supplied by single-phase power supplies. If the input voltage complies with the specifications, set H0A.00 (Power input phase loss protection) to 2 (Inhibit phase loss faults and warnings). If the input voltage is outside the specified range, replace or adjust the power supply.

- E420.1: Main circuit PL signal detection error  
Cause:

Cause	Confirming Method	Solution
1. The three-phase input cables are connected improperly.	Check whether RST cables on the drive side and non-drive side are in good condition and connected properly.	Power off and on the servo drive again. If unexpected power failure occurs, ensure the power supply is stable.
2. A single-phase power supply is used for a three-phase servo drive.	Check the specifications of the power supply and measure whether the voltage input to the main circuit is within the following range:	Replace or adjust the power supply according to the specified range.
3. The three-phase power supply is unbalanced or the voltages of the three phases are too low.	220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: -10% to +10% (198 V to 264 V) 380 V servo drive: Effective value: 380 V to 440 V Allowable deviation: -10% to +10% (342 V to 484 V) Measure the voltages of all the three phases.	

- E430.0: Control circuit power supply undervoltage  
Cause:

Cause	Confirming Method	Solution
1. The control circuit power supply of servo drives in size C/D/E is unstable or fails.	Check the specifications of the power supply and measure whether the voltage input to the main circuit is within the following range: 220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: -10% to +10% (198 V to 264 V) 380 V servo drive: Effective value: 380 V to 440 V Allowable deviation: -10% to +10% (342 V to 484 V) Measure the voltages of all the three phases.	Increase the capacity of the power supply.
2. The control circuit power supply of servo drives in size C/D/E is unstable or fails.	Check whether control circuit cables are connected properly and whether the voltage of control circuit cables (L1C, L2C) is within the specified range.	Re-connect or replace the control cables.

- E500.0: Motor overspeed

Cause:

The actual speed of the motor exceeds the overspeed threshold.

Cause	Confirming Method	Solution
1. The U/V/W phase sequence of motor cables is wrong.	Check whether the servo drive power cables are connected in the correct sequence at both ends.	Connect the U/V/W cables in the correct phase sequence.
2. H0A.08 (Overspeed threshold) is set improperly.	Check whether the overspeed threshold is lower than the maximum speed needed: Overspeed threshold = 1.2 x Maximum motor speed (H0A.08 = 0) Overspeed threshold = H0A.08 (when H0A.08 ≠ 0, and H0A-08 < 1.2 x maximum motor speed)	Reset the overspeed threshold according to the mechanical requirements.

Cause	Confirming Method	Solution
<p>3. The input reference exceeds the overspeed threshold.</p>	<p>Check whether the motor speed corresponding to the input reference exceeds the overspeed threshold.</p> <ul style="list-style-type: none"> <li>• Position control mode: In CSP mode, view the gear ratio 6091.01h/6091.02h to determine the position reference increment for an individual synchronization cycle and convert it to the speed information. In PP mode, view the gear ratio 6091.01h/6091.02h and determine the value of 6081h (Profile velocity). In HM mode, view the gear ratio 6091.01h/6091.02h, and determine the values 6099.01h 6099.02h.</li> <li>• Speed control mode: View the gear ratio (6091h), target velocity (60FFh), speed limits (H06.06 to H06.09), and the maximum profile velocity (607Fh).</li> <li>• Torque control mode: View the speed limit defined by H07.17 in the torque control mode and check the corresponding speed limit.</li> </ul>	<ul style="list-style-type: none"> <li>• Position control mode: CSP: Decrease the position reference increment for an individual synchronization cycle. The host controller should handle the position ramp when generating references. PP: Decrease the value of 6081h or increase the acceleration/ deceleration ramp (6083h, 6084h). HM: Decrease the values 6099.01h and 6099.02h or increase the acceleration/ deceleration ramp (609Ah). Decrease the gear ratio according to actual conditions.</li> <li>• Speed control mode: Decrease the target velocity, speed limit, and gear ratio. In PV mode, increase the speed ramp (6083h and 6084h). In CSV mode, the host controller should cover the speed ramp.</li> <li>• Torque control mode: Set the speed limit to a value lower than the overspeed threshold.</li> </ul>
<p>4. The motor speed overshoots.</p>	<p>Check in the software tool whether the speed feedback exceeds the overspeed threshold.</p>	<p>Adjust the gains or mechanical operating conditions.</p>
<p>5. The servo drive is faulty.</p>	<p>The fault persists after the servo drive is powered off and on again.</p>	<p>Replace the servo drive.</p>

- E500.1: Speed feedback overflow

Cause:

The FPGA speed measurement overflows.

Cause	Confirming Method	Solution
1. The FPGA internal speed overflows.	Check whether the servo drive power cables are connected in the correct sequence at both ends.	Connect the U/V/W cables in the correct phase sequence.
2. The motor speed overshoots.	Check in the software tool whether the speed feedback exceeds the overspeed threshold.	Adjust the gains or mechanical operating conditions.

- E500.2: Speed feedback error 2

Cause	Confirming Method	Solution
The board-to-board communication of the servo drive is abnormal.	The fault persists even though the servo drive is powered off and on again.	Replace the servo drive.

- E602.0: Angle auto-tuning error

Cause:

Unusual jitter occurs on the encoder feedback during angle auto-tuning.

Cause	Confirming Method	Solution
The data fed back by the encoder is abnormal.	Check if the encoder communication is being disturbed.	Check the wiring of the encoder.

- E602.2: U/V/W phase sequence reversed

Cause:

A wrong U/V/W phase sequence is detected during angle auto-tuning.

Cause	Confirming Method	Solution
A wrong U/V/W phase sequence is detected during angle auto-tuning.	Check whether U/V/W phases are wired correctly.	Exchange cables of any two phases among U/V/W and perform auto-tuning again.

- E605.0: Bootstrap overspeed

Cause:

The motor speed exceeds the rated speed when the servo drive in size A/B is enabled.

Cause	Confirming Method	Solution
The motor speed exceeds the rated speed when the servo drive is enabled.	Check whether the drive is enabled when the motor is in the generating state.	Enable the drive when the motor is at standstill.

- E620.0: Motor overload

Cause:

The accumulative heat of the motor reaches the fault threshold.

Cause	Confirming Method	Solution
<p>1. The motor and encoder cables are connected improperly or in poor contact.</p>	<p>Check the wiring among the servo drive, motor and encoder according to the correct wiring diagram.</p>	<p>Connect cables according to the correct wiring diagram. It is recommended to use the cables provided by Inovance. When customized cables are used, prepare and connect the customized cables according to the wiring instructions.</p>
<p>2. The load is so heavy that the effective torque outputted by the motor keeps exceeding the rated torque.</p>	<p>Confirm the overload characteristics of the servo drive or motor. Check whether the average load rate (H0b.12) of the servo drive keeps exceeding 100.0%.</p>	<p>Replace with a servo drive of higher capacity and a matching servo motor, or reduce the load and increase the acceleration/ deceleration time.</p>
<p>3. Acceleration/deceleration is too frequent or the load inertia is too large.</p>	<p>Calculate the mechanical inertia ratio or perform inertia auto-tuning. View the value of H08.00 (Load inertia ratio). Confirm the individual operation cycle when the servo motor operates cyclically.</p>	<p>Increase the acceleration/ deceleration time in an individual operation cycle.</p>
<p>4. The gains are improper or the stiffness level is too high.</p>	<p>Check whether the motor vibrates and generates unusual noise during operation.</p>	<p>Adjust the gains again.</p>
<p>5. The model of the servo drive or motor is set improperly.</p>	<p>View the motor model (H0d.05) saved in the serial-type encoder and the servo drive model (H01.10).</p>	<p>View the servo drive nameplate and set the servo drive model (H01.10) and motor model properly according to section "Servo Drive Model and Nameplate" in SV680N Series Servo Drive Hardware Guide.</p>

Cause	Confirming Method	Solution
6. The motor is stalled due to mechanical factors, resulting in overload during operation.	<p>Check the reference and motor speed (H0b.00) through the software tool or keypad.</p> <ul style="list-style-type: none"> <li>References in the position control mode: H0b.13 (Input position reference counter)</li> <li>References in the speed control mode: H0b.01 (Speed reference)</li> <li>References in the torque control mode: H0b.02 (Internal torque reference)</li> </ul> <p>Check whether the reference value is not 0 but the motor speed is 0 rpm in the corresponding mode.</p>	Eliminate the mechanical factors.
7. The servo drive is faulty.	The fault persists after the servo drive is powered off and on again.	Replace the servo drive.

## Note

When E620.0 occurs, stop the servo drive for at least 30s before further operations.

- E625.0: Brake release error

Cause	Confirming Method	Solution
The brake malfunctions when it is released.	Check whether the motor shaft end is locked by the brake when the brake release signal is activated.	<ol style="list-style-type: none"> <li>1. Check the wiring of the brake.</li> <li>2. Replace with a new motor with brake.</li> </ol>

- E626.0: Brake apply error

Cause	Confirming Method	Solution
The brake malfunctions when it is applied.	Check whether the motor shaft end is not locked or is locked loosely by the brake when the brake apply signal is activated.	<ol style="list-style-type: none"> <li>1. Check the wiring of the brake.</li> <li>2. Replace with a new motor with brake.</li> </ol>

- E630.0: Motor stall  
Cause:

The actual motor speed is lower than 10 rpm but the torque reference reaches the limit, and such status lasts for the time defined by H0A.32.

Cause	Confirming Method	Solution
1. U/V/W phase loss, disconnection, or incorrect phase sequence occurs on the servo drive.	Perform motor trial run without load and check cable connections and the phase sequence.	Connect cables again according to the correct wiring diagram or replace the cables.
2. The motor parameters (especially the number of pole pairs) are set improperly and motor angle auto-tuning is not performed.	View parameters in group H00 to check whether the number of pole pairs are set properly. Perform angle auto-tuning on the motor several times and check whether the value of H00.28 is consistent during angle auto-tuning.	Modify the motor parameter values.
3. The communication commands are being disturbed.	Check whether jitter occurs on the commands sent from the host controller and whether EtherCAT communication is being disturbed.	Check whether the communication line between the host controller and the servo drive is being disturbed.
4. The motor is stalled due to mechanical factors.	Check the reference and motor speed (H0b.00) through the software tool or keypad. <ul style="list-style-type: none"> <li>• References in the position control mode: H0b.13 (Input position reference counter)</li> <li>• References in the speed control mode: H0b.01 (Speed reference)</li> <li>• References in the torque control mode: H0b.02 (Internal torque reference)</li> </ul> Check whether the reference value is not 0 but the motor speed is 0 rpm in the corresponding mode. Check the current feedback (torque reference) waveform.	Check whether any mechanical part gets stuck or eccentric.

## Note

When E620.0 occurs, stop the servo drive for at least 30s before further operations.



- E631.1: 24 V or brake not connected

Cause:

The brake circuit is faulty.

Cause	Confirming Method	Solution
The brake or 24 V is not connected when the brake function applies.	Check whether 24 V power supply or the brake is not connected when H02.16 is set to 1.	<ol style="list-style-type: none"> <li>1. Set H02.16 to 0.</li> <li>2. Replace the motor.</li> <li>3. Switch on the motor brake cable and 24 V power supply cable.</li> </ol>

- E631.2: P-Mos disconnected

Cause:

The brake circuit is faulty.

Cause	Confirming Method	Solution
P-MOS of the brake circuit is disconnected when the brake function applies.	Ensure the brake cable is connected properly. Check whether the fault persists after the servo drive is powered off and on again.	<ol style="list-style-type: none"> <li>1. Replace the servo drive.</li> <li>2. Switch off the brake switch (H02.16).</li> </ol>

- E631.3: N-Mos disconnected

Cause:

The brake circuit is faulty.

Cause	Confirming Method	Solution
N-MOS of the brake circuit is disconnected when the brake function applies.	Ensure the brake cable is connected properly. Check whether the fault persists after the servo drive is powered off and on again.	<ol style="list-style-type: none"> <li>1. Replace the servo drive.</li> <li>2. Switch off the brake switch (H02.16).</li> </ol>

- E631.4: P-Mos short-circuited

Cause:

The brake circuit is faulty.

Cause	Confirming Method	Solution
P-MOS of the brake circuit is short-circuited when the brake function applies.	Ensure the brake cable is connected properly. Check whether the fault persists after the servo drive is powered off and on again.	<ol style="list-style-type: none"> <li>1. Replace the servo drive.</li> <li>2. Switch off the brake switch (H02.16).</li> </ol>

- E640.0: IGBT overtemperature

Cause:

The IGBT temperature reaches the fault threshold defined by H0A.18.

Cause	Confirming Method	Solution
1. The ambient temperature is too high. 2. The servo drive is restarted repeatedly to reset the overload fault.	Measure the ambient temperature and view the fault records (set H0b.33 and view H0b.34) to check whether an overload fault/warning is reported (E620.0, E630.0, E650.0, E909.0, E920.0, E922.0).	<ul style="list-style-type: none"> <li>• Improve the cooling conditions of the servo drive to lower down the ambient temperature.</li> <li>• Change the fault reset method. After overload occurs, wait for 30s before reset. Increase the capacities of the servo drive and motor. Increase the acceleration/ deceleration time and reduce the load.</li> </ul>
3. The fan is damaged.	Check whether the fan works properly during operation.	Replace the servo drive.
4. The servo drive is installed in a wrong direction and the clearance between servo drives is improper.	Check whether the servo drive is installed properly.	Install the servo drive according to the installation requirements.
5. The servo drive is faulty.	The fault persists even though the servo drive is restarted five minutes after power-off.	Replace the servo drive.

## Note

When E620.0 occurs, stop the servo drive for at least 30s before further operations.

- E640.1: Flywheel diode overtemperature

Cause:

The temperature of the flywheel diode reaches the fault threshold defined by H0A.18.

Cause	Confirming Method	Solution
1. The ambient temperature is too high. 2. The servo drive is restarted repeatedly to reset the overload fault.	Measure the ambient temperature and view the fault records (set H0b.33 and view H0b.34) to check whether an overload fault/warning is reported (E620.0, E630.0, E650.0, E909.0, E920.0, E922.0).	<ul style="list-style-type: none"> <li>• Improve the cooling conditions of the servo drive to lower down the ambient temperature.</li> <li>• Change the fault reset method. After overload occurs, wait for 30s before reset. Increase the capacities of the servo drive and motor. Increase the acceleration/ deceleration time and reduce the load.</li> </ul>
3. The fan is damaged.	Check whether the fan works properly during operation.	Replace the servo drive.
4. The servo drive is installed in a wrong direction and the clearance between servo drives is improper.	Check whether the servo drive is installed properly.	Install the servo drive according to the installation requirements.
5. The servo drive is faulty.	The fault persists even though the servo drive is restarted five minutes after power-off.	Replace the servo drive.

---

## Note

When E620.0 occurs, stop the servo drive for at least 30s before further operations.

---

- E650.0: Heatsink overtemperature

Cause:

The temperature of the servo drive power module exceeds the overtemperature threshold.

Cause	Confirming Method	Solution
1. The ambient temperature is too high.	Measure the ambient temperature.	Improve the cooling conditions of the servo drive to lower down the ambient temperature.
2. The servo drive is restarted repeatedly to reset the overload fault.	View the fault log (set H0b.33 and view H0b.34). Check whether an overload fault or warning (E620.0, E630.0, E650.5, E909.0, E920.0, E922.0) occurs.	Change the fault reset method. After overload occurs, wait for 30s before reset. Increase the capacities of the servo drive and motor. Increase the acceleration/deceleration time and reduce the load.
3. The fan is damaged.	Check whether the fan works properly during operation.	Replace the servo drive.
4. The servo drive is installed in a wrong direction and the clearance between servo drives is improper.	Check whether the servo drive is installed properly.	Install the servo drive according to the installation requirements.
5. The servo drive is faulty.	The fault persists even though the servo drive is restarted five minutes after power-off.	Replace the servo drive.

## Note

When E620.0 occurs, stop the servo drive for at least 30s before further operations.

- E660.0: Motor overtemperature

Cause:

The temperature of the air-cooled motor is too high.

Cause	Confirming Method	Solution
The temperature of the air-cooled motor is too high.	Measure whether the temperature of the air-cooled motor is too high.	Cool the motor down.

- E661.0: STune fault

Cause	Confirming Method	Solution
<p>The gain values fall below the lower limit during ETune operation.                      Position loop gain &lt; 5                      Speed loop gain &lt; 5                      Model loop gain &lt; 10</p>	<p>Check whether resonance in the system is not suppressed. The torque resonance amplitude exceeds the setpoint of H09.11.</p>	<ol style="list-style-type: none"> <li>1. Set the notch manually.</li> <li>2. Modify the electronic gear ratio to improve the reference resolution, and increase the reference filter time constant in the parameter configuration interface.</li> <li>3. Check whether the machine suffers from periodic fluctuation.</li> <li>4. Set H09.58 to 1 to clear resonance suppression parameters, and perform STune again.</li> </ol>

- E662.0: ETune failure

Cause	Confirming Method	Solution
<p>Check whether resonance that occurred during ETune operation cannot be suppressed.</p>	<p>Check whether unusual noise or torque fluctuation occurs during operation.</p>	<ol style="list-style-type: none"> <li>1. Set the notch manually when vibration cannot be suppressed automatically.</li> <li>2. Modify the electronic gear ratio to improve the reference resolution, increase the reference filter time constant in the parameter configuration interface.</li> <li>3. Increase the vibration threshold defined by H09.11 properly.</li> <li>4. Check whether the machine suffers from periodic fluctuation.</li> <li>5. Check whether the positioning threshold is too low. Increase the reference acceleration/ deceleration time.</li> </ol>

- E663.0: ITune fault

Cause	Confirming Method	Solution
<p>Check whether resonance that occurred during ITune operation cannot be suppressed.</p>	<p>Check whether unusual noise or torque fluctuation occurs during operation.</p>	<ol style="list-style-type: none"> <li>1. Set the notch manually when vibration cannot be suppressed automatically.</li> <li>2. Modify the electronic gear ratio to improve the reference resolution, and increase the reference filter time constant in the parameter configuration interface.</li> <li>3. Check whether the machine suffers from periodic fluctuation.</li> <li>4. Increase the vibration threshold defined by H09.11 properly.</li> </ol>

- E664.0: System resonance too strong

Cause	Confirming Method	Solution
<p>Resonance occurs on the servo system and the torque fluctuation amplitude is higher than the value of H09.54.</p>	<p>Check whether unusual noise or torque fluctuation occurs during operation.</p>	<ol style="list-style-type: none"> <li>1. Check whether the inertia ratio or loop gain parameters are set properly.</li> <li>2. Check whether resonance parameters are set properly.</li> <li>3. Increase the value of H09.54 or set H09.54 to 0 to hide this function.</li> </ol>

- E731.0: Encoder battery failure

Cause:

The voltage of the absolute encoder battery is lower than 2.8 V.

Cause	Confirming Method	Solution
1. The battery is not connected during power-off.	Check whether the battery is connected during power-off.	Set H0d.20 to 1 to clear the fault.
2. The encoder battery voltage is too low.	Measure the battery voltage.	Use a new battery with the matching voltage.

- E733.0: Encoder multi-turn counting error

Cause:

An encoder multi-turn counting error occurs.

Cause	Confirming Method	Solution
The encoder is faulty.	Set H0d.20 to 2 to clear the fault, but E733.0 persists after restart.	Replace the motor.

- E735.0: Encoder multi-turn counting overflow

Cause:

A multi-turn counting overflow occurs on the absolute encoder.

Cause	Confirming Method	Solution
The number of forward revolutions exceeds 32767 or the number of reverse revolutions exceeds 32768.	Check whether the value of H0b.70 (Number of absolute encoder revolutions) is 32767 or 32768 when the servo drive works in the absolute linear mode (H02.01 = 1).	Set H0d.20 to 2 to power on again. Perform homing if necessary.

- E740.0: Absolute encoder communication timeout

Cause:

Communication timeout occurs on the absolute encoder.

Cause	Confirming Method	Solution
The communication between the servo drive and the encoder times out.	Check the wiring of the encoder and power on the servo drive again.	<ol style="list-style-type: none"> <li>1. Check whether the encoder version (H00.04) is set properly.</li> <li>2. Check whether the servo drive software version (H01.00) is set properly.</li> <li>3. Check the encoder cable connections.</li> <li>4. Replace the servo motor.</li> </ol>

- E740.2: Absolute encoder error

Cause:

A communication error occurs on the RX end of the encoder.

Cause	Confirming Method	Solution
An error occurs on the communication between the servo drive and the encoder.	Check whether the value of H0b.28 is not 0.	<ol style="list-style-type: none"> <li>1. Check whether H00.00 (Motor code) is set properly.</li> <li>2. Check whether the encoder cable is connected properly.</li> <li>3. Check whether the servo drive and motor are grounded properly. You can wind a magnetic ring around the encoder cable to reduce interference.</li> </ol>

- E740.3: Absolute encoder single-turn calculation error

Cause:

The encoder is faulty.

Cause	Confirming Method	Solution
An encoder fault occurs.	Check whether bit7 of H0b.28 is set to 1.	<ol style="list-style-type: none"> <li>1. Check whether the encoder version (H00.04) is proper.</li> <li>2. Check whether the encoder cable is proper.</li> <li>3. Replace the motor.</li> </ol>

- E740.6: Encoder data write error

Cause:

The attempt to write the encoder data fails.

Cause	Confirming Method	Solution
An error occurs when writing the position offset after angle auto-tuning.	Replace with a new encoder cable. If the fault no longer occurs after cable replacement, it indicates the original encoder cable is damaged. Keep the motor in a certain position, power on the system repeatedly and observe the change of H0b.17 (Electrical angle). The electrical angle deviation should be within $\pm 30^\circ$ when the motor position does not change.	Replace with a new encoder cable. If the fault persists after the encoder cable is replaced, the encoder may be faulty. In this case, replace the servo motor.



- E760.0: Encoder overtemperature

Cause:

The temperature of the absolute encoder is too high.

Cause	Confirming Method	Solution
The temperature of the absolute encoder is too high.	Measure the encoder or motor temperature.	Switch off the S-ON signal to wait for the encoder to cool down.

- E765.0: Nikon encoder overtemperature or overspeed

Cause:

Cause	Confirming Method	Solution
The motor temperature is too high.	Check whether the ambient temperature or average load rate is too high, leading to motor overtemperature.	Switch off the S-ON signal to wait for the encoder to cool down.

- E770.0: Phase-A input disconnected in fully-closed loop mode

Cause	Confirming Method	Solution
The phase-A input differential voltage is disconnected in the fully closed-loop mode.	Measure whether the differential voltage of phase A/B is lower than 2.5 V.	Adjust the phase-A input voltage in the fully closed-loop mode.

- E770.1: Phase- B input disconnected in fully-closed loop mode

Cause	Confirming Method	Solution
The phase- B input differential voltage is disconnected in the fully closed-loop mode.	Measure whether the differential voltage of phase- B is lower than 2.5 V.	Adjust the phase- B input voltage in the fully closed-loop mode.

- E770.2: Phase-Z input disconnected in fully-closed loop mode

Cause	Confirming Method	Solution
The phase-Z input differential voltage is disconnected in the fully closed-loop mode.	Measure whether the differential voltage of phase- Z is lower than 2.5 V.	Adjust the phase-Z input voltage in the fully closed-loop mode.

- E770.3: BiSS communication protocol timeout

Cause	Confirming Method	Solution
Communication timeout occurs on the BiSS encoder in the outer loop in the fully closed-loop mode.	<ul style="list-style-type: none"> <li>● Check whether the wiring is correct.</li> <li>● Check whether H0F.28, H0F.29, and H0F.30 are set correctly.</li> </ul>	<ul style="list-style-type: none"> <li>● Check whether the wiring is correct.</li> <li>● Set H0F.28, H0F.29, and H0F.30 based on the BiSS encoder specifications.</li> </ul>

- E770.4: BiSS communication CRC error

Cause	Confirming Method	Solution
Communication CRC error occurs on the BiSS encoder in the outer loop in the fully closed-loop mode.	Check whether the data cable is being disturbed.	Use shielded twisted pair cable as the data cable and connect the cable again.

- E770.5: BiSS response data error

Cause	Confirming Method	Solution
Response data error occurs on the BiSS encoder in the outer loop in the fully closed-loop mode.	Check whether the data cable is being disturbed.	Use shielded twisted pair cable as the data cable and connect the cable again.

- E770.6: 2nd encoder initialization communication error in fully closed-loop mode

Cause	Confirming Method	Solution
<p>1. The encoder is wired improperly. 2. The encoder cable is loose.</p>	<p>Check the wiring of the encoder. Check whether vibration on site is too strong, which loosens the encoder cable and even damages the encoder. Replace with a new encoder cable. If the fault no longer occurs after cable replacement, it indicates the original encoder cable is damaged.</p>	<p>Connect the cables again according to the correct wiring diagram and ensure encoder terminals are connected securely. Preferably use cables provided by Inovance. If a customized encoder cable is used, check whether this cable is a shielded twisted pair cable complying with the specifications. Route the motor cables and encoder cables through different routes. Ensure the servo motor and servo drive are grounded properly. Check whether the connectors at both ends of the encoder are in good contact and whether any pin retracts. Replace with a new encoder cable. If the fault persists after the encoder cable is replaced, the encoder may be faulty. In this case, replace the servo motor.</p>
<p>3. The encoder Z signal is being disturbed.</p>	<p>Check whether ambient devices are generating interference and whether multiple interference sources are present in the cabinet. Make the servo drive stay in "Rdy" status and rotate motor shaft counterclockwise (CCW) manually. Observe whether H0b.10 (Electrical angle) increases/decreases smoothly and turning one circle corresponds to five 0-360° (for Z series motor). For X series motors, turning one circle should correspond to four 0-360°. If H0b.10 changes abnormally when you rotate the motor shaft manually, the encoder is faulty. If no warning is reported during rotation but the servo drive reports a warning during operation, disturbance may be present.</p>	
<p>4. The encoder is faulty.</p>	<p>Keep the motor in a certain position, power on the system several times and observe the change of H0b.10 (Electrical angle). The electrical angle deviation should be within <math>\pm 30^\circ</math> when the motor position does not change.</p>	

- E770.7: 2nd encoder communication error in fully closed-loop mode

Cause	Confirming Method	Solution
<p>1. The encoder is wired improperly. 2. The encoder cable is loose.</p>	<p>Check the wiring of the encoder. Check whether vibration on site is too strong, which loosens the encoder cable and even damages the encoder. Replace with a new encoder cable. If the fault no longer occurs after cable replacement, it indicates the original encoder cable is damaged.</p>	<p>Connect the cables again according to the correct wiring diagram and ensure encoder terminals are connected securely. Preferably use cables provided by Inovance. If a customized encoder cable is used, check whether this cable is a shielded twisted pair cable complying with the specifications. Route the motor cables and encoder cables through different routes. Ensure the servo motor and servo drive are grounded properly. Check whether the connectors at both ends of the encoder are in good contact and whether any pin retracts. Replace with a new encoder cable. If the fault persists after the encoder cable is replaced, the encoder may be faulty. In this case, replace the servo motor.</p>
<p>3. The encoder Z signal is being disturbed.</p>	<p>Check whether ambient devices are generating interference and whether multiple interference sources are present in the cabinet. Make the servo drive stay in "Rdy" status and rotate motor shaft counterclockwise (CCW) manually. Observe whether H0b.10 (Electrical angle) increases/decreases smoothly and turning one circle corresponds to five 0-360° (for Z series motor). For X series motors, turning one circle should correspond to four 0-360°. If H0b.10 changes abnormally when you rotate the motor shaft manually, the encoder is faulty. If no warning is reported during rotation but the servo drive reports a warning during operation, disturbance may be present.</p>	
<p>4. The encoder is faulty.</p>	<p>Keep the motor in a certain position, power on the system several times and observe the change of H0b.10 (Electrical angle). The electrical angle deviation should be within <math>\pm 30^\circ</math> when the motor position does not change.</p>	

- E939.0: Motor power cable disconnected

Cause	Confirming Method	Solution
The power cables of all the three phases of the motor are disconnected.	Check the wiring of U/V/W power cables.	1. Check whether the power cables are disconnected or in poor contact. Re-connect the power cables. 2. Replace the servo motor.

- E939.1: Phase-U power cable disconnected

Cause	Confirming Method	Solution
The phase-U power cable of the motor is disconnected.	Check the wiring of the phase-U power cable.	1. Check whether the power cables are disconnected or in poor contact. Re-connect the power cables. 2. Replace the servo motor.

- E939.2: Phase-V power cable disconnected

Cause	Confirming Method	Solution
The phase-V power cable of the motor is disconnected.	Check the wiring of the phase-V power cable.	1. Check whether the power cables are disconnected or in poor contact. Re-connect the power cables. 2. Replace the servo motor.

- E939.3: Phase-W power cable disconnected

Cause	Confirming Method	Solution
The phase-W power cable of the motor is disconnected.	Check the wiring of the phase-W power cable.	1. Check whether the power cables are disconnected or in poor contact. Re-connect the power cables. 2. Replace the servo motor.

- EA33.0: Encoder read/write check error

Cause:

Encoder parameters are abnormal.

Cause	Confirming Method	Solution
1. The serial incremental encoder cable is disconnected or loose.	Check the wiring.	Check for wrong connection, disconnection and poor contact of the encoder cable. Route the motor cable and encoder cable through different routes.
2. An error occurs when reading/writing the serial incremental encoder parameters.	If the fault persists after the servo drive is powered off and on repeatedly, the encoder is faulty.	Replace the servo motor.

- EB00.0: Position deviation too large

Cause:

The position deviation exceeds the setpoint of 6065h in the position control mode.

Cause	Confirming Method	Solution
1. U/V/W phase loss or incorrect phase sequence occurs on the servo drive.	Perform a no-load trial run on the motor and check the wiring.	Connect cables again according to the correct wiring diagram or replace the cables.
2. The servo drive U/V/W cables or the encoder cable is disconnected.	Check the wiring.	Connect the cables again. The servo drive power cables must be connected in the correct sequence at both ends. Replace with new cables if necessary and ensure cables are connected properly.
3. The motor is stalled due to mechanical factors.	Check the reference and motor speed (H0b.00) through the software tool or keypad. <ul style="list-style-type: none"> <li>● References in the position control mode: H0b.13 (Input position reference counter)</li> <li>● References in the speed control mode: H0b.01 (Speed reference)</li> <li>● References in the torque control mode: H0b.02 (Internal torque reference)</li> </ul> Check whether the reference value is not 0 but the motor speed is 0 rpm in the corresponding mode.	Eliminate the mechanical factors.

Cause	Confirming Method	Solution
4. The gain values are too low.	Check the position loop gain and speed loop gain of the servo drive. 1st gain set: H08.00...H08.02 2nd gain set: H08.03...H08.05	Adjust the gain values manually or perform gain auto-tuning.
5. The position reference increment is too large.	Position control mode: <ul style="list-style-type: none"> <li>● In CSP mode, view the gear ratio 6091.01h/6091.02h to determine the position reference increment for an individual synchronization cycle and convert it to the speed information.</li> <li>● In PP mode, view the gear ratio 6091.01h/6091.02h and determine the value of 6081h (Profile velocity).</li> <li>● In HM mode, view the gear ratio 6091.01h/6091.02h, and determine the values of 6099.01h and 6099.02h.</li> </ul>	<ul style="list-style-type: none"> <li>● CSP: Decrease the position reference increment for an individual synchronization cycle. The host controller should handle the position ramp when generating references.</li> <li>● PP: Decrease the value of 6081h or increase the acceleration/deceleration ramp (6083h, 6084h).</li> <li>● HM: Decrease the values of 6099.01h and 6099.02h or increase the acceleration/deceleration ramp (609Ah).</li> <li>● Decrease the gear ratio according to actual conditions.</li> </ul>
6. Given the operating condition, the value of 6065h (Following error window) is too low.	Check whether the setpoint of 6065h is too low.	Increase the setpoint of 6065h.
7. The servo drive/motor is faulty.	Monitor the operating waveforms using the oscilloscope function in the software tool: position reference, position feedback, speed reference, torque reference	If the position reference is not 0 but the position feedback is always 0, replace the servo drive or motor.

- EB00.1: Position deviation overflow

Cause:

Deviation of the position calculated by the servo drive is too large.



Cause	Confirming Method	Solution
1. U/V/W phase loss or incorrect phase sequence occurs on the servo drive.	Perform a no-load trial run on the motor and check the wiring.	Connect cables again according to the correct wiring diagram or replace the cables.
2. The servo drive U/V/W cables or the encoder cable is disconnected.	Check the wiring.	Connect the cables again. The servo drive power cables must be connected in the correct sequence at both ends. Replace with new cables if necessary and ensure cables are connected properly.
3. The motor is stalled due to mechanical factors.	<p>Check the reference and motor speed (H0b.00) through the software tool or keypad.</p> <ul style="list-style-type: none"> <li>● References in the position control mode: H0b.13 (Input position reference counter)</li> <li>● References in the speed control mode: H0b.01 (Speed reference)</li> <li>● References in the torque control mode: H0b.02 (Internal torque reference)</li> </ul> <p>Check whether the reference value is not 0 but the motor speed is 0 rpm in the corresponding mode.</p>	Eliminate the mechanical factors.
4. The gain values are too low.	<p>Check the position loop gain and speed loop gain of the servo drive.</p> <ul style="list-style-type: none"> <li>● 1st gain set: H08.00... H08.02</li> <li>● 2nd gain set: H08.03... H08.05</li> </ul>	Adjust the gain values manually or perform gain auto-tuning.

Cause	Confirming Method	Solution
5. The position reference increment is too large.	<p>Position control mode:</p> <ul style="list-style-type: none"> <li>• In CSP mode, view the gear ratio 6091.01h/6091.02h to determine the position reference increment for an individual synchronization cycle and convert it to the speed information.</li> <li>• In PP mode, view the gear ratio 6091.01h/6091.02h and determine the value of 6081h (Profile velocity).</li> <li>• In HM mode, view the gear ratio 6091.01h/6091.02h, and determine the values of 6099.01h and 6099.02h.</li> </ul>	<ul style="list-style-type: none"> <li>• CSP: Decrease the position reference increment for an individual synchronization cycle. The host controller should handle the position ramp when generating references.</li> <li>• PP: Decrease the value of 6081h or increase the acceleration/deceleration ramp (6083h, 6084h).</li> <li>• HM: Decrease the values of 6099.01h and 6099.02h or increase the acceleration/deceleration ramp (609Ah). Decrease the gear ratio according to actual conditions.</li> </ul>
6. The servo drive/motor is faulty.	Monitor the operation waveform through the oscilloscope function in the software tool: position references, position feedback, speed references, and torque references.	If the position reference is not 0 but the position feedback is always 0, replace the servo drive or motor.

- EB01.0: Position reference increment too large  
Cause:

Cause	Confirming Method	Solution
The pulse reference increment exceeds the excessive reference threshold three times consecutively.	Check whether the baud rate of pulse reference input exceeds H0A.09.	<ol style="list-style-type: none"> <li>1. Increase the value of H0A.09.</li> <li>2. Reduce the baud rate of pulse input.</li> </ol>

- EB01.1: Individual position reference increment too large  
Cause:

The target position increment is too large.

Cause	Confirming Method	Solution
<p>The target position increment is too large.</p>	<p>Check the variation between two adjacent target positions using the software tool.</p>	<ol style="list-style-type: none"> <li>1. Check whether the maximum speed of the motor fulfills the application requirement. If yes, reduce the target position reference increment, which is to lower the profile reference speed. If not, replace the servo motor.</li> <li>2. Before switching the mode or enabling the servo drive, check whether the target position is aligned with current position feedback.</li> <li>3. The communication sequence of the host controller is abnormal, leading to slave data error. Check the communication sequence of the host controller.</li> </ol>

- EB01.2: Position reference increment too large continuously

Cause:

The target position increment is too large.

Cause	Confirming Method	Solution
<p>The target position increment is too large.</p>	<p>Check the variation between two adjacent target positions using the software tool.</p>	<ol style="list-style-type: none"> <li>1. Check whether the maximum speed of the motor fulfills the application requirement. If yes, reduce the target position reference increment, which is to lower the profile reference speed. If not, replace the servo motor.</li> <li>2. Before switching the mode or enabling the servo drive, check whether the target position is aligned with current position feedback.</li> <li>3. The communication sequence of the host controller is abnormal, leading to slave data error. Check the communication sequence of the host controller.</li> </ol>

- EB01.3: Command overflow

Cause:

The target position is still in the process of transmission when the servo limit or software position limit signal is activated and the 32-bit upper/lower limit is reached.

Cause	Confirming Method	Solution
<p>The target position is still in the process of transmission when the servo limit or software position limit signal is activated and the 32-bit upper/lower limit is reached.</p>	<p>Check whether the host controller continues sending commands after overtravel warning is reported by the servo drive.</p>	<ol style="list-style-type: none"> <li>1. Detect the servo limit signal (bit0 and bit1 of 60FDh recommended) through the host controller.</li> <li>2. Stop sending limit direction commands when an active servo limit signal is detected by the host controller.</li> </ol>

- EB01.4: Max. value of single-turn position exceeded in rotation mode

Cause:

The target position exceeds the upper/lower limit of the unit position in the single-turn absolute mode.

Cause	Confirming Method	Solution
The target position exceeds the upper/lower limit of the unit position in the single-turn absolute mode.	Check whether the set target position is within the single-turn upper/lower limit.	Set the target position to a value within the upper/lower limit.

- EB02.0: Excessive position deviation in fully closed-loop mode

Cause:

The absolute value of position deviation in fully closed-loop mode exceeds the value of H0F.08 (Excessive position deviation threshold in fully closed-loop mode).

Cause	Confirming Method	Solution
1. U/V/W phase loss or incorrect phase sequence occurs on the servo drive.	Perform a no-load trial run on the motor and check the wiring.	Connect cables again according to the correct wiring diagram or replace the cables.
2. The servo drive UVW cables or the internal/external encoder cable is disconnected.	Check the wiring.	Connect the cables again. The servo drive power cables must be connected in the correct sequence at both ends. Replace with new cables if necessary and ensure cables are connected properly.
3. The motor is stalled due to mechanical factors.	Check the reference and motor speed (H0b.00) through the software tool or keypad. References in the position control mode: H0b.13 (Input position reference counter) References in the speed control mode: H0b.01 (Speed reference) References in the torque control mode: H0b.02 (Internal torque reference) Check whether the reference value is not 0 but the motor speed is 0 rpm in the corresponding mode.	Eliminate the mechanical factors.

Cause	Confirming Method	Solution
4. The gain values are too low.	Check the position loop gain and speed loop gain of the servo drive. 1st gain set: H08.00...H08.02 2nd gain set: H08.03...H08.05	Adjust the gain values manually or use gain auto-tuning.
5. The input pulse frequency is high.	When the position reference source is pulse reference, check whether the input pulse frequency is too high or whether the acceleration/deceleration time is set to 0 or an excessively low value.	Reduce the position reference frequency or the electronic gear ratio. If position pulses are outputted through the host controller, you can set the acceleration/deceleration time through the host controller directly. If not, increase the values of H05.04 and H05.06.
6. The value of H0F.08 (Threshold of excessive position deviation) is too low under current operating conditions.	Check whether the value of H0F.08 is too low.	Increase the setpoint of H0F.08.
7. The servo drive/motor is faulty.	Monitor the operation waveform through the oscilloscope function in the software tool: position references, position feedback, speed references, and torque references.	If the position reference is not 0 but the position feedback is always 0, replace the servo drive or motor.

- EB03.0: Electronic gear ratio beyond the limit - H05.02

Cause:

The electronic gear ratio (H05.02) exceeds the following limit:  $(0.001 \times \text{Encoder resolution}/10000, 4000 \times \text{Encoder resolution}/10000)$ .

Cause	Confirming Method	Solution
The electronic gear ratio converted by H05.02 is higher than the maximum value of the gear ratio or is lower than the minimum value of the gear ratio.	Check whether the electronic gear ratio converted by H05.02 is within the range of $0.001$ to $4000 \times \text{Encoder resolution}/10000$ .	Adjust the value of H05.02.

- EB03.1: Electronic gear ratio beyond the limit - Electronic gear ratio 1

Cause:

The electronic gear ratio 1 exceeds the following limit:  $(0.001 \times \text{Encoder resolution}/10000, 4000 \times \text{Encoder resolution}/10000)$ .

Cause	Confirming Method	Solution
The electronic gear ratio 1 is higher than the maximum value of the gear ratio or is lower than the minimum value of the gear ratio.	Check whether the electronic gear ratio 1 is within the range of 0.001 to 4000 x Encoder resolution/10000.	Adjust electronic gear ratio 1 (H05.07/H05.09).

- EB03.2: Electronic gear ratio beyond the limit - Electronic gear ratio 2

Cause:

The electronic gear ratio 2 exceeds the following limit: (0.001 x Encoder resolution/10000, 4000 x Encoder resolution/10000).

Cause	Confirming Method	Solution
The electronic gear ratio 2 is higher than the maximum value of the gear ratio or is lower than the minimum value of the gear ratio.	Check whether the electronic gear ratio 2 is within the range of 0.001 to 4000 x Encoder resolution/10000.	Adjust electronic gear ratio 2(H05.11/H05.13).

- EE08.0: Synchronization (SYNC) signal loss

Cause:

The SYNC signal is turned off when the EtherCAT network is in the OP state.

Cause	Confirming Method	Solution
The SYNC signal is not generated due to hardware errors.	Check whether the SYNC signal cycle is 0 using the oscilloscope in the software tool.	Replace the servo drive. Contact Inovance for maintenance.

- EE08.1: Network status switchover error

Cause:

When the servo drive is enabled, the EtherCAT network status switches from OP to other status.

Cause	Confirming Method	Solution
This fault is caused by mal-operation of the master or the operator.	Check whether the master switches the network status when the servo drive is enabled.	Check the network status switchover program of the host controller.

- EE08.3: Network cable connected improperly

Cause:

The network cable of the servo drive is connected improperly. (The low 16 bits of H0E.29 represents the number of IN port loss events. The high 16 bits of H0E.29 represents the number of OUT port loss events.)

Cause	Confirming Method	Solution
The physical connection of the data link is unstable or the process data is lost due to plug-in/plug-out of the network cable.	Check: (1) whether the network cable of the servo drive is connected securely; (2) whether strong vibration occurs on site; (3) whether the network cable is plugged in or out; and (4) whether the network cable designated by Inovance is used.	Check the connection of the network port through the value change of H0E.29. Replace with a new network cable.

- EE08.4 Data frame loss protection error

Cause:

The PDO data is corrupted due to EMC interference or inferior network cable.

Cause	Confirming Method	Solution
The data is lost due to EMC interference, poor quality of the network cable or improper connection.	Check whether the high 16 bits of H0E.25 have values that are increased.	<ul style="list-style-type: none"> <li>● Check whether the servo drive is grounded properly, and rectify the EMC problem.</li> <li>● Check whether the network cable used is the one designated by Inovance.</li> <li>● Check whether the network cable is connected properly.</li> </ul>

- EE08.5: Data frame transfer error

Cause:

The upstream slave detects that the data frame has been corrupted and marked, which is then transferred to the downstream slave, leading to a warning event.

Cause	Confirming Method	Solution
The upstream station detects that the data frame has been corrupted and marked, which is then transferred to the slave, leading to a warning report.	Check whether a processing unit error occurs due to transfer error (H0E.27) or invalid frames (H0E.28) upon occurrence of the fault, and check whether no counting is performed in RX-ERR of Port0.	Check the upstream slave to locate the fault cause.

- EE08.6: Data update timeout

Cause:

The slave is in the OP status and does not receive the data frame in a long time.



Cause	Confirming Method	Solution
The data frame is lost or aborted in the upstream slave or the master performance is not up to standard.	Check through the software tool whether the phase difference between SYNC and IRQ exceeds the value of H0E.22 multiplied by the communication cycle.	<ul style="list-style-type: none"> <li>• Check whether the operating load of the master CPU is excessive. Increase the communication time or set H0E.22 to a large value.</li> <li>• Check whether link loss occurs on the upstream slave.</li> </ul>

- EE09.0: Software position limit setting error

Cause:

The lower limit of the software limit is equal to or larger than the upper limit.

Cause	Confirming Method	Solution
The lower limit of the software position limit is equal to or larger than the upper limit.	Check the values of 607D.01h and 607D.02h.	Reset the values of 607D-01h and 607D-02h and ensure the former is lower than the latter.

- EE09.1: Home setting error

Cause:

The home offset exceeds the upper/lower limit.

Cause	Confirming Method	Solution
1. The home offset is outside the software position limit.	The home offset is outside the software position limit when the encoder works in the incremental mode, absolute linear mode, and single-turn absolute mode.	Set the home offset to a value within the software position limit.
2. The home offset is beyond the upper/lower limit in the rotation mode.	The home offset is outside the mechanical single-turn upper/lower limit when the encoder works in the rotation mode.	Set the home offset to a value within the mechanical single-turn upper/lower limit.

- EE09.2: Gear ratio beyond the limit

Cause:

The electronic gear ratio exceeds the limit:  $(0.001, 4000 \times \text{Encoder resolution} / 10000)$ .

Cause	Confirming Method	Solution
The set electronic gear ratio exceeds the preceding range.	Check whether the ratio of 6091.01h to 6091.02h exceeds the preceding range.	Set the gear ratio according to the preceding range.

- EE09.3: No synchronization signal

Cause:

The MCU does not receive the synchronization signal when the servo communication is switched to OP status.

Cause	Confirming Method	Solution
1. The communication synchronization clock is configured improperly.	Replace with another master (such as Beckhoff or Omron PLC) and perform tests to compare between different masters.	Rectify improper configurations.
2. The IN/OUT port of EtherCAT communication is connected reversely.	Check whether the IN/OUT port is connected reversely.	Connect the IN and OUT ports in the correct sequence.
3. The slave controller integrated circuit is damaged.	If the fault persists after the master is replaced, measure the synchronization signal generated by the slave controller integrated circuit with an oscilloscope. If there is no signal, the slave controller integrated circuit is damaged.	Contact Inovance for replacing the slave controller integrated circuit.
4. The MCU pins are damaged.	Test the synchronization signal generated by the slave controller integrated circuit with an oscilloscope. If there is a signal, the pins of the MCU integrated circuit are damaged.	Contact Inovance for replacing the MCU integrated circuit.

- EE09.5: PDO mapping beyond the limit

Cause:

The number of the mapping objects in TPDO or RPDO exceeds 10.

Cause	Confirming Method	Solution
The number of mapping objects in TPDO or RPDO exceeds 10.	Check the number of self-indexes configured in 1600h or 1A00h.	The number of mapping objects in TPDO or RPDO cannot exceed 10.

- EE10.0: Mailbox setting error protection

Cause	Confirming Method	Solution
1. The master is configured improperly. 2. The XML file of the slave is wrong.	The keypad displays the fault code.	Ensure SM0 and SM1 are configured properly.

- EE10.1: SM2 configuration error

Cause:

- The index of the object dictionary mapped by PDO exceeds the maximum value (0x1600-0x170A).
- The length of SM and RxPDO is not 0 when SM2 is not enabled.
- The length of RxPDO does not match.
- SM2 is configured as the read direction.
- The address of RxPDO in the pre-operational state is not in the set address field (maximum address, minimum address) or the address of SM2 is the same as the starting address of RxPDO when the pre-operational state does not apply.
- The memory of SM2 overlaps with adjacent SM1 or SM3.

Cause	Confirming Method	Solution
1. The master is configured improperly. 2. The XML file of the slave is wrong.	Check whether SM2 channel is configured improperly. Check whether the index of the object dictionary mapped by RxPDO exceeds the limit (maximum index being 0x0A).	Ensure SM2 channel is configured correctly. Ensure the index of the object dictionary mapped by RxPDO is correct.

- EE10.2: SM3 configuration error

Cause:

- The index of the object dictionary mapped by PDO exceeds the maximum value (0x1A00-0x1B0A).
- The length of SM and TxPDO is not 0 when SM3 is not enabled.
- The length of TxPDO does not match.
- SM2 is configured as the write direction.
- The address of TxPDO in the pre-operational state is not in the set address field (maximum address, minimum address) or the address of SM3 is the same as the starting address of TxPDO when the pre-operational state does not apply.
- The buffer is beyond the limit (The memory of SM2 overlaps with SM3, SM0, or SM1).

Cause	Confirming Method	Solution
1. The master is configured improperly. 2. The XML file of the slave is wrong.	Check whether SM3 channel is configured improperly. Check whether the index of the object dictionary mapped by TxPDO exceeds the limit (maximum index being 0x1A).	Ensure SM3 channel is configured correctly. Ensure the index of the object dictionary mapped by TxPDO is correct.

- EE10.3: PDO watchdog setting error

Cause:

Cause	Confirming Method	Solution
<ol style="list-style-type: none"> <li>1. The watchdog is enabled but the counting value is 0.</li> <li>2. The watchdog is not enabled but the counting value is not 0.</li> </ol>	The master is configured improperly.	Ensure the watchdog is configured properly.

- EE10.4: PLL error protection not completed (no sync signal)

Cause:

Cause	Confirming Method	Solution
The distributed clock is enabled but not operating during SAFEOP_2_OP.	The master is configured improperly.	Ensure the sync0 signal is generated.

- EE11.0: ESI check error

Cause:

The attempt to load the XML file fails during EtherCAT communication.

Cause	Confirming Method	Solution
<ol style="list-style-type: none"> <li>1. The XML file is not programmed in the EEPROM.</li> <li>2. The XML file in the EEPROM is modified unexpectedly.</li> </ol>	Check whether the XML version displayed in H0E.96 is normal.	Program the XML file.

- EE11.1: EEPROM cannot be read by the bus

Cause:

The EEPROM communication of external EtherCAT devices fails.

Cause	Confirming Method	Solution
The EtherCAT data in the EEPROM cannot be read	This fault persists after the servo drive is powered off and on several times.	Replace the servo drive.

- EE11.3: ESI and drive model mismatch

Cause	Confirming Method	Solution
<ol style="list-style-type: none"> <li>1. The XML file programmed does not match the drive model.</li> <li>2. The servo drive is faulty and the XML file is modified unexpectedly.</li> </ol>	Check whether the XML version displayed in H0E.96 is correct.	Program the XML file.

- EE12.0: EtherCAT initialization failure

Cause:

Cause	Confirming Method	Solution
1. The device configuration file is not programmed.	The slave ID is null when the host controller scans the slave.	Program the device configuration file.
2. The servo drive is faulty.	The servo drive is faulty.	Replace the servo drive.

- EE13.0: Synchronization cycle setting error

Cause:

The synchronization cycle is not an integer multiple of 125 us or 250 us after the network switches to the OP mode.

Cause	Confirming Method	Solution
The synchronization cycle is not an integer multiple of 125 us or 250 us.	Check the setting of the synchronization cycle in the controller.	Set the synchronization cycle to an integer multiple of 125 us or 250 us.

- EE15.0: Synchronization cycle error too large

Cause:

The synchronization cycle error exceeds the threshold.

Cause	Confirming Method	Solution
The synchronization cycle error of the controller is too large.	<ul style="list-style-type: none"> <li>● Measure the synchronization cycle of the controller.</li> <li>● Measure the synchronization cycle of the controller using a digital oscilloscope or the oscilloscope function in the software tool.</li> <li>●</li> </ul>	Increase the value of H0E.32.

---

## Note

You can clear the fault or restart the power supply 30s after overload occurs.

---

- EE16.0: MCU and ESC communication error

Cause	Confirming Method	Solution
Communication between MCU and ESC times out.	The fault persists after the servo drive is powered off and on several times.	Replace the servo drive.

### 3.4 Solutions to Warnings

- E108.0: Parameter write error

Cause:

Parameter values cannot be written to EEPROM.

Cause	Confirming Method	Solution
An error occurs during parameter-writing.	Modify a certain parameter, power off and on the servo drive again and check whether the modification is saved.	If the modification is not saved and the fault persists after the servo drive is powered off and on repeatedly, replace the servo drive.

- E108.1: Parameter read error

Cause:

Parameter values cannot be read in EEPROM.

Cause	Confirming Method	Solution
The parameter-read operation is abnormal, and the system indicates an EEPROM read failure.	Modify a certain parameter, power off and on the servo drive again and check whether the modification is saved.	If the modification is not saved and the fault persists after the servo drive is powered off and on repeatedly, replace the servo drive.

- E108.2: Check on data written in EEPROM failed

Cause:

The check on the data written in EEPROM fails.

Cause	Confirming Method	Solution
An error occurs during parameter-writing.	Modify a certain parameter, power off and on the servo drive again and check whether the modification is saved.	If the modification is not saved and the fault persists after the servo drive is powered off and on repeatedly, replace the servo drive.

- E108.3: Check on data read in EEPROM failed

Cause:

The check on the data read in EEPROM fails.

Cause	Confirming Method	Solution
An error occurs during parameter-reading.	Modify a certain parameter, power off and on the servo drive again and check whether the modification is saved.	If the modification is not saved and the fault persists after the servo drive is powered off and on repeatedly, replace the servo drive.

- E110.0: Frequency-division pulse output setting error

Cause	Confirming Method	Solution
The number of frequency-division pulses (frequency quadrupled) exceeds the motor resolution.	Check the setpoint of H05.17.	Adjust the setpoint of H05.17 based on the motor resolution.

- E121.0: Invalid S-ON command

Cause:

A redundant S-ON signal is sent when some auxiliary functions are used.

Cause	Confirming Method	Solution
The external S-ON signal is active when servo drive is enabled internally.	Check whether the following auxiliary functions are used: Check whether auxiliary functions (H0d.02, H0d.03, and H0d.12) are used and whether FunIN.1 (S-ON signal) is active.	Deactivate the DI assigned with FunIN.1 (both hardware DI and virtual DI).

- E510.0: Frequency-division output overspeed

Cause:

The output pulse frequency exceeds the frequency upper limit allowed by the hardware (8 MHz) when pulse output is used (H05.38 = 0 or 1).

Cause	Confirming Method	Solution
<p>The MCU detects excessive pulse increment fed back by FPGA.</p>	<p>When H05.38 is set to 0 (Encoder frequency-division output), check whether the output pulse frequency corresponding to the motor speed upon fault exceeds the limit.            Output pulse frequency (Hz) = Motor speed (rpm)/60 x H05.17</p>	<p>Decrease the value of H05.17 (Encoder frequency-division pulses) to allow the output pulse frequency, within the speed range required by the machine, to drop below the frequency upper limit allowed by the hardware.</p>
	<p>The input pulse frequency exceeds 2 MHz or interference exists in the pulse input pins when H05.38 is set to 1 (Reference pulse synchronous output).</p> <ul style="list-style-type: none"> <li>● Low-speed pulse input pins: open-collector input terminals: PULLHI, PULSE+, PULSE-, SIGN+, SIGN-; maximum pulse frequency: 200 kpps</li> <li>● High-speed pulse input pins: differential input terminals: HPULSE+, HPULSE-, HSIGN+, HSIGN-; maximum pulse frequency: 8 Mpps</li> </ul>	<p>Decrease the input pulse frequency to a value within the frequency upper limit allowed by hardware.</p> <p><b>Note:</b>            In this case, if you do not modify the electronic gear ratio, the motor speed will be reduced.            If the input pulse frequency is high but is still within the frequency upper limit allowed by the hardware, take anti-interference measures (use STP cable for pulse input and set pin filter parameter H0A.24 or H0A.30). This is to prevent false warnings caused by interference pulses superimposed to actual pulse references.</p>

● E600.0: Inertia auto-tuning failure

Cause:

Vibration cannot be suppressed. You can set notch parameters (H09.12...H09.23) manually to suppress vibration.

The auto-tuned values fluctuate dramatically. Increase the maximum operating speed, reduce the acceleration/deceleration time, and shorten the stroke of the lead screw during ETune operation.

Mechanical couplings of the load are loose or eccentric. Rectify the mechanical faults.

A warning occurs during auto-tuning and causes interruption. Rectify the fault causes and perform inertia auto-tuning again.



The vibration cannot be suppressed if the load carries a large inertia. In this case, increase the acceleration/deceleration time first to ensure the motor current is unsaturated.

Cause	Confirming Method	Solution
<ol style="list-style-type: none"> <li>1. Continuous vibration occurs during auto-tuning.</li> <li>2. The auto-tuned values fluctuate dramatically.</li> <li>3. Mechanical couplings of the load are loose or eccentric.</li> <li>4. A warning occurs during auto-tuning and causes interruption.</li> <li>5. The vibration cannot be suppressed if the load carries a large inertia. In this case, increase the acceleration/deceleration time first to ensure the motor current is unsaturated.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform internal inspection to check whether the torque jitters upon stop (not FFT). Check whether Three times more than the last auto-tuned value for variation less than 5 times; 0.5 times more than last auto-tuned value for variation above 5 times</li> </ol>	<ol style="list-style-type: none"> <li>1. Rectify the fault and perform inertia auto-tuning again.</li> <li>2. For vibration that cannot be suppressed, enable vibration suppression.</li> <li>3. Ensure mechanical couplings are connected securely.</li> <li>4. Increase the maximum operating speed, reduce the acceleration/ deceleration time, and shorten the stroke of the lead screw during ETune operation.</li> </ol>

- E601.0: Homing warning  
Cause:

Cause	Confirming Method	Solution
1. The home switch is faulty.	There is only high-speed searching but no low-speed searching during homing. After high-speed searching, low-speed searching in the reverse direction applies.	If a hardware DI is used, check whether the corresponding DI function is allocated to a certain DI in group 2003h and check the wiring of this DI. Change the DI logic manually and observe the value of H0b.03 to monitor whether the servo drive receives corresponding DI level changes. If the home signal is Z signal and the home signal cannot be found, check the condition of the Z signal.
2. The time limit for homing is too short.	Check whether the value of H05.35 (Homing time limit) is too small.	Increase the value of H05.35.
3. The speed in high-speed searching for the home switch signal is too low.	Check the distance between the initial position of homing and the home switch. Then check whether the value defined by 6099.01h is too small, resulting in a long homing process.	Increase the value of 6099.01h.

- E601.1: Homing switch error

Cause:

The homing switch is set improperly.

Cause	Confirming Method	Solution
The home switch is set improperly.	Check whether the limit signals at both sides are activated. Check whether the limit signal and the deceleration point signal/home signal are both activated. Check whether the positive and negative position limits are activated successively.	Set the position of the physical switch properly.

- E601.2: Homing mode setting error

Cause:

The setpoint of homing method exceeds the existing homing method.

Cause	Confirming Method	Solution
The setpoint of homing method exceeds the existing homing method.	Check the setpoint of 6098h.	Adjust the setpoint of 6098h.

- E631.4: P-Mos short circuit

Cause:

The brake circuit is faulty.

Cause	Confirming Method	Solution
The brake circuit P-MOS is short-circuited when the brake function is used.	The brake is wired properly but the fault persists after the servo drive is powered off and on again.	1. Replace the servo drive. 2. Turn off the brake switch (H02.16).

- E631.5: N-Mos short circuit

Cause:

The brake circuit is faulty.

原因	确认方法	处理措施
The brake circuit N-MOS is short-circuited when the brake function is used.	The brake is wired properly but the fault persists after the servo drive is powered off and on again.	1. Replace the servo drive. 2. Turn off the brake switch (H02.16).

- E730.0: Encoder battery warning

Cause:

The voltage of the absolute encoder battery is lower than 3.0V.

Cause	Confirming Method	Solution
The voltage of the absolute encoder battery is lower than 3.0 V.	Measure the battery voltage.	Use a new battery with the matching voltage.

## Note

E731.0 and E733.0 can trigger E730.0. See E731.0 and E733.0 for other solutions.

- E730.1: 2nd encoder battery voltage too low

Cause:

The battery voltage of Inovance 2nd encoder is lower than 3.0 V.

Cause	Confirming Method	Solution
The battery voltage of Inovance 2nd encoder is too low.	Measure the battery voltage.	Replace with a new battery of matching voltage.

- E831.0: AI1 zero offset too large

Cause	Confirming Method	Solution
1. The wiring is incorrect or interference exists.	Check the wiring according to the correct wiring diagram.	Use shielded twisted pairs and shorten the circuit length. Increase AI1 input filter time.
2. The servo drive is faulty.	Disconnect AI1 and measure whether the actual terminal voltage exceeds 0.5 V.	If not, replace the servo drive.

- E834.2: AI1 overvoltage

Cause	Confirming Method	Solution
1. The wiring is incorrect or interference exists.	Check the wiring according to the correct wiring diagram	Use shielded twisted pairs and shorten the circuit length. Increase AI1 input filter time.
2. The input voltage is too high.	Measure whether the actual terminal voltage exceeds 11.5 V.	Adjust the input voltage to a value lower than 11.5 V.

- E834.2: AI2 input current too high

Cause	Confirming Method	Solution
1. The wiring is incorrect or interference exists.	Check the wiring according to the correct wiring diagram	Use shielded twisted pairs and shorten the circuit length. Increase AI2 input filter time.
2. The input current is too high.	View the current value displayed in H0b.22.	Adjust the input current to a value lower than 21 mA.

- E900.0: DI emergency braking

Cause:

The logic of the DI (hardware DI or virtual DI) assigned with FunIN.34 (EmergencyStop) is active.

Cause	Confirming Method	Solution
FunIN.34 (EmergencyStop) is triggered.	Check whether the logic of the DI assigned with FunIN.34 (EmergencyStop) is active.	Check the operation mode and clear the active DI braking signal without affecting the safety performance.

- E902.0: DI setting invalid

Cause:

DI function parameters are set to invalid values.

Cause	Confirming Method	Solution
DI (DI1...DI5) function parameters are set to invalid values.	Check whether H03.02, H03.04, H03.06, H03.08, and H03.10 are set to invalid values.	Set DI function parameters to valid values.

- E902.1: DO setting invalid  
Cause:

DO function parameters are set to invalid values.

Cause	Confirming Method	Solution
DO (DO1 and DO2) function parameters are set to invalid values.	Check whether H04.00 and H04.02 are set to invalid values.	Set DO function parameters to valid values.

- E902.2: Invalid setting for torque reach  
Cause:

The DO parameters set for torque reach in the torque control mode are invalid.

Cause	Confirming Method	Solution
The DO parameters set for torque reach in the torque control mode are invalid.	Check whether the value of H07.22 is lower than or equal to the value of H07.23 (unit: 0.1%).	Set H07.22 to a value higher than that of H07.23.

- E908.0: Model identification failure

Cause	Confirming Method	Solution
1. The model identification check word saved in EEPROM is wrong.	1. Check whether the warning persists after restart.	Set H01.72 to 1 to hide model identification temporarily.
2. The model parameters are not programmed before delivery.	2. Check whether parameters can be saved to EEPROM properly.	

- E909.0: Motor overload warning  
Cause:

The accumulative heat of the motor reaches the warning threshold (90% of the maximum allowable heat).

Cause	Confirming Method	Solution
1. The motor cables and encoder cable are connected improperly or in poor contact.	Check the wiring among the servo drive, servo motor and the encoder according to the correct wiring diagram.	Connect cables according to the correct wiring diagram. It is recommended to use the cables provided by Inovance. When customized cables are used, prepare and connect the customized cables according to the wiring instructions.
2. The load is so heavy that the effective torque outputted by the motor keeps exceeding the rated torque.	Confirm the overload characteristics of the servo drive or motor. Check whether the average load rate (H0b.12) keeps exceeding 100.0%.	Replace with a servo drive of higher capacity and a matching servo motor. Reduce the load and increase the acceleration/ deceleration time.
3. Acceleration/Deceleration is too frequent or the load inertia is too large.	Check the mechanical inertia ratio or perform inertia auto-tuning. View the value of H08.15 (Load moment of inertia ratio). Confirm the individual operation cycle when the servo motor operates cyclically.	Increase the acceleration/ deceleration time.
4. The gain values are improper or the stiffness level is too high.	Check whether the motor vibrates and generates unusual noise during operation.	Adjust the gains again.
5. The model of the servo drive or motor is set improperly.	View the model of the motor equipped with a serial-type encoder in H00.05 and the servo drive model in H01.10.	Read the servo drive nameplate and set the servo drive model (H01.10) and motor model properly according to section "Servo Drive Model and Nameplate" in SV680N Series Servo Drive Selection Guide.

Cause	Confirming Method	Solution
<p>6. The motor is stalled due to mechanical factors, resulting in overload during operation.</p>	<p>Check the reference and the motor speed (H0b.00) through the software tool or the keypad.</p> <ul style="list-style-type: none"> <li>● References in the position control mode: H0b.13 (Input position reference counter)</li> <li>● References in the speed control mode: H0b.01 (Speed reference)</li> <li>● References in the torque control mode: H0b.02 (Internal torque reference)</li> </ul> <p>Check whether the reference value is not 0 or is very large but the motor speed is 0 RPM in the corresponding mode.</p>	<p>Eliminate the mechanical factors.</p>
<p>7. The servo drive is faulty.</p>	<p>Power off and on the servo drive again.</p>	<p>Replace the servo drive if the fault persists after the servo drive is powered off and on again.</p>

- E910.0: Control circuit overvoltage

Cause	Confirming Method	Solution
<p>The voltage of the control circuit in the servo drive exceeds the overvoltage threshold.</p>	<ol style="list-style-type: none"> <li>1. Measure whether the input voltage on the control circuit side is within the following range: 220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: -10% to +10% (198 V to 264 V) 380 V servo drive: Effective value: 380 V to 440 V Allowable deviation: -10% to +10% (342 V to 484 V)</li> <li>2. Check whether control circuit cables are connected properly and whether the voltage of control circuit cables (L1C, L2C) is within the specified range.</li> </ol>	<p>Re-connect or replace the cables.</p>

- E920.0: Regenerative resistor overload

Cause:

The accumulative heat of the regenerative resistor exceeds the set value.

Cause	Confirming Method	Solution
<p>1. The external regenerative resistor is connected improperly or disconnected.</p>	<p>Remove the external regenerative resistor and measure whether its resistance is "<math>\infty</math>" (infinite). Measure whether the resistance between terminals P<math>\oplus</math> and C is "<math>\infty</math>" (infinite).</p>	<p>Replace with a new external regenerative resistor. After confirming the resistance measured is the same as the nominal value, connect it between terminals P<math>\oplus</math> and C.</p> <p>Connect the external regenerative resistor between terminals P<math>\oplus</math> and C with a proper cable.</p>
<p>2. The jumper between terminals P<math>\oplus</math> and D is shorted or disconnected when the built-in regenerative resistor is used.</p>	<p>Measure whether the resistance between terminals P<math>\oplus</math> and D is "<math>\infty</math>" (infinite).</p>	<p>Ensure terminals P<math>\oplus</math> and D are jumpered.</p>



Cause	Confirming Method	Solution
<p>3. H02.25 (Regenerative resistor type) is set improperly when an external regenerative resistor is used.</p>	<ul style="list-style-type: none"> <li>● View the setpoint of H02.25.</li> <li>● Measure the resistance of the external regenerative resistor connected between P⊕ and C. Check whether the resistance measured is too large by comparing it with the value listed in Table "Specifications of the regenerative resistor".</li> </ul>	<p>Set H02.25 according to section "Wiring and Setting of Regenerative Resistor" in SV680N Series Servo Drive Hardware Guide.                      H02.25 = 1 (external, naturally ventilated)                      H02.25 = 2 (external, forced-air cooling)</p>
<p>4. The resistance of the external regenerative resistor is too large.</p>	<ul style="list-style-type: none"> <li>● Check whether the value of H02.27 is larger than the resistance of the external regenerative resistor connected between terminals P⊕ and C.</li> </ul>	<p>Select a proper regenerative resistor according to section "Specifications of the Regenerative Resistor" in SV680N Series Servo Drive Commissioning Guide.</p>
<p>5. The setpoint of H02.27 (Resistance of external regenerative resistor) is higher than the resistance of the external regenerative resistor used.</p>		<p>Set H02.27 according to the resistance of the external regenerative resistor used.</p>
<p>6. The input voltage of the main circuit is beyond the specified range.</p>	<p>Check whether the input voltage of the main circuit cable on the drive side is within the following range:</p> <ul style="list-style-type: none"> <li>● 220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: – 10% to +10% (198 V to 264 V)</li> <li>● 380 V servo drive: Effective value: 380 V to 440 V Allowable deviation: – 10% to +10% (342 V to 484 V)</li> </ul>	<p>Replace or adjust the power supply according to the specified range.</p>

Cause	Confirming Method	Solution
7. The load moment of inertia ratio is too large.	Perform moment of inertia auto-tuning according to section "Inertia auto-tuning" in SV680N Series Servo Drive Function Guide or calculate the total mechanical inertia based on mechanical parameters. Check whether the actual load inertia ratio exceeds 30.	<ul style="list-style-type: none"> <li>• Select an external regenerative resistor with large capacity and set H02.26 to a value consistent with the actual power.</li> <li>• Select a servo drive with large capacity.</li> <li>• Reduce the load if allowed.</li> <li>• Increase the acceleration/ deceleration time if allowed.</li> <li>• Increase the motor operation cycle if allowed.</li> </ul>
8. The motor speed is excessively high and deceleration is not done within the set time. The motor is in the continuous deceleration status during cyclic operation.	View the motor speed curve during cyclic operation and check whether the motor is in the deceleration status continuously.	
9. The capacity of the servo drive or the regenerative resistor is insufficient.	View the motor speed curve in an individual cycle and calculate whether the maximum braking energy can be absorbed completely.	
10. The servo drive is faulty.	-	Replace with a new servo drive.

- E922.0: Resistance of the external regenerative resistor too small

Cause:

The value of H02.27 (Resistance of external regenerative resistor) is lower than the value of H02.21 (Permissible minimum resistance of external regenerative resistor).

Cause	Confirming Method	Solution
When an external regenerative resistor is used (H02.25 = 1 or 2), the resistance of this resistor is lower than the minimum resistance allowed by the servo drive.	Measure whether the resistance of the external regenerative resistor between terminals P⊕ and C is lower than the value of H02.21 (Permissible minimum resistance of regenerative resistor).	<ul style="list-style-type: none"> <li>• If yes, replace with an external regenerative resistor that matches the servo drive, then set H02.27 according to the resistance of the resistor used. Finally, connect the new resistor between P⊕ and C.</li> <li>• If not, set H02.27 to a value consistent with the resistance of the external regenerative resistor used.</li> </ul>

- E924.0: Regenerative transistor overtemperature

Cause:

The estimated temperature of the regenerative transistor is higher than H0A.18 (IGBT overtemperature threshold).

Cause	Confirming Method	Solution
1. The junction temperature of the regenerative transistor is too high. 2. The regenerative transistor will be turned off automatically after overload occurs.	The regenerative transistor temperature exceeds the threshold defined by H0A.49.	Control the working conditions and usage of the regenerative transistor.

- E941.0: Parameter modifications activated at next power-on

Cause:

The parameters modified are those whose "Effective time" is "Next power-on".

Cause	Confirming Method	Solution
The parameters modified are those whose "Effective time" is "Next power-on".	Check whether parameters you modified are those whose "Effective Time" is "Next power-on".	Power off and on the servo drive again.

- E942.0: Parameter saved frequently

Cause:

The number of parameters modified at a time exceeds 200.

Cause	Confirming Method	Solution
Too many parameters are modified and saved to EEPROM (H0C.13 = 1) at a brief interval.	Check whether parameters are modified through the host controller at a brief interval.	Check the operation mode. For parameters that need not be saved to EEPROM, set H0C.13 to 0.

- E950.0: Forward overtravel warning

Cause:

The logic of DI assigned with FunIN.14 (P-OT, positive limit switch) is active.

Cause	Confirming Method	Solution
1. The logic of the DI assigned with FunIN.14 (P-OT, positive limit switch) is active.	<ul style="list-style-type: none"> <li>• Check whether a certain DI in group H03 is assigned with FunIN.14.</li> <li>• Check whether the logic of DI corresponding to the bit of H0b.03 (Monitored DI status) is active.</li> </ul>	Check the operation mode and on the prerequisite of ensuring safety, send a reverse run command or rotate the motor to deactivate the logic of the DI assigned with FunIN.14.
2. The servo drive position feedback reaches the positive software position limit.	Check whether the position feedback (H0b.17) is close to the value of H0A.41 (Forward overtravel). Check whether the software position limit is set in H0A.40.	Ensure the servo drive references are proper, allowing the load travel range to be within the software position limit.

- E952.0: Reverse overtravel warning  
Cause:

The logic of the DI assigned with FunIN.15 (N-OT, negative limit switch) is active.

Cause	Confirming Method	Solution
1. The logic of the DI assigned with FunIN.15 (N-OT, negative limit switch) is active	<ul style="list-style-type: none"> <li>• Check whether a certain DI in group H03 is assigned with FunIN.15.</li> <li>• Check whether the logic of DI corresponding to the bit of H0b.03 (Monitored DI status) is active.</li> </ul>	Check the operation mode. On the prerequisite of ensuring safety, send a forward run command or rotate the motor to deactivate the logic of DI assigned with FunIN.15.
2. The servo drive position feedback reaches the negative software position limit	Check whether the position feedback (H0b.17) is close to the value of H0A.43 (Reverse overtravel). Check whether the software position limit is set in H0A.40.	Ensure the servo drive references are proper, allowing the load travel range to be within the software position limit.

- E954.0: Position reference overflow

Cause	Confirming Method	Solution
The position reference exceeds the limit in the PR mode.	<ol style="list-style-type: none"> <li>1. Check the set position reference.</li> <li>2. Check the set limit value.</li> </ol>	Modify the position reference and limit value.

- E971.0: Undervoltage warning of voltage drop protection

Cause	Confirming Method	Solution
The bus voltage is lower than the undervoltage threshold when voltage drop protection is enabled.	Check the bus voltage.	Check the quality of the mains power supply.

- E980.0: Encoder algorithm error

Cause:

An encoder algorithm error occurs.

Cause	Confirming Method	Solution
An encoder fault occurs.	If the servo drive is powered off and on several times but the warning is still reported, it indicates that the encoder is faulty.	Replace the servo motor.

- EA41.0: Torque fluctuation compensation failure

Cause	Confirming Method	Solution
The torque compensation fails.	-	Turn off the torque fluctuation compensation function.

### 3.5 Internal Faults

When any one of the following fault occurs, contact Inovance for technical support.

- E111.0: Internal parameter error
- E602.0: Angle auto-tuning failure
- E220.0: Phase sequence incorrect
- EA40.0: Parameter auto-tuning failure

## 4 List of Parameters

### 4.1 Parameter Group H00

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H00.00	0x0000	Motor code	0 to 65535	14102	-	At stop	<a href="#">"H00.00" on page 254</a>
H00.02	0x0002	Customized No.	0.00 to 4294967295.00	0	-	Unchangeable	<a href="#">"H00.02" on page 254</a>
H00.04	0x0004	Encoder version	0.0 to 6553.5	0	-	Unchangeable	<a href="#">"H00.04" on page 254</a>
H00.05	0x0005	Serial-type motor code	0 to 65535	0	-	Unchangeable	<a href="#">"H00.05" on page 254</a>
H00.06	0x0006	Customized FPGA No.	0.00 to 655.35	0	-	Unchangeable	<a href="#">"H00.06" on page 255</a>
H00.07	0x0007	STO version	0.00 to 655.35	0	-	Unchangeable	<a href="#">"H00.07" on page 255</a>
H00.08	0x0008	Serial encoder type	0 to 65535	0	-	At stop	<a href="#">"H00.08" on page 255</a>

### 4.2 Parameter Group H01

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H01.00	0x0100	MCU software version	0.0 to 6553.5	0	-	Unchangeable	<a href="#">"H01.00" on page 256</a>
H01.01	0x0101	FPGA software version	0.0 to 6553.5	0	-	Unchangeable	<a href="#">"H01.01" on page 256</a>
H01.02	0x0102	Servo drive series No.	0 to 65535	0	-	Unchangeable	<a href="#">"H01.02" on page 256</a>
H01.06	0x0106	Board software version	0.0 tp 6553.5	0	-	Unchangeable	<a href="#">"H01.06" on page 256</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H01.10	0x010A	Drive series No.	2: S1R6 3: S2R8 5: S5R5 6: S7R6 7: S012 8: S018 9: S022 10: S027 10001: T3R5 10002: T5R4 10003: T8R4 10004: T012 10005: T017 10006: T021 10007: T026	3	-	At stop	<i>"H01.10" on page 257</i>
H01.11	0x010B	DC-AC voltage class	0 V to 65535 V	220	V	Unchangeable	<i>"H01.11" on page 257</i>
H01.12	0x010C	Rated power of the drive	0.00 kW to 10737418.24 kW	0.4	kW	Unchangeable	<i>"H01.12" on page 257</i>
H01.14	0x010E	Max. output power of the drive	0.00 kW to 10737418.24 kW	0.4	kW	Unchangeable	<i>"H01.14" on page 258</i>
H01.16	0x0110	Rated output current of the drive	0.00 A to 10737418.24 A	2.8	A	Unchangeable	<i>"H01.16" on page 258</i>
H01.18	0x0112	Max. output current of the drive	0.00 A to 10737418.24 A	10.1	A	Unchangeable	<i>"H01.18" on page 258</i>
H01.40	0x0128	DC bus overvoltage protection threshold	0 V to 2000 V	420	V	At once	<i>"H01.40" on page 258</i>
H01.75	0x014B	Current loop amplification factor	0.00 to 655.35	1	-	At once	<i>"H01.75" on page 259</i>
H01.89	0x0159	Junction temperature parameter version	0.00 to 655.35	0	-	Unchangeable	<i>"H01.89" on page 259</i>

### 4.3 Parameter Group H02

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H02.00	0x0200	Control mode	0: Speed control mode 1: Position control mode 2: Torque control mode 9: EtherCAT mode	9	-	At stop	<a href="#">" H02.00" on page 259</a>
H02.01	0x0201	Absolute system selection	0: Incremental mode 1: Absolute position linear mode 2: Absolute position rotation mode 3: Absolute position linear mode (without encoder overflow warning) 4: Absolute position single-turn mode	0	-	At stop	<a href="#">" H02.01" on page 260</a>
H02.02	0x0202	Direction of rotation	0: Counterclockwise (CCW) as forward direction 1: Clockwise (CW) as forward direction	0	-	At stop	<a href="#">" H02.02" on page 260</a>
H02.03	0x0203	Output pulse phase	0: Phase A leads phase B 1: Phase A lags behind phase B	0	-	At stop	<a href="#">" H02.03" on page 260</a>
H02.05	0x0205	Stop mode at S-ON OFF	-4: Ramp to stop as defined by 6085h, keeping dynamic braking state -3: Stop at zero speed, keeping dynamic braking state -2: Ramp to stop as defined by 6084h/609Ah (HM), keeping dynamic braking state -1: Dynamic braking stop, keeping dynamic braking state 0: Coast to stop, keeping de-energized state 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state 2: Dynamic braking stop, keeping de-energized state	0	-	At once	<a href="#">" H02.05" on page 260</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H02.06	0x0206	Stop mode at No. 2 fault	-5: Stop at zero speed, keeping dynamic braking state -4: Stop at emergency stop torque, keeping dynamic braking state -3: Ramp to stop as defined by 6085h, keeping dynamic braking state -2: Ramp to stop as defined by 6084h/609Ah (HM), keeping dynamic braking state -1: Dynamic braking stop, keeping dynamic braking state 0: Coast to stop, keeping de-energized state 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state 2: Ramp to stop as defined by 6085h, keeping de-energized state 3: Stop at emergency stop torque, keeping de-energized state 4: Dynamic braking stop, keeping de-energized state	2	-	At once	<a href="#">"H02.06" on page 261</a>
H02.07	0x0207	Stop mode at overtravel	0: Coast to stop, keeping de-energized state 1: Stop at zero speed, keeping position lock state 2: Stop at zero speed, keeping de-energized state 3: Ramp to stop as defined by 6085h, keeping de-energized state 4: Ramp to stop as defined by 6085h, keeping position lock state 5: Dynamic braking stop, keeping de-energized state 6: Dynamic braking stop, keeping dynamic braking state 7: Not responding to overtravel	1	-	At stop	<a href="#">"H02.07" on page 261</a>
H02.08	0x0208	Stop mode at No. 1 fault	0: Coast to stop, keeping de-energized state 1: Dynamic braking stop, keeping de-energized state 2: Dynamic braking stop, keeping dynamic braking state	2	-	At stop	<a href="#">"H02.08" on page 262</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H02.09	0x0209	Delay from brake output ON to command received	0 ms to 500 ms	250	ms	At once	<a href="#">" H02.09" on page 262</a>
H02.10	0x020A	Delay from brake output OFF to motor de-energized	50 ms to 1000 ms	150	ms	At once	<a href="#">" H02.10" on page 262</a>
H02.11	0x020B	Speed threshold at brake output OFF in rotation state	20 rpm to 3000 rpm	30	rpm	At once	<a href="#">" H02.11" on page 263</a>
H02.12	0x020C	Delay from S-ON OFF to brake output OFF in the rotation state	1 ms to 65535 ms	500	ms	At once	<a href="#">" H02.12" on page 263</a>
H02.15	0x020F	Warning display on the keypad	0: Output warning information immediately 1: Not output warning information	0	-	At once	<a href="#">" H02.15" on page 263</a>
H02.16	0x0210	Brake enable switch	0: OFF 1: ON	0	-	At once	<a href="#">" H02.16" on page 263</a>
H02.17	0x0211	Stop mode upon main circuit power failure	0: Keep present action 1: Stop upon fault as defined by H02.06 2: Stop at S-ON OFF as defined by H02.05 3: Stop quickly as defined by H02.18	2	-	At once	<a href="#">" H02.17" on page 264</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H02.18	0x0212	Quick stop mode	0: Coast to stop, keeping de-energized state 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state 2: Ramp to stop as defined by 6085h, keeping de-energized state 3: Stop at emergency stop torque, keeping de-energized state 5: Ramp to stop as defined by 6084h/609Ah (HM), keeping position lock state 6: Ramp to stop as defined by 6085h, keeping position lock state 7: Stop at emergency stop torque, keeping position lock state	2	-	At once	<i>"H02.18" on page 264</i>
H02.21	0x0215	Permissible minimum resistance of regenerative resistor	1 Ω to 1000 Ω	40	Ω	Unchangeable	<i>"H02.21" on page 264</i>
H02.22	0x0216	Power of built-in regenerative resistor	0 W to 65535 W	50	W	Unchangeable	<i>"H02.22" on page 265</i>
H02.23	0x0217	Resistance of built-in regenerative resistor	0 Ω to 65535 Ω	50	Ω	Unchangeable	<i>"H02.23" on page 265</i>
H02.24	0x0218	Resistor heat dissipation coefficient	10% to 100%	30	%	At once	<i>"H02.24" on page 265</i>
H02.25	0x0219	Regenerative resistor type	0: Built-in 1: External, natural cooling 2: External, forced air cooling 3: No resistor needed	3	-	At once	<i>"H02.25" on page 266</i>
H02.26	0x021A	Power of external regenerative resistor	1 W to 65535 W	40	W	At once	<i>"H02.26" on page 266</i>
H02.27	0x021B	Resistance of external regenerative resistor	15 Ω to 1000 Ω	50	Ω	At once	<i>"H02.27" on page 266</i>
H02.30	0x021E	User password	0 to 65535	0	-	At once	<i>"H02.30" on page 267</i>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H02.31	0x021F	System parameter initialization	0: No operation 1: Restore default settings 2: Clear fault records	0	-	At stop	<a href="#">"H02.31" on page 267</a>
H02.32	0x0220	Selection of parameters in group H0b	0 to 99	50	-	At once	<a href="#">"H02.32" on page 267</a>
H02.35	0x0223	Keypad data refresh frequency	0 Hz to 20 Hz	0	Hz	At once	<a href="#">"H02.35" on page 267</a>
H02.41	0x0229	Manufacturer password	0 to 65535	0	-	At once	<a href="#">"H02.41" on page 268</a>

#### 4.4 Parameter Group H03

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H03.02	0x0302	DI1 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jog 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 38: Touch probe 1 39: Touch probe 2 40: Multi-speed enable	14	-	At once	<a href="#">"H03.02" on page 268</a>
H03.03	0x0303	DI1 logic	0: Normally open 1: Closed	0	-	At once	<a href="#">"H03.03" on page 269</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H03.04	0x0304	DI2 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jog 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 38: Touch probe 1 39: Touch probe 2 40: Multi-speed enable	15	-	At once	<a href="#">" H03.04" on page 269</a>
H03.05	0x0305	DI2 logic	0: Normally open 1: Closed	0	-	At once	<a href="#">" H03.05" on page 270</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H03.06	0x0306	DI3 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jog 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 38: Touch probe 1 39: Touch probe 2 40: Multi-speed enable	31	-	At once	<i>" H03.06" on page 270</i>
H03.07	0x0307	DI3 logic	0: Normally open 1: Closed	0	-	At once	<i>" H03.07" on page 270</i>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H03.08	0x0308	DI4 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jog 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 38: Touch probe 1 39: Touch probe 2 40: Multi-speed enable	34	-	At once	<i>" H03.08" on page 271</i>
H03.09	0x0309	DI4 logic	0: Normally open 1: Closed	0	-	At once	<i>" H03.09" on page 271</i>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H03.10	0x030A	DI5 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jog 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 38: Touch probe 1 39: Touch probe 2 40: Multi-speed enable	38	-	At once	<a href="#">"H03.10" on page 272</a>
H03.11	0x030B	DI5 logic	0: Normally open 1: Closed	0	-	At once	<a href="#">"H03.11" on page 272</a>
H03.50	0x0332	Voltage-type AI1 offset	-5000 mV to +5000 mV	0	mV	At once	<a href="#">"H03.50" on page 273</a>
H03.51	0x0333	Voltage-type AI1 input filter time constant	0.00 ms to 655.35 ms	2	ms	At once	<a href="#">"H03.51" on page 273</a>
H03.53	0x0335	Voltage-type AI1 dead zone	0.0 mV to 1000.0 mV	10	mV	At once	<a href="#">"H03.53" on page 273</a>
H03.54	0x0336	Voltage-type AI1 zero drift	-500 mV to +500 mV	0	mV	At once	<a href="#">"H03.54" on page 273</a>
H03.56	0x0338	Current-type AI2 input filter time constant	0.00 ms to 655.35 ms	2	ms	At once	<a href="#">"H03.56" on page 274</a>
H03.60	0x033C	DI1 filter time	0.00 ms to 500.00 ms	0.5	ms	At once	<a href="#">"H03.60" on page 274</a>
H03.61	0x033D	DI2 filter time	0.00 ms to 500.00 ms	0.5	ms	At once	<a href="#">"H03.61" on page 274</a>
H03.62	0x033E	DI3 filter time	0.00 ms to 500.00 ms	0.5	ms	At once	<a href="#">"H03.62" on page 275</a>
H03.63	0x033F	DI4 filter time	0.00 ms to 500.00 ms	0.5	ms	At once	<a href="#">"H03.63" on page 275</a>



Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H03.64	0x0340	DI5 filter time	0.00 ms to 500.00 ms	0.5	ms	At once	<a href="#">" H03.64" on page 275</a>
H03.78	0x034E	Speed value corresponding to analog 20 mA	0 rpm to 9999 rpm	3000	rpm	At stop	<a href="#">" H03.78" on page 275</a>
H03.79	0x034F	Torque value corresponding to analog 20 mA	1.00 to 8.00	1	Multiplier	At stop	<a href="#">" H03.79" on page 276</a>
H03.80	0x0350	Speed value corresponding to analog 10 V	0 rpm to 9999 rpm	3000	rpm	At stop	<a href="#">" H03.80" on page 276</a>
H03.81	0x0351	Torque value corresponding to analog 10 V	1.00 to 8.00	1	Multiplier	At stop	<a href="#">" H03.81" on page 276</a>

## 4.5 Parameter Group H04

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H04.00	0x0400	DO1 function	0: No assignment 1: Servo ready 2: Motor rotation signal 10: Warning 11: Fault 25: Comparison output DO 31: Communication-forced DO 32: EDM output	1	-	At once	<a href="#">" H04.00" on page 276</a>
H04.01	0x0401	DO1 logic	0: Normally open 1: Closed	0	-	At once	<a href="#">" H04.01" on page 277</a>
H04.02	0x0402	DO2 function	0: No assignment 1: Servo ready 2: Motor rotation signal 10: Warning 11: Fault 25: Comparison output DO 31: Communication-forced DO 32: EDM output	11	-	At once	<a href="#">" H04.02" on page 277</a>
H04.03	0x0403	DO2 logic	0: Normally open 1: Closed	0	-	At once	<a href="#">" H04.03" on page 278</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H04.22	0x0416	DO source	bit 0: DO1 source 0: DO1 function output 1: bit 0 of H31.04 set through communication bit 1: DO2 source 0: DO2 function output 1: bit 1 of H31.04 set through communication	0	-	At once	<a href="#">"H04.22" on page 278</a>
H04.23	0x0417	EtherCAT-forced DO logic in non-OP status	bit 0: DO1 0: Status unchanged 1: No output bit 1: DO2 0: Status unchanged 1: No output	0	-	At once	<a href="#">"H04.23" on page 278</a>
H04.50	0x0432	AO1 signal selection	0: Motor speed (1 V/1000 rpm) 1: Speed reference (1 V/1000 rpm) 2: Torque reference (1 V/100 x rated torque) 3: Position deviation (0.5 mV/1 reference unit) 4: Position deviation (0.5 mV/1 encoder unit) 5: Position reference speed (1 V/1000 rpm) 6: Positioning completed 8: AI1 voltage 10: Defined by H31.05	0	-	At once	<a href="#">"H04.50" on page 279</a>
H04.51	0x0433	AO1 offset voltage	-10000 mV to +10000 mV	0	mV	At once	<a href="#">"H04.51" on page 279</a>
H04.52	0x0434	AO1 multiplier	-99.99 to +99.99	1	-	At once	<a href="#">"H04.52" on page 279</a>

## 4.6 Parameter Group H05

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H05.00	0x0500	Main position reference source	0 to 2 (Multi-position reference)	2	-	At once	<a href="#">"H05.00" on page 280</a>
H05.02	0x0502	Pulses per revolution	0 to 4294967295	0	PPR	At stop	<a href="#">"H05.02" on page 280</a>
H05.04	0x0504	First-order low-pass filter time constant	0.0 to 6553.5	0	ms	At stop	<a href="#">"H05.04" on page 280</a>
H05.06	0x0506	Moving average filter time constant 1	0.0 to 128.0	0	ms	At stop	<a href="#">"H05.06" on page 280</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H05.07	0x0507	Electronic gear ratio 1 (numerator)	1 to 1073741824	1	-	At once	<a href="#">" H05.07" on page 281</a>
H05.09	0x0509	Electronic gear ratio 1 (denominator)	1 to 1073741824	1	-	At once	<a href="#">" H05.09" on page 281</a>
H05.11	0x050B	Electronic gear ratio 2 (numerator)	1 to 1073741824	1	-	At once	<a href="#">" H05.11" on page 281</a>
H05.13	0x050D	Electronic gear ratio 2 (denominator)	1 to 1073741824	1	-	At once	<a href="#">" H05.13" on page 281</a>
H05.16	0x0510	Clear action	0: Position deviation cleared upon S-OFF or non-operational state 1: Position deviation cleared upon S-OFF or fault 2: Position deviation cleared in the non-operational state or when FunIN.35 is activated	0	-	At stop	<a href="#">" H05.16" on page 282</a>
H05.17	0x0511	Number of encoder frequency-division pulses	0 to 4194303	2500	PPR	At stop	<a href="#">" H05.17" on page 282</a>
H05.19	0x0513	Speed feedforward control	0: No speed feedforward 1: Internal speed feedforward 2: 60B1h 3: Zero phase	1	-	At stop	<a href="#">" H05.19" on page 282</a>
H05.30	0x051E	Homing selection	0: Disable 6: Current position as the home	0	-	At once	<a href="#">" H05.30" on page 283</a>
H05.35	0x0523	Homing time limit	0 to 65535	10000	ms	At once	<a href="#">" H05.35" on page 283</a>
H05.36	0x0524	Mechanical home offset	-2147483648 to +2147483648	0	Reference unit	At once	<a href="#">" H05.36" on page 283</a>
H05.38	0x0526	Frequency-division output source	0: Encoder frequency-division output 1: Pulse reference synchronous output 2: Frequency-division output inhibited 3: Second encoder frequency-division output	0	-	At once	<a href="#">" H05.38" on page 283</a>
H05.39	0x0527	Electronic gear ratio switchover condition	0: Switched if position reference kept 0 for 2.5 ms 1: Switched in real time	0	-	At stop	<a href="#">" H05.39" on page 284</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H05.40	H05.40	Mechanical home offset and action upon overtravel	0: H05.36 (Mechanical home offset) used as the coordinate after homing, reverse homing applied after homing triggered again upon overtravel 1: H05.36 (Mechanical home offset) used as the relative offset after homing, reverse homing applied after homing triggered again upon overtravel 2: H05.36 (Mechanical home offset) used as the coordinate after homing, reverse homing applied automatically upon overtravel 3: H05-36 (Mechanical home offset) used as the relative offset after homing, reverse homing applied automatically upon overtravel	0	-	At once	<a href="#">"H05.40" on page 284</a>
H05.41	0x0529	Z pulse output polarity	Bit 0: Frequency-division Z output polarity 0: Positive (high level upon active Z pulse) 1: Negative (low level upon active Z pulse) Bit 1: OCZ output polarity 0: Positive (high level upon active Z pulse) 1: Negative (low level upon active Z pulse) Bit 2: Inner loop touch probe Z signal source 0: Motor Z signal 1: Frequency-division output Z signal	1	-	At stop	<a href="#">"H05.41" on page 284</a>
H05.44	0x052C	Numerator of frequency-division output reduction ratio	1 to 16383	1	-	At stop	<a href="#">"H05.44" on page 285</a>
H05.45	0x052D	Denominator of frequency-division output reduction ratio	1 to 8191	1	-	At stop	<a href="#">"H05.45" on page 285</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H05.46	0x052E	DI selection of multi-turn frequency-division Z starting point	0: No selection 1: DI1 2: DI2 3: DI3 4: DI4 5: DI5	0	-	At once	<a href="#">" H05.46" on page 285</a>
H05.47	0x052F	Frequency-division Z pulse width	0 to 400	0	us	At once	<a href="#">" H05.47" on page 286</a>
H05.50	0x0532	Mechanical gear ratio (numerator) in absolute position rotation mode	1 to 65535	1	-	At stop	<a href="#">" H05.50" on page 286</a>
H05.51	0x0533	Mechanical gear ratio (denominator) in absolute position rotation mode	1 to 65535	1	-	At stop	<a href="#">" H05.51" on page 286</a>
H05.52	0x0534	Pulses per revolution of the load in absolute position rotation mode (low 32 bits)	0 to 4294967295	0	Encoder unit	At stop	<a href="#">" H05.52" on page 287</a>
H05.54	0x0536	Pulses per revolution of the load in absolute position rotation mode (high 32 bits)	0 to 4294967295	0	Encoder unit	At stop	<a href="#">" H05.54" on page 287</a>
H05.56	0x0538	Speed threshold in homing upon hit-and-stop	0 to 1000	2	rpm	At once	<a href="#">" H05.56" on page 287</a>
H05.58	0x053A	Torque threshold in homing upon hit-and-stop	0.0% to 400.0%	100	%	At once	<a href="#">" H05.58" on page 287</a>
H05.60	0x053C	Hold time of positioning completed	0 to 30000	0	ms	At once	<a href="#">" H05.60" on page 288</a>
H05.66	0x0542	Homing time unit	0: 1 1: 10 2: 100	2	-	At stop	<a href="#">" H05.66" on page 288</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H05.67	0x0543	Offset between zero point and single-turn absolute position	-2147483648 to +2147483647	0	Encoder unit	At stop	<a href="#">" H05.67" on page 288</a>
H05.69	0x0545	Auxiliary homing function	0: Inhibited 1: Record offset position 2: Clear offset position	0	-	At stop	<a href="#">" H05.69" on page 288</a>
H05.70	0x0546	Moving average filter time constant 2	0.0 to 1000.0	0	ms	At stop	<a href="#">" H05.70" on page 289</a>
H05.71	0x0547	Motor Z signal width	1 to 100	4	ms	At once	<a href="#">" H05.71" on page 289</a>
H05.72	0x0548	Positioning completed/ Position deviation threshold in fully closed-loop mode	0: Threshold scaled to outer loop unit 1: Same threshold used for inner and outer loops	0	-	At stop	<a href="#">" H05.72" on page 289</a>

## 4.7 Parameter Group H06

Param. No.	Address	Name	Setpoint	Default	Unit	Change Condition	Page
H06.00	0x0600	Source of main speed reference A	0: Digital setting (H06.03) 1: AI1	0	-	At stop	<a href="#">" H06.00" on page 290</a>
H06.01	0x0601	Source of auxiliary speed reference B	0: Digital setting (H06.03) 1: AI1 5: Multi-speed reference	1	-	At stop	<a href="#">" H06.01" on page 290</a>
H06.02	0x0602	Speed reference source	0: Source of main speed reference A 1: Source of auxiliary speed reference B 2: A+B 3: Switched between A and B 4: Communication	0	-	At stop	<a href="#">" H06.02" on page 290</a>
H06.03	0x0603	Speed reference set through keypad	-9999 rpm to +9999 rpm	200	rpm	At once	<a href="#">" H06.03" on page 290</a>
H06.04	0x0604	DI jog speed reference	0 rpm to 9999 rpm	150	rpm	At once	<a href="#">" H06.04" on page 291</a>
H06.05	0x0605	Acceleration ramp time of speed reference	0 ms to 65535 ms	0	ms	At once	<a href="#">" H06.05" on page 291</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change Condition	Page
H06.06	0x0606	Deceleration ramp time of speed reference	0 ms to 65535 ms	0	ms	At once	"H06.06" on page 292
H06.07	0x0607	Maximum speed limit	0 rpm to 9999 rpm	6000	rpm	At once	"H06.07" on page 292
H06.08	0x0608	Forward speed threshold	0 rpm to 9999 rpm	6000	rpm	At once	"H06.08" on page 292
H06.09	0x0609	Reverse speed threshold	0 rpm to 9999 rpm	6000	rpm	At once	"H06.09" on page 292
H06.10	0x060A	Deceleration unit in emergency stop	0: Multiplied by 1 1: Multiplied by 10 2: Multiplied by 100	0	-	At stop	"H06.10" on page 293
H06.11	0x060B	Torque feedforward control	0: No torque feedforward 1: Internal torque feedforward 2: 60B2h used as external torque feedforward	1	-	At once	"H06.11" on page 293
H06.12	0x060C	Acceleration ramp time of jog speed	0 ms to 65535 ms	10	ms	At once	"H06.12" on page 293
H06.13	0x060D	Speed feedforward smoothing filter	0 us to 65535 us	0	us	At once	"H06.13" on page 293
H06.15	0x060F	Zero clamp speed threshold	0 rpm to 9999 rpm	10	rpm	At once	"H06.15" on page 294
H06.16	0x0610	Threshold of TGON (motor rotation) signal	0 rpm to 1000 rpm	20	rpm	At once	"H06.16" on page 294
H06.17	0x0611	Threshold of V-Cmp (speed matching) signal	0 rpm to 100 rpm	10	rpm	At once	"H06.17" on page 294
H06.18	0x0612	Threshold of speed reach signal	20 rpm to 9999 rpm	1000	rpm	At once	"H06.18" on page 294
H06.19	0x0613	Threshold of zero speed output signal	1 rpm to 9999 rpm	10	rpm	At once	"H06.19" on page 295
H06.40	0x0628	Deceleration time of ramp 1	0 ms to 65535 ms	0	ms	At stop	"H06.40" on page 295
H06.41	0x0629	Deceleration time of ramp 2	0 ms to 65535 ms	0	ms	At stop	"H06.41" on page 295
H06.50	0x0628	Speed S-curve enable switch	0: Disable 1: Enable	0	-	At stop	"H06.50" on page 295

Param. No.	Address	Name	Setpoint	Default	Unit	Change Condition	Page
H06.51	0x0633	Increasing acceleration of speed S-curve acceleration segment	0.0% to 100.0%	50	%	At stop	<a href="#">" H06.51" on page 296</a>
H06.52	0x0634	Decreasing acceleration of speed S-curve acceleration segment	0.0% to 100.0%	50	%	At stop	<a href="#">" H06.52" on page 296</a>
H06.53	0x0635	Increasing acceleration of speed S-curve deceleration segment	0.0% to 100.0%	50	%	At stop	<a href="#">" H06.53" on page 296</a>
H06.54	0x0636	Decreasing acceleration of speed S-curve deceleration segment	0.0% to 100.0%	50	%	At stop	<a href="#">" H06.54" on page 296</a>

## 4.8 Parameter Group H07

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H07.00	0x0700	Source of main torque reference A	0: Keypad (H07.03) 1: AI1	0	-	At stop	<a href="#">" H07.00" on page 297</a>
H07.01	0x0701	Source of auxiliary torque reference B	0: Keypad (H07.03) 1: AI1	1	-	At stop	<a href="#">" H07.01" on page 297</a>
H07.02	0x0702	Torque reference source	0: Source of main torque reference A 1: Source of auxiliary torque reference B 2: Source of A+B 3: Switched between A and B 4: Communication	0	-	At stop	<a href="#">" H07.02" on page 297</a>
H07.03	0x0703	Torque reference set through keypad	-400.0% to +400.0%	0	%	At once	<a href="#">" H07.03" on page 298</a>
H07.05	0x0705	Torque reference filter time constant 1	0.00 ms to 30.00 ms	0.5	ms	At once	<a href="#">" H07.05" on page 298</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H07.06	0x0706	Torque reference filter time constant 2	0.00 ms to 30.00 ms	0.27	ms	At once	<a href="#">" H07.06" on page 298</a>
H07.07	0x0707	Torque limit source	0: Positive/Negative internal torque limit 1: Internal or external limit as defined by DI 2: T-LMT 3: T_LMT or external limit as defined by DI (FunIN.16 or FunIN.17) 4: T_LMT or internal limit (FunIN.16 or FunIN.17) as defined by DI	0	-	At once	<a href="#">" H07.07" on page 298</a>
H07.08	0x0708	T-LMT selection	1: AI1 2: AI2	1	-	At once	<a href="#">" H07.08" on page 299</a>
H07.09	0x0709	Positive internal torque limit	0.0% to 400.0%	350	%	At once	<a href="#">" H07.09" on page 299</a>
H07.10	0x070A	Negative internal torque limit	0.0% to 400.0%	350	%	At once	<a href="#">" H07.10" on page 299</a>
H07.11	0x070B	Positive external torque limit	0.0% to 400.0%	350	%	At once	<a href="#">" H07.11" on page 299</a>
H07.12	0x070C	Negative external torque limit	0.0% to 400.0%	350	%	At once	<a href="#">" H07.12" on page 300</a>
H07.15	0x070F	Emergency stop torque	0.0% to 400.0%	100	%	At once	<a href="#">" H07.15" on page 300</a>
H07.17	0x0711	Speed limit source	0: Internal speed limit 1: V-LMT 2: H07.19 or H07.20 as defined by DI	0	-	At once	<a href="#">" H07.17" on page 300</a>
H07.18	0x0712	V-LMT selection	1: AI1 2: AI2	1	-	At once	<a href="#">" " on page</a>
H07.19	0x0713	Positive speed limit/Speed limit 1 in torque control	0 rpm to 9999 rpm	3000	rpm	At once	<a href="#">" H07.19" on page 301</a>
H07.20	0x0714	Negative speed limit/Speed limit 2 in torque control	0 rpm to 9999 rpm	3000	rpm	At once	<a href="#">" H07.20" on page 301</a>
H07.21	0x0715	Base value for torque reach	0.0% to 400.0%	0	%	At once	<a href="#">" H07.21" on page 301</a>
H07.22	0x0716	Threshold of valid torque reach	0.0% to 400.0%	20	%	At once	<a href="#">" H07.22" on page 301</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H07.23	0x0717	Threshold of invalid torque reach	0.0% to 400.0%	10	%	At once	<a href="#">"H07.23" on page 302</a>
H07.24	0x0718	Field weakening depth	60% to 115%	115	%	At once	<a href="#">"H07.24" on page 302</a>
H07.25	0x0719	Max. permissible demagnetizing current	0% to 300%	100	%	At once	<a href="#">"H07.25" on page 302</a>
H07.26	0x071A	Field weakening selection	0: Disable 1: Enable	0	-	At stop	<a href="#">"H07.26" on page 302</a>
H07.27	0x071B	Field weakening gain	0.001 Hz to 1.000 Hz	0.03	Hz	At once	<a href="#">"H07.27" on page 303</a>
H07.28	0x071C	Speed of field weakening point	0 to 65535	0	-	Unchangeable	<a href="#">"H07.28" on page 303</a>
H07.35	0x0723	Motor torque output correction	0: Switched off 1: Enabled	0	-	At stop	<a href="#">" " on page</a>
H07.36	0x0724	Time constant of low-pass filter 2	0.00 ms to 10.00 ms	0	ms	At once	<a href="#">"H07.36" on page 303</a>
H07.37	0x0725	Torque reference filter selection	0: First-order filter 1: Biquad filter	0	-	At once	<a href="#">"H07.37" on page 304</a>
H07.38	0x0726	Biquad filter attenuation ratio	0 to 50	16	-	At stop	<a href="#">"H07.38" on page 304</a>
H07.40	0x0728	Speed limit window in the torque control mode	0.0 ms to 300.0 ms	10	ms	At once	<a href="#">"H07.40" on page 304</a>

## 4.9 Parameter Group H08

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H08.00	0x0800	Speed loop gain	0.1 Hz to 2000.0 Hz	40	Hz	At once	<a href="#">"H08.00" on page 304</a>
H08.01	0x0801	Speed loop integral time constant	0.15 ms to 512.00 ms	19.89	ms	At once	<a href="#">"H08.01" on page 305</a>
H08.02	0x0802	Position loop gain	0.1 Hz to 2000.0 Hz	64	Hz	At once	<a href="#">"H08.02" on page 305</a>
H08.03	0x0803	2nd speed loop gain	0.1 Hz to 2000.0 Hz	75	Hz	At once	<a href="#">"H08.03" on page 305</a>
H08.04	0x0804	2nd speed loop integral time constant	0.15 ms to 512.00 ms	10.61	ms	At once	<a href="#">"H08.04" on page 306</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H08.05	0x0805	2nd position loop gain	0.1 Hz to 2000.0 Hz	120	Hz	At once	<a href="#">"H08.05" on page 306</a>
H08.08	0x0808	2nd gain mode setting	0: Fixed to the 1st gain set, switched between P and PI as defined by bit26 of external 60FEh 1: Switched between the 1st and 2nd gain sets as defined by H08.09	1	-	At once	<a href="#">"H08.08" on page 306</a>
H08.09	0x0809	Gain switchover condition	0: Fixed to the 1st gain set (PS) 1: Switched as defined by bit26 of 60FEh 2: Torque reference too large (PS) 3: Speed reference too large (PS) 4: Speed reference change rate too large (PS) 5: Speed reference low/high speed threshold (PS) 6: Position deviation too large (P) 7: Position reference available (P) 8: Positioning unfinished (P) 9: Actual speed (P) 10: Position reference + Actual speed (P)	0	-	At once	<a href="#">"H08.09" on page 307</a>
H08.10	0x080A	Gain switchover delay	0.0 ms to 1000.0 ms	5	ms	At once	<a href="#">"H08.10" on page 307</a>
H08.11	0x080B	Gain switchover level	0 to 20000	50	-	At once	<a href="#">"H08.11" on page 307</a>
H08.12	0x080C	Gain switchover dead time	0 to 20000	30	-	At once	<a href="#">"H08.12" on page 308</a>
H08.13	0x080D	Position gain switchover time	0.0 ms to 1000.0 ms	3	ms	At once	<a href="#">"H08.13" on page 308</a>
H08.15	0x080F	Load moment of inertia ratio	0.00 to 120.00	1	-	At once	<a href="#">"H08.15" on page 308</a>
H08.17	0x0811	Zero phase delay	0.0 ms to 4.0 ms	0	ms	At once	<a href="#">"H08.17" on page 309</a>
H08.18	0x0812	Speed feedforward filter time constant	0.00 ms to 64.00 ms	0.5	ms	At once	<a href="#">"H08.18" on page 309</a>
H08.19	0x0813	Speed feedforward gain	0.0% to 100.0%	0	%	At once	<a href="#">"H08.19" on page 309</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H08.20	0x0814	Torque feedforward filter time constant	0.00 ms to 64.00 ms	0.5	ms	At once	<a href="#">"H08.20" on page 309</a>
H08.21	0x0815	Torque feedforward gain	0.0% to 300.0%	0	%	At once	<a href="#">"H08.21" on page 310</a>
H08.22	0x0816	Speed feedback filtering option	0: Inhibited 1: 2 times 2: 4 times 3: 8 times 4: 16 times	0	-	At stop	<a href="#">"H08.22" on page 310</a>
H08.23	0x0817	Cutoff frequency of speed feedback low-pass filter	100 Hz to 8000 Hz	8000	Hz	At once	<a href="#">"H08.23" on page 311</a>
H08.24	0x0818	PDFF control coefficient	0.0% to 200.0%	100	%	At once	<a href="#">"H08.24" on page 311</a>
H08.27	0x081B	Speed observer cutoff frequency	50 Hz to 600 Hz	170	Hz	At once	<a href="#">"H08.27" on page 311</a>
H08.28	0x081C	Speed observer inertia correction coefficient	1% to 1600%	100	%	At once	<a href="#">"H08.28" on page 312</a>
H08.29	0x081D	Speed observer filter time	0.00 ms to 10.00 ms	0.8	ms	At once	<a href="#">"H08.29" on page 312</a>
H08.31	0x081F	Disturbance cutoff frequency	10 Hz to 4000 Hz	600	Hz	At once	<a href="#">"H08.31" on page 312</a>
H08.32	0x0820	Disturbance compensation gain	0% to 100%	0	%	At once	<a href="#">"H08.32" on page 313</a>
H08.33	0x0821	Disturbance observer inertia correction coefficient	1% to 1600%	100	%	At once	<a href="#">"H08.33" on page 313</a>
H08.37	0x0825	Phase modulation for medium-frequency jitter suppression 2	-90° to +90°	0	°	At once	<a href="#">"H08.37" on page 313</a>
H08.38	0x0826	Frequency of medium-frequency jitter suppression 2	0 Hz to 1000 Hz	0	Hz	At once	<a href="#">"H08.38" on page 313</a>
H08.39	0x0827	Compensation gain of medium-frequency jitter suppression 2	0% to 300%	0	%	At once	<a href="#">"H08.39" on page 314</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H08.40	0x0828	Speed observer selection	0: Disable 1: Enable	0	-	At once	<a href="#">"H08.40" on page 314</a>
H08.42	0x082A	Model control selection	0: Disable 1: Enable 2: Dual-inertia model	0	-	At once	<a href="#">"H08.42" on page 314</a>
H08.43	0x082B	Model gain	0.1 to 2000.0	40	-	At once	<a href="#">"H08.43" on page 314</a>
H08.46	0x082E	Feedforward value	0.0 to 102.4	95	-	At once	<a href="#">"H08.46" on page 315</a>
H08.53	0x0835	Medium- and low-frequency jitter suppression frequency 3	0.0 Hz to 300.0 Hz	0	Hz	At once	<a href="#">"H08.53" on page 315</a>
H08.54	0x0836	Medium- and low-frequency jitter suppression compensation 3	0% to 200%	0	%	At once	<a href="#">"H08.54" on page 315</a>
H08.56	0x0838	Medium- and low-frequency jitter suppression phase modulation 3	0% to 600%	100	%	At once	<a href="#">"H08.56" on page 315</a>
H08.59	0x083B	Medium- and low-frequency jitter suppression frequency 4	0.0 Hz to 300.0 Hz	0	Hz	At once	<a href="#">"H08.59" on page 316</a>
H08.60	0x083C	Medium- and low-frequency jitter suppression compensation 4	0% to 200%	0	%	At once	<a href="#">"H08.60" on page 316</a>
H08.61	0x083D	Medium- and low-frequency jitter suppression phase modulation 4	0% to 600%	100	%	At once	<a href="#">"H08.61" on page 316</a>
H08.62	0x083E	Position loop integral time constant	0.15 to 512.00	512	-	At once	<a href="#">"H08.62" on page 316</a>
H08.63	0x083F	2nd position loop integral time constant	0.15 to 512.00	512	-	At once	<a href="#">"H08.63" on page 317</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H08.64	0x0840	Speed observer feedback source	0: Disable 1: Enable	0	-	At once	<a href="#">"H08.64" on page 317</a>
H08.65	0x0841	Zero deviation control selection	0: Disable 1: Enable	0	-	At once	<a href="#">"H08.65" on page 317</a>
H08.66	0x0842	Moving average filter for zero deviation control position	0.0 ms to 320.0 ms	5	ms	At once	<a href="#">"H08.66" on page 317</a>
H08.68	0x0844	Speed feedforward of zero deviation control	0.0% to 100.0%	100	%	At once	<a href="#">"H08.68" on page 318</a>
H08.69	0x0845	Torque feedforward of zero deviation control	0.0% to 100.0%	100	%	At once	<a href="#">"H08.69" on page 318</a>
H08.81	0x0851	Anti-resonance frequency of dual-inertia model	1.0 Hz to 400.0 Hz	20	Hz	At once	<a href="#">"H08.81" on page 318</a>
H08.82	0x0852	Resonance frequency of dual-inertia model	0.0 Hz to 6553.5 Hz	0	Hz	At once	<a href="#">"H08.82" on page 319</a>
H08.83	0x0853	Dual-inertia model gain	$0.1s^{-1}$ to $300.0s^{-1}$	60	-1	At once	<a href="#">"H08.83" on page 319</a>
H08.84	0x0854	Inertia ratio of dual-inertia model	0.00 to 120.00	1	-	At once	<a href="#">"H08.84" on page 319</a>
H08.88	0x0858	Speed feedforward value of dual-inertia model	0.0 to 6553.5	100	-	At once	<a href="#">"H08.88" on page 319</a>
H08.89	0x0859	Torque feedforward value of dual-inertia model	0.0 to 6553.5	100	-	At once	<a href="#">"H08.89" on page 320</a>

## 4.10 Parameter Group H09

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H09.00	0x0900	Gain auto-tuning mode	0: Disabled, manual gain tuning required 1: Enabled, gain parameters generated automatically based on the stiffness level 2: Positioning mode, gain parameters generated automatically based on the stiffness level 3: Interpolation mode+Inertia auto-tuning 4: Normal mode+Inertia auto-tuning 6: Quick positioning mode+Inertia auto-tuning	4	-	At once	<a href="#">"H09.00" on page 320</a>
H09.01	0x0901	Stiffness level	0 to 41	15	-	At once	<a href="#">"H09.01" on page 320</a>
H09.02	0x0902	Adaptive notch mode	0: Adaptive notch no longer updated; 1: One adaptive notch activated (3rd notch) 2: Two adaptive notches activated (3rd and 4th notches) 3: Resonance point tested only (displayed in H09.24) 4: Adaptive notch cleared, values of 3rd and 4th notches restored to default	3	-	At once	<a href="#">"H09.02" on page 321</a>
H09.03	0x0903	Online inertia auto-tuning mode	0: Disabled 1: Enabled, changing slowly 2: Enabled, changing normally 3: Enabled, changing quickly	2	-	At once	<a href="#">"H09.03" on page 321</a>
H09.05	0x0905	Offline inertia auto-tuning mode	0: Bi-directional 1: Unidirectional	1	-	At stop	<a href="#">"H09.05" on page 321</a>
H09.06	0x0906	Maximum speed of inertia auto-tuning	100 rpm to 1000 rpm	500	rpm	At stop	<a href="#">"H09.06" on page 322</a>
H09.07	0x0907	Time constant for accelerating to the max. speed during inertia auto-tuning	20 ms to 800 ms	125	ms	At stop	<a href="#">"H09.07" on page 322</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H09.08	0x0908	Interval time after an individual inertia auto-tuning	50 ms to 10000 ms	800	ms	At stop	<a href="#">"H09.08" on page 322</a>
H09.09	0x0909	Number of motor revolutions per inertia auto-tuning	0.00 to 100.00	1	-	At once	<a href="#">"H09.09" on page 323</a>
H09.11	0x090B	Vibration threshold	0.0% to 100.0%	5	%	At once	<a href="#">"H09.11" on page 323</a>
H09.12	0x090C	Frequency of the 1st notch	50 Hz to 8000 Hz	8000	Hz	At once	<a href="#">"H09.12" on page 323</a>
H09.13	0x090D	Width level of the 1st notch	0 to 20	2	-	At once	<a href="#">"H09.13" on page 323</a>
H09.14	0x090E	Depth level of the 1st notch	0 to 99	0	-	At once	<a href="#">"H09.14" on page 324</a>
H09.15	0x090F	Frequency of the 2nd notch	50 Hz to 8000 Hz	8000	Hz	At once	<a href="#">"H09.15" on page 324</a>
H09.16	0x0910	Width level of the 2nd notch	0 to 20	2	-	At once	<a href="#">"H09.16" on page 324</a>
H09.17	0x0911	Depth level of the 2nd notch	0 to 99	0	-	At once	<a href="#">"H09.17" on page 325</a>
H09.18	0x0912	Frequency of the 3rd notch	50 Hz to 8000 Hz	8000	Hz	At once	<a href="#">"H09.18" on page 325</a>
H09.19	0x0913	Width level of the 3rd notch	0 to 20	2	-	At once	<a href="#">"H09.19" on page 325</a>
H09.20	0x0914	Depth level of the 3rd notch	0 to 99	0	-	At once	<a href="#">"H09.20" on page 325</a>
H09.21	0x0915	Frequency of the 4th notch	50 Hz to 8000 Hz	8000	Hz	At once	<a href="#">"H09.21" on page 326</a>
H09.22	0x0916	Width level of the 4th notch	0 to 20	2	-	At once	<a href="#">"H09.22" on page 326</a>
H09.23	0x0917	Depth level of the 4th notch	0 to 99	0	-	At once	<a href="#">"H09.23" on page 326</a>
H09.24	0x0918	Auto-tuned resonance frequency	0 Hz to 5000 Hz	0	Hz	At once	<a href="#">"H09.24" on page 326</a>
H09.26	0x091A	ITune response	50.0% to 500.0%	100	%	At once	<a href="#">"H09.26" on page 327</a>
H09.27	0x091B	ITune mode	0: Disable 1: ITune mode 1 2: ITune mode 2	0	-	At once	<a href="#">"H09.27" on page 327</a>
H09.28	0x091C	Minimum inertia ratio of ITune	0.0% to 80.0%	0	%	At once	<a href="#">"H09.28" on page 327</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H09.29	0x091D	Maximum inertia ratio of ITune	1.0% to 120.0%	30	%	At once	<a href="#">" H09.29" on page 327</a>
H09.32	0x0920	Gravity compensation value	0.0% to 100.0%	0	%	At once	<a href="#">" H09.32" on page 328</a>
H09.33	0x0921	Positive friction compensation value	0.0% to 100.0%	0	%	At once	<a href="#">" H09.33" on page 328</a>
H09.34	0x0922	Negative friction compensation value	-100.0% to 0.0%	0	%	At once	<a href="#">" H09.34" on page 328</a>
H09.35	0x0923	Friction compensation speed	0.0 to 20.0	2	-	At once	<a href="#">" H09.35" on page 328</a>
H09.36	0x0924	Friction compensation speed	0x00: Slow mode+Speed reference 0x01: Slow mode+Model speed 0x02: Slow mode+Speed feedback 0x03: Slow mode+Observe speed 0x10: Quick mode +Speed reference 0x11: Quick mode +Model speed 0x12: Quick mode +Speed feedback 0x13: Quick mode+Observe speed	0	-	At once	<a href="#">" H09.36" on page 329</a>
H09.37	0x0925	Vibration monitoring time	0 to 65535	600	-	At once	<a href="#">" H09.37" on page 329</a>
H09.38	0x0926	Frequency of low-frequency resonance suppression 1 at the mechanical end	1.0 Hz to 100.0 Hz	100	Hz	At once	<a href="#">" H09.38" on page 329</a>
H09.39	0x0927	Low-frequency resonance suppression 1 at the mechanical end	0 to 3	2	-	At stop	<a href="#">" H09.39" on page 330</a>
H09.44	0x092C	Frequency of low-frequency resonance suppression 2 at mechanical load end	0.0 to 100.0	0	-	At once	<a href="#">" H09.44" on page 330</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H09.45	0x092D	Responsiveness of low-frequency resonance suppression 2 at mechanical load end	0.01 to 5.00	1	-	At once	<a href="#">" H09.45" on page 330</a>
H09.47	0x092F	Width of low-frequency resonance suppression 2 at mechanical load end	0.00 to 2.00	1	-	At once	<a href="#">" H09.47" on page 330</a>
H09.49	0x0931	Frequency of low-frequency resonance suppression 3 at mechanical load end	0.0 to 100.0	0	-	At once	<a href="#">" H09.49" on page 331</a>
H09.50	0x0932	Responsiveness of low-frequency resonance suppression 3 at mechanical load end	0.01 to 5.00	1	-	At once	<a href="#">" H09.50" on page 331</a>
H09.52	0x0934	Width of low-frequency resonance suppression 3 at mechanical load end	0.00 to 2.00	1	-	At once	<a href="#">" H09.52" on page 331</a>
H09.54	0x0936	Vibration threshold	0.0% to 300.0%	50	%	At once	<a href="#">" H09.54" on page 331</a>
H09.56	0x0938	Max. overshoot allowed by ETune	0 to 65535	2936	-	At once	<a href="#">" H09.56" on page 332</a>
H09.57	0x0939	STune resonance suppression switchover frequency	0 Hz to 4000 Hz	900	Hz	At once	<a href="#">" H09.57" on page 332</a>
H09.58	0x093A	STune resonance suppression reset selection	0: Disable 1: Enable	0	-	At once	<a href="#">" H09.58" on page 332</a>

## 4.11 Parameter Group H0A

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0A.00	0x0A00	Power input phase loss protection	0: Enable 1: Disable	0	-	At once	<a href="#">"H0A.00" on page 333</a>
H0A.01	0x0A01	Absolute position limit	0: Disabled 1: Enabled 2: Enabled after homing	0	-	At once	<a href="#">"H0A.01" on page 333</a>
H0A.04	0x0A04	Motor overload protection gain	50 to 300	100	-	At once	<a href="#">"H0A.04" on page 333</a>
H0A.08	0x0A08	Overspeed threshold	0 to 20000	0	rpm	At once	<a href="#">"H0A.08" on page 334</a>
H0A.10	0x0A0A	Threshold of excessive local position deviation	0 to 4294967295	219895608	-	At once	<a href="#">"H0A.10" on page 334</a>
H0A.12	0x0A0C	Runaway protection	0: Disable 1: Enable	1	-	At once	<a href="#">"H0A.12" on page 334</a>
H0A.18	0x0A12	IGBT overtemperature threshold	120°C to 175°C	140	°C	At once	<a href="#">"H0A.18" on page 335</a>
H0A.19	0x0A13	Filter time constant of touch probe 1	0.00 to 6.30	2	us	At once	<a href="#">"H0A.19" on page 335</a>
H0A.20	0x0A14	Filter time constant of touch probe 2	0.00 to 6.30	2	us	At once	<a href="#">"H0A.20" on page 335</a>
H0A.23	0x0A17	TZ signal filter time	0 to 31	15	25 ns	At stop	<a href="#">"H0A.23" on page 335</a>
H0A.25	0x0A19	Speed display DO low-pass filter time	0 to 5000	0	ms	At once	<a href="#">"H0A.25" on page 336</a>
H0A.26	0x0A1A	Motor overload detection	0: Show motor overload warning (E909.0) and fault (E620.0) 1: Hide motor overload warning (E909.0) and fault (E620.0)	0	-	At once	<a href="#">"H0A.26" on page 336</a>
H0A.27	0x0A1B	Motor rotation DO speed filter time	0 to 100	50	ms	At once	<a href="#">"H0A.27" on page 336</a>
H0A.29	0x0A1D	Fully closed-loop encoder (ABZ) filter time	0 to 255	15	25 ns	At stop	<a href="#">"H0A.29" on page 336</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0A.32	0x0A20	Motor stall overtemperature protection time window	10 to 65535	200	ms	At once	<a href="#">"H0A.32" on page 337</a>
H0A.33	0x0A21	Motor stall overtemperature detection	0: Hide 1: Enable	1	-	At once	<a href="#">"H0A.33" on page 337</a>
H0A.36	0x0A24	Encoder multi-turn overflow fault selection	0: Not hide 1: Hide	0	-	At once	<a href="#">"H0A.36" on page 337</a>
H0A.40	0x0A28	Compensation function selection	bit0: Overtravel compensation 0: Enable 1: Disable bit1: Touch probe rising edge compensation 0: Disable 1: Enable bit2: Touch probe falling edge compensation 0: Disable 1: Enable bit3: Touch probe solution 0: New solution 1: Old solution (same as SV660N)	6	-	At stop	<a href="#">"H0A.40" on page 338</a>
H0A.41	0x0A29	Forward position of software position limit	-2147483648 to +2147483647	2147483647	Encoder unit	At stop	<a href="#">"H0A.41" on page 338</a>
H0A.43	0x0A2B	Reverse position of software position limit	-2147483648 to +2147483647	-2147483648	Encoder unit	At stop	<a href="#">"H0A.43" on page 338</a>
H0A.49	0x0A31	Regenerative resistor overtemperature threshold	100°C to 175°C	115	°C	At once	<a href="#">"H0A.49" on page 339</a>
H0A.50	0x0A32	Encoder communication fault tolerance threshold	0 to 31	5	-	At once	<a href="#">"H0A.50" on page 339</a>
H0A.51	0x0A33	Phase loss detection filter times	3 to 36	20	55 ms	At once	<a href="#">"H0A.51" on page 339</a>
H0A.52	0x0A34	Encoder temperature protection threshold	0°C to 175°C	125	°C	At once	<a href="#">"H0A.52" on page 339</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0A.53	0x0A35	Touch probe DI ON-compensation time	-3000 to +3000	200	25 ns	At once	<a href="#">" H0A.53" on page 340</a>
H0A.54	0x0A36	Touch probe DI OFF-compensation time	-3000 to +3000	1512	25 ns	At once	<a href="#">" H0A.54" on page 340</a>
H0A.55	0x0A37	Runaway current threshold	100.0% to 400.0%	200	%	At once	<a href="#">" H0A.55" on page 340</a>
H0A.56	0x0A38	Fault reset delay	0 to 60000	10000	ms	At once	<a href="#">" H0A.56" on page 340</a>
H0A.57	0x0A39	Runaway speed threshold	1 to 1000	50	rpm	At once	<a href="#">" H0A.57" on page 340</a>
H0A.58	0x0A3A	Runaway speed filter time	0.1 to 100.0	2	ms	At once	<a href="#">" H0A.58" on page 341</a>
H0A.59	0x0A3B	Runaway protection detection time	10 to 1000	30	ms	At once	<a href="#">" H0A.59" on page 341</a>
H0A.60	0x0A3C	Black box function mode	0: Disable 1: Any fault 2: Designated fault 3: Triggered by designated condition	1	-	At once	<a href="#">" H0A.60" on page 341</a>
H0A.61	0x0A3D	Designated fault code	0.0 to 6553.5	0	-	At once	<a href="#">" H0A.61" on page 342</a>
H0A.62	0x0A3E	Trigger source	0 to 25	0	-	At once	<a href="#">" H0A.62" on page 342</a>
H0A.63	0x0A3F	Trigger level	-2147483648 to +2147483647	0	-	At once	<a href="#">" H0A.63" on page 342</a>
H0A.65	0x0A41	Trigger level	0: Rising edge 1: Equal 2: Falling edge 3: Edge-triggered	0	-	At once	<a href="#">" H0A.65" on page 342</a>
H0A.66	0x0A42	Trigger position	0% to 100%	75	%	At once	<a href="#">" H0A.66" on page 343</a>
H0A.67	0x0A43	Sampling frequency	0: Current loop 1: Position loop 2: Main cycle	0	-	At once	<a href="#">" H0A.67" on page 343</a>
H0A.70	0x0A46	Overspeed threshold 2	0 to 20000	0	rpm	At once	<a href="#">" H0A.70" on page 343</a>
H0A.71	0x0A47	MS1 motor overload curve switchover	0 to 3	2	-	At once	<a href="#">" H0A.71" on page 343</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0A.72	0x0A48	Maximum stop time in ramp-to-stop	0 to 65535	10000	ms	At stop	<a href="#">"H0A.72" on page 344</a>
H0A.73	0x0A49	STO 24 V disconnection filter time	1 to 5	5	ms	At once	<a href="#">"H0A.73" on page 344</a>
H0A.74	0x0A4A	Filter time for two inconsistent STO channels	1 to 1000	10	ms	At once	<a href="#">"H0A.74" on page 344</a>
H0A.75	0x0A4B	Servo OFF delay after STO triggered	0 to 25	20	ms	At once	<a href="#">"H0A.75" on page 345</a>
H0A.90	0x0A5A	Moving average filter time constant for speed display values	0 to 100	0	ms	At once	<a href="#">"H0A.90" on page 345</a>
H0A.91	0x0A5B	Moving average filter time constant for torque display values	0 to 100	0	ms	At once	<a href="#">"H0A.91" on page 345</a>
H0A.92	0x0A5C	Moving average filter time constant for position display values	0 to 100	0	ms	At once	<a href="#">"H0A.92" on page 345</a>
H0A.93	0x0A5D	Low-pass filter time constant for voltage display values	0 to 250	0	ms	At once	<a href="#">"H0A.93" on page 346</a>
H0A.94	0x0A5E	Low-pass filter time constant for thermal display values	0 to 250	0	ms	At once	<a href="#">"H0A.94" on page 346</a>

## 4.12 Parameter Group H0b

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0b.00	0x0B00	Motor speed actual value	-32767 rpm to +32767 rpm	0	rpm	Unchangeable	<a href="#">"H0b.00" on page 346</a>
H0b.01	0x0B01	Speed reference	-32767 rpm to +32767 rpm	0	rpm	Unchangeable	<a href="#">"H0b.01" on page 346</a>
H0b.02	0x0B02	Internal torque reference	-500.0% to +500.0%	0	%	Unchangeable	<a href="#">"H0b.02" on page 347</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0b.03	0x0B03	Monitored DI status	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.03" on page 347</a>
H0b.05	0x0B05	Monitored DO status	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.05" on page 347</a>
H0b.07	0x0B07	Absolute position counter	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b.07" on page 348</a>
H0b.09	0x0B09	Mechanical angle	0.0° to 360.0°	0	°	Unchangeable	<a href="#">"H0b.09" on page 348</a>
H0b.10	0x0B0A	Electrical angle	0.0° to 360.0°	0	°	Unchangeable	<a href="#">"H0b.10" on page 348</a>
H0b.12	0x0B0C	Average load rate	0.0% to 800.0%	0	%	Unchangeable	<a href="#">"H0b.12" on page 348</a>
H0b.15	0x0B0F	Position following error (encoder unit)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b.15" on page 349</a>
H0b.17	0x0B11	Feedback pulse counter	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b.17" on page 349</a>
H0b.19	0x0B13	Total power-on time	0.0s to 429496729.5s	0	s	Unchangeable	<a href="#">"H0b.19" on page 349</a>
H0b.21	0x0B15	A11 voltage display	-12.000 V to +12.000 V	0	V	Unchangeable	<a href="#">"H0b.21" on page 350</a>
H0b.22	0x0B16	A12 current display	0.000 mA to 21.000 mA	0	mA	Unchangeable	<a href="#">"H0b.22" on page 350</a>
H0b.24	0x0B18	RMS value of phase current	0.0 A to 6553.5 A	0	A	Unchangeable	<a href="#">"H0b.24" on page 350</a>
H0b.25	0x0B19	Angle obtained upon voltage injection auto-tuning	0.0° to 360.0°	0	°	Unchangeable	<a href="#">"H0b.25" on page 350</a>
H0b.26	0x0B1A	Bus voltage	0.0 V to 6553.5 V	0	V	Unchangeable	<a href="#">"H0b.26" on page 351</a>
H0b.27	0x0B1B	Module temperature	-20°C to +200°C	0	°C	Unchangeable	<a href="#">"H0b.27" on page 351</a>
H0b.28	0x0B1C	Absolute encoder fault information given by FPGA	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.28" on page 351</a>
H0b.29	0x0B1D	Axis status information given by FPGA	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.29" on page 351</a>
H0b.30	0x0B1E	Axis fault information given by FPGA	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.30" on page 352</a>
H0b.31	0x0B1F	Encoder fault information	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.31" on page 352</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0b.33	0x0B21	Fault log	0: Present fault 1: Last fault 2: 2nd to last fault 3: 3rd to last fault 4: 4th to last fault 5: 5th to last fault 6: 6th to last fault 7: 7th to last fault 8: 8th to last fault 9: 9th to last fault 10: 10th to last fault 11: 11th to last fault 12: 12th to last fault 13: 13th to last fault 14: 14th to last fault 15: 15th to last fault 16: 16th to last fault 17: 17th to last fault 18: 18th to last fault 19: 19th to last fault	0	-	At once	<a href="#">"H0b.33" on page 352</a>
H0b.34	0x0B22	Fault code of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.34" on page 353</a>
H0b.35	0x0B23	Time stamp upon occurrence of the selected fault	0.0s to 429496729.5s	0	s	Unchangeable	<a href="#">"H0b.35" on page 353</a>
H0b.37	0x0B25	Motor speed upon occurrence of the selected fault	-32767 rpm to +32767 rpm	0	rpm	Unchangeable	<a href="#">"H0b.37" on page 354</a>
H0b.38	0x0B26	Motor phase U current upon occurrence of the selected fault	-3276.7 A to +3276.7 A	0	A	Unchangeable	<a href="#">"H0b.38" on page 354</a>
H0b.39	0x0B27	Motor phase V current upon occurrence of the selected fault	-3276.7 A to +3276.7 A	0	A	Unchangeable	<a href="#">"H0b.39" on page 354</a>
H0b.40	0x0B28	Bus voltage upon occurrence of the selected fault	0.0 V to 6553.5 V	0	V	Unchangeable	<a href="#">"H0b.40" on page 354</a>
H0b.41	0x0B29	DI status upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.41" on page 354</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0b.43	0x0B2B	DO status upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.43" on page 355</a>
H0b.45	0x0B2D	Internal fault code	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.45" on page 355</a>
H0b.46	0x0B2E	Absolute encoder fault information given by FPGA upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.46" on page 355</a>
H0b.47	0x0B2F	System status information given by FPGA upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.47" on page 355</a>
H0b.48	0x0B30	System fault information given by FPGA upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.48" on page 356</a>
H0b.49	0x0B31	Encoder fault information upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.49" on page 356</a>
H0b.51	0x0B33	Internal fault code upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.51" on page 356</a>
H0b.52	0x0B34	FPGA timeout fault standard bit upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.52" on page 356</a>
H0b.53	0x0B35	Position following error (reference unit)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b.53" on page 357</a>
H0b.55	0x0B37	Motor speed actual value	-2147483648 rpm to +2147483647 rpm	0	rpm	Unchangeable	<a href="#">"H0b.55" on page 357</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0b.57	0x0B39	Bus voltage of the control circuit	0.0 V to 6553.5 V	0	V	Unchangeable	<a href="#">"H0b.57" on page 357</a>
H0b.58	0x0B3A	Mechanical absolute position (low 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b.58" on page 358</a>
H0b.60	0x0B3C	Mechanical absolute position (high 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b.60" on page 358</a>
H0b.63	0x0B3F	NotRdy state	1: Control circuit power input error 2: Main circuit power input error 3: Undervoltage 4: Soft start failed 5: Encoder initialization not completed 6: Short circuit to ground failed 7: Others	0	-	Unchangeable	<a href="#">"H0b.63" on page 358</a>
H0b.66	0x0B42	Encoder temperature	-32768°C to +32767°C	0	°C	Unchangeable	<a href="#">"H0b.66" on page 359</a>
H0b.67	0x0B43	Load rate of regenerative resistor	0.0% to 200.0%	0	%	Unchangeable	<a href="#">"H0b.67" on page 359</a>
H0b.70	0x0B46	Number of absolute encoder revolutions	0 Rev to 65535 Rev	0	Rev	Unchangeable	<a href="#">"H0b.70" on page 359</a>
H0b.71	0x0B47	Single-turn position fed back by the absolute encoder	0 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b.71" on page 359</a>
H0b.74	0x0B4A	System fault information given by FPGA	0 to 65535	0	-	Unchangeable	<a href="#">"H0b.74" on page 359</a>
H0b.77	0x0B4D	Encoder position (low 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b.77" on page 360</a>
H0b.79	0x0B4F	Encoder position (high 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b.79" on page 360</a>
H0b.81	0x0B51	Single-turn position of the rotary load (low 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b.81" on page 360</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0b.83	0x0B53	Single-turn position of the rotary load (high 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	"H0b.83" on page 360
H0b.85	0x0B55	Single-turn position of the rotary load (reference unit)	-2147483648 p to +2147483647 p	0	p	Unchangeable	"H0b.85" on page 361
H0b.87	0x0B57	IGBT junction temperature	0 to 200	0	-	Unchangeable	"H0b.87" on page 361
H0b.90	0x0B5A	Group No. of the abnormal parameter	0 to 65535	0	-	At once	"H0b.90" on page 361
H0b.91	0x0B5B	Offset of the abnormal parameter within the group	0 to 65535	0	-	At once	"H0b.91" on page 362
H0b.94	0x0B5E	Individual power-on time	0.0s to 429496729.5s	0	s	Unchangeable	"H0b.94" on page 362
H0b.96	0x0B60	Individual power-on time upon occurrence of the selected fault	0.0s to 429496729.5s	0	s	Unchangeable	"H0b.96" on page 362

### 4.13 Parameter Group H0d

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0d.00	0x0D00	Software reset	0: No operation 1: Enable	0	-	At stop	"H0d.00" on page 362
H0d.01	0x0D01	Fault reset	0: No operation 1: Enable	0	-	At stop	"H0d.01" on page 363
H0d.02	0x0D02	Inertia auto-tuning selection	0 to 65	0	-	At once	"H0d.02" on page 363
H0d.04	0x0D04	Read/write in encoder ROM	0: No operation 1: Write ROM 2: Read ROM 3: ROM failure	0	-	At stop	"H0d.04" on page 363
H0d.05	0x0D05	Emergency stop	0: No operation 1: Enable	0	-	At once	"H0d.05" on page 364
H0d.10	0x0D0A	Auto-tuning of analog channel	0: No operation 1: Adjust A11	0	-	At stop	"H0d.10" on page 364
H0d.12	0x0D0C	Phase U/V current balance correction	0: Disable 1: Enable	0	-	At stop	"H0d.12" on page 364

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0d.17	0x0D11	Forced DI/DO enable switch	bit 0: Forced DI enable switch 0: Disable 1: Enable bit 1: Forced DO enable switch 0: Disable 1: Enable	0	-	At once	<a href="#">"H0d.17" on page 364</a>
H0d.18	0x0D12	Forced DI value	0 to 31	31	-	At once	<a href="#">"H0d.18" on page 365</a>
H0d.19	0x0D13	Forced DO value	0 to 3	0	-	At once	<a href="#">"H0d.19" on page 365</a>
H0d.20	0x0D14	Absolute encoder reset selection	0: No operation 1: Reset the fault 2: Reset the fault and multi-turn data 3: Reset Inovance 2nd encoder fault 4: Reset Inovance 2nd encoder fault and multi-turn data	0	-	At stop	<a href="#">"H0d.20" on page 365</a>
H0d.23	0x0D17	Torque fluctuation auto-tuning	0 to 1	0	-	At stop	<a href="#">"H0d.23" on page 366</a>
H0d.26	0x0D1A	Brake and dynamic brake started forcibly	0: Disable 1: Dynamic brake deactivated forcibly 2: Brake released forcibly 3: Dynamic brake deactivated and brake released forcibly	0	-	At stop	<a href="#">"H0d.26" on page 366</a>

## 4.14 Parameter Group H0E

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0E.00	0x0E00	Node address	1 to 127	1	-	At stop	<a href="#">"H0E.00" on page 366</a>
H0E.01	0x0E01	Save objects written through communication to EEPROM	0: Not save 1: Save parameters written through communication to EEPROM 2: Save object dictionaries written through communication to EEPROM 3: Save parameters and object dictionaries written through communication to EEPROM 4: Save object dictionaries written before communication (OP) to EEPROM	4	-	At once	<a href="#">"H0E.01" on page 367</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0E.07	0x0E07	Object dictionary unit	0: Reference unit system (p/s, p/s <sup>2</sup> ) 1: User unit system (0.01 rpm, ms)	0	-	At stop	<a href="#">"H0E.07" on page 367</a>
H0E.15	0x0E0F	Index of group 6000 (the last two bits)	0 to 255	255	-	At once	<a href="#">"H0E.15" on page 368</a>
H0E.16	0x0E10	Sub-index of group 6000	0 to 2	0	-	At once	<a href="#">"H0E.16" on page 368</a>
H0E.20	0x0E14	EtherCAT slave name	0 to 65535	0	-	Unchangeable	<a href="#">"H0E.20" on page 368</a>
H0E.21	0x0E15	EtherCAT slave alias	0 to 65535	0	-	At stop	<a href="#">"H0E.21" on page 368</a>
H0E.22	0x0E16	Number of SYNC loss events allowed by EtherCAT	1 to 20	8	-	At once	<a href="#">"H0E.22" on page 369</a>
H0E.24	0x0E18	Number of SYNC loss events	0 to 65535	0	-	Unchangeable	<a href="#">"H0E.24" on page 369</a>
H0E.25	0x0E19	Max. error value and invalid frames of EtherCAT port 0 per unit time	0 to 65535	0	-	Unchangeable	<a href="#">"H0E.25" on page 369</a>
H0E.26	0x0E1A	Max. error value and invalid frames of EtherCAT port 1 per unit time	0 to 65535	0	-	Unchangeable	<a href="#">"H0E.26" on page 369</a>
H0E.27	0x0E1B	Max. transfer error of EtherCAT port per unit time	0 to 65535	0	-	Unchangeable	<a href="#">"H0E.27" on page 369</a>
H0E.28	0x0E1C	Max. EtherCAT data frame processing unit error per unit time	0 to 255	0	-	Unchangeable	<a href="#">"H0E.28" on page 370</a>
H0E.29	0x0E1D	Max. link loss value of EtherCAT port 0 per unit time	0 to 65535	0	-	Unchangeable	<a href="#">"H0E.29" on page 370</a>
H0E.31	0x0E1F	EtherCAT synchronization mode setting	0 to 2	2	-	At stop	<a href="#">"H0E.31" on page 370</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0E.32	0x0E20	EtherCAT synchronization error threshold	100 ns to 4000 ns	3000	ns	At stop	<a href="#">" H0E.32" on page 370</a>
H0E.33	0x0E21	EtherCAT state machine state and port connection state	0 to 65535	0	-	Unchangeable	<a href="#">" H0E.33" on page 371</a>
H0E.34	0x0E22	Number of excessive position reference increment events in CSP mode	1 to 30	20	-	At once	<a href="#">" H0E.34" on page 371</a>
H0E.35	0x0E23	AL fault code	0 to 65535	0	-	Unchangeable	<a href="#">" H0E.35" on page 371</a>
H0E.36	0x0E24	EtherCAT enhanced link selection	0: Disable 1: Enable	0	-	At once	<a href="#">" H0E.36" on page 371</a>
H0E.37	0x0E25	EtherCAT XML reset selection	0: Disable 1: Enable	0	-	At once	<a href="#">" H0E.37" on page 372</a>
H0E.80	0x0E50	Modbus baud rate	0: 300 bps 1: 600 bps 2: 1200 bps 3: 2400 bps 4: 4800 bps 5: 9600 bps 6: 19200 bps 7: 38400 bps 8: 57600 bps 9: 115200 bps	9	-	At once	<a href="#">" H0E.80" on page 372</a>
H0E.81	0x0E51	Modbus data format	0: No parity, 2 stop bits (N-2) 1: Even parity, 1 stop bit (E-1) 2: Odd parity, 1 stop bit (O-1) 3: No parity, 1 stop bit (N-1)	3	-	At once	<a href="#">" H0E.81" on page 372</a>
H0E.82	0x0E52	Modbus response delay	0 ms to 20 ms	0	ms	At once	<a href="#">" H0E.82" on page 373</a>
H0E.83	0x0E53	Modbus communication timeout	0 ms to 600 ms	500	ms	At once	<a href="#">" H0E.83" on page 373</a>
H0E.84	0x0E54	Modbus communication data sequence	0: High bits before low bits 1: Low bits before high bits	1	-	At once	<a href="#">" H0E.84" on page 373</a>
H0E.90	0x0E5A	Modbus version	0.00 to 655.35	0	-	Unchangeable	<a href="#">" H0E.90" on page 374</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0E.93	0x0E5D	EtherCAT COE version	0.00 to 655.35	0	-	Unchangeable	<a href="#">"H0E.93" on page 374</a>
H0E.96	0x0E60	XML version information	0.00 to 655.35	0	-	Unchangeable	<a href="#">"H0E.96" on page 374</a>

## 4.15 Parameter Group H0F

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0F.00	0x0F00	Encoder feedback mode	0: Internal encoder feedback 1: External encoder feedback 2: Inner/Outer loop switchover	0	-	At once	<a href="#">"H0F.00" on page 375</a>
H0F.01	0x0F01	External encoder operation mode	0: Standard operating direction 1: Reverse operating direction	0	-	At once	<a href="#">"H0F.01" on page 375</a>
H0F.02	0x0F02	External encoder mode	0: Incremental mode 1: Absolute linear mode	0	-	At stop	<a href="#">"H0F.02" on page 376</a>
H0F.03	0x0F03	External encoder feedback type	0: Quadrature pulse 1: Inovance 2: BiSS	0	-	At stop	<a href="#">"H0F.03" on page 376</a>
H0F.04	0x0F04	External encoder pulses per revolution	0 to 2147483647	10000	-	At stop	<a href="#">"H0F.04" on page 376</a>
H0F.08	0x0F08	Excessive deviation threshold in compound control mode	0 to 2147483647	1000	-	At once	<a href="#">"H0F.08" on page 377</a>
H0F.10	0x0F0A	Clear deviation in compound control mode	0 to 100	1	R	At once	<a href="#">"H0F.10" on page 377</a>
H0F.13	0x0F0D	Compound vibration suppression filter time	0.0 ms to 6553.5 ms	0	ms	At stop	<a href="#">"H0F.13" on page 378</a>
H0F.16	0x0F10	Pulse deviation display in compound control mode	-2147483648 to +2147483647	0	Reference unit	Unchangeable	<a href="#">"H0F.16" on page 378</a>
H0F.18	0x0F12	Internal position pulse feedback display	-2147483648 to +2147483647	0	Reference unit	Unchangeable	<a href="#">"H0F.18" on page 378</a>
H0F.20	0x0F14	External position pulse feedback display	-2147483648 to +2147483647	0	Reference unit	Unchangeable	<a href="#">"H0F.20" on page 379</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H0F.22	0x0F16	External encoder phase Z detection invalid (quadrature pulse feedback)	0: Detected 1: Not detected	0	-	At once	<a href="#">"H0F.22" on page 379</a>
H0F.23	0x0F17	BiSS absolute homing offset	-2147483648 to +2147483647	0	-	At once	<a href="#">"H0F.23" on page 379</a>
H0F.25	0x0F19	Source of touch probe Z signal in fully closed-loop mode	0: Motor Z signal 1: External feedback Z signal	0	-	At once	<a href="#">"H0F.25" on page 379</a>
H0F.26	0x0F1A	BiSS absolute feedback offset	-2147483648 to +2147483647	0	-	At once	<a href="#">"H0F.26" on page 380</a>
H0F.28	0x0F1C	Index value of BiSS communication warning	0 to 65535	0	-	Unchangeable	<a href="#">"H0F.28" on page 380</a>
H0F.29	0x0F1D	CRC of BiSS fully closed-loop feedback	0: Positive 1: Negative	1	-	At once	<a href="#">"H0F.29" on page 380</a>
H0F.30	0x0F1E	Valid bit of BiSS communication position feedback	0 to 127	29	-	At stop	<a href="#">"H0F.30" on page 380</a>
H0F.31	0x0F1F	Valid bit of BiSS communication warning index	0 to 31	2	-	At stop	<a href="#">"H0F.31" on page 381</a>
H0F.40	0x0F28	Inovance fully closed-loop encoder communication error register	0 to 65535	0	-	Unchangeable	<a href="#">"H0F.40" on page 381</a>
H0F.41	0x0F29	Inovance fully closed-loop encoder version	0.0 to 6553.5	0	-	Unchangeable	<a href="#">"H0F.41" on page 381</a>
H0F.42	0x0F2A	Inovance fully closed-loop encoder resolution	0 to 4294967295	0	-	Unchangeable	<a href="#">"H0F.42" on page 381</a>



## 4.16 Parameter Group H11

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H11.00	0x1100	Multi-position operation mode	0: Individual operation (number of displacements defined by H11.01) 1: Cyclic operation (number of displacement defined by H11.01) 2: DI-based operation (defined by DI) 3: Sequential operation 5: Axis-controlled continuous operation	1	-	At stop	"H11.00" on page 382
H11.01	0x1101	Number of displacement references in multi-position mode	1 to 16	1	-	At stop	"H11.01" on page 383
H11.02	0x1102	Starting displacement No. after pause	0: Continue to execute the unexecuted displacements 1: Start from displacement 1	0	-	At stop	"H11.02" on page 383
H11.03	0x1103	Interval time unit	0: ms 1: s	0	-	At stop	"H11.03" on page 384
H11.04	0x1104	Displacement reference type	0: Relative displacement reference 1: Absolute displacement reference	0	-	At once	"H11.04" on page 384
H11.05	0x1105	Starting displacement No. in sequential operation	0 to 16	0	-	At stop	"H11.05" on page 384
H11.09	0x1109	Deceleration upon axis control OFF	0 ms to 65535 ms	65535	ms	At once	"H11.09" on page 385
H11.10	0x110A	Starting speed of displacement 1	0 rpm to 9999 rpm	0	rpm	At once	"H11.10" on page 385
H11.11	0x110B	Stop speed of displacement 1	0 rpm to 9999 rpm	0	rpm	At once	"H11.11" on page 385
H11.12	0x110C	Displacement 1	-1073741824 to +1073741824	10000	Reference unit	At once	"H11.12" on page 385
H11.14	0x110E	Maximum speed of displacement 1	1 rpm to 9999 rpm	200	rpm	At once	"H11.14" on page 386

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H11.15	0x110F	Acceleration/ Deceleration time of displacement 1	0 ms to 65535 ms	10	ms	At once	<a href="#">"H11.15" on page 386</a>
H11.16	0x1110	Interval time after displacement 1	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	<a href="#">"H11.16" on page 386</a>
H11.17	0x1111	Displacement 2	-1073741824 to +1073741824	10000	Refer ence unit	At once	<a href="#">"H11.17" on page 387</a>
H11.19	0x1113	Maximum speed of displacement 2	1 rpm to 9999 rpm	200	rpm	At once	<a href="#">"H11.19" on page 387</a>
H11.20	0x1114	Acceleration/ Deceleration time of displacement 2	0 ms to 65535 ms	10	ms	At once	<a href="#">"H11.20" on page 387</a>
H11.21	0x1115	Interval time after displacement 2	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	<a href="#">"H11.21" on page 387</a>
H11.22	0x1116	Displacement 3	-1073741824 to +1073741824	10000	Refer ence unit	At once	<a href="#">"H11.22" on page 388</a>
H11.24	0x1118	Maximum speed of displacement 3	1 rpm to 9999 rpm	200	rpm	At once	<a href="#">"H11.24" on page 388</a>
H11.25	0x1119	Acceleration/ Deceleration time of displacement 3	0 ms to 65535 ms	10	ms	At once	<a href="#">"H11.25" on page 388</a>
H11.26	0x111A	Interval time after displacement 3	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	<a href="#">"H11.26" on page 388</a>
H11.27	0x111B	Displacement 4	-1073741824 to +1073741824	10000	Refer ence unit	At once	<a href="#">"H11.27" on page 389</a>
H11.29	0x111D	Maximum speed of displacement 4	1 rpm to 9999 rpm	200	rpm	At once	<a href="#">"H11.29" on page 389</a>
H11.30	0x111E	Acceleration/ Deceleration time of displacement 4	0 ms to 65535 ms	10	ms	At once	<a href="#">"H11.30" on page 389</a>
H11.31	0x111F	Interval time after displacement 4	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	<a href="#">"H11.31" on page 389</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H11.32	0x1120	Displacement 5	-1073741824 to +1073741824	10000	Reference unit	At once	" H11.32" on page 390
H11.34	0x1122	Maximum speed of displacement 5	1 rpm to 9999 rpm	200	rpm	At once	" H11.34" on page 390
H11.35	0x1123	Acceleration/Deceleration time of displacement 5	0 ms to 65535 ms	10	ms	At once	" H11.35" on page 390
H11.36	0x1124	Interval time after displacement 5	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	" H11.36" on page 390
H11.37	0x1125	Displacement 6	-1073741824 to +1073741824	10000	Reference unit	At once	" H11.37" on page 391
H11.39	0x1127	Maximum speed of displacement 6	1 rpm to 9999 rpm	200	rpm	At once	" H11.39" on page 391
H11.40	0x1128	Acceleration/Deceleration time of displacement 6	0 ms to 65535 ms	10	ms	At once	" H11.40" on page 391
H11.41	0x1129	Interval time after displacement 6	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	" H11.41" on page 391
H11.42	0x112A	Displacement 7	-1073741824 to +1073741824	10000	Reference unit	At once	" H11.42" on page 392
H11.44	0x112C	Maximum speed of displacement 7	1 rpm to 9999 rpm	200	rpm	At once	" H11.44" on page 392
H11.45	0x112D	Acceleration/Deceleration time of displacement 7	0 ms to 65535 ms	10	ms	At once	" H11.45" on page 392
H11.46	0x112E	Interval time after displacement 7	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	" H11.46" on page 392
H11.47	0x112F	Displacement 8	-1073741824 to +1073741824	10000	Reference unit	At once	" H11.47" on page 393
H11.49	0x1131	Maximum speed of displacement 8	1 rpm to 9999 rpm	200	rpm	At once	" H11.49" on page 393

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H11.50	0x1132	Acceleration/ Deceleration time of displacement 8	0 ms to 65535 ms	10	ms	At once	<a href="#">" H11.50" on page 393</a>
H11.51	0x1133	Interval time after displacement 8	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	<a href="#">" H11.51" on page 393</a>
H11.52	0x1134	Displacement 9	-1073741824 to +1073741824	10000	Refer ence unit	At once	<a href="#">" H11.52" on page 394</a>
H11.54	0x1136	Maximum speed of displacement 9	1 rpm to 9999 rpm	200	rpm	At once	<a href="#">" H11.54" on page 394</a>
H11.55	0x1137	Acceleration/ Deceleration time of displacement 9	0 ms to 65535 ms	10	ms	At once	<a href="#">" H11.55" on page 394</a>
H11.56	0x1138	Interval time after displacement 9	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	<a href="#">" H11.56" on page 394</a>
H11.57	0x1139	Displacement 10	-1073741824 to +1073741824	10000	Refer ence unit	At once	<a href="#">" H11.57" on page 395</a>
H11.59	0x113B	Maximum speed of displacement 10	1 rpm to 9999 rpm	200	rpm	At once	<a href="#">" H11.59" on page 395</a>
H11.60	0x113C	Acceleration/ Deceleration time of displacement 10	0 ms to 65535 ms	10	ms	At once	<a href="#">" H11.60" on page 395</a>
H11.61	0x113D	Interval time after displacement 10	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	<a href="#">" H11.61" on page 395</a>
H11.62	0x113E	Displacement 11	-1073741824 to +1073741824	10000	Refer ence unit	At once	<a href="#">" H11.62" on page 396</a>
H11.64	0x1140	Maximum speed of displacement 11	1 rpm to 9999 rpm	200	rpm	At once	<a href="#">" H11.64" on page 396</a>
H11.65	0x1141	Acceleration/ Deceleration time of displacement 11	0 ms to 65535 ms	10	ms	At once	<a href="#">" H11.65" on page 396</a>
H11.66	0x1142	Interval time after displacement 11	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	<a href="#">" H11.66" on page 396</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H11.67	0x1143	Displacement 12	-1073741824 to +1073741824	10000	Reference unit	At once	" H11.67" on page 397
H11.69	0x1145	Maximum speed of displacement 12	1 rpm to 9999 rpm	200	rpm	At once	" H11.69" on page 397
H11.70	0x1146	Acceleration/Deceleration time of displacement 12	0 ms to 65535 ms	10	ms	At once	" H11.70" on page 397
H11.71	0x1147	Interval time after displacement 12	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	" H11.71" on page 397
H11.72	0x1148	Displacement 13	-1073741824 to +1073741824	10000	Reference unit	At once	" H11.72" on page 398
H11.74	0x114A	Maximum speed of displacement 13	1 rpm to 9999 rpm	200	rpm	At once	" H11.74" on page 398
H11.75	0x114B	Acceleration/Deceleration time of displacement 13	0 ms to 65535 ms	10	ms	At once	" H11.75" on page 398
H11.76	0x114C	Interval time after displacement 13	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	" H11.76" on page 398
H11.77	0x114D	Displacement 14	-1073741824 to +1073741824	10000	Reference unit	At once	" H11.77" on page 399
H11.79	0x114F	Maximum speed of displacement 14	1 rpm to 9999 rpm	200	rpm	At once	" H11.79" on page 399
H11.80	0x1150	Acceleration/Deceleration time of displacement 14	0 ms to 65535 ms	10	ms	At once	" H11.80" on page 399
H11.81	0x1151	Interval time after displacement 14	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	" H11.81" on page 399
H11.82	0x1152	Displacement 15	-1073741824 to +1073741824	10000	Reference unit	At once	" H11.82" on page 400
H11.84	0x1154	Maximum speed of displacement 15	1 rpm to 9999 rpm	200	rpm	At once	" H11.84" on page 400

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H11.85	0x1155	Acceleration/ Deceleration time of displacement 15	0 ms to 65535 ms	10	ms	At once	<a href="#">"H11.85" on page 400</a>
H11.86	0x1156	Interval time after displacement 15	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	<a href="#">"H11.86" on page 400</a>
H11.87	0x1157	Displacement 16	-1073741824 to +1073741824	10000	Refer ence unit	At once	<a href="#">"H11.87" on page 401</a>
H11.89	0x1159	Maximum speed of displacement 16	1 rpm to 9999 rpm	200	rpm	At once	<a href="#">"H11.89" on page 401</a>
H11.90	0x115A	Acceleration/ Deceleration time of displacement 16	0 ms to 65535 ms	10	ms	At once	<a href="#">"H11.90" on page 401</a>
H11.91	0x115B	Interval time after displacement 16	0 ms(s) to 10000 ms(s)	10	ms (s)	At once	<a href="#">"H11.91" on page 401</a>

## 4.17 Parameter Group H12

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H12.00	0x1200	Multi-speed operation mode	0: Individual operation (number of speeds defined by H12.01) 1: Cyclic operation (number of speeds defined by H12.01) 2: DI-based operation	1	-	At stop	<a href="#">"H12.00" on page 402</a>
H12.01	0x1201	Number of speed references in multi-speed mode	1 to 16	16	-	At stop	<a href="#">"H12.01" on page 402</a>
H12.02	0x1202	Operating time unit	0: s 1: min	0	-	At stop	<a href="#">"H12.02" on page 403</a>
H12.03	0x1203	Acceleration time 1	0 ms to 65535 ms	10	ms	At once	<a href="#">"H12.03" on page 403</a>
H12.04	0x1204	Deceleration time 1	0 ms to 65535 ms	10	ms	At once	<a href="#">"H12.04" on page 403</a>
H12.05	0x1205	Acceleration time 2	0 ms to 65535 ms	50	ms	At once	<a href="#">"H12.05" on page 403</a>
H12.06	0x1206	Deceleration time 2	0 ms to 65535 ms	50	ms	At once	<a href="#">"H12.06" on page 404</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H12.07	0x1207	Acceleration time 3	0 ms to 65535 ms	100	ms	At once	<a href="#">" H12.07" on page 404</a>
H12.08	0x1208	Deceleration time 3	0 ms to 65535 ms	100	ms	At once	<a href="#">" H12.08" on page 404</a>
H12.09	0x1209	Acceleration time 4	0 ms to 65535 ms	150	ms	At once	<a href="#">" H12.09" on page 405</a>
H12.10	0x120A	Deceleration time 4	0 ms to 65535 ms	150	ms	At once	<a href="#">" H12.10" on page 405</a>
H12.20	0x1214	Speed reference for speed 1	-9999 to +9999	0	rpm	At once	<a href="#">" H12.20" on page 405</a>
H12.21	0x1215	Operating time of speed 1	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.21" on page 406</a>
H12.22	0x1216	Acceleration/Deceleration time of speed 1	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.22" on page 406</a>
H12.23	0x1217	Speed reference for speed 2	-9999 to +9999	100	rpm	At once	<a href="#">" H12.23" on page 407</a>
H12.24	0x1218	Operating time of speed 2	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.24" on page 407</a>
H12.25	0x1219	Acceleration/Deceleration time of speed 2	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.25" on page 407</a>
H12.26	0x121A	Speed reference for speed 3	-9999 to +9999	300	rpm	At once	<a href="#">" H12.26" on page 407</a>
H12.27	0x121B	Operating time of speed 3	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.27" on page 408</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H12.28	0x121C	Acceleration/ Deceleration time of speed 3	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.28" on page 408</a>
H12.29	0x121D	Speed reference for speed 4	-9999 to +9999	500	rpm	At once	<a href="#">" H12.29" on page 408</a>
H12.30	0x121E	Operating time of speed 4	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.30" on page 408</a>
H12.31	0x121F	Acceleration/ Deceleration time of speed 4	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.31" on page 409</a>
H12.32	0x1220	Speed reference for speed 5	-9999 to +9999	700	rpm	At once	<a href="#">" H12.32" on page 409</a>
H12.33	0x1221	Operating time of speed 5	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.33" on page 409</a>
H12.34	0x1222	Acceleration/ Deceleration time of speed 5	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.34" on page 410</a>
H12.35	0x1223	Speed reference for speed 6	-9999 to +9999	900	rpm	At once	<a href="#">" H12.35" on page 410</a>
H12.36	0x1224	Operating time of speed 6	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.36" on page 410</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H12.37	0x1225	Acceleration/ Deceleration time of speed 6	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.37" on page 410</a>
H12.38	0x1226	Speed reference for speed 7	-9999 to +9999	600	rpm	At once	<a href="#">" H12.38" on page 411</a>
H12.39	0x1227	Operating time of speed 7	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.39" on page 411</a>
H12.40	0x1228	Acceleration/ Deceleration time of speed 7	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.40" on page 411</a>
H12.41	0x1229	Speed reference for speed 8	-9999 to +9999	300	rpm	At once	<a href="#">" H12.41" on page 412</a>
H12.42	0x122A	Operating time of speed 8	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.42" on page 412</a>
H12.43	0x122B	Acceleration/ Deceleration time of speed 8	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.43" on page 412</a>
H12.44	0x122C	Speed reference for speed 9	-9999 to +9999	100	rpm	At once	<a href="#">" H12.44" on page 412</a>
H12.45	0x122D	Operating time of speed 9	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.45" on page 413</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H12.46	0x122E	Acceleration/ Deceleration time of speed 9	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.46" on page 413</a>
H12.47	0x122F	Speed reference for speed 10	-9999 to +9999	-100	rpm	At once	<a href="#">" H12.47" on page 413</a>
H12.48	0x1230	Operating time of speed 10	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.48" on page 413</a>
H12.49	0x1231	Acceleration/ Deceleration time of speed 10	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.49" on page 414</a>
H12.50	0x1232	Speed reference for speed 11	-9999 to +9999	-300	rpm	At once	<a href="#">" H12.50" on page 414</a>
H12.51	0x1233	Operating time of speed 11	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.51" on page 414</a>
H12.52	0x1234	Acceleration/ Deceleration time of speed 11	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.52" on page 415</a>
H12.53	0x1235	Speed reference for speed 12	-9999 to +9999	-500	rpm	At once	<a href="#">" H12.53" on page 415</a>
H12.54	0x1236	Operating time of speed 12	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.54" on page 415</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H12.55	0x1237	Acceleration/ Deceleration time of speed 12	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.55" on page 415</a>
H12.56	0x1238	Speed reference for speed 13	-9999 to +9999	-700	rpm	At once	<a href="#">" H12.56" on page 416</a>
H12.57	0x1239	Operating time of speed 13	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.57" on page 416</a>
H12.58	0x123A	Acceleration/ Deceleration time of speed 13	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.58" on page 416</a>
H12.59	0x123B	Speed reference for speed 14	-9999 to +9999	-900	rpm	At once	<a href="#">" H12.59" on page 417</a>
H12.60	0x123C	Operating time of speed 14	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.60" on page 417</a>
H12.61	0x123D	Acceleration/ Deceleration time of speed 14	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.61" on page 417</a>
H12.62	0x123E	Speed reference for speed 15	-9999 to +9999	-600	rpm	At once	<a href="#">" H12.62" on page 417</a>
H12.63	0x123F	Operating time of speed 15	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.63" on page 418</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H12.64	0x1240	Acceleration/ Deceleration time of speed 15	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.64" on page 418</a>
H12.65	0x1241	Speed reference for speed 16	-9999 to +9999	-300	rpm	At once	<a href="#">" H12.65" on page 418</a>
H12.66	0x1242	Operating time of speed 16	0.0s(m) to 6553.5s(m)	5	s (m)	At once	<a href="#">" H12.66" on page 418</a>
H12.67	0x1243	Acceleration/ Deceleration time of speed 16	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	At once	<a href="#">" H12.67" on page 419</a>

## 4.18 Parameter Group H17

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.90	0x175A	Communication VDI enable	0: Disable 1: Enable	0	-	At stop	<a href="#">"H17.90" on page 419</a>
H17.91	0x175B	VDI default value upon power-on	0: 0x0: No default 1: 0x01: VDI1 default value 2: 0x02: VDI2 default value 4: 0x04: VDI3 default value 8: 0x08: VDI4 default value 16: 0x10: VDI5 default value 32: 0x20: VDI6 default value 64: 0x40: VDI7 default value 128: 0x80: VDI8 default value 256: 0x100: VDI9 default value 512: 0x200: VDI10 default value 1024: 0x400: VDI11 default value 2048: 0x800: VDI12 default value 4096: 0x1000: VDI13 default value 8092: 0x2000: VDI14 default value 16384: 0x4000: VDI15 default value 32768: 0x8000: VDI16 default value	0	-	At once	<a href="#">"H17.91" on page 419</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.00	0x1700	VDI1 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<i>"H17.00" on page 420</i>
H17.01	0x1701	VDI1 logic level	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<i>"H17.01" on page 421</i>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.02	0x1702	VDI2 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<a href="#">" H17.02" on page 421</a>
H17.03	0x1703	VDI2 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">" H17.03" on page 422</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.04	0x1704	VDI3 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<i>"H17.04" on page 422</i>
H17.05	0x1705	VDI3 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<i>"H17.05" on page 423</i>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.06	0x1706	VDI4 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<i>" H17.06" on page 423</i>
H17.07	0x1707	VDI4 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<i>" H17.07" on page 424</i>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.08	0x1708	VDI5 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<i>" H17.08" on page 424</i>
H17.09	0x1709	VDI5 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<i>" H17.09" on page 425</i>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.10	0x170A	VDI6 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<a href="#">"H17.10" on page 425</a>
H17.11	0x170B	VDI6 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17.11" on page 426</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.12	0x170C	VDI7 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<i>"H17.12" on page 426</i>
H17.13	0x170D	VDI7 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<i>"H17.13" on page 426</i>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.14	0x170E	VDI8 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<i>"H17.14" on page 427</i>
H17.15	0x170F	VDI8 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<i>"H17.15" on page 427</i>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.16	0x1710	VDI9 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<i>" H17.16" on page 428</i>
H17.17	0x1711	VDI9 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<i>" H17.17" on page 428</i>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.18	0x1712	VDI10 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<a href="#">" H17.18" on page 428</a>
H17.19	0x1713	VDI10 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">" H17.19" on page 429</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.20	0x1714	VDI11 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<i>"H17.20" on page 429</i>
H17.21	0x1715	VDI11 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<i>"H17.21" on page 429</i>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.22	0x1716	VDI12 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<i>"H17.22" on page 430</i>
H17.23	0x1717	VDI12 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<i>"H17.23" on page 430</i>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.24	0x1718	VDI13 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<i>"H17.24" on page 431</i>
H17.25	0x1719	VDI13 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<i>"H17.25" on page 431</i>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.26	0x171A	VDI14 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<a href="#">" H17.26" on page 431</a>
H17.27	0x171B	VDI14 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">" H17.27" on page 432</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.28	0x171C	VDI15 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<a href="#">"H17.28" on page 432</a>
H17.29	0x171D	VDI15 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17.29" on page 433</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.30	0x171E	VDI16 function	0: No assignment 1: Servo ON 2: Alarm reset signal 5: Multi-reference direction 6: Multi-reference switchover CMD1 7: Multi-reference switchover CMD2 8: Multi-reference switchover CMD3 9: Multi-reference switchover CMD4 14: Positive limit switch 15: Negative limit switch 18: Forward jog 19: Reverse jot 24: Electronic gear ratio selection 28: Multi-position reference enable 31: Home switch 34: Emergency stop 40: Multi-speed enable	0	-	At once	<a href="#">" H17.30" on page 433</a>
H17.31	0x171F	VDI16 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">" H17.31" on page 434</a>
H17.92	0x175C	Communication VDO enable	0: Disable 1: Enable	0	-	At stop	<a href="#">" H17.92" on page 434</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.93	0x175D	VDO default value after power-on	0: 0x0: No default 1: 0x01: VDI1 default value 2: 0x02: VDI2 default value 4: 0x04: VDI3 default value 8: 0x08: VDI4 default value 16: 0x10: VDI5 default value 32: 0x20: VDI6 default value 64: 0x40: VDI7 default value 128: 0x80: VDI8 default value 256: 0x100: VDI9 default value 512: 0x200: VDI10 default value 1024: 0x400: VDI11 default value 2048: 0x800: VDI12 default value 4096: 0x1000: VDI13 default value 8192: 0x2000: VDI14 default value 16384: 0x4000: VDI15 default value 32768: 0x8000: VDI16 default value	0	-	At stop	<a href="#">"H17.93" on page 434</a>
H17.32	0x1720	VDO virtual level	0 to 65535	0	-	At once	<a href="#">"H17.32" on page 435</a>
H17.33	0x1721	VDO1 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">"H17.33" on page 435</a>
H17.34	0x1722	VDO1 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">"H17.34" on page 436</a>
H17.35	0x1723	VDO2 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">"H17.35" on page 436</a>
H17.36	0x1724	VDO2 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">"H17.36" on page 436</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.37	0x1725	VDO3 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">" H17.37" on page 437</a>
H17.38	0x1726	VDO3 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">" H17.38" on page 437</a>
H17.39	0x1727	VDO4 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">" H17.39" on page 437</a>
H17.40	0x1728	VDO4 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">" H17.40" on page 438</a>
H17.41	0x1729	VDO5 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">" H17.41" on page 438</a>
H17.42	0x172A	VDO5 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">" H17.42" on page 438</a>
H17.43	0x172B	VDO6 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">" H17.43" on page 439</a>
H17.44	0x172C	VDO6 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">" H17.44" on page 439</a>
H17.45	0x172D	VDO7 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">" H17.45" on page 439</a>
H17.46	0x172E	VDO7 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">" H17.46" on page 440</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.47	0x172F	VDO8 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">"H17.47" on page 440</a>
H17.48	0x1730	VDO8 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">"H17.48" on page 440</a>
H17.49	0x1731	VDO9 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">"H17.49" on page 441</a>
H17.50	0x1732	VDO9 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">"H17.50" on page 441</a>
H17.51	0x1733	VDO10 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">"H17.51" on page 441</a>
H17.52	0x1734	VDO10 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">"H17.52" on page 442</a>
H17.53	0x1735	VDO11 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">"H17.53" on page 442</a>
H17.54	0x1736	VDO11 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">"H17.54" on page 442</a>
H17.55	0x1737	VDO12 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">"H17.55" on page 443</a>
H17.56	0x1738	VDO12 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">"H17.56" on page 443</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H17.57	0x1739	VDO13 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">" H17.57" on page 443</a>
H17.58	0x173A	VDO13 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">" H17.58" on page 444</a>
H17.59	0x173B	VDO14 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">" H17.59" on page 444</a>
H17.60	0x173C	VDO14 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">" H17.60" on page 444</a>
H17.61	0x173D	VDO15 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">" H17.61" on page 445</a>
H17.62	0x173E	VDO15 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">" H17.62" on page 445</a>
H17.63	0x173F	VDO16 function	0: No assignment 1: Servo ready 2: Motor rotating 10: Warning 11: Fault 31: Communication-forced DO 32: EDM output	0	-	At once	<a href="#">" H17.63" on page 445</a>
H17.64	0x1740	VDO16 logic level	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	At once	<a href="#">" H17.64" on page 446</a>

## 4.19 Parameter Group H18

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H18.00	0x1800	Position comparison output selection	0: Disable 1: Enable (rising edge-triggered)	0	-	At once	<a href="#">"H18.00" on page 446</a>
H18.01	0x1801	Position comparison output feedback source	0: Motor encoder feedback 1: Fully closed-loop position feedback	0	-	At once	<a href="#">"H18.01" on page 446</a>
H18.02	0x1802	Position comparison resolution	0: 24-bit 1: 23-bit 2: 22-bit 3: 21-bit 4: 20-bit 5: 19-bit 6: 18-bit 7: 17-bit	1	-	At once	<a href="#">"H18.02" on page 447</a>
H18.03	0x1803	Position comparison mode	0: Individual comparison mode 1: Cyclic comparison mode 2: Fixed cyclic comparison mode	0	-	At once	<a href="#">"H18.03" on page 447</a>
H18.04	0x1804	Current position as zero	0: Disable 1: Enable (rising edge-triggered)	0	-	At once	<a href="#">"H18.04" on page 447</a>
H18.05	0x1805	Position comparison output width	0.1 ms to 204.7 ms	0.1	ms	At once	<a href="#">"H18.05" on page 448</a>
H18.06	0x1806	Position comparison output ABZ port polarity	bit 0: OCZ output logic 0: Positive, output high level upon active logic 1: Negative, output low level upon active logic bit 1: Z port output logic 0: Positive, output high level upon active logic 1: Negative, output low level upon active logic bit 2: A/B output logic 0: Positive, output high level upon active logic 1: Negative, output low level upon active logic	0	-	At once	<a href="#">"H18.06" on page 448</a>
H18.07	0x1807	Start point of position comparison	0 to 40	0	-	At once	<a href="#">"H18.07" on page 448</a>
H18.08	0x1808	End point of position comparison	0 to 40	0	-	At once	<a href="#">"H18.08" on page 449</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H18.09	0x1809	Current status of position comparison	0 to 1024	0	-	Unchangeable	<a href="#">"H18.09" on page 449</a>
H18.10	0x180A	Real-time position of position comparison	-2147483648 to +2147483647	0	-	Unchangeable	<a href="#">"H18.10" on page 449</a>
H18.12	0x180C	Zero offset of position comparison	-2147483648 to +2147483647	0	-	At once	<a href="#">"H18.12" on page 449</a>
H18.14	0x180E	Position comparison output delay compensation	-12.00 us to +12.00 us	0	us	At once	<a href="#">"H18.14" on page 450</a>
H18.15	0x180F	Cycles of fixed mode	1 to 65535	1	-	At once	<a href="#">"H18.15" on page 450</a>
H18.16	0x1810	ABZ output function setting	bit 0: OCZ output function 0: Frequency-division output 1: Position comparison bit 1: Z port output function 0: Frequency-division output 1: Position comparison bit 2: A/B port output function 0: Frequency-division output 1: Position comparison	0	-	At once	<a href="#">"H18.16" on page 450</a>
H18.17	0x1811	Number of fixed modes completed	0 to 65535	0	-	Unchangeable	<a href="#">"H18.17" on page 451</a>

## 4.20 Parameter Group H19

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.00	0x1900	Target value of position comparison 1	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.00" on page 451</a>
H19.02	0x1902	Attribute value of position comparison 1	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.02" on page 451</a>
H19.03	0x1903	Target value of position comparison 2	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.03" on page 452</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.05	0x1905	Attribute value of position comparison 2	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">" H19.05" on page 453</a>
H19.06	0x1906	Target value of position comparison 3	-2147483648 to +2147483647	0	-	At once	<a href="#">" H19.06" on page 453</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.08	0x1908	Attribute value of position comparison 3	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.08" on page 453</a>
H19.09	0x1909	Target value of position comparison 4	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.09" on page 454</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.11	0x190B	Attribute value of position comparison 4	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.11" on page 454</a>
H19.12	0x190C	Target value of position comparison 5	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.12" on page 455</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.14	0x190E	Attribute value of position comparison 5	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.14" on page 455</a>
H19.15	0x190F	Target value of position comparison 6	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.15" on page 456</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.17	0x1911	Attribute value of position comparison 6	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.17" on page 456</a>
H19.18	0x1912	Target value of position comparison 7	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.18" on page 457</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.20	0x1914	Attribute value of position comparison 7	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.20" on page 457</a>
H19.21	0x1915	Target value of position comparison 8	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.21" on page 458</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.23	0x1917	Attribute value of position comparison 8	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">" H19.23" on page 458</a>
H19.24	0x1918	Target value of position comparison 9	-2147483648 to +2147483647	0	-	At once	<a href="#">" H19.24" on page 459</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.26	0x191A	Attribute value of position comparison 9	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.26" on page 459</a>
H19.27	0x191B	Target value of position comparison 10	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.27" on page 460</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.29	0x191D	Attribute value of position comparison 10	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.29" on page 460</a>
H19.30	0x191E	Target value of position comparison 11	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.30" on page 461</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.32	0x1920	Attribute value of position comparison 11	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.32" on page 461</a>
H19.33	0x1921	Target value of position comparison 12	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.33" on page 462</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.35	0x1923	Attribute value of position comparison 12	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">" H19.35" on page 462</a>
H19.36	0x1924	Target value of position comparison 13	-2147483648 to +2147483647	0	-	At once	<a href="#">" H19.36" on page 463</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.38	0x1926	Attribute value of position comparison 13	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.38" on page 463</a>
H19.39	0x1927	Target value of position comparison 14	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.39" on page 464</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.41	0x1929	Attribute value of position comparison 14	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.41" on page 464</a>
H19.42	0x192A	Target value of position comparison 15	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.42" on page 465</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.44	0x192C	Attribute value of position comparison 15	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">" H19.44" on page 465</a>
H19.45	0x192D	Target value of position comparison 16	-2147483648 to +2147483647	0	-	At once	<a href="#">" H19.45" on page 466</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.47	0x192F	Attribute value of position comparison 16	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">" H19.47" on page 466</a>
H19.48	0x1930	Target value of position comparison 17	-2147483648 to +2147483647	0	-	At once	<a href="#">" H19.48" on page 467</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.50	0x1932	Attribute value of position comparison 17	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.50" on page 467</a>
H19.51	0x1933	Target value of position comparison 18	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.51" on page 468</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.53	0x1935	Attribute value of position comparison 18	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.53" on page 468</a>
H19.54	0x1936	Target value of position comparison 19	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.54" on page 469</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.56	0x1938	Attribute value of position comparison 19	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.56" on page 469</a>
H19.57	0x1939	Target value of position comparison 20	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.57" on page 470</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.59	0x193B	Attribute value of position comparison 20	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">" H19.59" on page 470</a>
H19.60	0x193C	Target value of position comparison 21	-2147483648 to +2147483647	0	-	At once	<a href="#">" H19.60" on page 471</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.62	0x193E	Attribute value of position comparison 21	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.62" on page 471</a>
H19.63	0x193F	Target value of position comparison 22	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.63" on page 472</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.65	0x1941	Attribute value of position comparison 22	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">" H19.65" on page 472</a>
H19.66	0x1942	Target value of position comparison 23	-2147483648 to +2147483647	0	-	At once	<a href="#">" H19.66" on page 473</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.68	0x1944	Attribute value of position comparison 23	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.68" on page 473</a>
H19.69	0x1945	Target value of position comparison 24	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.69" on page 474</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.71	0x1947	Attribute value of position comparison 24	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.71" on page 474</a>
H19.72	0x1948	Target value of position comparison 25	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.72" on page 475</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.74	0x194A	Attribute value of position comparison 25	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.74" on page 475</a>
H19.75	0x194B	Target value of position comparison 26	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.75" on page 476</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.77	0x194D	Attribute value of position comparison 26	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">" H19.77" on page 476</a>
H19.78	0x194E	Target value of position comparison 27	-2147483648 to +2147483647	0	-	At once	<a href="#">" H19.78" on page 477</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.80	0x1950	Attribute value of position comparison 27	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.80" on page 477</a>
H19.81	0x1951	Target value of position comparison 28	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.81" on page 478</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.83	0x1953	Attribute value of position comparison 28	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.83" on page 478</a>
H19.84	0x1954	Target value of position comparison 29	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.84" on page 479</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.86	0x1956	Attribute value of position comparison 29	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.86" on page 479</a>
H19.87	0x1957	Target value of position comparison 30	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.87" on page 480</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.89	0x1959	Attribute value of position comparison 30	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">" H19.89" on page 480</a>
H19.90	0x195A	Target value of position comparison 31	-2147483648 to +2147483647	0	-	At once	<a href="#">" H19.90" on page 481</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.92	0x195C	Attribute value of position comparison 31	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.92" on page 481</a>
H19.93	0x195D	Target value of position comparison 32	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.93" on page 482</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.95	0x195F	Attribute value of position comparison 32	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.95" on page 482</a>
H19.96	0x1960	Target value of position comparison 33	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.96" on page 483</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.98	0x1962	Attribute value of position comparison 33	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.98" on page 483</a>
H19.99	0x1963	Target value of position comparison 34	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.99" on page 484</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.101	0x1965	Attribute value of position comparison 34	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.101" on page 484</a>
H19.102	0x1966	Target value of position comparison 35	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.102" on page 485</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.104	0x1968	Attribute value of position comparison 35	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.104" on page 485</a>
H19.105	0x1969	Target value of position comparison 36	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.105" on page 486</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.107	0x196B	Attribute value of position comparison 36	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.107" on page 486</a>
H19.108	0x196C	Target value of position comparison 37	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.108" on page 487</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.110	0x196E	Attribute value of position comparison 37	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.110" on page 487</a>
H19.111	0x196F	Target value of position comparison 38	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.111" on page 488</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.113	0x1971	Attribute value of position comparison 38	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.113" on page 488</a>
H19.114	0x1972	Target value of position comparison 39	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.114" on page 489</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.116	0x1974	Attribute value of position comparison 39	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.116" on page 489</a>
H19.117	0x1975	Target value of position comparison 40	-2147483648 to +2147483647	0	-	At once	<a href="#">"H19.117" on page 490</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H19.119	0x1977	Attribute value of position comparison 40	bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point bit 2: N/A bit 3: N/A bit 4: N/A bit 5: N/A bit 6: N/A bit 7: DO1 output bit 8: DO2 output bit 9: N/A bit 10: N/A bit 11: N/A bit 12: Frequency-division A output bit 13: Frequency-division B output bit 14: Frequency-division Z output bit 15: Frequency-division OCZ output	0	-	At once	<a href="#">"H19.119" on page 490</a>

## 4.21 Parameter Group H1F

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H1F.90	0x1F5A	DI function state 1 read through communication	0 to 65535	0	-	Unchangeable	<a href="#">"H1F.90" on page 491</a>
H1F.91	0x1F5B	DI function state 2 read through communication	0 to 65535	0	-	Unchangeable	<a href="#">"H1F.91" on page 491</a>
H1F.92	0x1F5C	DI function state 3 read through communication	0 to 65535	0	-	Unchangeable	<a href="#">"H1F.92" on page 492</a>
H1F.93	0x1F5D	DI function state 4 read through communication	0 to 65535	0	-	Unchangeable	<a href="#">"H1F.93" on page 492</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H1F.94	0x1F5E	DO function state 1 read through communication	0 to 65535	0	-	Unchangeable	<a href="#">"H1F.94" on page 492</a>
H1F.95	0x1F5F	DO function state 2 read through communication	0 to 65535	0	-	Unchangeable	<a href="#">"H1F.95" on page 493</a>

## 4.22 Parameter Group H30

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H30.00	0x3000	Servo status read through communication	0 to 65535	0	-	Unchangeable	<a href="#">"H30.00" on page 493</a>
H30.01	0x3001	DO function state 1 read through communication	0 to 65535	0	-	Unchangeable	<a href="#">"H30.01" on page 493</a>
H30.02	0x3002	DO function state 2 read through communication	0 to 65535	0	-	Unchangeable	<a href="#">"H30.02" on page 494</a>

## 4.23 Parameter Group H31

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
H31.00	0x3100	VDI virtual level set through communication	0 to 65535	0	-	At once	<a href="#">"H31.00" on page 494</a>
H31.04	0x3104	DO status set through communication	0 to 65535	0	-	At once	<a href="#">"H31.04" on page 495</a>
H31.05	0x3105	AO set through communication	-10000 mV to +10000 mV	0	mV	At once	<a href="#">"H31.05" on page 495</a>
H31.09	0x3109	Speed reference set through communication	-9999.000 rpm to +9999.000 rpm	0	rpm	At once	<a href="#">"H31.09" on page 495</a>
H31.11	0x310B	Torque reference set through communication	-100.000% to +100.000%	0	%	At once	<a href="#">"H31.11" on page 495</a>

## 4.24 Parameter Group 1000h

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
1000.00h	0x5405	Device type	0 to 65535	0	-	Unchangeable	"1000.00h" on page 496
1001.00h	0x5406	Error register	0 to 255	0	-	Unchangeable	"1001.00h" on page 496
1018.01h	0x5401	Vendor ID	0 to 65535	0	-	Unchangeable	"1018.01h" on page 496
1018.02h	0x5402	Product code	0 to 65535	0	-	Unchangeable	"1018.02h" on page 496
1018.03h	0x5403	Revision number	0 to 65535	0	-	Unchangeable	"1018.03h" on page 497
1600.00h	0x3900	Number of valid mapped objects in RPDO1	0 to 20	3	-	At once	"1600.00h" on page 497
1600.01h	0x3901	1st mapped object in RPDO1	0 to 2147483647	1614807040	-	At once	"1600.01h" on page 497
1600.02h	0x3902	2nd mapped object in RPDO1	0 to 2147483647	1618608128	-	At once	"1600.02h" on page 497
1600.03h	0x3903	3rd mapped object in RPDO1	0 to 2147483647	1622671360	-	At once	"1600.03h" on page 498
1600.04h	0x3904	4th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.04h" on page 498
1600.05h	0x3905	5th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.05h" on page 498
1600.06h	0x3906	6th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.06h" on page 498
1600.07h	0x3907	7th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.07h" on page 499
1600.08h	0x3908	8th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.08h" on page 499
1600.09h	0x3909	9th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.09h" on page 499
1600.0Ah	0x390A	10th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.0Ah" on page 499
1600.0Bh	0x390B	11th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.0Bh" on page 500
1600.0Ch	0x390C	12th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.0Ch" on page 500
1600.0Dh	0x390D	13th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.0Dh" on page 500
1600.0Eh	0x390E	14th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.0Eh" on page 500

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
1600.0Fh	0x390F	15th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.0Fh" on page 501
1600.10h	0x3910	16th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.10h" on page 501
1600.11h	0x3911	17th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.11h" on page 501
1600.12h	0x3912	18th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.12h" on page 501
1600.13h	0x3913	19th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.13h" on page 502
1600.14h	0x3914	20th mapped object in RPDO1	0 to 2147483647	0	-	At once	"1600.14h" on page 502
1A00.00h	0x4000	Number of valid mapped objects in TPDO1	0 to 20	7	-	At once	"1A00.00h" on page 502
1A00.01h	0x4001	1st mapped object in TPDO1	0 to 2147483647	1614872576	-	At once	"1A00.01h" on page 502
1A00.02h	0x4002	2nd mapped object in TPDO1	0 to 2147483647	1617166336	-	At once	"1A00.02h" on page 503
1A00.03h	0x4003	3rd mapped object in TPDO1	0 to 2147483647	1622736896	-	At once	"1A00.03h" on page 503
1A00.04h	0x4004	4th mapped object in TPDO1	0 to 2147483647	1622802432	-	At once	"1A00.04h" on page 503
1A00.05h	0x4005	5th mapped object in TPDO1	0 to 2147483647	1622933504	-	At once	"1A00.05h" on page 503
1A00.06h	0x4006	6th mapped object in TPDO1	0 to 2147483647	1614741504	-	At once	"1A00.06h" on page 504
1A00.07h	0x4007	7th mapped object in TPDO1	0 to 2147483647	1627193344	-	At once	"1A00.07h" on page 504
1A00.08h	0x4008	8th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.08h" on page 504
1A00.09h	0x4009	9th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.09h" on page 504
1A00.0Ah	0x400A	10th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.0Ah" on page 505
1A00.0Bh	0x400B	11th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.0Bh" on page 505
1A00.0Ch	0x400C	12th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.0Ch" on page 505
1A00.0Dh	0x400D	13th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.0Dh" on page 505
1A00.0Eh	0x400E	14th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.0Eh" on page 506
1A00.0Fh	0x400F	15th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.0Fh" on page 506

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
1A00.10h	0x4010	16th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.10h" on page 506
1A00.11h	0x4011	17th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.11h" on page 506
1A00.12h	0x4012	18th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.12h" on page 507
1A00.13h	0x4013	19th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.13h" on page 507
1A00.14h	0x4014	20th mapped object in TPDO1	0 to 2147483647	0	-	At once	"1A00.14h" on page 507
1C12.00h	0x5000	Number of assigned PDOs	0 to 2	1	-	At once	"1C12.00h" on page 507
1C12.01h	0x5001	Index of assigned RPDO1	5632 to 5898	0	-	At once	"1C12.01h" on page 508
1C12.02h	0x5002	Index of assigned RPDO2	5632 to 5898	0	-	At once	"1C12.02h" on page 508
1C13.00h	0x5100	Number of assigned PDOs	0 to 2	0	-	At once	"1C13.00h" on page 508
1C13.01h	0x5101	Index of assigned TPDO1	6656 to 6922	0	-	At once	"1C13.01h" on page 508
1C13.02h	0x5102	Index of assigned TPDO2	6656 to 6922	0	-	At once	"1C13.02h" on page 509
1C32.01h	0x5201	Synchronization type	0 to 65535	0	-	At once	"1C32.01h" on page 509
1C32.02h	0x5202	Cycle time	0 to 4294967295	0	-	At once	"1C32.02h" on page 509
1C32.04h	0x5204	Synchronization types supported	0 to 65535	0	-	At once	"1C32.04h" on page 509
1C32.05h	0x5205	Minimum cycle time	0 to 4294967295	0	-	At once	"1C32.05h" on page 510
1C33.01h	0x5301	Synchronization type	0 to 65535	0	-	At once	"1C33.01h" on page 510
1C33.02h	0x5302	Cycle time	0 to 4294967295	0	-	At once	"1C33.02h" on page 510
1C33.04h	0x5304	Synchronization types supported	0 to 65535	0	-	At once	"1C33.04h" on page 510
1C33.05h	0x5305	Minimum cycle time	0 to 4294967295	0	-	At once	"1C33.05h" on page 511

## 4.25 Parameter Group 6000h

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
603Fh	0x3500	Error Code	0 to 65535	0	-	Unchangeable	<a href="#">"603Fh" on page 511</a>
6040h	0x3502	Control word	0 to 65535	0	-	At once	<a href="#">"6040h" on page 511</a>
6041h	0x3504	Status word	0 to 65535	0	-	Unchangeable	<a href="#">"6041h" on page 512</a>
605Ah	0x3536	Quick stop option code	0: Coast to stop, keeping de-energized state 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state 2: Ramp to stop as defined by 6085h, keeping de-energized state 3: Stop at emergency stop torque, keeping de-energized state 5: Ramp to stop as defined by 6084h/609Ah (HM), keeping position lock state 6: Ramp to stop as defined by 6085h, keeping position lock state 7: Stop at emergency stop torque, keeping position lock state	2	-	At stop	<a href="#">"605Ah" on page 512</a>



List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
605Ch	0x353A	Disable operation option code	-4: Ramp to stop as defined by 6085h, keeping dynamic braking state -3: Stop at zero speed, keeping dynamic braking state -2: Ramp to stop as defined by 6084h/609Ah (HM), keeping dynamic braking state -1: Dynamic braking stop, keeping dynamic braking state 0: Coast to stop, keeping de-energized state 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state 2: Dynamic braking stop, keeping de-energized state	0	-	At stop	<a href="#">"605Ch" on page 512</a>
605Dh	0x353C	Stop option code	1: Ramp to stop as defined by 6084h/609Ah (HM), keeping position lock state 2: Ramp to stop as defined by 6085h, keeping position lock state 3: Stop at emergency stop torque, keeping position lock state	1	-	At stop	<a href="#">"605Dh" on page 513</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
605Eh	0x353E	Fault reaction option code	<p>-5: Stop at zero speed, keeping dynamic braking state</p> <p>-4: Stop at emergency stop torque, keeping dynamic braking state</p> <p>-3: Ramp to stop as defined by 6085h, keeping dynamic braking state</p> <p>-2: Ramp to stop as defined by 6084h/609Ah (HM), keeping dynamic braking state</p> <p>-1: Dynamic braking stop, keeping dynamic braking state</p> <p>0: Coast to stop, keeping de-energized state</p> <p>1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state</p> <p>2: Ramp to stop as defined by 6085h, keeping de-energized state</p> <p>3: Stop at emergency stop torque, keeping de-energized state</p> <p>4: Dynamic braking stop, keeping de-energized state</p>	2	-	At stop	<i>"605Eh" on page 513</i>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
6060h	0x3542	Modes of operation	1: Profile position (PP) mode 3: Profile velocity (PV) mode 4: Profile torque (PT) mode 6: Homing (HM) mode 8: Cyclic synchronous position (CSP) mode 9: Cyclic synchronous velocity (CSV) mode 10: Cyclic synchronous torque (CST) mode	0	-	At once	<a href="#">" 6060h" on page 514</a>
6061h	0x3544	Modes of operation display	1: Profile position (PP) mode 3: Profile velocity (PV) mode 4: Profile torque (PT) mode 6: Homing (HM) mode 8: Cyclic synchronous position (CSP) mode 9: Cyclic synchronous velocity (CSV) mode 10: Cyclic synchronous torque (CST) mode	0	-	Unchangeable	<a href="#">" 6061h" on page 515</a>
6062h	0x3546	Position demand value	-2147483648 to +2147483647	0	Reference unit	Unchangeable	<a href="#">" 6062h" on page 515</a>
6063h	0x3548	Position actual value	-2147483648 to +2147483647	0	Pulse	Unchangeable	<a href="#">" 6063h" on page 516</a>
6064h	0x354A	Position actual value	-2147483648 to +2147483647	0	Reference unit	Unchangeable	<a href="#">" 6064h" on page 516</a>
6065h	0x354C	Following error window	0 to 4294967295	219895608	Reference unit	At once	<a href="#">" 6065h" on page 516</a>
6066h	0x354E	Following error time out	0 ms to 65535 ms	0	ms	At once	<a href="#">" 6066h" on page 516</a>
6067h	0x3550	Position window	0 to 4294967295	46976	Reference unit	At once	<a href="#">" 6067h" on page 517</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
6068h	0x3552	Position window time	0 ms to 65535 ms	0	ms	At once	<a href="#">"6068h" on page 517</a>
606Ch	0x355A	Velocity actual value	-2147483648 to +2147483647	0	Reference unit/s	Unchangeable	<a href="#">"606Ch" on page 517</a>
606Dh	0x355C	Velocity window	0 rpm to 65535 rpm	10	rpm	At once	<a href="#">"606Dh" on page 518</a>
606Eh	0x355E	Velocity window time	0 ms to 65535 ms	0	ms	At once	<a href="#">"606Eh" on page 518</a>
606Fh	0x3560	Velocity threshold	0 rpm to 65535 rpm	10	rpm	At once	<a href="#">"606Fh" on page 518</a>
6070h	0x3562	Velocity threshold time	0 ms to 65535 ms	0	ms	At once	<a href="#">"6070h" on page 519</a>
6071h	0x3564	Target torque	-4000 to +4000	0	0.001	At once	<a href="#">"6071h" on page 519</a>
6072h	0x3566	Max. torque value	0 to 4000	3500	0.001	At once	<a href="#">"6072h" on page 519</a>
6074h	0x356A	Torque demand value	-4000 to +4000	0	0.001	Unchangeable	<a href="#">"6074h" on page 519</a>
6077h	0x3570	Torque actual value	-4000 to +4000	0	0.001	Unchangeable	<a href="#">"6077h" on page 520</a>
607Ah	0x3576	Target position	-2147483648 to +2147483647	0	Reference unit	At once	<a href="#">"607Ah" on page 520</a>
607Ch	0x357A	Home offset	-2147483648 to +2147483647	0	Reference unit	At once	<a href="#">"607Ch" on page 520</a>
607D.01h	0x3700	Min. position limit	-2147483648 to +2147483647	-2147483648	Reference unit	At once	<a href="#">"607D.01h" on page 521</a>
607D.02h	0x3800	Max. position limit	-2147483648 to +2147483647	2147483647	Reference unit	At once	<a href="#">"607D.02h" on page 521</a>
607Eh	0x357E	Polarity	0 to 127	0	-	At once	<a href="#">"607Eh" on page 522</a>
607Fh	0x3580	Max. profile velocity	0 to 4294967295	4294967295	Reference unit/s	At once	<a href="#">"607Fh" on page 522</a>
6081h	0x3584	Profile velocity	0 to 4294967295	111848106	Reference unit/s	At once	<a href="#">"6081h" on page 522</a>
6083h	0x3588	Profile acceleration	0 to 4294967295	4294967295	Reference unit/s <sup>2</sup>	At once	<a href="#">"6083h" on page 523</a>
6084h	0x358A	Profile deceleration	0 to 4294967295	4294967295	Reference unit/s <sup>2</sup>	At once	<a href="#">"6084h" on page 523</a>
6085h	0x358C	Quick stop deceleration	0 to 4294967295	2147483648	Reference unit/s <sup>2</sup>	At once	<a href="#">"6085h" on page 523</a>
6087h	0x3590	Torque slope	0 to 4294967295	4294967295	0.1%/s	At once	<a href="#">"6087h" on page 524</a>
6091.01h	0x3714	Motor revolutions	1 to 4294967295	1	-	At stop	<a href="#">"6091.01h" on page 524</a>

List of Parameters

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
6091.02h	0x3814	Shaft revolutions	1 to 4294967295	1	-	At stop	<a href="#">"6091.02h" on page 525</a>
6098h	0x35B2	Homing method	-2 to +35	1	-	At once	<a href="#">"6098h" on page 525</a>
6099.01h	0x371C	Speed during search for switch	0 to 4294967295	111848106	Reference unit/s	At stop	<a href="#">"6099.01h" on page 526</a>
6099.02h	0x381C	Speed during search for zero	0 to 4294967295	11184810	Reference unit/s	At stop	<a href="#">"6099.02h" on page 526</a>
609Ah	0x35B6	Homing acceleration	0 to 4294967295	4294967295	Reference unit/s <sup>2</sup>	At once	<a href="#">"609Ah" on page 527</a>
60B0h	0x35E2	Position offset	-2147483648 to +2147483647	0	Reference unit	At once	<a href="#">"60B0h" on page 527</a>
60B1h	0x35E4	Velocity offset	-2147483648 to +2147483647	0	Reference unit/s	At once	<a href="#">"60B1h" on page 527</a>
60B2h	0x35E6	Torque offset	-4000 to +4000	0	0.001	At once	<a href="#">"60B2h" on page 527</a>
60B8h	0x35F2	Touch probe function	0 to 65535	0	-	At once	<a href="#">"60B8h" on page 528</a>
60B9h	0x35F4	Touch probe status	0 to 65535	0	-	Unchangeable	<a href="#">"60B9h" on page 529</a>
60BAh	0x35F6	Touch probe 1 positive edge	-2147483648 to +2147483647	0	Reference unit	Unchangeable	<a href="#">"60BAh" on page 530</a>
60BBh	0x35F8	Touch probe 1 negative edge	-2147483648 to +2147483647	0	Reference unit	Unchangeable	<a href="#">"60BBh" on page 530</a>
60BCh	0x35FA	Touch probe 2 positive edge	-2147483648 to +2147483647	0	Reference unit	Unchangeable	<a href="#">"60BCh" on page 531</a>
60BDh	0x35FC	Touch probe 2 negative edge	-2147483648 to +2147483647	0	Reference unit	Unchangeable	<a href="#">"60BDh" on page 531</a>
60C5h	0x360C	Max. acceleration	0 to 4294967295	4294967295	Reference unit/s <sup>2</sup>	At once	<a href="#">"60C5h" on page 531</a>
60C6h	0x360E	Max. deceleration	0 to 4294967295	4294967295	Reference unit/s <sup>2</sup>	At once	<a href="#">"60C6h" on page 531</a>
60D5h	0x362C	Touch probe 1 positive edge counter	0 to 65535	0	-	Unchangeable	<a href="#">"60D5h" on page 532</a>
60D6h	0x362E	Touch probe 1 negative edge counter	0 to 65535	0	-	Unchangeable	<a href="#">"60D6h" on page 532</a>
60D7h	0x3630	Touch probe 2 positive edge counter	0 to 65535	0	-	Unchangeable	<a href="#">"60D7h" on page 532</a>
60D8h	0x3632	Touch probe 2 negative edge counter	0 to 65535	0	-	Unchangeable	<a href="#">"60D8h" on page 532</a>

Param. No.	Address	Name	Setpoint	Default	Unit	Change	Page
60E0h	0x3642	Positive torque limit value	0 to 4000	3500	0.001	At once	<a href="#">"60E0h" on page 533</a>
60E1h	0x3644	Negative torque limit value	0 to 4000	3500	0.001	At once	<a href="#">"60E1h" on page 533</a>
60E6h	0x364E	Actual position calculation method	0 to 1	0	-	At once	<a href="#">"60E6h" on page 533</a>
60F4h	0x366A	Following error actual value	-2147483648 to +2147483647	0	Reference unit	Unchangeable	<a href="#">"60F4h" on page 534</a>
60FCh	0x367A	Position demand value	-2147483648 to +2147483647	0	pulse	Unchangeable	<a href="#">"60FCh" on page 534</a>
60FDh	0x367C	Digital inputs	0 to 4294967295	0	-	Unchangeable	<a href="#">"60FDh" on page 534</a>
60FFh	0x3680	Target velocity	-2147483648 to +2147483647	0	Reference unit/s	At once	<a href="#">"60FFh" on page 535</a>
60FE.01h	0x3781	Physical outputs	0 to 4294967295	0	-	At once	<a href="#">"60FE.01h" on page 535</a>
60FE.02h	0x3881	Bitmask	0 to 4294967295	0	-	At once	<a href="#">"60FE.02h" on page 536</a>

## 5 Parameter Descriptions

### 5.1 H00: Servo Motor Parameters

#### H00.00 Motor code

Address: 0x0000

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 14102

Change: At stop

#### Value Range:

0 to 65535

#### Description

14000: Inovance motor with 20-bit incremental encoder

14101: Inovance motor with 23-bit absolute encoder

14102: Inovance motor with 26-bit absolute encoder

#### H00.02 Customized No.

Address: 0x0002

Min.: 0

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 0

Change: Unchangeable

#### Value Range:

0.00 to 4294967295.00

#### Description

Used to differentiate the customized MCU software version, which is not applicable to standard models.

#### H00.04 Encoder version

Address: 0x0004

Min.: 0

Unit: -

Max.: 6553.5

Data Type: UInt16

Default: 0

Change: Unchangeable

#### Value Range:

0.0 to 6553.5

#### Description

Saved in the encoder to differentiate the encoder software version.

#### H00.05 Serial-type motor code

Address: 0x0005

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

Displays the code of the serial-type motor, which is determined by the motor model.

**H00.06 Customized FPGA No.**

Address: 0x0006

Min.: 0

Unit: -

Max.: 655.35

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0.00 to 655.35

**Description**

Used to differentiate the customized FPGA software version, which is not applicable to standard models.

**H00.07 STO version**

Address: 0x0007

Min.: 0

Unit: -

Max.: 655.35

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0.00 to 655.35

**Description**

Displays the software version of the STO function.

**H00.08 Serial encoder type**

Address: 0x0008

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0 to 65535

**Description**

14100: Multi-turn absolute encoder

Others: Single-turn absolute encoder



## 5.2 H01: Servo Drive Parameters

### H01.00 MCU software version

Address: 0x0100

Min.: 0

Unit: -

Max.: 6553.5

Data Type: UInt16

Default: 0

Change: Unchangeable

#### Value Range:

0.0 to 6553.5

#### Description

Displays the MCU software version (with one decimal place).

### H01.01 FPGA software version

Address: 0x0101

Min.: 0

Unit: -

Max.: 6553.5

Data Type: UInt16

Default: 0

Change: Unchangeable

#### Value Range:

0.0 to 6553.5

#### Description

Displays the FPGA software version (with one decimal place).

### H01.02 Servo drive series No.

Address: 0x0102

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

#### Value Range:

0 to 65535

#### Description

Displays the servo drive series No. (without decimal place).

### H01.06 Board software version

Address: 0x0106

Min.: 0

Unit: -

Max.: 6553.5

Data Type: UInt16

Default: 0

Change: Unchangeable

Setpoint

0.0 to 6553.5

#### Description

Displays the board software version (with one decimal place).

**H01.10 Drive series No.**

Address: 0x010A

Min.: 0

Max.: 65535

Default: 3

Unit: -

Data Type: UInt16

Change: At stop

**Value Range:**

2: S1R6

3: S2R8

5: S5R5

6: S7R6

7: S012

8: S018

9: S022

10: S027

10001: T3R5

10002: T5R4

10003: T8R4

10004: T012

10005: T017

10006: T021

10007: T026

**Description**

Displays the drive series No. (without decimal place).

**H01.11 DC-AC voltage class**

Address: 0x010B

Min.: 0

Max.: 65535

Default: 220

Unit: V

Data Type: UInt16

Change: Unchangeable

**Value Range:**

0 V to 65535 V

**Description**

Displays DC-AC voltage class (without decimal place).

**H01.12 Rated power of the drive**

Address: 0x010C

Min.: 0

Max.: 10737418.24

Default: 0.4

Unit: kW

Data Type: UInt32

Change: Unchangeable

**Value Range:**

0.00 kW to 10737418.24 kW

**Description**

Displays the rated power of the servo drive (with two decimal places).

**H01.14 Max. output power of the drive**

Address: 0x010E

Min.: 0

Unit: kW

Max.: 10737418.24

Data Type: UInt32

Default: 0.4

Change: Unchangeable

**Value Range:**

0.00 kW to 10737418.24 kW

**Description**

Displays the maximum output power of the drive (with two decimal places).

**H01.16 Rated output current of the drive**

Address: 0x0110

Min.: 0

Unit: A

Max.: 10737418.24

Data Type: UInt32

Default: 2.8

Change: Unchangeable

**Value Range:**

0.00 A to 10737418.24 A

**Description**

Displays the rated output current of the drive (with two decimal places).

**H01.18 Max. output current of the drive**

Address: 0x0112

Min.: 0

Unit: A

Max.: 10737418.24

Data Type: UInt32

Default: 10.1

Change: Unchangeable

**Value Range:**

0.00 A to 10737418.24 A

**Description**

Displays the maximum output current of the drive (with two decimal places).

**H01.40 DC bus overvoltage protection threshold**

Address: 0x0128

Min.: 0

Unit: V

Max.: 2000

Data Type: UInt16

Default: 420

Change: At once

**Value Range:**

0 V to 2000 V

**Description**

Displays DC bus overvoltage protection threshold (without decimal place).

**H01.75 Current loop amplification factor**

Address: 0x014B

Min.: 0

Unit: -

Max.: 655.35

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

0.00 to 655.35

**Description**

Displays current loop amplification coefficient (with two decimal places).

**H01.89 Junction temperature parameter version**

Address: 0x0159

Min.: 0

Unit: -

Max.: 655.35

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0.00 to 655.35

**Description**

Displays the junction temperature parameter version.

**5.3 H02: Basic Control Parameters****H02.00 Control mode**

Address: 0x0200

Min.: 0

Unit: -

Max.: 9

Data Type: UInt16

Default: 9

Change: At stop

**Value Range:**

0: Speed control mode

1: Position control mode

2: Torque control mode

9: EtherCAT mode

**Description**

0: Speed control mode

1: Position control mode

2: Torque control mode

9: EtherCAT mode

**H02.01 Absolute system selection**

Address: 0x0201

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Incremental mode

1: Absolute position linear mode

2: Absolute position rotation mode

3: Absolute position linear mode (without encoder overflow warning)

4: Absolute position single-turn mode

**Description**

Used to set the absolute position function.

**H02.02 Direction of rotation**

Address: 0x0202

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Counterclockwise (CCW) as forward direction

1: Clockwise (CW) as forward direction

**Description**

Defines the forward direction of the motor when viewed from the motor shaft side.

**H02.03 Output pulse phase**

Address: 0x0203

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Phase A leads phase B

1: Phase A lags behind phase B

**Description**

Defines the relationship between phase A and phase B on the condition that the motor direction of rotation remains unchanged when pulse output is enabled.

**H02.05 Stop mode at S-ON OFF**

Address: 0x0205

Min.: -4

Unit: -



- 0: Coast to stop, keeping de-energized state
- 1: Stop at zero speed, keeping position lock state
- 2: Stop at zero speed, keeping de-energized state
- 3: Ramp to stop as defined by 6085h, keeping de-energized state
- 4: Ramp to stop as defined by 6085h, keeping position lock state
- 5: Dynamic braking stop, keeping de-energized state
- 6: Dynamic braking stop, keeping dynamic braking state
- 7: Not responding to overtravel

**Description**

Defines the deceleration mode of the servo motor for stopping rotating and the servo motor status when overtravel occurs.

**H02.08 Stop mode at No. 1 fault**

Address: 0x0208

Min.:	0	Unit:	-
Max.:	2	Data Type:	UInt16
Default:	2	Change:	At stop

**Value Range:**

- 0: Coast to stop, keeping de-energized state
- 1: Dynamic braking stop, keeping de-energized state
- 2: Dynamic braking stop, keeping dynamic braking state

**Description**

Defines the deceleration mode of the servo motor for stopping rotating and the servo motor status when a No. 1 fault occurs.

**H02.09 Delay from brake output ON to command received**

Address: 0x0209

Min.:	0	Unit:	ms
Max.:	500	Data Type:	UInt16
Default:	250	Change:	At once

**Value Range:**

0 ms to 500 ms

**Description**

Defines the delay from the moment the brake (BK) output signal is ON to the moment the servo drive starts to receive commands after power-on.

**H02.10 Delay from brake output OFF to motor de-energized**

Address: 0x020A

Min.:	50	Unit:	ms
Max.:	1000	Data Type:	UInt16
Default:	150	Change:	At once

**Value Range:**

50 ms to 1000 ms

**Description**

Defines the delay from the moment brake output is OFF to the moment when the motor at standstill enters the de-energized status.

**H02.11 Speed threshold at brake output OFF in rotation state**

Address: 0x020B

Min.: 20

Unit: rpm

Max.: 3000

Data Type: UInt16

Default: 30

Change: At once

**Value Range:**

20 rpm to 3000 rpm

**Description**

Defines the motor speed threshold when brake (BK) output is OFF in the rotation state.

**H02.12 Delay from S-ON OFF to brake output OFF in the rotation state**

Address: 0x020C

Min.: 1

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 500

Change: At once

**Value Range:**

1 ms to 65535 ms

**Description**

Defines the delay from the moment the S-ON signal is OFF to the moment the brake (BK) output signal is OFF in the rotation state.

**H02.15 Warning display on the keypad**

Address: 0x020F

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output warning information immediately

1: Not output warning information

**Description**

Defines whether to switch the keypad to the fault display mode when a No. 3 fault occurs.

**H02.16 Brake enable switch**

Address: 0x0210



Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0: OFF

1: ON

**Description**

Used to turn on or off the brake function.

**H02.17 Stop mode upon main circuit power failure**

Address: 0x0211

Min.:	0	Unit:	-
Max.:	3	Data Type:	UInt16
Default:	2	Change:	At once

**Value Range:**

0: Keep present action

1: Stop upon fault as defined by H02.06

2: Stop at S-ON OFF as defined by H02.05

3: Stop quickly as defined by H02.18

**Description**

Defines the stop mode of the motor for stopping rotating upon main circuit power failure.

**H02.18 Quick stop mode**

Address: 0x0212

Min.:	0	Unit:	-
Max.:	7	Data Type:	UInt16
Default:	2	Change:	At once

**Value Range:**

0: Coast to stop, keeping de-energized state

1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state

2: Ramp to stop as defined by 6085h, keeping de-energized state

3: Stop at emergency stop torque, keeping de-energized state

5: Ramp to stop as defined by 6084h/609Ah (HM), keeping position lock state

6: Ramp to stop as defined by 6085h, keeping position lock state

7: Stop at emergency stop torque, keeping position lock state

**Description**

Defines the deceleration mode of the motor for stopping rotating upon quick stop and the motor status after stop.

**H02.21 Permissible minimum resistance of regenerative resistor**

Address: 0x0215

Min.:	1	Unit:	$\Omega$
Max.:	1000	Data Type:	UInt16
Default:	40	Change:	Unchangeable

**Value Range:**1  $\Omega$  to 1000  $\Omega$ **Description**

-

**H02.22 Power of built-in regenerative resistor**

Address: 0x0216

Min.:	0	Unit:	W
Max.:	65535	Data Type:	UInt16
Default:	50	Change:	Unchangeable

**Value Range:**

0 W to 65535 W

**Description**

The power of the built-in regenerative resistor is only related to the servo drive model, which is unchangeable.

**H02.23 Resistance of built-in regenerative resistor**

Address: 0x0217

Min.:	0	Unit:	$\Omega$
Max.:	65535	Data Type:	UInt16
Default:	50	Change:	Unchangeable

**Value Range:**0  $\Omega$  to 65535  $\Omega$ **Description**

The resistance of the built-in regenerative resistor is only related to the servo drive model, which is unchangeable.

**H02.24 Resistor heat dissipation coefficient**

Address: 0x0218

Min.:	10	Unit:	%
Max.:	100	Data Type:	UInt16
Default:	30	Change:	At once

**Value Range:**

10% to 100%

**Description**

Defines the heat dissipation coefficient of the regenerative resistor, which is applicable to both external and built-in regenerative resistors.

Set this parameter properly according to actual heat dissipation conditions of the resistor.

Recommendations:

Generally, the value of H02.24 cannot exceed 30% for natural cooling or 50% for forced air cooling.

### **H02.25 Regenerative resistor type**

Address: 0x0219

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 3

Change: At once

#### **Value Range:**

0: Built-in

1: External, natural cooling

2: External, forced air cooling

3: No resistor needed

#### **Description**

Defines the resistor type and the mode of absorbing and releasing the braking energy.

### **H02.26 Power of external regenerative resistor**

Address: 0x021A

Min.: 1

Unit: W

Max.: 65535

Data Type: UInt16

Default: 40

Change: At once

#### **Value Range:**

1 W to 65535 W

#### **Description**

Defines the power of external regenerative resistor.

### **H02.27 Resistance of external regenerative resistor**

Address: 0x021B

Min.: 15

Unit:  $\Omega$

Max.: 1000

Data Type: UInt16

Default: 50

Change: At once

#### **Value Range:**

15  $\Omega$  to 1000  $\Omega$

#### **Description**

Defines the resistance of the external regenerative resistor.

**H02.30 User password**

Address: 0x021E

Min.: 0

Max.: 65535

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0 to 65535

**Description**

-

**H02.31 System parameter initialization**

Address: 0x021F

Min.: 0

Max.: 2

Default: 0

Unit: -

Data Type: UInt16

Change: At stop

**Value Range:**

0: No operation

1: Restore default settings

2: Clear fault records

**Description**

Used to restore default values or clear fault records.

**H02.32 Selection of parameters in group H0b**

Address: 0x0220

Min.: 0

Max.: 99

Default: 50

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0 to 99

**Description**

Used to set the offset of the parameter to be displayed on the keypad.

For example, the setpoint 0 indicates the value of H0b.00 (Motor speed actual value) is displayed on the keypad.

The setpoint 1 indicates the value of H0b.01 (Speed reference) is displayed on the keypad.

**H02.35 Keypad data refresh frequency**

Address: 0x0223

Min.: 0

Max.: 20

Default: 0

Unit: Hz

Data Type: UInt16

Change: At once

**Value Range:**

0 Hz to 20 Hz

**Description**

-

**H02.41 Manufacturer password**

Address: 0x0229

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 65535

**Description**

-

## 5.4 H03: Terminal Input Parameters

**H03.02 D11 function**

Address: 0x0302

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 14

Change: At once

**Value Range:**

0: No assignment

1: Servo ON

2: Alarm reset signal

5: Multi-reference direction

6: Multi-reference switchover CMD1

7: Multi-reference switchover CMD2

8: Multi-reference switchover CMD3

9: Multi-reference switchover CMD4

14: Positive limit switch

15: Negative limit switch

18: Forward jog

19: Reverse jog

24: Electronic gear ratio selection

28: Multi-position reference enable

31: Home switch

34: Emergency stop

38: Touch probe 1

39: Touch probe 2

40: Multi-speed enable

**Description**

Defines the function of DI1.

**H03.03 D11 logic**

Address: 0x0303

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Normally open

1: Closed

**Description**

Used to set the level logic of DI1 when the function assigned to DI1 is active.

**H03.04 D12 function**

Address: 0x0304

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 15

Change: At once

**Value Range:**

0: No assignment

1: Servo ON

2: Alarm reset signal

5: Multi-reference direction

6: Multi-reference switchover CMD1

7: Multi-reference switchover CMD2

8: Multi-reference switchover CMD3

9: Multi-reference switchover CMD4

14: Positive limit switch

15: Negative limit switch

18: Forward jog

19: Reverse jog

24: Electronic gear ratio selection

28: Multi-position reference enable

31: Home switch

34: Emergency stop

38: Touch probe 1

39: Touch probe 2

40: Multi-speed enable

**Description**

-

**H03.05 D12 logic**

Address: 0x0305

Min.: 0

Max.: 1

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: Normally open

1: Closed

**Description**

-

**H03.06 D13 function**

Address: 0x0306

Min.: 0

Max.: 40

Default: 31

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: No assignment

1: Servo ON

2: Alarm reset signal

5: Multi-reference direction

6: Multi-reference switchover CMD1

7: Multi-reference switchover CMD2

8: Multi-reference switchover CMD3

9: Multi-reference switchover CMD4

14: Positive limit switch

15: Negative limit switch

18: Forward jog

19: Reverse jog

24: Electronic gear ratio selection

28: Multi-position reference enable

31: Home switch

34: Emergency stop

38: Touch probe 1

39: Touch probe 2

40: Multi-speed enable

**Description**

Defines the function of D13.

**H03.07 D13 logic**

Address: 0x0307

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Normally open

1: Closed

**Description**

-

**H03.08 D14 function**

Address: 0x0308

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 34

Change: At once

**Value Range:**

0: No assignment

1: Servo ON

2: Alarm reset signal

5: Multi-reference direction

6: Multi-reference switchover CMD1

7: Multi-reference switchover CMD2

8: Multi-reference switchover CMD3

9: Multi-reference switchover CMD4

14: Positive limit switch

15: Negative limit switch

18: Forward jog

19: Reverse jog

24: Electronic gear ratio selection

28: Multi-position reference enable

31: Home switch

34: Emergency stop

38: Touch probe 1

39: Touch probe 2

40: Multi-speed enable

**Description**

-

**H03.09 D14 logic**

Address: 0x0309

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**



0: Normally open  
 1: Closed

**Description**

-

**H03.10 D15 function**

Address: 0x030A

Min.: 0

Max.: 40

Default: 38

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: No assignment

1: Servo ON

2: Alarm reset signal

5: Multi-reference direction

6: Multi-reference switchover CMD1

7: Multi-reference switchover CMD2

8: Multi-reference switchover CMD3

9: Multi-reference switchover CMD4

14: Positive limit switch

15: Negative limit switch

18: Forward jog

19: Reverse jog

24: Electronic gear ratio selection

28: Multi-position reference enable

31: Home switch

34: Emergency stop

38: Touch probe 1

39: Touch probe 2

40: Multi-speed enable

**Description**

-

**H03.11 D15 logic**

Address: 0x030B

Min.: 0

Max.: 1

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: Normally open

1: Closed

**Description**

-

**H03.50 Voltage-type AI1 offset**

Address: 0x0332

Min.: -5000

Unit: mV

Max.: 5000

Data Type: Int16

Default: 0

Change: At once

**Value Range:**

-5000 mV to +5000 mV

**Description**

Defines the actual AI1 input voltage when the drive sampling voltage is 0 after zero drift correction.

**H03.51 Voltage-type AI1 input filter time constant**

Address: 0x0333

Min.: 0

Unit: ms

Max.: 655.35

Data Type: UInt16

Default: 2

Change: At once

**Value Range:**

0.00 ms to 655.35 ms

**Description**

Defines the filter time constant of AI1 input current signal.

**H03.53 Voltage-type AI1 dead zone**

Address: 0x0335

Min.: 0

Unit: mV

Max.: 1000

Data Type: UInt16

Default: 10

Change: At once

**Value Range:**

0.0 mV to 1000.0 mV

**Description**

Defines the AI1 input voltage range when the drive sampling voltage is 0.

**H03.54 Voltage-type AI1 zero drift**

Address: 0x0336

Min.: -500

Unit: mV

Max.: 500

Data Type: Int16

Default: 0

Change: At once

**Value Range:**

-500.0 mV to +500.0 mV

**Description**

Zero drift indicates the value of the drive sampling voltage relative to GND upon zero AI voltage.

Set H0d.10 (Automatic adjustment of analog channels) to 1 (AI1 adjustment) to perform automatic adjustment on AI1 zero drift. The AI1 zero drift adjusted will be saved into H03.54.

**H03.56 Current-type AI2 input filter time constant**

Address: 0x0338

Min.:	0	Unit:	ms
Max.:	655.35	Data Type:	UInt16
Default:	2	Change:	At once

**Value Range:**

0.00 ms to 655.35 ms

**Description**

Set this parameter properly to avoid motor reference fluctuation caused by unstable analog voltage input and reduce motor maloperation caused by interference signals.

The filter function cannot eliminate or suppress zero drift or dead zone.

**H03.60 D11 filter time**

Address: 0x033C

Min.:	0	Unit:	ms
Max.:	500	Data Type:	UInt16
Default:	0.5	Change:	At once

**Value Range:**

0.00 ms to 500.00 ms

**Description**

Defines the filter time of D11. The DI function is active only after the effective level is kept within the time defined by H03.60.

**H03.61 D12 filter time**

Address: 0x033D

Min.:	0	Unit:	ms
Max.:	500	Data Type:	UInt16
Default:	0.5	Change:	At once

**Value Range:**

0.00 ms to 500.00 ms

**Description**

Defines the filter time of D12. The DI function is active only after the effective level is kept within the time defined by H03.61.

**H03.62 D13 filter time**

Address: 0x033E

Min.: 0

Max.: 500

Default: 0.5

Unit: ms

Data Type: UInt16

Change: At once

**Value Range:**

0.00 ms to 500.00 ms

**Description**

Defines the filter time of D13. The DI function is active only after the effective level is kept within the time defined by H03.62.

**H03.63 D14 filter time**

Address: 0x033F

Min.: 0

Max.: 500

Default: 0.5

Unit: ms

Data Type: UInt16

Change: At once

**Value Range:**

0.00 ms to 500.00 ms

**Description**

Defines the filter time of D14. The DI function is active only after the effective level is kept within the time defined by H03.63.

**H03.64 D15 filter time**

Address: 0x0340

Min.: 0

Max.: 500

Default: 0.5

Unit: ms

Data Type: UInt16

Change: At once

**Value Range:**

0.00 ms to 500.00 ms

**Description**

Defines the filter time of D15. The DI function is active only after the effective level is kept within the time defined by H03.64.

**H03.78 Speed value corresponding to analog 20 mA**

Address: 0x034E

Min.: 0

Max.: 9999

Default: 3000

Unit: rpm

Data Type: UInt16

Change: At stop

**Value Range:**

0 rpm to 9999 rpm

**Description**

Defines the motor speed corresponding to AI2 sampling current of 20 mA.  
 Speed limit value in the torque control mode = Sampling current/20 x H03.78

**H03.79 Torque value corresponding to analog 20 mA**

Address: 0x034F

Min.: 1	Unit: Multiplier
Max.: 8	Data Type: UInt16
Default: 1	Change: At stop

**Value Range:**

1.00 to 8.00

**Description**

Defines the motor torque value corresponding to AI2 sampling current of 20 mA.  
 Torque reference value = Sampling voltage/20 x H03.79

**H03.80 Speed corresponding to analog 10 V**

Address: 0x0350

Min.: 0	Unit: rpm
Max.: 9999	Data Type: UInt16
Default: 3000	Change: At stop

**Value Range:**

0 rpm to 9999 rpm

**Description**

Defines the corresponding motor speed when sampling the voltage is 10 V.  
 Speed reference value = Sampling voltage/10 x H03.80

**H03.81 Torque corresponding to analog 10 V**

Address: 0x0351

Min.: 1	Unit: Multiplier
Max.: 8	Data Type: UInt16
Default: 1	Change: At stop

**Value Range:**

1.00 to 8.00

**Description**

Defines the motor torque corresponding to a sampling voltage of 10 V.  
 Torque reference value = Sampling voltage/10 x H03.81

**5.5 H04: Terminal Output Parameters**

**H04.00 DO1 function**

Address: 0x0400

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	1	Change:	At once

**Value Range:**

0: No assignment  
 1: Servo ready  
 2: Motor rotation signal  
 10: Warning  
 11: Fault  
 25: Comparison output DO  
 31: Communication-forced DO  
 32: EDM output

**Description**

Defines the function of DO1.

**H04.01 DO1 logic**

Address: 0x0401		Unit:	-
Min.:	0	Data Type:	UInt16
Max.:	1	Change:	At once
Default:	0		

**Value Range:**

0: Normally open  
 1: Closed

**Description**

Defines the level logic of DO1 when the function assigned to DO1 is active.

**H04.02 DO2 function**

Address: 0x0402		Unit:	-
Min.:	0	Data Type:	UInt16
Max.:	65535	Change:	At once
Default:	11		

**Value Range:**

0: No assignment  
 1: Servo ready  
 2: Motor rotation signal  
 10: Warning  
 11: Fault  
 25: Comparison output DO  
 31: Communication-forced DO  
 32: EDM output

**Description**

-

**H04.03 DO2 logic**

Address: 0x0403

Min.: 0

Max.: 1

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: Normally open

1: Closed

**Description**

-

**H04.22 DO source**

Address: 0x0416

Min.: 0

Max.: 3

p

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

bit 0: DO1 source

0: DO1 function output

1: bit 0 of H31.04 set through communication

bit 1: DO2 source

0: DO2 function output

1: bit 1 of H31.04 set through communication

**Description**

Defines whether the logic of a physical DO terminal is defined by the actual state of the drive or by communication.

**H04.23 EtherCAT-forced DO logic in non-operational status**

Address: 0x0417

Min.: 0

Max.: 3

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

bit 0: DO1

0: Status unchanged

1: No output

bit 1: DO2

0: Status unchanged

1: No output

**Description**

Defines the DO status when EtherCAT communication is disconnected.

**H04.50 AO1 signal selection**

Address: 0x0432

Min.: 0

Unit: -

Max.: 10

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Motor speed (1 V/1000 rpm)

1: Speed reference (1 V/1000 rpm)

2: Torque reference (1 V/100 x rated torque)

3: Position deviation (0.5 mV/1 reference unit)

4: Position deviation (0.5 mV/1 encoder unit)

5: Position reference speed (1 V/1000 rpm)

6: Positioning completed

8: AI1 voltage

10: Defined by H31.05

**Description**

Defines the physical value source of AO1.

**H04.51 AO1 offset voltage**

Address: 0x0433

Min.: -10000

Unit: mV

Max.: 10000

Data Type: Int16

Default: 5000

Change: At once

**Value Range:**

-10000 mV to +10000 mV

**Description**

Defines the actual AO1 output voltage after offset when the output voltage is 0 V in theory.

**H04.52 AO1 multiplier**

Address: 0x0434

Min.: -99.99

Unit: -

Max.: 99.99

Data Type: Int16

Default: 1

Change: At once

**Value Range:**

-99.99 to +99.99

**Description**

Defines the actual AO1 output voltage after amplification when the output voltage is 1 V in theory.



## 5.6 H05: Position Control Parameters

### H05.00 Main position reference source

Address: 0x0500

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 2

Change: At once

#### Value Range:

0 to 2 (Multi-position reference)

#### Description

Defines the position reference source in the position control mode.

### H05.02 Pulses per revolution

Address: 0x0502

Min.: 0

Unit: PPR

Max.: 4294967295

Data Type: UInt32

Default: 0

Change: At stop

#### Value Range:

0 to 4294967295

#### Description

Defines the number of pulses required per revolution of the motor in the local mode and communication mode.

### H05.04 First-order low-pass filter time constant

Address: 0x0504

Min.: 0

Unit: ms

Max.: 6553.5

Data Type: UInt16

Default: 0

Change: At stop

#### Value Range:

0.0 ms to 6553.5 ms

#### Description

Defines the first-order low pass filter time constant of position references.

### H05.06 Moving average filter time constant 1

Address: 0x0506

Min.: 0

Unit: ms

Max.: 128

Data Type: UInt16

Default: 0

Change: At stop

#### Value Range:

0.0 ms to 128.0 ms

**Description**

Defines the moving average filter time constant of position references.

**H05.07 Electronic gear ratio 1 (numerator)**

Address: 0x0507

Min.: 1

Unit: -

Max.: 1073741824

Data Type: UInt32

Default: 1

Change: At once

**Value Range:**

1 to 1073741824

**Description**

Defines the numerator of electronic gear ratio 1.

**H05.09 Electronic gear ratio 1 (denominator)**

Address: 0x0509

Min.: 1

Unit: -

Max.: 1073741824

Data Type: UInt32

Default: 1

Change: At once

**Value Range:**

1 to 1073741824

**Description**

Defines the denominator of electronic gear ratio 1.

**H05.11 Electronic gear ratio 2 (numerator)**

Address: 0x050B

Min.: 1

Unit: -

Max.: 1073741824

Data Type: UInt32

Default: 1

Change: At once

**Value Range:**

1 to 1073741824

**Description**

Defines the numerator of electronic gear ratio 2.

**H05.13 Electronic gear ratio 2 (denominator)**

Address: 0x050D

Min.: 1

Unit: -

Max.: 1073741824

Data Type: UInt32

Default: 1

Change: At once

**Value Range:**

1 to 1073741824

**Description**

Defines the denominator of electronic gear ratio 2.

**H05.16 Clear action**

Address: 0x0510

Min.:	0	Unit:	-
Max.:	2	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

- 0: Position deviation cleared upon S-OFF or non-operational state
- 1: Position deviation cleared upon S-OFF or fault
- 2: Position deviation cleared in the non-operational state or when FunIN.35 is activated

**Description**

Defines the condition for clearing the position deviation.

**H05.17 Number of encoder frequency-division pulses**

Address: 0x0511

Min.:	0	Unit:	PPR
Max.:	4194303	Data Type:	UInt32
Default:	2500	Change:	At stop

**Value Range:**

0 PPR to 4194303 PPR

**Description**

Defines the number of pulses outputted by PAO or PBO per revolution.  
Pulse output resolution per revolution = (H05.17) x 4

**H05.19 Speed feedforward control**

Address: 0x0513

Min.:	0	Unit:	-
Max.:	3	Data Type:	UInt16
Default:	1	Change:	At stop

**Value Range:**

- 0: No speed feedforward
- 1: Internal speed feedforward
- 2: 60B1h

3: Zero phase

**Description**

Defines the source of the speed loop feedforward signal.

**H05.30 Homing selection**

Address: 0x051E

Min.: 0

Unit: -

Max.: 6

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Disable

6: Current position as the home

**Description**

Defines the homing mode and the trigger signal source.

**H05.35 Homing time limit**

Address: 0x0523

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 10000

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the maximum homing time.

**H05.36 Mechanical home offset**

Address: 0x0524

Min.: -2147483648

Unit: Reference unit

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

Defines the absolute position value of the motor after homing.

**H05.38 Frequency-division output source**

Address: 0x0526

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Encoder frequency-division output

1: Pulse reference synchronous output

2: Frequency-division output inhibited

3: Second encoder frequency-division output

**Description**

Defines the output source of the pulse output terminal.

**H05.39 Electronic gear ratio switchover condition**

Address: 0x0527

Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0: Switched if position reference kept 0 for 2.5 ms

1: Switched in real time

**Description**

Defines the condition for switching the electronic gear ratio.

**H05.40 Mechanical home offset and action upon overtravel**

Address: 0x0528

Min.:	0	Unit:	-
Max.:	3	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0: H05.36 as the coordinate after homing, reverse homing applied after homing triggered again upon overtravel

1: H05.36 as the relative offset after homing, reverse homing applied after homing triggered again upon overtravel

2: H05.36 as the coordinate after homing, reverse homing applied automatically upon overtravel

3: H05.36 as the relative offset after homing, reverse homing applied automatically upon overtravel

**Description**

Defines the offset relationship between the mechanical home and mechanical zero point, as well as the action upon overtravel during homing.

**H05.41 Z pulse output polarity**

Address: 0x0529

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	1	Change:	At stop

**Value Range:**

bit 0: Frequency-division Z output polarity  
 0: Positive (high level upon active Z pulse)  
 1: Negative (low level upon active Z pulse)  
 bit 1: OCZ output polarity  
 0: Positive (high level upon active Z pulse)  
 1: Negative (low level upon active Z pulse)  
 bit 2: Inner loop probe Z signal source  
 0: Motor Z signal  
 1: Frequency-division output Z signal

**Description**

Defines the output level when the Z pulse of pulse output terminal is active.

**H05.44 Numerator of frequency-division output reduction ratio**

Address: 0x052C

Min.:	1	Unit:	-
Max.:	16383	Data Type:	UInt16
Default:	1	Change:	At stop

**Value Range:**

1 to 16383

**Description**

Defines the numerator of frequency-division output reduction ratio.

**H05.45 Denominator of frequency-division output reduction ratio**

Address: 0x052D

Min.:	1	Unit:	-
Max.:	8191	Data Type:	UInt16
Default:	1	Change:	At stop

**Value Range:**

1 to 8191

**Description**

Defines the denominator of frequency-division output reduction ratio.

**H05.46 DI selection of multi-turn frequency-division Z starting point**

Address: 0x052E

Min.:	0	Unit:	-
Max.:	5	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0: No selection

1: DI1

2: DI2

3: DI3

4: DI4

5: DI5

**Description**

In the absolute position linear mode, the position offset is the difference between absolute position of current encoder and the mechanical position.

**H05.47 Frequency-division Z pulse width**

Address: 0x052F

Min.: 0

Unit: us

Max.: 400

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 us to 400 us

**Description**

Defines the minimum output width (us) of frequency-division output PZ.

**H05.50 Mechanical gear ratio (numerator) in absolute position rotation mode**

Address: 0x0532

Min.: 1

Unit: -

Max.: 65535

Data Type: UInt16

Default: 1

Change: At stop

**Value Range:**

1 to 65535

**Description**

Defines the transmission ratio between the mechanical rotary load and the motor in the absolute position rotation mode.

**H05.51 Mechanical gear ratio (denominator) in absolute position rotation mode**

Address: 0x0533

Min.: 1

Unit: -

Max.: 65535

Data Type: UInt16

Default: 1

Change: At stop

**Value Range:**

1 to 65535

**Description**

Defines the transmission ratio between the mechanical rotary load and the motor in the absolute position rotation mode.

**H05.52 Pulses per revolution of the load in absolute position rotation mode (low 32 bits)**

Address:

Min.: 0

Unit: Encoder unit

Max.: 4294967295

Data Type: UInt32

Default: 0

Change: At stop

**Value Range:**

0 to 4294967295

**Description**

Defines the number of pulses per revolution of the rotary load in the absolute position rotation mode.

**H05.54 Pulses per revolution of the load in absolute position rotation mode (high 32 bits)**

Address: 0x0536

Min.: 0

Unit: Encoder unit

Max.: 4294967295

Data Type: UInt32

Default: 0

Change: At stop

**Value Range:**

0 to 4294967295

**Description**

Defines the number of pulses per revolution of the rotary load in the absolute position rotation mode.

**H05.56 Speed threshold in homing upon hit-and-stop**

Address: 0x0538

Min.: 0

Unit: rpm

Max.: 1000

Data Type: UInt16

Default: 2

Change: At once

**Value Range:**

0 rpm to 1000 rpm

**Description**

Defines the speed threshold for judging whether the load reaches the mechanical position during homing upon hit-and-stop.

**H05.58 Torque threshold in homing upon hit-and-stop**

Address: 0x053A

Min.: 0

Unit: %

Max.: 400

Data Type: UInt16

Default: 100

Change: At once

**Value Range:**



0.0% to 400.0%

**Description**

Defines the maximum positive/negative torque limit during homing upon hit-and-stop.

**H05.60 Hold time of positioning completed**

Address: 0x053C

Min.: 0

Unit: ms

Max.: 30000

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 ms to 30000 ms

**Description**

Defines the hold time of an active positioning completed signal.

**H05.66 Homing time unit**

Address: 0x0542

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 2

Change: At stop

**Value Range:**

0: 1 ms

1: 10 ms

2: 100 ms

**Description**

Defines the homing time unit. The actual timeout time is H05.35 x H05.66 (ms).

**H05.67 Offset between zero point and single-turn absolute position**

Address: 0x0543

Min.: -2147483648

Unit: Encoder unit

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At stop

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H05.69 Auxiliary homing function**

Address: 0x0545

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0 Change: At stop

**Value Range:**

0: Inhibited

1: Record offset position

2: Clear offset position

**Description**

Used to set the operation mode of H05.67.

**H05.70 Moving average filter time constant 2**

Address: 0x0546

Min.: 0

Unit: ms

Max.: 1000

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0.0 ms to 1000.0 ms

**Description**

Defines the moving average filter time constant for the second group of position references.

**H05.71 Motor Z signal width**

Address: 0x0547

Min.: 1

Unit: ms

Max.: 100

Data Type: UInt16

Default: 4

Change: At once

**Value Range:**

1 ms to 100 ms

**Description**

Defines the pulse width output upon active motor Z signal.

**H05.72 Positioning completed/Position deviation threshold in fully closed-loop mode**

Address: 0x0548

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Threshold scaled to outer loop unit

1: Same threshold used for inner and outer loops

**Description**

0: 6067h/6065h (scaled to outer loop unit)

1: Same threshold used for inner and outer loops

## 5.7 H06: Speed Control Parameters

### H06.00 Source of main speed reference A

Address: 0x0600

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

#### Value Range:

0: Digital setting (H06.03)

1: AI1

#### Description

Defines the source of main speed reference A.

### H06.01 Source of auxiliary speed reference B

Address: 0x0601

Min.: 0

Unit: -

Max.: 5

Data Type: UInt16

Default: 1

Change: At stop

#### Value Range:

0: Digital setting (H06.03)

1: AI1

5: Multi-speed reference

#### Description

Defines the source of auxiliary speed reference B.

### H06.02 Speed reference source

Address: 0x0602

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At stop

#### Value Range:

0: Source of main speed reference A

1: Source of auxiliary speed reference B

2: A+B

3: Switched between A and B

4: Communication

#### Description

Defines the source of speed references.

### H06.03 Speed reference set through keypad

Address: 0x0603

Min.:	-9999	Unit:	rpm
Max.:	9999	Data Type:	Int16
Default:	200	Change:	At once

**Value Range:**

-9999 rpm to +9999 rpm

**Description**

Defines the speed reference value through the keypad.

**H06.04 DI jog speed reference**

Address: 0x0604

Min.:	0	Unit:	rpm
Max.:	9999	Data Type:	Int16
Default:	150	Change:	At once

**Value Range:**

0 rpm to 9999 rpm

**Description**

Defines the DI jog speed reference.

**H06.05 Acceleration ramp time of speed reference**

Address: 0x0605

Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the speed reference acceleration ramp time. The acceleration/ deceleration time constant of multi-speed references are defined only by parameters in group H12.

H06.05 defines the time for the speed reference to change from 0 rpm to 1000 rpm.

H06.06 defines the time for the speed reference to change from 1000 rpm to 0 rpm.

The formulas for calculating the actual acceleration/deceleration time are as follows:

Actual acceleration time  $t_1 = \text{Speed reference}/1000 \times \text{Speed reference acceleration ramp time}$

Actual deceleration time  $t_2 = \text{Speed reference}/1000 \times \text{Speed reference deceleration ramp time}$

**H06.06 Deceleration ramp time of speed reference**

Address: 0x0606

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Defines speed reference deceleration ramp time.

**H06.07 Maximum speed limit**

Address: 0x0607

Min.: 0

Unit: rpm

Max.: 9999

Data Type: UInt16

Default: 6000

Change: At once

**Value Range:**

0 rpm to 9999 rpm

**Description**

Defines the maximum speed limit.

**H06.08 Forward speed threshold**

Address: 0x0608

Min.: 0

Unit: rpm

Max.: 9999

Data Type: UInt16

Default: 6000

Change: At once

**Value Range:**

0 rpm to 9999 rpm

**Description**

Defines the forward speed threshold.

**H06.09 Reverse speed threshold**

Address: 0x0609

Min.: 0

Unit: rpm

Max.: 9999

Data Type: UInt16

Default: 6000

Change: At once

**Value Range:**

0 rpm to 9999 rpm

**Description**

Defines the reverse speed threshold.

**H06.10 Deceleration unit in emergency stop**

Address: 0x060A

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Multiplied by 1

1: Multiplied by 10

2: Multiplied by 100

**Description**

Defines the deceleration unit in emergency stop.

**H06.11 Torque feedforward control**

Address: 0x060B

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

0: No torque feedforward

1: Internal torque feedforward

2: 60B2h used as external torque feedforward

**Description**

Defines the speed reference source for torque feedforward control.

**H06.12 Acceleration ramp time of jog speed**

Address: 0x060C

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 10

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the acceleration ramp time of jog speed.

**H06.13 Speed feedforward smoothing filter**

Address: 0x060D

Min.: 0

Unit: us

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 us to 65535 us

**Description**

Defines the speed feedforward smoothing filter time.

**H06.15 Zero clamp speed threshold**

Address: 0x060F

Min.: 0

Unit: rpm

Max.: 9999

Data Type: UInt16

Default: 10

Change: At once

**Value Range:**

0 rpm to 9999 rpm

**Description**

Defines zero clamp speed threshold.

**H06.16 Threshold of TGON (motor rotation) signal**

Address: 0x0610

Min.: 0

Unit: rpm

Max.: 1000

Data Type: UInt16

Default: 20

Change: At once

**Value Range:**

0 rpm to 1000 rpm

**Description**

Defines the threshold of TGON (motor rotation) signal.

**H06.17 Threshold of V-Cmp (speed matching) signal**

Address: 0x0611

Min.: 0

Unit: rpm

Max.: 100

Data Type: UInt16

Default: 10

Change: At once

**Value Range:**

0 rpm to 100 rpm

**Description**

Defines the threshold of V-Cmp (speed matching) signal.

**H06.18 Threshold of speed reach signal**

Address: 0x0612

Min.: 20

Unit: rpm

Max.: 9999

Data Type: UInt16

Default: 1000

Change: At once

**Value Range:**

20 rpm to 9999 rpm

**Description**

Defines the threshold of speed reach signal.

**H06.19 Threshold of zero speed output signal**

Address: 0x0613

Min.:	1	Unit:	rpm
Max.:	9999	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

Defines the threshold of zero speed output signal.

**H06.40 Deceleration time of ramp 1**

Address: 0x0628

Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the speed reference source of deceleration time of ramp 1.

**H06.41 Deceleration time of ramp 2**

Address: 0x0629

Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the speed reference source of deceleration time of ramp 2.

**H06.50 Speed S-curve enable switch**

Address: 0x0628

Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0: Disable

1: Enable



**Description**

0: Accelerate/Decelerate at fixed acceleration rate

1: Accelerate/Decelerate based on the S-curve

**H06.51 Increasing acceleration of speed S-curve acceleration segment**

Address: 0x0633

Min.: 0

Unit: %

Max.: 100

Data Type: UInt16

Default: 50

Change: At stop

**Value Range:**

0.0% to 100.0%

**Description**

-

**H06.52 Decreasing acceleration of speed S-curve acceleration segment**

Address: 0x0634

Min.: 0

Unit: %

Max.: 100

Data Type: UInt16

Default: 50

Change: At stop

**Value Range:**

0.0% to 100.0%

**Description**

-

**H06.53 Increasing acceleration of speed S-curve deceleration segment**

Address: 0x0635

Min.: 0

Unit: %

Max.: 100

Data Type: UInt16

Default: 50

Change: At stop

**Value Range:**

0.0% to 100.0%

**Description**

-

**H06.54 Decreasing acceleration of speed S-curve deceleration segment**

Address: 0x0636

Min.: 0

Unit: %

Max.: 100

Data Type: UInt16

Default: 50

Change: At stop

**Value Range:**

0.0% to 100.0%

**Description**

-

**5.8 H07: Torque Control Parameters****H07.00 Source of main torque reference A**

Address: 0x0700

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Keypad (H07.03)

1: AI1

**Description**

Defines the source of main torque reference A.

**H07.01 Source of auxiliary torque reference B**

Address: 0x0701

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 1

Change: At stop

**Value Range:**

0: Keypad (H07.03)

1: AI1

**Description**

Defines the source of auxiliary torque references.

**H07.02 Torque reference source**

Address: 0x0702

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Source of main torque reference A

1: Source of auxiliary torque reference B

2: Source of A+B

3: Switched between A and B

4: Communication

**Description**

Defines the source of torque references.

**H07.03 Torque reference set through keypad**

Address: 0x0703

Min.:	-400	Unit:	%
Max.:	400	Data Type:	Int16
Default:	0	Change:	At once

**Value Range:**

-400.0% to +400.0%

**Description**

Defines the torque reference value set through the keypad.

**H07.05 Torque reference filter time constant 1**

Address: 0x0705

Min.:	0	Unit:	ms
Max.:	30	Data Type:	UInt16
Default:	0.5	Change:	At once

**Value Range:**

0.00 ms to 30.00 ms

**Description**

Defines the torque reference filter time constant 1.

**H07.06 Torque reference filter time constant 2**

Address: 0x0706

Min.:	0	Unit:	ms
Max.:	30	Data Type:	UInt16
Default:	0.27	Change:	At once

**Value Range:**

0.00 ms to 30.00 ms

**Description**

Defines torque reference filter time constant 2.

**H07.07 Torque limit source**

Address: 0x0707

Min.:	0	Unit:	-
Max.:	4	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

- 0: Positive/Negative internal torque limit
- 1: Internal or external limit as defined by DI
- 2: T-LMT
- 3: T\_LMT or external limit as defined by DI (FunIN.16 or FunIN.17)
- 4: T\_LMT or internal limit (FunIN.16 or FunIN.17) as defined by DI

**Description**

Defines the source of torque limit.

**H07.08 T-LMT selection**

Address: 0x0708

Min.: 1

Unit: -

Max.: 2

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

1: AI1

2: AI2

**Description**

Defines the torque limit source.

**H07.09 Positive internal torque limit**

Address: 0x0709

Min.: 0

Unit: %

Max.: 400

Data Type: UInt16

Default: 350

Change: At once

**Value Range:**

0.0% to 400.0%

**Description**

Defines the positive internal torque limit.

**H07.10 Negative internal torque limit**

Address: 0x070A

Min.: 0

Unit: %

Max.: 400

Data Type: UInt16

Default: 350

Change: At once

**Value Range:**

0.0% to 400.0%

**Description**

Defines the negative internal torque limit.

**H07.11 Positive external torque limit**

Address: 0x070B

Min.: 0

Unit: %

Max.: 400

Data Type: UInt16

Default: 350

Change: At once

**Value Range:**

0.0% to 400.0%

**Description**

Defines positive external torque limit.

**H07.12 Negative external torque limit**

Address: 0x070C

Min.:	0	Unit:	%
Max.:	400	Data Type:	UInt16
Default:	350	Change:	At once

**Value Range:**

0.0% to 400.0%

**Description**

Defines negative external torque limit.

**H07.15 Emergency stop torque**

Address: 0x070F

Min.:	0	Unit:	%
Max.:	400	Data Type:	UInt16
Default:	100	Change:	At once

**Value Range:**

0.0% to 400.0%

**Description**

Defines the emergency stop torque.

**H07.17 Speed limit source**

Address: 0x0711

Min.:	0	Unit:	-
Max.:	3	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0: Internal speed limit

1: V-LMT

2: H07.19 or H07.20 as defined by DI

**Description**

Defines the source of speed limit.

**H07.18 V-LMT selection**

Address: 0x0712

Min.:	1	Unit:	-
Max.:	2	Data Type:	UInt16
Default:	1	Change:	At once

**Value Range:**

1: AI1

2: AI2

**Description**

Defines the speed limit source.

**H07.19 Positive speed limit/Speed limit 1 in torque control**

Address: 0x0713

Min.: 0

Unit: rpm

Max.: 9999

Data Type: UInt16

Default: 3000

Change: At once

**Value Range:**

0 rpm to 9999 rpm

**Description**

Defines the positive speed limit in torque control.

**H07.20 Negative speed limit/Speed limit 2 in torque control**

Address: 0x0714

Min.: 0

Unit: rpm

Max.: 9999

Data Type: UInt16

Default: 3000

Change: At once

**Value Range:**

0 rpm to 9999 rpm

**Description**

Defines the negative speed limit in torque control.

**H07.21 Base value for torque reach**

Address: 0x0715

Min.: 0

Unit: %

Max.: 400

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0.0% to 400.0%

**Description**

Defines the base value for torque reach.

**H07.22 Threshold of valid torque reach**

Address: 0x0716

Min.: 0

Unit: %

Max.: 400

Data Type: UInt16

Default: 20

Change: At once

**Value Range:**

0.0% to 400.0%

**Description**

Defines the threshold of valid torque reach.

**H07.23 Threshold of invalid torque reach**

Address: 0x0717

Min.: 0

Unit: %

Max.: 400

Data Type: UInt16

Default: 10

Change: At once

**Value Range:**

0.0% to 400.0%

**Description**

Defines the threshold of invalid torque reach.

**H07.24 Field weakening depth**

Address: 0x0718

Min.: 60

Unit: %

Max.: 115

Data Type: UInt16

Default: 115

Change: At once

**Value Range:**

60% to 115%

**Description**

Defines the field weakening depth.

**H07.25 Max. permissible demagnetizing current**

Address: 0x0719

Min.: 0

Unit: %

Max.: 300

Data Type: UInt16

Default: 100

Change: At once

**Value Range:**

0% to 300%

**Description**

Defines the max. permissible demagnetizing current.

**H07.26 Field weakening selection**

Address: 0x071A

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Disable

1: Enable

**Description**

Defines whether to enable field weakening.

**H07.27 Field weakening gain**

Address: 0x071B

Min.: 0.001

Unit: Hz

Max.: 1

Data Type: UInt16

Default: 0.03

Change: At once

**Value Range:**

0.001 Hz to 1.000 Hz

**Description**

Defines the field weakening gain.

**H07.28 Speed of field weakening point**

Address: 0x071C

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

Defines the speed of field weakening point.

**H07.35 Motor torque output correction**

Address: 0x0723

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Switched off

1: Enabled

**Description**

Defines whether to enable motor torque output correction.

**H07.36 Time constant of low-pass filter 2**

Address: 0x0724

Min.: 0

Unit: ms

Max.: 10

Data Type: UInt16

Default: 0

Change: At once



**Value Range:**

0.00 ms to 10.00 ms

**Description**

Defines the time constant of low-pass filter 2.

**H07.37 Torque reference filter selection**

Address: 0x0725

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: First-order filter

1: Biquad filter

**Description**

Used to select the torque reference filter.

**H07.38 Biquad filter attenuation ratio**

Address: 0x0726

Min.: 0

Unit: -

Max.: 50

Data Type: UInt16

Default: 16

Change: At stop

**Value Range:**

0 to 50

**Description**

Defines the biquad filter attenuation ratio.

**H07.40 Speed limit window in the torque control mode**

Address: 0x0728

Min.: 0

Unit: ms

Max.: 300

Data Type: UInt16

Default: 10

Change: At once

**Value Range:**

0.0 ms to 300.0 ms

**Description**

Defines the speed limit window in the torque control mode.

## 5.9 H08: Gain Parameters

**H08.00 Speed loop gain**

Address: 0x0800

Min.:	0.1	Unit:	Hz
Max.:	2000	Data Type:	UInt16
Default:	40	Change:	At once

**Value Range:**

0.1 Hz to 2000.0 Hz

**Description**

Defines the responsiveness of the speed loop. The higher the setpoint, the faster the speed loop response is. Note that an excessively high setpoint may cause vibration.

In the position control mode, the position loop gain must be increased together with the speed loop gain.

**H08.01 Speed loop integral time constant**

Address: 0x0801

Min.:	0.15	Unit:	ms
Max.:	512	Data Type:	UInt16
Default:	19.89	Change:	At once

**Value Range:**

0.15 ms to 512.00 ms

**Description**

Defines the integral time constant of the speed loop.

The lower the setpoint, the better the integral action, and the quicker will the deviation value be close to 0.

Note:

There is no integral action when H08.01 is set to 512.00.

**H08.02 Position loop gain**

Address: 0x0802

Min.:	0.1	Unit:	Hz
Max.:	2000	Data Type:	UInt16
Default:	64	Change:	At once

**Value Range:**

0.1 Hz to 2000.0 Hz

**Description**

Defines the proportional gain of the position loop.

Defines the responsiveness of the position loop. A high setpoint shortens the positioning time. Note that an excessively high setpoint may cause vibration.

The 1st gain set include H08.00 (Speed loop gain), H08.01 (Speed loop integral time constant), H08.02, and H07.05 (Filter time constant of torque reference).

**H08.03 2nd speed loop gain**

Address: 0x0803

Min.:	0.1	Unit:	Hz
Max.:	2000	Data Type:	UInt16
Default:	75	Change:	At once

**Value Range:**

0.1 Hz to 2000.0 Hz

**Description**

-

**H08.04 2nd speed loop integral time constant**

Address: 0x0804

Min.:	0.15	Unit:	ms
Max.:	512	Data Type:	UInt16
Default:	10.61	Change:	At once

**Value Range:**

0.15 ms to 512.00 ms

**Description**

-

**H08.05 2nd position loop gain**

Address: 0x0805

Min.:	0.1	Unit:	Hz
Max.:	2000	Data Type:	UInt16
Default:	120	Change:	At once

**Value Range:**

0.1 Hz to 2000.0 Hz

**Description**

Defines the second gain set of the position loop and speed loop. The 2nd gain set include H08.03 (Speed loop gain), H08.04 (Speed loop integral time constant), H08.05, and H07.06 (2nd torque reference filter time constant).

**H08.08 2nd gain mode setting**

Address: 0x0808

Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	1	Change:	At once

**Value Range:**

0: Fixed to the 1st gain set, switched between P and PI as defined by bit26 of external 60FEh

1: Switched between the 1st and 2nd gain sets as defined by H08.09

**Description**

Defines the mode for switching to the 2nd gain set.

**H08.09 Gain switchover condition**

Address: 0x0809

Min.: 0

Unit: -

Max.: 10

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- 0: Fixed to the 1st gain set (PS)
- 1: Switched as defined by bit26 of 60FEh
- 2: Torque reference too large (PS)
- 3: Speed reference too large (PS)
- 4: Speed reference change rate too large (PS)
- 5: Speed reference low/high speed threshold (PS)
- 6: Position deviation too large (P)
- 7: Position reference available (P)
- 8: Positioning unfinished (P)
- 9: Actual speed (P)
- 10: Position reference + Actual speed (P)

**Description**

Used to set the condition for gain switchover.

**H08.10 Gain switchover delay**

Address: 0x080A

Min.: 0

Unit: ms

Max.: 1000

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

0.0 ms to 1000.0 ms

**Description**

Defines the delay when the drive switches from the 2nd gain set to the 1st gain set.

**H08.11 Gain switchover level**

Address: 0x080B

Min.: 0

Unit: -

Max.: 20000

Data Type: UInt16

Default: 50

Change: At once

**Value Range:**

0 to 20000

**Description**

Defines the gain switchover level.

Gain switchover is affected by both the level and the dead time, as defined by H08.09. The unit of gain switchover level varies with the switchover condition.

**H08.12 Gain switchover dead time**

Address: 0x080C

Min.: 0

Unit: -

Max.: 20000

Data Type: UInt16

Default: 30

Change: At once

**Value Range:**

0 to 20000

**Description**

Defines the dead time for gain switchover.

Gain switchover is affected by both the level and the dead time, as defined by H08.09. The unit of gain switchover dead time varies with the switchover condition.

Note:

Set H08.11 to a value higher than or equal to H08.12. Otherwise, the drive forcibly sets H08.11 to the same value as H08.12.

**H08.13 Position gain switchover time**

Address: 0x080D

Min.: 0

Unit: ms

Max.: 1000

Data Type: UInt16

Default: 3

Change: At once

**Value Range:**

0.0 ms to 1000.0 ms

**Description**

In position control, if H08.05 (2nd position loop gain) is much higher than H08.02 (Position loop gain), set the time for switching from H08.02 to H08.05.

This parameter can be used to reduce the impact caused by an increase in the position loop gain.

**H08.15 Load moment of inertia ratio**

Address: 0x080F

Min.: 0

Unit: -

Max.: 120

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

0.00 to 120.00

**Description**

Defines the mechanical load inertia ratio relative to the motor moment of inertia. When H08.15 is set to 0, it indicates the motor carries no load; if it is set to 1.00, it indicates the mechanical load inertia is the same as the motor moment of inertia.

**H08.17 Zero phase delay**

Address: 0x0811

Min.: 0

Max.: 4

Default: 0

Unit: ms

Data Type: UInt16

Change: At once

**Value Range:**

0.0 ms to 4.0 ms

**Description**

-

**H08.18 Speed feedforward filter time constant**

Address: 0x0812

Min.: 0

Max.: 64

Default: 0.5

Unit: ms

Data Type: UInt16

Change: At once

**Value Range:**

0.00 ms to 64.00 ms

**Description**

Defines the filter time constant of speed feedforward.

**H08.19 Speed feedforward gain**

Address: 0x0813

Min.: 0

Max.: 100

Default: 0

Unit: %

Data Type: UInt16

Change: At once

**Value Range:**

0.0% to 100.0%

**Description**

In position control and full closed-loop control, speed feedforward is the product of speed feedforward signal multiplied by H08.19 and is part of the speed reference.

Increasing the setpoint improves the responsiveness to position references and reduces the position deviation during operation at a constant speed.

Set H08.18 to a fixed value first, and then increase the value of H08.19 gradually from 0 to a certain value at which speed feedforward achieves the desired effect.

Adjust H08.18 and H08.19 repeatedly until a balanced performance is achieved.

Note:

For how to enable the speed feedforward function and select the speed feedforward signal, see H05.19 (Speed feedforward control).

**H08.20 Torque feedforward filter time constant**

Address: 0x0814

Min.:	0	Unit:	ms
Max.:	64	Data Type:	UInt16
Default:	0.5	Change:	At once

**Value Range:**

0.00 ms to 64.00 ms

**Description**

Defines the filter time constant of torque feedforward.

**H08.21 Torque feedforward gain**

Address: 0x0815

Min.:	0	Unit:	%
Max.:	300	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0.0% to 300.0%

**Description**

In control modes other than torque control, torque feedforward is the product of torque feedforward signal multiplied by H08.21 and is part of the torque reference. Increasing the setpoint improves the responsiveness to variable speed references. Increasing the setpoint improves the responsiveness to position references and reduces the position deviation during operation at a constant speed.

During parameter adjustment, set H08.20 (Torque feedforward filter time constant) to the default value first, and then increase H08.21 gradually to enhance the effect of torque feedforward. When speed overshoot occurs, keep H08.21 unchanged and increase the value of H08.20. Adjust H08.20 and H08.21 repeatedly until a balanced performance is achieved.

Note:

For how to enable the torque feedforward function and select the torque feedforward signal, see H06.11 (Torque feedforward control).

**H08.22 Speed feedback filtering option**

Address: 0x0816

Min.:	0	Unit:	-
Max.:	4	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0: Inhibited

1: 2 times

2: 4 times

3: 8 times

4: 16 times

**Description**

Defines the moving average filtering times for speed feedback.  
The higher the setpoint, the weaker the speed feedback fluctuation, but the longer the feedback delay will be.

### H08.23 Cutoff frequency of speed feedback low-pass filter

Address: 0x0817

Min.: 100

Unit: Hz

Max.: 8000

Data Type: UInt16

Default: 8000

Change: At once

#### Value Range:

100 Hz to 8000 Hz

#### Description

Defines the cutoff frequency for first-order low-pass filtering on the speed feedback.

Note:

The lower the setpoint, the weaker the speed feedback fluctuation, and the longer the feedback delay will be.

Setting this parameter to 4000 Hz negates the filtering effect.

### H08.24 PDFF control coefficient

Address: 0x0818

Min.: 0

Unit: %

Max.: 200

Data Type: UInt16

Default: 100

Change: At once

#### Value Range:

0.0% to 200.0%

#### Description

Defines the control mode of the speed loop.

When the setpoint is 100.0, PI control (default control mode of the speed loop) is applied to the speed loop, which features fast dynamic response.

When the setpoint is 0.0, speed loop integral action is enhanced, which filters out low-frequency interference but also slows down the dynamic response.

H08.24 can be used to keep a good responsiveness of the speed loop, with anti-interference capacity in low-frequency bands improved and speed feedback overshoot unaffected.

### H08.27 Speed observer cutoff frequency

Address: 0x081B

Min.: 50

Unit: Hz

Max.: 600

Data Type: UInt16

Default: 170

Change: At once



**Value Range:**

50 Hz to 600 Hz

**Description**

Defines the cutoff frequency of the speed observer. Note that an excessively high setpoint may incur resonance. Decrease the setpoint properly in case of loud speed feedback noise.

**H08.28 Speed observer inertia correction coefficient**

Address: 0x081C

Min.:	1	Unit:	%
Max.:	1600	Data Type:	UInt16
Default:	100	Change:	At once

**Value Range:**

1% to 1600%

**Description**

Defines the speed observer inertia correction coefficient. If H08.15 is set based on the actual inertia, there is no need to adjust this parameter.

**H08.29 Speed observer filter time**

Address: 0x081D

Min.:	0	Unit:	ms
Max.:	10	Data Type:	UInt16
Default:	0.8	Change:	At once

**Value Range:**

0.00 ms to 10.00 ms

**Description**

Defines the speed observer filter time. It is recommended to set this parameter to a value equal to the sum of H07.05 plus 0.2 ms.

**H08.31 Disturbance cutoff frequency**

Address: 0x081F

Min.:	10	Unit:	Hz
Max.:	4000	Data Type:	UInt16
Default:	600	Change:	At once

**Value Range:**

10 Hz to 4000 Hz

**Description**

Defines the cutoff frequency of the disturbance observer. Increasing the setpoint improves the responsiveness of the disturbance observer and the compensation effect. Note that an excessively high setpoint may incur resonance.

**H08.32 Disturbance compensation gain**

Address: 0x0820

Min.: 0

Unit: %

Max.: 100

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0% to 100%

**Description**

Defines the compensation gain of the disturbance observer. The setpoint 100% indicates full compensation.

**H08.33 Disturbance observer inertia correction coefficient**

Address: 0x0821

Min.: 1

Unit: %

Max.: 1600

Data Type: UInt16

Default: 100

Change: At once

**Value Range:**

1% to 1600%

**Description**

Defines the disturbance observer inertia correction coefficient. If H08.15 is set based on the actual inertia, there is no need to adjust this parameter.

**H08.37 Phase modulation for medium-frequency jitter suppression 2**

Address: 0x0825

Min.: -90

Unit: °

Max.: 90

Data Type: Int16

Default: 0

Change: At once

**Value Range:**

-90° to +90°

**Description**

Defines the compensation phase of medium-frequency jitter suppression 2.

**H08.38 Frequency of medium-frequency jitter suppression 2**

Address: 0x0826

Min.: 0

Unit: Hz

Max.: 1000

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 Hz to 1000 Hz

**Description**

Set this parameter based on actual resonance frequency. The valid suppression frequency range for medium-frequency jitter suppression 2 is 100 Hz to 1000 Hz.

**H08.39 Compensation gain of medium-frequency jitter suppression 2**

Address: 0x0827

Min.: 0

Unit: %

Max.: 300

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0% to 300%

**Description**

Defines the compensation gain for medium-frequency jitter suppression 2. Set this parameter to 40%...55% in general cases. Setting this parameter to 0 negates the effect of medium-frequency jitter suppression 2.

**H08.40 Speed observer selection**

Address: 0x0828

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Disable

1: Enable

**Description**

Used to set the enable bit for speed observer.

**H08.42 Model control selection**

Address: 0x082A

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Disable

1: Enable

2: Dual-inertia model

**Description**

Used to enable model tracking control.

**H08.43 Model gain**

Address: 0x082B

Min.: 0.1

Unit: -

Max.: 2000

Data Type: UInt16

Default: 40

Change: At once

**Value Range:**

0.1 to 2000.0

**Description**

Defines the single inertia model gain. The higher the gain, the faster the position response. Note that an excessively high setpoint may incur excessive overshoot.

**H08.46 Feedforward value**

Address: 0x082E

Min.: 0

Unit: -

Max.: 102.4

Data Type: UInt16

Default: 95

Change: At once

**Value Range:**

0.0 to 102.4

**Description**

Defines the speed feedforward gain for single inertia model control. If overshoot occurs, reduce the setpoint properly.

**H08.53 Medium- and low-frequency jitter suppression frequency 3**

Address: 0x0835

Min.: 0

Unit: Hz

Max.: 300

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0.0 Hz to 300.0 Hz

**Description**

Set this parameter based on actual resonance frequency. The resonance suppression range is 100 Hz to 300 Hz.

**H08.54 Medium- and low-frequency jitter suppression compensation 3**

Address: 0x0836

Min.: 0

Unit: %

Max.: 200

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0% to 200%

**Description**

Defines the compensation gain for medium- and low-frequency jitter suppression compensation 3. The setpoint 200% indicates full compensation.

**H08.56 Medium- and low-frequency jitter suppression phase modulation 3**

Address: 0x0838

Min.: 0

Unit: %

Max.: 600

Data Type: UInt16

Default: 100 Change: At once

**Value Range:**

0% to 600%

**Description**

Adjust this parameter based on the actual compensation effect.

**H08.59 Medium- and low-frequency jitter suppression frequency 4**

Address: 0x083B

Min.: 0 Unit: Hz

Max.: 300 Data Type: UInt16

Default: 0 Change: At once

**Value Range:**

0.0 Hz to 300.0 Hz

**Description**

Set this parameter based on actual resonance frequency. The resonance suppression range is 100 Hz to 300 Hz.

**H08.60 Medium- and low-frequency jitter suppression compensation 4**

Address: 0x083C

Min.: 0 Unit: %

Max.: 200 Data Type: UInt16

Default: 0 Change: At once

**Value Range:**

0% to 200%

**Description**

Defines the compensation gain for medium- and low-frequency suppression compensation 4. The setpoint 200% indicates full compensation.

**H08.61 Medium- and low-frequency jitter suppression phase modulation 4**

Address: 0x083D

Min.: 0 Unit: %

Max.: 600 Data Type: UInt16

Default: 100 Change: At once

**Value Range:**

0% to 600%

**Description**

Adjust this parameter based on the actual compensation effect.

**H08.62 Position loop integral time constant**

Address: 0x083E

Min.: 0.15 Unit: -

Max.: 512 Data Type: UInt16  
Default: 512 Change: At once

**Value Range:**

0.15 to 512.00

**Description**

Defines the position loop integral time constant.

**H08.63 2nd position loop integral time constant**

Address: 0x083F

Min.: 0.15 Unit: -  
Max.: 512 Data Type: UInt16  
Default: 512 Change: At once

**Value Range:**

0.15 to 512.00

**Description**

Defines the 2nd position loop integral time constant.

**H08.64 Speed observer feedback source**

Address: 0x0840

Min.: 0 Unit: -  
Max.: 1 Data Type: UInt16  
Default: 0 Change: At once

**Value Range:**

0: Disable

1: Enable

**Description**

-

**H08.65 Zero deviation control selection**

Address: 0x0841

Min.: 0 Unit: -  
Max.: 1 Data Type: UInt16  
Default: 0 Change: At once

**Value Range:**

0: Disable

1: Enable

**Description**

Used to enable/disable zero deviation control.

**H08.66 Moving average filter for zero deviation control position**

Address: 0x0842

Min.:	0	Unit:	ms
Max.:	320	Data Type:	UInt16
Default:	5	Change:	At once

**Value Range:**

0.0 ms to 320.0 ms

**Description**

Defines the moving average filter time of zero deviation control position. It is recommended to increase the setpoint in case of loud noise caused by low command resolution.

**H08.68 Speed feedforward of zero deviation control**

Address: 0x0844

Min.:	0	Unit:	%
Max.:	100	Data Type:	UInt16
Default:	100	Change:	At once

**Value Range:**

0.0% to 100.0%

**Description**

Defines the speed feedforward of zero deviation control.

**H08.69 Torque feedforward of zero deviation control**

Address: 0x0845

Min.:	0	Unit:	%
Max.:	100	Data Type:	UInt16
Default:	100	Change:	At once

**Value Range:**

0.0% to 100.0%

**Description**

Defines the torque feedforward of zero deviation control.

**H08.81 Anti-resonance frequency of dual-inertia model**

Address: 0x0851

Min.:	1	Unit:	Hz
Max.:	400	Data Type:	UInt16
Default:	20	Change:	At once

**Value Range:**

1.0 Hz to 400.0 Hz

**Description**

Used to set the anti-resonance frequency of dual-inertia model. You can set this parameter based on the frequency sweeping analysis of mechanical characteristics.

**H08.82 Resonance frequency of dual-inertia model**

Address: 0x0852

Min.: 0

Unit: Hz

Max.: 6553.5

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0.0 Hz to 6553.5 Hz

**Description**

Used to set the resonance frequency of dual-inertia model. You can set this parameter based on the frequency sweeping analysis of mechanical characteristics. If accurate resonance frequency is unknown, set H08.84 based on the inertia ratio of the resonance model.

**H08.83 Dual-inertia model gain**

Address: 0x0853

Min.: 0.1

Unit: s<sup>-1</sup>

Max.: 300

Data Type: UInt16

Default: 60

Change: At once

**Value Range:**0.1s<sup>-1</sup> to 300.0s<sup>-1</sup>**Description**

Defines the dual-inertia model gain.

**H08.84 Inertia ratio of dual-inertia model**

Address: 0x0854

Min.: 0

Unit: -

Max.: 120

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

0.00 to 120.00

**Description**

If the resonance frequency of dual-inertia model is set accurately, there is no need to set this parameter.

**H08.88 Speed feedforward value of dual-inertia model**

Address: 0x0858

Min.: 0

Unit: -

Max.: 6553.5

Data Type: UInt16

Default: 100

Change: At once

**Value Range:**

0.0 to 6553.5



**Description**

Set this parameter to 100% in general cases.

**H08.89 Torque feedforward value of dual-inertia model**

Address: 0x0859

Min.: 0

Unit: -

Max.: 6553.5

Data Type: UInt16

Default: 100

Change: At once

**Value Range:**

0.0 to 6553.5

**Description**

Set this parameter to 100% in general cases.

**5.10 H09: Gain Auto-tuning Parameters****H09.00 Gain auto-tuning mode**

Address: 0x0900

Min.: 0

Unit: -

Max.: 7

Data Type: UInt16

Default: 4

Change: At once

**Value Range:**

0: Disabled, manual gain tuning required

1: Enabled, gain parameters generated automatically based on the stiffness level

2: Positioning mode, gain parameters generated automatically based on the stiffness level

3: Interpolation mode+Inertia auto-tuning

4: Normal mode+Inertia auto-tuning

6: Quick positioning mode+Inertia auto-tuning

**Description**

Defines different gain tuning modes. Related gain parameters can be set manually or automatically according to the stiffness level.

**H09.01 Stiffness level**

Address: 0x0901

Min.: 0

Unit: -

Max.: 41

Data Type: UInt16

Default: 15

Change: At once

**Value Range:**

0 to 41

**Description**

Defines the stiffness level of the servo system. The higher the stiffness level, the stronger the gains and the quicker the response will be. But an excessively high stiffness level will cause vibration.  
The setpoint 0 indicates the lowest stiffness and 41 indicates the highest stiffness.

### H09.02 Adaptive notch mode

Address: 0x0902

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 3

Change: At once

#### Value Range:

0: Adaptive notch no longer updated;

1: One adaptive notch activated (3rd notch)

2: Two adaptive notches activated (3rd and 4th notches)

3: Resonance point tested only (displayed in H09.24)

4: Adaptive notch cleared, values of 3rd and 4th notches restored to default

#### Description

Defines the operation mode of the adaptive notch.

### H09.03 Online inertia auto-tuning mode

Address: 0x0903

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 2

Change: At once

#### Value Range:

0: Disabled

1: Enabled, changing slowly

2: Enabled, changing normally

3: Enabled, changing quickly

#### Description

Defines whether to enable online inertia auto-tuning and the inertia ratio update speed during online inertia auto-tuning.

### H09.05 Offline inertia auto-tuning mode

Address: 0x0905

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 1

Change: At stop

#### Value Range:

0: Bi-directional

1: Unidirectional

**Description**

Defines the offline inertia auto-tuning mode. The offline inertia auto-tuning function can be enabled through H0d.02.

**H09.06 Maximum speed of inertia auto-tuning**

Address: 0x0906

Min.: 100

Unit: rpm

Max.: 1000

Data Type: UInt16

Default: 500

Change: At stop

**Value Range:**

100 rpm to 1000 rpm

**Description**

Defines the maximum permissible speed reference in offline inertia auto-tuning mode.

During inertia auto-tuning, the higher the speed, the more accurate the auto-tuned values. Use the default setpoint in general cases.

**H09.07 Time constant for accelerating to the max. speed during inertia auto-tuning**

Address: 0x0907

Min.: 20

Unit: ms

Max.: 800

Data Type: UInt16

Default: 125

Change: At stop

**Value Range:**

20 ms to 800 ms

**Description**

Defines the time for the motor to accelerate from 0 rpm to the maximum speed of inertia auto-tuning (H09.06) during offline inertia auto-tuning.

**H09.08 Interval time after an individual inertia auto-tuning**

Address: 0x0908

Min.: 50

Unit: ms

Max.: 10000

Data Type: UInt16

Default: 800

Change: At stop

**Value Range:**

50 ms to 10000 ms

**Description**

Defines the interval time between two consecutive speed references when H09.05 (Offline inertia auto-tuning mode) is set to 1 (Positive/Negative triangular wave mode).

**H09.09 Number of motor revolutions per inertia auto-tuning**

Address: 0x0909

Min.: 0

Unit: -

Max.: 100

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

0.00 to 100.00

**Description**

Defines the motor revolutions per inertia auto-tuning when H09.05 (Offline inertia auto-tuning mode) is set to 1 (Positive/Negative triangular wave mode).

Note:

When using the offline inertia auto-tuning function, check that the travel distance of the motor at the stop position is larger than the value of H09.09. If not, decrease the value of H09.06 (Maximum speed for inertia auto-tuning) or H09.07 (Time constant of accelerating to max. speed during inertia auto-tuning) properly until the motor travel distance fulfills the requirement.

**H09.11 Vibration threshold**

Address: 0x090B

Min.: 0

Unit: %

Max.: 100

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

0.0% to 100.0%

**Description**

Defines the warning threshold for current feedback vibration.

**H09.12 Frequency of the 1st notch**

Address: 0x090C

Min.: 50

Unit: Hz

Max.: 8000

Data Type: UInt16

Default: 8000

Change: At once

**Value Range:**

50 Hz to 8000 Hz

**Description**

Defines the center frequency of the notch, which is the mechanical resonance frequency.

In the torque control mode, setting the notch frequency to 4000 Hz deactivates the notch function.

**H09.13 Width level of the 1st notch**

Address: 0x090D

Min.:	0	Unit:	-
Max.:	20	Data Type:	UInt16
Default:	2	Change:	At once

**Value Range:**

0 to 20

**Description**

Defines the width level of the notch. Use the default setpoint in general cases. Width level is the ratio of the notch width to the notch center frequency.

**H09.14 Depth level of the 1st notch**

Address: 0x090E

Min.:	0	Unit:	-
Max.:	99	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0 to 99

**Description**

Defines the depth level of the notch.

The depth level of the notch is the ratio between the input to the output at the notch center frequency.

The higher the setpoint, the lower the notch depth and the weaker the mechanical resonance suppression will be. Note that an excessively high setpoint may cause system instability.

**H09.15 Frequency of the 2nd notch**

Address: 0x090F

Min.:	50	Unit:	Hz
Max.:	8000	Data Type:	UInt16
Default:	8000	Change:	At once

**Value Range:**

50 Hz to 8000 Hz

**Description**

-

**H09.16 Width level of the 2nd notch**

Address: 0x0910

Min.:	0	Unit:	-
Max.:	20	Data Type:	UInt16
Default:	2	Change:	At once

**Value Range:**

0 to 20

**Description**

-

**H09.17 Depth level of the 2nd notch**

Address: 0x0911

Min.: 0

Unit: -

Max.: 99

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 99

**Description**

-

**H09.18 Frequency of the 3rd notch**

Address: 0x0912

Min.: 50

Unit: Hz

Max.: 8000

Data Type: UInt16

Default: 8000

Change: At once

**Value Range:**

50 Hz to 8000 Hz

**Description**

-

**H09.19 Width level of the 3rd notch**

Address: 0x0913

Min.: 0

Unit: -

Max.: 20

Data Type: UInt16

Default: 2

Change: At once

**Value Range:**

0 to 20

**Description**

-

**H09.20 Depth level of the 3rd notch**

Address: 0x0914

Min.: 0

Unit: -

Max.: 99

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 99

**Description**

-

**H09.21 Frequency of the 4th notch**

Address: 0x0915

Min.: 50

Max.: 8000

Default: 8000

Unit: Hz

Data Type: UInt16

Change: At once

**Value Range:**

50 Hz to 8000 Hz

**Description**

-

**H09.22 Width level of the 4th notch**

Address: 0x0916

Min.: 0

Max.: 20

Default: 2

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0 to 20

**Description**

-

**H09.23 Depth level of the 4th notch**

Address: 0x0917

Min.: 0

Max.: 99

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0 to 99

**Description**

-

**H09.24 Auto-tuned resonance frequency**

Address: 0x0918

Min.: 0

Max.: 5000

Default: 0

Unit: Hz

Data Type: UInt16

Change: At once

**Value Range:**

0 Hz to 5000 Hz

**Description**

When H09.02 (Adaptive notch mode) is set to 3, the current mechanical resonance frequency is displayed.

**H09.26 ITune response**

Address: 0x091A

Min.: 50

Unit: %

Max.: 500

Data Type: UInt16

Default: 100

Change: At once

**Value Range:**

50.0% to 500.0%

**Description**

Defines the ITune response capability. Increasing the setpoint improves the responsiveness but may incur resonance.

**H09.27 ITune mode**

Address: 0x091B

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Disable

1: ITune mode 1

2: ITune mode 2

**Description**

Setting H09.27 to 1 enables the ITune function.

Note: ITune mode 2 is manufacturer commissioning mode, which should be used with caution.

**H09.28 Minimum inertia ratio of ITune**

Address: 0x091C

Min.: 0

Unit: %

Max.: 80

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0.0% to 80.0%

**Description**

Inertia ratio range for ITune adjustment: The minimum and maximum inertia ratios of ITune are 0.0 and 30.0 by default.

If the actual maximum load inertia ratio is higher than 30.0, increase the value of H09.29 to prevent positioning jitter.

If the actual load inertia change range is small, set H09.28 and H09.29 based on actual conditions to achieve optimal control effect.

**H09.29 Maximum inertia ratio of ITune**

Address: 0x091D



Min.:	1	Unit:	%
Max.:	120	Data Type:	UInt16
Default:	30	Change:	At once

**Value Range:**

1.0% to 120.0%

**Description**

-

**H09.32 Gravity compensation value**

Address: 0x0920

Min.:	0	Unit:	%
Max.:	100	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0.0% to 100.0%

**Description**

Defines the gravity compensation value. Setting this parameter properly in vertical axis applications can reduce the falling amplitude upon start.

**H09.33 Positive friction compensation value**

Address: 0x0921

Min.:	0	Unit:	%
Max.:	100	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0.0% to 100.0%

**Description**

Defines the positive friction compensation value.

**H09.34 Negative friction compensation value**

Address: 0x0922

Min.:	-100	Unit:	%
Max.:	0	Data Type:	Int16
Default:	0	Change:	At once

**Value Range:**

-100.0% to 0.0%

**Description**

Defines the negative direction friction compensation value.

**H09.35 Friction compensation speed**

Address: 0x0923

Min.:	0	Unit:	-
Max.:	20	Data Type:	UInt16
Default:	2	Change:	At once

**Value Range:**

0.0 to 20.0

**Description**

Defines the friction compensation speed.

**H09.36 Friction compensation speed**

Address: 0x0924

Min.:	0	Unit:	-
Max.:	19	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0x00: Slow mode+Speed reference

0x01: Slow mode+Model speed

0x02: Slow mode+Speed feedback

0x03: Slow mode+Observe speed

0x10: Quick mode+Speed reference

0x11: Quick mode+Model speed

0x12: Quick mode+Speed feedback

0x13: Quick mode+Observe speed

**Description**

-

**H09.37 Vibration monitoring time**

Address: 0x0925

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	600	Change:	At once

**Value Range:**

0 to 65535

**Description**

The resonance detection suppression function is turned off automatically after the time defined by this parameter elapses. To suppress the resonance suppression function, set this parameter to 65536.

**H09.38 Frequency of low-frequency resonance suppression 1 at the mechanical end**

Address: 0x0926

Min.:	1	Unit:	Hz
Max.:	100	Data Type:	UInt16

Default: 100 Change: At once

**Value Range:**

1.0 Hz to 100.0 Hz

**Description**

Set this parameter based on the actual jitter frequency.

**H09.39 Low-frequency resonance suppression 1 at the mechanical end**

Address: 0x0927

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 2

Change: At stop

**Value Range:**

0 to 3

**Description**

Defines different low-frequency resonance suppression types at the mechanical load. Type 1 features the shortest delay.

**H09.44 Frequency of low-frequency resonance suppression 2 at mechanical load end**

Address: 0x092C

Min.: 0

Unit: -

Max.: 100

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0.0 to 100.0

**Description**

Set this parameter based on the actual jitter frequency.

**H09.45 Responsiveness of low-frequency resonance suppression 2 at mechanical load end**

Address: 0x092D

Min.: 0.01

Unit: -

Max.: 5

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

0.01 to 5.00

**Description**

Use the default setpoint in general cases. To increase the setpoint, reduce the delay time.

**H09.47 Width of low-frequency resonance suppression 2 at mechanical load end**

Address: 0x092F

Min.:	0	Unit:	-
Max.:	2	Data Type:	UInt16
Default:	1	Change:	At once

**Value Range:**

0.00 to 2.00

**Description**

Use the default setpoint in general cases. To increase the setpoint, increase the delay time.

**H09.49 Frequency of low-frequency resonance suppression 3 at mechanical load end**

Address: 0x0931

Min.:	0	Unit:	-
Max.:	100	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0.0 to 100.0

**Description**

-

**H09.50 Responsiveness of low-frequency resonance suppression 3 at mechanical load end**

Address: 0x0932

Min.:	0.01	Unit:	-
Max.:	5	Data Type:	UInt16
Default:	1	Change:	At once

**Value Range:**

0.01 to 5.00

**Description**

-

**H09.52 Width of low-frequency resonance suppression 3 at mechanical load end**

Address: 0x0934

Min.:	0	Unit:	-
Max.:	2	Data Type:	UInt16
Default:	1	Change:	At once

**Value Range:**

0.00 to 2.00

**Description**

-

**H09.54 Vibration threshold**

Address: 0x0936

Min.:	0	Unit:	%
Max.:	300	Data Type:	UInt16
Default:	50	Change:	At once

**Value Range:**

0.0% to 300.0%

**Description**

If the torque fluctuation exceeds the setpoint, an error will be reported. Setting this parameter to 0 hides the resonance detection function.

**H09.56 Max. overshoot allowed by ETune**

Address: 0x0938

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	2936	Change:	At once

**Value Range:**

0 to 65535

**Description**

Defines the maximum overshoot value allowed during ETune adjustment.

**H09.57 STune resonance suppression switchover frequency**

Address: 0x0939

Min.:	0	Unit:	Hz
Max.:	4000	Data Type:	UInt16
Default:	900	Change:	At once

**Value Range:**

0 Hz to 4000 Hz

**Description**

If the resonance frequency is lower than the setpoint, use medium-frequency resonance suppression 2 to suppress resonance. Otherwise, use the notch to suppress resonance.

**H09.58 STune resonance suppression reset selection**

Address: 0x093A

Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0: Disable

1: Enable

**Description**

Used to enable STune resonance suppression reset to clear parameters related to resonance suppression, medium-frequency resonance suppression 2, and notches 3 and 4.

**5.11 H0A: Fault and Protection Parameters****H0A.00 Power input phase loss protection**

Address: 0x0A00

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Enable

1: Disable

**Description**

Servo drives supporting single-phase/three-phase 220 V and three-phase 380 V power supplies are available. When voltage fluctuation or phase loss occurs on the power supply, the drive triggers power input phase loss protection based on H0A.00.

**H0A.01 Absolute position limit**

Address: 0x0A01

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Disabled

1: Enabled

2: Enabled after homing

**Description**

Used to set the activation condition for enabling the software position limit.

**H0A.04 Motor overload protection gain**

Address: 0x0A04

Min.: 50

Unit: -

Max.: 300

Data Type: UInt16

Default: 100

Change: At once

**Value Range:**

50 to 300

**Description**

Determines the motor overload duration before E620.0 (Motor overload) is reported.

You can change the setpoint to advance or delay the time when overload protection is triggered based on the motor temperature. The setpoint 50% indicates the time is cut by half; 150% indicates the time is prolonged by 50%. Set this parameter based on the actual temperature of the motor.

#### **H0A.08    Overspeed threshold**

Address: 0x0A08

Min.: 0

Unit: rpm

Max.: 20000

Data Type: UInt16

Default: 0

Change: At once

##### **Value Range:**

0 rpm to 20000 rpm

##### **Description**

Defines the overspeed threshold of the motor.

#### **H0A.10    Threshold of excessive local position deviation**

Address: 0x0A0A

Min.: 0

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 219895608

Change: At once

##### **Value Range:**

0 to 4294967295

##### **Description**

Defines the threshold for excessive position deviation in the position control mode.

When the position deviation exceeds this threshold, the drive reports EB00.0 (Position deviation too large).

#### **H0A.12    Runaway protection**

Address: 0x0A0C

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 1

Change: At once

##### **Value Range:**

0: Disable

1: Enable

##### **Description**

Defines whether to enable runaway protection.

0: Hide E234.0 when the motor drives a vertical axis or is driven by the load

1: Enable runaway protection

**H0A.18 IGBT overtemperature threshold**

Address: 0x0A12

Min.: 120

Unit: °C

Max.: 175

Data Type: UInt16

Default: 140

Change: At once

**Value Range:**

120°C to 175°C

**Description**

Defines the threshold for reporting E640.0 (IGBT overtemperature) and E640.1 (Flywheel diode overtemperature).

**H0A.19 Filter time constant of touch probe 1**

Address: 0x0A13

Min.: 0

Unit: us

Max.: 6.3

Data Type: UInt16

Default: 2

Change: At once

**Value Range:**

0.00 us to 6.30 us

**Description**

Defines the filter time of touch probe 1. An active input must last for the time defined by H0A.19.

**H0A.20 Filter time constant of touch probe 2**

Address: 0x0A14

Min.: 0

Unit: us

Max.: 6.3

Data Type: UInt16

Default: 2

Change: At once

**Value Range:**

0.00 us to 6.30 us

**Description**

Defines the filter time of touch probe 2. An active input must last for the time defined by H0A.20.

**H0A.23 TZ signal filter time**

Address: 0x0A17

Min.: 0

Unit: 25 ns

Max.: 31

Data Type: UInt16

Default: 15

Change: At stop

**Value Range:**

0 ns to 31 ns



**Description**

-

**H0A.25 Speed display DO low-pass filter time**

Address: 0x0A19

Min.: 0

Unit: -

Max.: 5000

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 ms to 5000 ms

**Description**

Defines the low-pass filter time constant of the speed information for speed feedback and position references.

**H0A.26 Motor overload detection**

Address: 0x0A1A

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Show motor overload warning (E909.0) and fault (E620.0)

1: Hide motor overload warning (E909.0) and fault (E620.0)

**Description**

Defines whether to enable motor overload detection.

**H0A.27 Motor rotation DO speed filter time**

Address: 0x0A1B

Min.: 0

Unit: ms

Max.: 100

Data Type: UInt16

Default: 50

Change: At once

**Value Range:**

0 ms to 100 ms

**Description**

Defines the low-pass filter time constant of the speed information for speed feedback and position references.

**H0A.29 Fully closed-loop encoder (ABZ) filter time**

Address: 0x0A1D

Min.: 0

Unit: 25 ns

Max.: 255

Data Type: UInt16

Default: 15

Change: At stop

**Value Range:**

0 ns to 255 ns

**Description**

-

**H0A.32 Motor stall overtemperature protection time window**

Address: 0x0A20

Min.: 10

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 200

Change: At once

**Value Range:**

10 ms to 65535 ms

**Description**

Defines the overtemperature duration before E630.0 (Motor stall) is detected by the servo drive.

H0A.32 can be used to adjust the sensitivity of motor stall overtemperature detection.

**H0A.33 Motor stall overtemperature detection**

Address: 0x0A21

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

0: Hide

1: Enable

**Description**

Defines whether to enable the detection for E630.0 (Motor stall overtemperature protection).

**H0A.36 Encoder multi-turn overflow fault selection**

Address: 0x0A24

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Not hide

1: Hide

**Description**

Defines whether to hide the encoder multi-turn overflow fault in the absolute position linear mode (H02.01 = 1).

**H0A.40 Compensation function selection**

Address: 0x0A28

Min.: 0

Unit: -

Max.: 15

Data Type: UInt16

Default: 6

Change: At stop

**Value Range:**

bit 0: Overtravel compensation

0: Enable

1: Disable

bit 1: Touch probe rising edge compensation

0: Disable

1: Enable

bit 2: Touch probe falling edge compensation

0: Disable

1: Enable

bit 3: Touch probe solution

0: New solution

1: Old solution (same as SV660N)

**Description**

-

**H0A.41 Forward position of software position limit**

Address: 0x0A29

Min.: -2147483648

Unit: Encoder unit

Max.: 2147483647

Data Type: Int32

Default: 2147483647

Change: At stop

**Value Range:**

-2147483648 to +2147483647

**Description**

When the absolute position counter (H0b.07) is larger than H0A.41, the servo drive reports E950.0 (Forward overtravel) and stops accordingly.

**H0A.43 Reverse position of software position limit**

Address: 0x0A2B

Min.: -2147483648

Unit: Encoder unit

Max.: 2147483647

Data Type: Int32

Default: -2147483648

Change: At stop

**Value Range:**

-2147483648 to +2147483647

**Description**

When the absolute position counter (H0b.07) is smaller than H0A.43, the servo drive reports E952.0 (Reverse overtravel) and stops accordingly.

**H0A.49 Regenerative resistor overtemperature threshold**

Address: 0x0A31

Min.: 100

Unit: °C

Max.: 175

Data Type: UInt16

Default: 115

Change: At once

**Value Range:**

100°C to 175°C

**Description**

Defines the temperature threshold for regenerative resistor overload.

**H0A.50 Encoder communication fault tolerance threshold**

Address: 0x0A32

Min.: 0

Unit: -

Max.: 31

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

0 to 31

**Description**

When the number of communication failures between the encoder and the drive exceeds H0A.50, the communication between the encoder and the drive fails.

**H0A.51 Phase loss detection filter times**

Address: 0x0A33

Min.: 3

Unit: 55 ms

Max.: 36

Data Type: UInt16

Default: 20

Change: At once

**Value Range:**

3 ms to 36 ms

**Description**

Phase loss fault is reported when phase loss keeps active for a period longer than that defined by H0A.51.

**H0A.52 Encoder temperature protection threshold**

Address: 0x0A34

Min.: 0

Unit: °C

Max.: 175

Data Type: UInt16

Default: 125

Change: At once

**Value Range:**

0°C to 175°C

**Description**

Defines the temperature threshold for encoder overtemperature protection.

**H0A.53 Touch probe DI ON-compensation time**

Address: 0x0A35

Min.: -3000

Unit: 25 ns

Max.: 3000

Data Type: Int16

Default: 200

Change: At once

**Value Range:**

-3000 ns to +3000 ns

**Description**

Used to compensate for the action time when the touch probe is switched on.

**H0A.54 Touch probe DI OFF-compensation time**

Address: 0x0A36

Min.: -3000

Unit: 25 ns

Max.: 3000

Data Type: Int16

Default: 1512

Change: At once

**Value Range:**

-3000 ns to +3000 ns

**Description**

Used to compensate for the action time when the touch probe is switched off.

**H0A.55 Runaway current threshold**

Address: 0x0A37

Min.: 100

Unit: %

Max.: 400

Data Type: UInt16

Default: 200

Change: At once

**Value Range:**

100.0% to 400.0%

**Description**

Defines the current threshold for runaway protection detection.

**H0A.56 Fault reset delay**

Address: 0x0A38

Min.: 0

Unit: ms

Max.: 60000

Data Type: UInt16

Default: 10000

Change: At once

**Value Range:**

0 ms to 60000 ms

**Description**

-

**H0A.57 Runaway speed threshold**

Address: 0x0A39

Min.:	1	Unit:	rpm
Max.:	1000	Data Type:	UInt16
Default:	50	Change:	At once

**Value Range:**

1 rpm to 1000 rpm

**Description**

Defines the overspeed threshold for runaway protection detection.

**H0A.58 Runaway speed filter time**

Address: 0x0A3A

Min.:	0.1	Unit:	ms
Max.:	100	Data Type:	UInt16
Default:	2	Change:	At once

**Value Range:**

0.1 ms to 100.0 ms

**Description**

Defines the speed feedback filter time for runaway protection detection.

**H0A.59 Runaway protection detection time**

Address: 0x0A3B

Min.:	10	Unit:	ms
Max.:	1000	Data Type:	UInt16
Default:	30	Change:	At once

**Value Range:**

10 ms to 1000 ms

**Description**

The runaway fault will be reported when runaway fault keeps active for a period longer than that defined by H0A.59.

**H0A.60 Black box function mode**

Address: 0x0A3C

Min.:	0	Unit:	-
Max.:	3	Data Type:	UInt16
Default:	1	Change:	At once

**Value Range:**

0: Disable

1: Any fault

2: Designated fault

3: Triggered based on designated condition

**Description**

Defines the condition for triggering black box sampling.

**H0A.61 Designated fault code**

Address: 0x0A3D

Min.: 0

Unit: -

Max.: 6553.5

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0.0 to 6553.5

**Description**

Defines the fault code for triggering the black box function.

**H0A.62 Trigger source**

Address: 0x0A3E

Min.: 0

Unit: -

Max.: 25

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 25

**Description**

Defines the fault code for triggering the black box function through designated channel.

**H0A.63 Trigger level**

Address: 0x0A3F

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

Defines the trigger level for triggering the black box function through designated channel.

**H0A.65 Trigger level**

Address: 0x0A41

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Rising edge

1: Equal

2: Falling edge

3: Edge-triggered

**Description**

Defines the trigger mode for triggering the black box function through H0A.63.

**H0A.66 Trigger position**

Address: 0x0A42

Min.: 0

Unit: %

Max.: 100

Data Type: UInt16

Default: 75

Change: At once

**Value Range:**

0% to 100%

**Description**

Defines the pre-trigger position for triggering black box sampling.

**H0A.67 Sampling frequency**

Address: 0x0A43

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Current loop

1: Position loop

2: Main cycle

**Description**

Defines the frequency sampling mode during black box sampling.

**H0A.70 Overspeed threshold 2**

Address: 0x0A46

Min.: 0

Unit: rpm

Max.: 20000

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 rpm to 20000 rpm

**Description**

Defines the speed threshold for reporting E500.2 (Position feedback pulse overspeed).

**H0A.71 MS1 motor overload curve switchover**

Address: 0x0A47

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 2

Change: At once



**Value Range:**

0 to 3

**Description**

bit0:

0: New overload curve

1: Old overload curve

bit1:

0: Enable discharging switch upon power failure

1: Hide discharging switch upon power failure

**H0A.72 Maximum stop time in ramp-to-stop**

Address: 0x0A48

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 10000

Change: At stop

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the time for the motor to decelerate from the maximum speed to 0 rpm during ramp-to-stop.

**H0A.73 STO 24 V disconnection filter time**

Address: 0x0A49

Min.: 1

Unit: ms

Max.: 5

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

1 ms to 5 ms

**Description**

Defines the delay from the moment when 24 V is disconnected to the moment when the STO state applies.

**H0A.74 Filter time for two inconsistent STO channels**

Address: 0x0A4A

Min.: 0

Unit: ms

Max.: 1000

Data Type: UInt16

Default: 100

Change: At once

**Value Range:**

1 ms to 1000 ms

**Description**

Defines the delay from the moment 24 V is inputted to the drive inconsistently through two channels to the moment when the STO state applies.

**H0A.75 Servo OFF delay after STO triggered**

Address: 0x0A4B

Min.: 0

Unit: ms

Max.: 25

Data Type: UInt16

Default: 20

Change: At once

**Value Range:**

0 ms to 25 ms

**Description**

Defines the delay from the moment the STO state is triggered to the moment the S-ON signal is switched off.

**H0A.90 Moving average filter time constant for speed display values**

Address: 0x0A5A

Min.: 0

Unit: ms

Max.: 100

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 ms to 100 ms

**Description**

Defines the moving average filter time constant for speed display values.

**H0A.91 Moving average filter time constant for torque display values**

Address: 0x0A5B

Min.: 0

Unit: ms

Max.: 100

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 ms to 100 ms

**Description**

Defines the moving average filter time constant for torque display values.

**H0A.92 Moving average filter time constant for position display values**

Address: 0x0A5C

Min.: 0

Unit: ms

Max.: 100

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 ms to 100 ms

**Description**

Defines the moving average filter time constant for position display values.

**H0A.93 Low-pass filter time constant for voltage display values**

Address: 0x0A5D

Min.: 0

Unit: ms

Max.: 250

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 ms to 250 ms

**Description**

Defines the low-pass filter time constant for voltage display values.

**H0A.94 Low-pass filter time constant for thermal display values**

Address: 0x0A5E

Min.: 0

Unit: ms

Max.: 250

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 ms to 250 ms

**Description**

Defines the filter time constant for thermal display values.

## 5.12 H0b: Monitoring Parameters

**H0b.00 Motor speed actual value**

Address: 0x0B00

Min.: -32767

Unit: rpm

Max.: 32767

Data Type: Int16

Default: 0

Change: Unchangeable

**Value Range:**

-32767 rpm to +32767 rpm

**Description**

Indicates the actual motor speed after round-off, which is accurate to 1 rpm. Set in H0A.25 (Filter time constant of speed feedback display) the filter time constant for H0b.00.

**H0b.01 Speed reference**

Address: 0x0B01

Min.: -32767

Unit: rpm

Max.: 32767

Data Type: Int16

Default: 0

Change: Unchangeable

**Value Range:**

-32767 rpm to +32767 rpm

### Description

Indicates the present speed reference (accurate to 1 rpm) of the drive in the position and speed control modes.

## H0b.02 Internal torque reference

Address: 0x0B02

Min.: -500

Unit: %

Max.: 500

Data Type: Int16

Default: 0

Change: Unchangeable

### Value Range:

-500.0% to +500.0%

### Description

Displays present torque reference (accurate to 0.1%). The value 100.0% corresponds to the rated torque of the motor.

## H0b.03 Monitored DI status

Address: 0x0B03

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

### Value Range:

0 to 65535

### Description

Displays the level status of eight DIs without filtering.

Upper LED segments ON: high level (indicated by "1") Lower LED segments ON: low level (indicated by "0")

## H0b.05 Monitored DO status

Address: 0x0B05

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

### Value Range:

0 to 65535

### Description

Displays the level status of five DOs without filtering.

Upper LED segments ON: high level (indicated by "1") Lower LED segments ON: low level (indicated by "0")

**H0b.07 Absolute position counter**

Address: 0x0B07  
 Min.: -2147483648 Unit: P  
 Max.: 2147483647 Data Type: Int32  
 Default: 0 Change: Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Indicates present absolute position (reference unit) of the motor in the position control mode.

This parameter is a 32-bit integer, which is displayed as a decimal on the keypad.

**H0b.09 Mechanical angle**

Address: 0x0B09  
 Min.: 0 Unit: °  
 Max.: 360 Data Type: UInt16  
 Default: 0 Change: Unchangeable

**Value Range:**

0.0° to 360.0°

**Description**

Displays present mechanical angle (encoder unit) of the motor. The setpoint 0 indicates the mechanical angle is 0°.

Actual mechanical angle =  $360^\circ \times \text{H0b.09} / (\text{Maximum value of H0b.09} + 1)$

Maximum value of H0b.09 for an absolute encoder: 65535

**H0b.10 Electrical angle**

Address: 0x0B0A  
 Min.: 0 Unit: °  
 Max.: 360 Data Type: UInt16  
 Default: 0 Change: Unchangeable

**Value Range:**

0.0° to 360.0°

**Description**

Indicates the present electrical angle of the motor, which is accurate to 0.1°.

The electrical angle variation range is  $\pm 360.0^\circ$  during rotation. If the motor has four pairs of poles, each revolution generates four rounds of angle change from 0° to 359°. Similarly, if the motor has five pairs of poles, each revolution generates five rounds of angle change from 0° to 359°.

**H0b.12 Average load rate**

Address: 0x0B0C

Min.:	0	Unit:	%
Max.:	800	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0.0% to 800.0%

**Description**

Displays the percentage of the average load torque to the rated torque of the motor, which is accurate to 0.1%. The value 100.0% corresponds to the rated torque of the motor.

**H0b.15 Position following error (encoder unit)**

Address:

Min.:	-2147483648	Unit:	p
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Used to count and display the position deviation value after being divided or multiplied by the electronic gear ratio in the position control mode.

This parameter is a 32-bit integer, which is displayed as a decimal on the keypad.

Note:

H0b.15 can be cleared when the condition defined in H05.16 (Clear action) is met.

**H0b.17 Feedback pulse counter**

Address: 0x0B11

Min.:	-2147483648	Unit:	p
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Used to count the position pulses fed back by the encoder in any control mode.

This parameter is a 32-bit integer, which is displayed as a decimal on the keypad.

**H0b.19 Total power-on time**

Address: 0x0B13

Min.:	0	Unit:	s
Max.:	429496729.5	Data Type:	UInt32
Default:	0	Change:	Unchangeable

**Value Range:**

0.0s to 429496729.5s

**Description**

Used to record the total operating time of the servo drive.

This parameter is a 32-bit integer, which is displayed as a decimal on the keypad.

Note:

If the servo drive is switched on and off repeatedly within a short period of time, a deviation within 1h may be present in the total power-on time record.

**H0b.21 AI1 voltage display**

Address: 0x0B15

Min.:	-12	Unit:	V
Max.:	12	Data Type:	Int16
Default:	0	Change:	Unchangeable

**Value Range:**

-12.000 V to +12.000 V

**Description**

Displays the actual sampling voltage of AI1.

**H0b.22 AI2 current display**

Address: 0x0B16

Min.:	0	Unit:	mA
Max.:	21	Data Type:	Int16
Default:	0	Change:	Unchangeable

**Value Range:**

0.000 mA to 21.000 mA

**Description**

Displays the actual sampling current of AI2.

**H0b.24 RMS value of phase current**

Address: 0x0B18

Min.:	0	Unit:	A
Max.:	6553.5	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0.0 A to 6553.5 A

**Description**

Displays the RMS value of the phase current of the motor, which is accurate to 0.01 A.

**H0b.25 Angle obtained upon voltage injection auto-tuning**

Address: 0x0B19

Min.:	0	Unit:	°
Max.:	360	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0.0° to 360.0°

**Description**

-

**H0b.26 Bus voltage**

Address: 0x0B1A

Min.:	0	Unit:	V
Max.:	6553.5	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0.0 V to 6553.5 V

**Description**

Displays the DC bus voltage of the main circuit input voltage after rectification, which is accurate to 0.01 V.

**H0b.27 Module temperature**

Address: 0x0B1B

Min.:	-20	Unit:	°C
Max.:	200	Data Type:	Int16
Default:	0	Change:	Unchangeable

**Value Range:**

-20°C to +200°C

**Description**

Indicates the temperature of the module inside the servo drive, which can be used as a reference for estimating the actual temperature of the drive.

**H0b.28 Absolute encoder fault information given by FPGA**

Address: 0x0B1C

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.29 Axis status information given by FPGA**

Address: 0x0B1D



Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.30 Axis fault information given by FPGA**

Address: 0x0B1E

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.31 Encoder fault information**

Address: 0x0B1F

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.33 Fault log**

Address: 0x0B21

Min.:	0	Unit:	-
Max.:	20	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0: Present fault  
 1: Last fault  
 2: 2nd to last fault  
 3: 3rd to last fault  
 4: 4th to last fault  
 5: 5th to last fault  
 6: 6th to last fault  
 7: 7th to last fault  
 8: 8th to last fault  
 9: 9th to last fault  
 10: 10th to last fault  
 11: 11th to last fault  
 12: 12th to last fault  
 13: 13th to last fault  
 14: 14th to last fault  
 15: 15th to last fault  
 16: 16th to last fault  
 17: 17th to last fault  
 18: 18th to last fault  
 19: 19th to last fault

**Description**

Used to view the latest 20 faults of the drive.

**H0b.34 Fault code of the selected fault**

Address: 0x0B22

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.35 Time stamp upon occurrence of the selected fault**

Address: 0x0B23

Min.: 0

Unit: s

Max.: 429496729.5

Data Type: UInt32

Default: 0

Change: Unchangeable

**Value Range:**

0.0s to 429496729.5s

**Description**

-

**H0b.37 Motor speed upon occurrence of the selected fault**

Address: 0x0B25

Min.: -32767

Max.: 32767

Default: 0

Unit: rpm

Data Type: Int16

Change: Unchangeable

**Value Range:**

-32767 rpm to +32767 rpm

**Description**

-

**H0b.38 Motor phase U current upon occurrence of the selected fault**

Address: 0x0B26

Min.: -3276.7

Max.: 3276.7

Default: 0

Unit: A

Data Type: Int16

Change: Unchangeable

**Value Range:**

-3276.7 A to +3276.7 A

**Description**

-

**H0b.39 Motor phase V current upon occurrence of the selected fault**

Address: 0x0B27

Min.: -3276.7

Max.: 3276.7

Default: 0

Unit: A

Data Type: Int16

Change: Unchangeable

**Value Range:**

-3276.7 A to +3276.7 A

**Description**

-

**H0b.40 Bus voltage upon occurrence of the selected fault**

Address: 0x0B28

Min.: 0

Max.: 6553.5

Default: 0

Unit: V

Data Type: UInt16

Change: Unchangeable

**Value Range:**

0.0 V to 6553.5 V

**Description**

-

**H0b.41 DI status upon occurrence of the selected fault**

Address: 0x0B29

Min.: 0  
Max.: 65535  
Default: 0

Unit: -  
Data Type: UInt16  
Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.43 DO status upon occurrence of the selected fault**

Address: 0x0B2B

Min.: 0  
Max.: 65535  
Default: 0

Unit: -  
Data Type: UInt16  
Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.45 Internal fault code**

Address: 0x0B2D

Min.: 0  
Max.: 65535  
Default: 0

Unit: -  
Data Type: UInt16  
Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.46 Absolute encoder fault information given by FPGA upon occurrence of the selected fault**

Address: 0x0B2E

Min.: 0  
Max.: 65535  
Default: 0

Unit: -  
Data Type: UInt16  
Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.47 System status information given by FPGA upon occurrence of the selected fault**

Address: 0x0B2F

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.48 System fault information given by FPGA upon occurrence of the selected fault**

Address: 0x0B30

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.49 Encoder fault information upon occurrence of the selected fault**

Address: 0x0B31

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.51 Internal fault code upon occurrence of the selected fault**

Address: 0x0B33

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.52 FPGA timeout fault standard bit upon occurrence of the selected fault**

Address: 0x0B34

Min.:	0	Unit:	-
-------	---	-------	---

Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.53 Position following error (reference unit)**

Address: 0x0B35

Min.: -2147483648

Unit: p

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Indicates the position deviation value which has not been divided or multiplied by the electronic gear ratio in the position control mode.

Position deviation (reference unit) is the value obtained after encoder position deviation calculation. The precision is compromised during division.

This parameter is a 32-bit integer, which is displayed as a decimal on the keypad.

**H0b.55 Motor speed actual value**

Address: 0x0B37

Min.: -2147483648

Unit: rpm

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 rpm to +2147483647 rpm

**Description**

Indicates the actual value of motor speed, which is accurate to 0.1 rpm.

This parameter is a 32-bit integer, which is displayed as a decimal on the keypad.

H0A.25 (Filter time constant of speed feedback display) can be used to set the filter time constant of the speed feedback.

**H0b.57 Bus voltage of the control circuit**

Address: 0x0B39

Min.: 0

Unit: V

Max.: 6553.5

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0.0 V to 6553.5 V

**Description**

Displays the bus voltage of the control circuit.

**H0b.58 Mechanical absolute position (low 32 bits)**

Address: 0x0B3A

Min.: -2147483648

Unit: p

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Displays the low 32-bit value (encoder unit) of the mechanical position feedback when the absolute encoder is used.

**H0b.60 Mechanical absolute position (high 32 bits)**

Address:

Min.: -2147483648

Unit: p

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Displays the high 32-bit value (encoder unit) of the mechanical position feedback when the absolute encoder is used.

**H0b.63 NotRdy state**

Address: 0x0B3F

Min.: 0

Unit: -

Max.: 7

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

- 1: Control circuit power input error
- 2: Main circuit power input error
- 3: Undervoltage
- 4: Soft start failed
- 5: Encoder initialization not completed
- 6: Short circuit to ground failed
- 7: Others

**Description**

Displays the reason for NotRdy state.

**H0b.66 Encoder temperature**

Address: 0x0B42

Min.: -32768

Max.: 32767

Default: 0

Unit: °C

Data Type: Int16

Change: Unchangeable

**Value Range:**

-32768°C to +32767°C

**Description**

-

**H0b.67 Load rate of regenerative resistor**

Address: 0x0B43

Min.: 0

Max.: 200

Default: 0

Unit: %

Data Type: UInt16

Change: Unchangeable

**Value Range:**

0.0% to 200.0%

**Description**

-

**H0b.70 Number of absolute encoder revolutions**

Address: 0x0B46

Min.: 0

Max.: 65535

Default: 0

Unit: Rev

Data Type: UInt16

Change: Unchangeable

**Value Range:**

0 Rev to 65535 Rev

**Description**

Indicates the number of revolutions of the absolute encoder.

**H0b.71 Single-turn position fed back by the absolute encoder**

Address: 0x0B47

Min.: 0

Max.: 2147483647

Default: 0

Unit: p

Data Type: UInt32

Change: Unchangeable

**Value Range:**

0 p to +2147483647 p

**Description**

Displays the position feedback of the absolute encoder within one turn.

**H0b.74 System fault information given by FPGA**

Address: 0x0B4A



Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.77 Encoder position (low 32 bits)**

Address: 0x0B4D

Min.:	-2147483648	Unit:	p
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Displays the low 32-bit value of the position feedback of the absolute encoder.

**H0b.79 Encoder position (high 32 bits)**

Address:

Min.:	-2147483648	Unit:	p
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Displays the high 32-bit value of the position feedback of the absolute encoder.

**H0b.81 Single-turn position of the rotary load (low 32 bits)**

Address: 0x0B51

Min.:	-2147483648	Unit:	p
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Displays the low 32-bit value of the position feedback of the rotary load when the absolute system works in the rotation mode.

**H0b.83 Single-turn position of the rotary load (high 32 bits)**

Address: 0x0B53

Min.:	-2147483648	Unit:	p
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Displays the high 32-bit value of the position feedback of the rotary load when the absolute system works the rotation mode.

**H0b.85 Single-turn position of the rotary load (reference unit)**

Address: 0x0B55

Min.:	-2147483648	Unit:	p
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

Displays the high 32-bit value of the position feedback of the rotary load when the absolute system works the rotation mode.

**H0b.87 IGBT junction temperature**

Address: 0x0B57

Min.:	0	Unit:	-
Max.:	200	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 200

**Description**

-

**H0b.90 Group No. of the abnormal parameter**

Address: 0x0B5A

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0 to 65535

**Description**

-

**H0b.91 Offset of the abnormal parameter within the group**

Address: 0x0B5B

Min.: 0

Max.: 65535

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0 to 65535

**Description**

-

**H0b.94 Individual power-on time**

Address: 0x0B5E

Min.: 0

Max.: 429496729.5

Default: 0

Unit: s

Data Type: UInt32

Change: Unchangeable

**Value Range:**

0.0s to 429496729.5s

**Description**

Display the individual power-on time of the drive.

**H0b.96 Individual power-on time upon occurrence of the selected fault**

Address: 0x0B60

Min.: 0

Max.: 429496729.5

Default: 0

Unit: s

Data Type: UInt32

Change: Unchangeable

**Value Range:**

0.0s to 429496729.5s

**Description**

-

**5.13 H0d: Auxiliary Function Parameters**

**H0d.00 Software reset**

Address: 0x0D00

Min.: 0

Max.: 1

Default: 0

Unit: -

Data Type: UInt16

Change: At stop

**Value Range:**

0: No operation

1: Enable

**Description**

Programs in the drive are reset automatically (similar to the program reset upon power-on) after the software reset function is enabled, without the need for a power cycle.

**H0d.01 Fault reset**

Address: 0x0D01

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: No operation

1: Enable

**Description**

When a No. 1 or No. 2 resettable fault occurs, you can enable the fault reset function in the non-operational state after rectifying the fault cause, stopping the keypad from displaying the fault and allowing the drive to enter the "rdy" state. When a No. 3 warning occurs, you can enable the fault reset function directly.

**H0d.02 Inertia auto-tuning selection**

Address: 0x0D02

Min.: 0

Unit: -

Max.: 65

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 65

**Description**

Used to enable offline inertia auto-tuning through the keypad. In the parameter display mode, switch to H0d.02 and press the SET key to enable offline inertia auto-tuning.

**H0d.04 Read/write in encoder ROM**

Address: 0x0D04

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: No operation

1: Write ROM

2: Read ROM

3: ROM failure

**Description**

-

**H0d.05 Emergency stop**

Address: 0x0D05

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No operation

1: Enable

**Description**

-

**H0d.10 Auto-tuning of analog channel**

Address: 0x0D0A

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: No operation

1: Adjust AI1

**Description**

When automatic adjustment of the analog channel is enabled, the drive automatically corrects the zero drift voltage of the analog channel to improve signal detection accuracy.

**H0d.12 Phase U/V current balance correction**

Address: 0x0D0C

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Disable

1: Enable

**Description**

-

**H0d.17 Forced DI/DO enable switch**

Address: 0x0D11

Min.: 0

Unit: -



Min.:	0	Unit:	-
Max.:	4	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

- 0: No operation
- 1: Reset the fault
- 2: Reset the fault and multi-turn data
- 3: Reset Inovance 2nd encoder fault
- 4: Reset Inovance 2nd encoder fault and multi-turn data

**Description**

You can reset the encoder fault or the multi-turn data fed back by the encoder through H0d.20.

**H0d.23 Torque fluctuation auto-tuning**

Address: 0x0D17			
Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0 to 1

**Description**

-

**H0d.26 Brake and dynamic brake started forcibly**

Address: 0x0D1A			
Min.:	0	Unit:	-
Max.:	3	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

- 0: Disable
- 1: Dynamic brake deactivated forcibly
- 2: Brake released forcibly
- 3: Dynamic brake deactivated and brake released forcibly

**Description**

-

## 5.14 H0E: Communication Function Parameters

**H0E.00 Node address**

Address: 0x0E00

Min.:	1	Unit:	-
Max.:	127	Data Type:	UInt16
Default:	1	Change:	At stop

**Value Range:**

1 to 127

**Description**

Indicates the CAN slave node address. Ensure this parameter is consistent with the configuration of the host controller.

**H0E.01 Save objects written through communication to EEPROM**

Address: 0x0E01

Min.:	0	Unit:	-
Max.:	4	Data Type:	UInt16
Default:	4	Change:	At once

**Value Range:**

0: Not save

1: Save parameters written through communication to EEPROM

2: Save object dictionaries written through communication to EEPROM

3: Save parameters and object dictionaries written through communication to EEPROM

4: Save object dictionaries written before communication (OP) to EEPROM

**Description**

Used to set whether to save parameters and object dictionaries written through the serial port or SDO communication.

**H0E.07 Object dictionary unit**

Address: 0x0E07

Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**0: Reference unit system (p/s, p/s<sup>2</sup>)

1: User unit system (0.01 rpm, ms)

**Description**

Defines the object dictionary unit.

0: Reference unit system, p/s for speed type object dictionaries and p/s<sup>2</sup> for acceleration type object dictionaries

1: User unit system, 0.01 rpm for speed type object dictionaries and ms (time taken for changing from 0 rpm to 1000 rpm) for acceleration type object dictionaries



**H0E.15 Index of group 6000 (the last two bits)**

Address: 0x0E0F

Min.: 0

Unit: -

Max.: 255

Data Type: UInt16

Default: 255

Change: At once

**Value Range:**

0 to 255

**Description**

Defines the index of the object dictionary displayed by the oscilloscope channel.

**H0E.16 Sub-index of group 6000**

Address: 0x0E10

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 2

**Description**

Defines the sub-index of the object dictionary displayed by the oscilloscope channel.

**H0E.20 EtherCAT slave name**

Address: 0x0E14

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0E.21 EtherCAT slave alias**

Address: 0x0E15

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0 to 65535

**Description**

-

**H0E.22 Number of SYNC loss events allowed by EtherCAT**

Address: 0x0E16

Min.: 1

Unit: -

Max.: 20

Data Type: UInt16

Default: 8

Change: At once

**Value Range:**

1 to 20

**Description**

-

**H0E.24 Number of SYNC loss events**

Address: 0x0E18

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0E.25 Max. error value and invalid frames of EtherCAT port 0 per unit time**

Address: 0x0E19

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0E.26 Max. error value and invalid frames of EtherCAT port 1 per unit time**

Address: 0x0E1A

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0E.27 Max. transfer error of EtherCAT port per unit time**

Address: 0x0E1B

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0E.28 Max. EtherCAT data frame processing unit error per unit time**

Address: 0x0E1C

Min.:	0	Unit:	-
Max.:	255	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 255

**Description**

-

**H0E.29 Max. link loss value of EtherCAT port 0 per unit time**

Address: 0x0E1D

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0E.31 EtherCAT synchronization mode setting**

Address: 0x0E1F

Min.:	0	Unit:	-
Max.:	2	Data Type:	UInt16
Default:	2	Change:	At stop

**Value Range:**

0 to 2

**Description**

-

**H0E.32 EtherCAT synchronization error threshold**

Address: 0x0E20

Min.:	100	Unit:	ns
Max.:	4000	Data Type:	UInt16

Default: 3000

Change: At stop

**Value Range:**

100 ns to 4000 ns

**Description**

-

**H0E.33 EtherCAT state machine state and port connection state**

Address: 0x0E21

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0E.34 Number of excessive position reference increment events in CSP mode**

Address: 0x0E22

Min.: 1

Unit: -

Max.: 30

Data Type: UInt16

Default: 20

Change: At once

**Value Range:**

1 to 30

**Description**

-

**H0E.35 AL fault code**

Address: 0x0E23

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0E.36 EtherCAT enhanced link selection**

Address: 0x0E24

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Disable

1: Enable

**Description**

-

**H0E.37 EtherCAT XML reset selection**

Address: 0x0E25

Min.: 0

Max.: 1

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: Disable

1: Enable

**Description**

-

**H0E.80 Modbus baud rate**

Address: 0x0E50

Min.: 0

Max.: 9

Default: 9

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: 300 bps

1: 600 bps

2: 1200 bps

3: 2400 bps

4: 4800 bps

5: 9600 bps

6: 19200 bps

7: 38400 bps

8: 57600 bps

9: 115200 bps

**Description**

Defines the communication rate between the servo drive and the host controller.

The baud rate set in the servo drive must be the same as that in the host controller. Otherwise, communication will fail.

**H0E.81 Modbus data format**

Address: 0x0E51

Min.: 0

Max.: 3

Default: 3

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

- 0: No parity, 2 stop bits (N-2)
- 1: Even parity, 1 stop bit (E-1)
- 2: Odd parity, 1 stop bit (O-1)
- 3: No parity, 1 stop bit (N-1)

**Description**

Defines the data check mode between the servo drive and the host controller during communication.

- 0: No parity, 2 stop bits
- 1: Even parity, 1 stop bit
- 2: Odd parity, 1 stop bit
- 3: No parity, 1 stop bit

The data format of the servo drive must be the same as that of the host controller. Otherwise, communication will fail.

**H0E.82 Modbus response delay**

Address: 0x0E52

Min.: 0

Unit: ms

Max.: 20

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 ms to 20 ms

**Description**

Defines the delay from the moment the slave receives a command to the moment the slave returns a response.

**H0E.83 Modbus communication timeout**

Address: 0x0E53

Min.: 0

Unit: ms

Max.: 600

Data Type: UInt16

Default: 500

Change: At once

**Value Range:**

0 ms to 600 ms

**Description**

-

**H0E.84 Modbus communication data sequence**

Address: 0x0E54

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

0: High bits before low bits

1: Low bits before high bits

**Description**

Defines the 32-bit data transmission format of Modbus communication.

0: High 16 bits before low 16 bits

1: Low 16 bits before high 16 bits

**H0E.90 Modbus version**

Address: 0x0E5A

Min.: 0

Max.: 655.35

Default: 0

Unit: -

Data Type: UInt16

Change: Unchangeable

**Value Range:**

0.00 to 655.35

**Description**

-

**H0E.93 EtherCAT COE version**

Address: 0x0E5D

Min.: 0

Max.: 655.35

Default: 0

Unit: -

Data Type: UInt16

Change: Unchangeable

**Value Range:**

0.00 to 655.35

**Description**

-

**H0E.96 XML version information**

Address: 0x0E60

Min.: 0

Max.: 655.35

Default: 0

Unit: -

Data Type: UInt16

Change: Unchangeable

**Value Range:**

0.00 to 655.35

**Description**

-

## 5.15 H0F: Fully Closed Loop Parameters

### H0F.00 Encoder feedback mode

Address: 0x0F00

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At once

#### Value Range:

0: Internal encoder feedback

1: External encoder feedback

2: Inner/Outer loop switchover

#### Description

Defines the encoder feedback signal source in fully closed-loop control.

0: Internal encoder feedback: The position feedback signals come from the motor encoder.

1: External encoder feedback: The position feedback signals come from the fully closed-loop external encoder.

Electronic gear ratio 1 is used.

2: Inner/Outer loop switchover: The DI assigned with FunIN.24 (GEAR\_SEL, electronic gear ratio switchover) is used to switch between inner and outer closed position loops.

(FunIN.24: Inactive, internal encoder feedback, with electronic gear ratio 1 used)

Active: External encoder feedback, with electronic gear ratio 2 used

### H0F.01 External encoder operation mode

Address: 0x0F01

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

#### Value Range:

0: Standard operating direction

1: Reverse operating direction

#### Description

Defines the feedback pulse counting direction of internal and external encoders when the motor rotates in the fully closed-loop mode.

0: Standard operating direction: The pulse feedback counter of the internal encoder (H0F.18) is in the same direction as that of the external encoder (H0F.20) during rotation of the motor.

1: Reverse operating direction: The counting direction of pulse feedback counter of the internal encoder (H0F.18) is opposite to the external encoder (H0F.20) during rotation of the motor.



**H0F.02 External encoder mode**

Address: 0x0F02

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Incremental mode

1: Absolute linear mode

**Description**

-

**H0F.03 External encoder feedback type**

Address: 0x0F03

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Quadrature pulse

1: Inovance

2: BiSS

**Description**

-

**H0F.04 External encoder pulses per revolution**

Address: 0x0F04

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 10000

Change: At stop

**Value Range:**

0 to 2147483647

**Description**

Defines the pulses fed back by the external encoder per revolution of the motor.

It defines the quantity relationship between feedback pulses from the external encoder and those from the internal encoder.

Calculate the value of this parameter through analyzing mechanical parameters.

When rigid connection is applied between the motor and the external encoder (scale), you can also set this parameter using the following method:

1. Manually rotate the motor and observe H0F.18 (Feedback pulse counter of internal encoder) in the meantime. After ensuring that the motor has rotated for a full turn ( $H0F.18 = \text{Motor resolution}$ ), calculate the change of H0F.20 (Feedback pulse counter of external encoder) and use the absolute value of the change as the value of H0F.04.

2. Assume values of H0F.18 and H0F.20 are  $X_1$  and  $Y_1$  before the motor rotates and  $X_2$  and  $Y_2$  after the motor rotates, then the following formula applies:  $H0F.04 = \text{Motor resolution} \times (Y_2 - Y_1) / (X_2 - X_1)$  The calculated result must be positive; if not, perform step 1 again.

For non-rigid connection, an error may exist in the calculation result.

Note:

Ensure H0F.04 is set properly. Otherwise, EB02.0 (Position deviation too large in fully closed loop) may occur after the drive operates.

### H0F.08 Excessive deviation threshold in compound control mode

Address: 0x0F08

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 1000

Change: At once

#### Value Range:

0 to 2147483647

#### Description

Defines the position deviation threshold at which the servo drive reports EB02.0 (Position deviation too large in fully closed-loop mode).

When H0F.08 is set to 0, the drive does not detect EB02.0 and always clears the fully closed-loop position deviation.

### H0F.10 Clear deviation in compound control mode

Address: 0x0F0A

Min.: 0

Unit: R

Max.: 100

Data Type: UInt16

Default: 1

Change: At once

#### Value Range:

0 to 100

#### Description

Defines the number of revolutions rotated by the motor per clear of the fully closed-loop position deviation during operation. The number of revolutions is reflected by H0F.18 (Feedback pulse counter of internal encoder). The number of motor revolutions will not be cleared when the drive is in the non-operational state.

**H0F.13 Compound vibration suppression filter time**

Address:

Min.:	0	Unit:	ms
Max.:	6553.5	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0.0 ms to 6553.5 ms

**Description**

Defines the time constant for compound vibration suppression in fully closed-loop control when external encoder feedback (H0F.00 = 1 or 2) is used.

Increase the setpoint gradually and check the change in the response.

When the stiffness of the transmission mechanism between fully closed loop and internal loop is insufficient, set H0F.13 properly to improve system stability, which is to generate the effect of internal loop temporarily and form a fully closed loop again after the system is stabilized. When the stiffness is sufficient, there is no need to adjust this parameter.

**H0F.16 Pulse deviation display in compound control mode**

Address: 0x0F10

Min.:	-2147483648	Unit:	Reference unit
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-1073741824 to +2147483647

**Des-2147483648cription**

Used to count and display the position deviation absolute value in fully closed loop control.

Pulse deviation in compound control = Absolute position feedback of external encoder - Absolute position feedback conversion value of internal encoder

**H0F.18 Internal position pulse feedback display**

Address: 0x0F12

Min.:	-2147483648	Unit:	Reference unit
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Used to count and display the number of feedback pulses of the internal encoder (after being divided or multiplied by electronic gear ratio, in internal encoder unit).

**H0F.20 External position pulse feedback display**

Address: 0x0F14

Min.: -2147483648

Unit: Reference unit

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Used to count and display the number of feedback pulses of the external encoder (after being divided or multiplied by electronic gear ratio, in external encoder unit).

**H0F.22 External encoder phase Z detection invalid (quadrature pulse feedback)**

Address: 0x0F16

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Detected

1: Not detected

**Description**

-

**H0F.23 BiSS absolute homing offset**

Address: 0x0F17

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H0F.25 Source of touch probe Z signal in fully closed-loop mode**

Address: 0x0F19

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Motor Z signal

1: External feedback Z signal

**Description**

-

**H0F.26 BiSS absolute feedback offset**

Address: 0x0F1A

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H0F.28 Index value of BiSS communication warning**

Address: 0x0F1C

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0F.29 CRC of BiSS fully closed-loop feedback**

Address: 0x0F1D

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

0: Positive

1: Negative

**Description**

-

**H0F.30 Valid bit of BiSS communication position feedback**

Address: 0x0F1E

Min.: 0

Unit: -

Max.: 127

Data Type: UInt16

Default: 29

Change: At stop

**Value Range:**

0 to 127

**Description**

-

**H0F.31 Valid bit of BiSS communication warning index**

Address: 0x0F1F

Min.: 0

Unit: -

Max.: 31

Data Type: UInt16

Default: 2

Change: At stop

**Value Range:**

0 to 31

**Description**

-

**H0F.40 Invoice fully closed-loop encoder communication error register**

Address: 0x0F28

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0F.41 Invoice fully closed-loop encoder version**

Address: 0x0F29

Min.: 0

Unit: -

Max.: 6553.5

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0.0 to 6553.5

**Description**

-

**H0F.42 Invoice fully closed-loop encoder resolution**

Address: 0x0F2A

Min.: 0

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 0

Change: Unchangeable

**Value Range:**

0 to 4294967295

**Description**

-

**5.16 H11: Multi-position Parameters****H11.00 Multi-position operation mode**

Address:	0x1100	Effective:	At once
Min.:	0	Unit:	-
Max.:	5	Data Type:	UInt16
Default:	1	Change:	At stop

**Value Range:**

- 0: Individual operation (number of displacements defined by H11.01)
- 1: Cyclic operation (number of displacement defined by H11.01)
- 2: DI-based operation (defined by DI)
- 3: Sequential operation
- 5: Axis-controlled continuous operation

**Description**

Defines the multi-position operation mode when the main position reference source is multi-position references (H05.00 = 2) in the position control mode.

0: Individual operation (stop after one cycle of operation)

Switching to the next displacement automatically

You can set the interval time between displacements.

The multi-position reference is level-triggered.

1: Cyclic operation (start from displacement 1 again at next operation)

Switching to the next displacement automatically

You can set the interval time between displacements.

The multi-position reference is level-triggered.

2: DI-based operation (continue if displacement No. updated)

The displacement No is determined by the DI logic.

The interval time between displacements is determined by the command delay of the host controller.

The multi-position reference is edge-triggered.

3: Sequential operation (stop after one cycle of operation); cyclic operation available (starting displacement No. defined by H11.05 after the 1st cycle of operation)

Switching to the next displacement automatically

There is no interval time between displacements.

The multi-position reference is level-triggered.

5: Axis-controlled continuous operation (used together with CANlink)

**H11.01 Number of displacement references in multi-position mode**

Address:	0x1101	Effective:	At cone
Min.:	1	Unit:	-
Max.:	16	Data Type:	UInt16
Default:	1	Change:	At stop

**Value Range:**

1 to 16

**Description**

Defines the total number of displacement references in the multi-position mode. You can set different displacements, operating speeds, and acceleration/deceleration time for each displacement.

H11.00 ≠ 2: Displacements are switched automatically in a sequence from 1, 2... H11.01.

H11.00 = 2: Assign four DIs (hardware DI or VDI) with DI functions 6 to 9 (FunIN.6: CMD1 to FunIN.9: CMD4) and control the DI logic through the host controller to switch between different displacements. The displacement No. is a 4-bit binary value. Bit 0...bit 3 correspond to CMD1...CMD4.

**H11.02 Starting displacement No. after pause**

Address:	0x1102	Effective:	At once
Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0: Continue to execute the unexecuted displacements

1: Start from displacement 1

**Description**

Defines the starting displacement No. when the multi-position operation recovers from a pause.

Pause:

① The servo drive switches to another control mode or the interrupt positioning function is enabled during multi-position operation.

② The internal multi-position enable signal (FunIN.28:PosInSen) changes from "active" to "inactive".

0: Continue to execute the unexecuted displacements: For example, if H11.01 is set to 16 and the drive pauses at displacement 2, after the drive recovers from the pause, it will start from displacement 3.

1: Start from displacement 1: For example, if H11.01 is set to 16 and the drive pauses at displacement 2, after the drive recovers from the pause, it will start from displacement 1.



**H11.03 Interval time unit**

Address:	0x1103	Effective:	At once
Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0: ms

1: s

**Description**

Defines the unit of acceleration/deceleration time and the interval time during multi-position operation.

Acceleration/Deceleration time: time for the motor to change from 0 rpm to 1000 rpm at a constant speed.

Interval time: interval time that starts from the end of the last reference to the beginning of the next reference

**H11.04 Displacement reference type**

Address:	0x1104	Effective:	At once
Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0: Relative displacement reference

1: Absolute displacement reference

**Description**

Relative displacement: position increment of the target position relative to the current motor position

Absolute displacement: position increment of the target position relative to the motor home.

**H11.05 Starting displacement No. in sequential operation**

Address:	0x1105	Effective:	At once
Min.:	0	Unit:	-
Max.:	16	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0 to 16

**Description**

Defines whether to perform cyclic operation and the starting displacement No. after the first cycle of operation in the sequential operation mode (H11.00 = 3).  
 0: The drive executes the displacements defined by H11.01 only once and then stops. The motor is in the locked state.  
 1–16: The drive operates cyclically, with the starting displacement No. defined by H11.05 after the first cycle of operation. The value of H11.05 should be lower than or equal to H11.01.

**H11.09 Deceleration upon axis control OFF**

Address: 0x1109	Effective: At once
Min.: 0	Unit: ms
Max.: 65535	Data Type: UInt16
Default: 65535	Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.10 Starting speed of displacement 1**

Address: 0x110A	Effective: At once
Min.: 0	Unit: rpm
Max.: 9999	Data Type: UInt16
Default: 0	Change: At once

**Value Range:**

0 rpm to 9999 rpm

**Description**

-

**H11.11 Stop speed of displacement 1**

Address: 0x110B	Effective: At once
Min.: 0	Unit: rpm
Max.: 9999	Data Type: UInt16
Default: 0	Change: At once

**Value Range:**

0 rpm to 9999 rpm

**Description**

-

**H11.12 Displacement 1**

Address: 0x110C	Effective: At once
Min.: -1073741824	Unit: Reference unit

Max.: 1073741824                      Data Type: Int32  
Default: 10000                      Change: At once

**Value Range:**

-1073741824 to +1073741824

**Description**

Defines displacement 1 (reference unit) in multi-position operation.

**H11.14 Maximum speed of displacement 1**

Address: 0x110E                      Effective: At once  
Min.: 1                                  Unit: rpm  
Max.: 9999                              Data Type: UInt16  
Default: 200                            Change: At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

Defines the maximum speed of displacement 1 in multi-position operation.

The maximum speed is the average operating speed when the motor is not in the acceleration/deceleration process. If H11.12 is set to a too low value, the actual motor speed will be lower than H11.14.

**H11.15 Acceleration/Deceleration time of displacement 1**

Address: 0x110F                      Effective: At once  
Min.: 0                                  Unit: ms  
Max.: 65535                              Data Type: UInt16  
Default: 10                              Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the time for the motor to change from 0 rpm 1000 rpm at a constant speed during displacement 1.

**H11.16 Interval time after displacement 1**

Address: 0x1110                      Effective: At once  
Min.: 0                                  Unit: ms (s)  
Max.: 10000                              Data Type: UInt16  
Default: 10                              Change: At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

Defines the interval time that starts from the end of displacement 1 to the beginning of the next displacement.

**H11.17 Displacement 2**

Address:	0x1111	Effective:	At once
Min.:	-1073741824	Unit:	Reference unit
Max.:	1073741824	Data Type:	Int32
Default:	10000	Change:	At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.19 Maximum speed of displacement 2**

Address:	0x1113	Effective:	At once
Min.:	1	Unit:	rpm
Max.:	9999	Data Type:	UInt16
Default:	200	Change:	At once

**Value Range:**

1 rpm to 9999 rpm

**Description****H11.20 Acceleration/Deceleration time of displacement 2**

Address:	0x1114	Effective:	At once
Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.21 Interval time after displacement 2**

Address:	0x1115	Effective:	At once
Min.:	0	Unit:	ms (s)
Max.:	10000	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

**H11.22 Displacement 3**

Address:	0x1116	Effective:	At once
Min.:	-1073741824	Unit:	Reference unit
Max.:	1073741824	Data Type:	Int32
Default:	10000	Change:	At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.24 Maximum speed of displacement 3**

Address:	0x1118	Effective:	At once
Min.:	1	Unit:	rpm
Max.:	9999	Data Type:	UInt16
Default:	200	Change:	At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.25 Acceleration/Deceleration time of displacement 3**

Address:	0x1119	Effective:	At once
Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.26 Interval time after displacement 3**

Address:	0x111A	Effective:	At once
Min.:	0	Unit:	ms (s)
Max.:	10000	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

**H11.27 Displacement 4**

Address:	0x111B	Effective:	At once
Min.:	-1073741824	Unit:	Reference unit
Max.:	1073741824	Data Type:	Int32
Default:	10000	Change:	At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.29 Maximum speed of displacement 4**

Address:	0x111D	Effective:	At once
Min.:	1	Unit:	rpm
Max.:	9999	Data Type:	UInt16
Default:	200	Change:	At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.30 Acceleration/Deceleration time of displacement 4**

Address:	0x111E	Effective:	At once
Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.31 Interval time after displacement 4**

Address:	0x111F	Effective:	At once
Min.:	0	Unit:	ms (s)
Max.:	10000	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

**H11.32 Displacement 5**

Address: 0x1120	Effective: At once
Min.: -1073741824	Unit: Reference unit
Max.: 1073741824	Data Type: Int32
Default: 10000	Change: At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.34 Maximum speed of displacement 5**

Address: 0x1122	Effective: At once
Min.: 1	Unit: rpm
Max.: 9999	Data Type: UInt16
Default: 200	Change: At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.35 Acceleration/Deceleration time of displacement 5**

Address: 0x1123	Effective: At once
Min.: 0	Unit: ms
Max.: 65535	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.36 Interval time after displacement 5**

Address: 0x1124	Effective: At once
Min.: 0	Unit: ms (s)
Max.: 10000	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

**H11.37 Displacement 6**

Address:	0x1125	Effective:	At once
Min.:	-1073741824	Unit:	Reference unit
Max.:	1073741824	Data Type:	Int32
Default:	10000	Change:	At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.39 Maximum speed of displacement 6**

Address:	0x1127	Effective:	At once
Min.:	1	Unit:	rpm
Max.:	9999	Data Type:	UInt16
Default:	200	Change:	At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.40 Acceleration/Deceleration time of displacement 6**

Address:	0x1128	Effective:	At once
Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.41 Interval time after displacement 6**

Address:	0x1129	Effective:	At once
Min.:	0	Unit:	ms (s)
Max.:	10000	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-



**H11.42 Displacement 7**

Address: 0x112A	Effective: At once
Min.: -1073741824	Unit: Reference unit
Max.: 1073741824	Data Type: Int32
Default: 10000	Change: At once

**Value Range:**  
-1073741824 to +1073741824

**Description**

-

**H11.44 Maximum speed of displacement 7**

Address: 0x112C	Effective: At once
Min.: 1	Unit: rpm
Max.: 9999	Data Type: UInt16
Default: 200	Change: At once

**Value Range:**  
1 rpm to 9999 rpm

**Description**

-

**H11.45 Acceleration/Deceleration time of displacement 7**

Address: 0x112D	Effective: At once
Min.: 0	Unit: ms
Max.: 65535	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**  
0 ms to 65535 ms

**Description**

-

**H11.46 Interval time after displacement 7**

Address: 0x112E	Effective: At once
Min.: 0	Unit: ms (s)
Max.: 10000	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**  
0 ms(s) to 10000 ms(s)

**Description**

-

**H11.47 Displacement 8**

Address: 0x112F	Effective: At once
Min.: -1073741824	Unit: Reference unit
Max.: 1073741824	Data Type: Int32
Default: 10000	Change: At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.49 Maximum speed of displacement 8**

Address: 0x1131	Effective: At once
Min.: 1	Unit: rpm
Max.: 9999	Data Type: UInt16
Default: 200	Change: At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.50 Acceleration/Deceleration time of displacement 8**

Address: 0x1132	Effective: At once
Min.: 0	Unit: ms
Max.: 65535	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.51 Interval time after displacement 8**

Address: 0x1133	Effective: At once
Min.: 0	Unit: ms (s)
Max.: 10000	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

**H11.52 Displacement 9**

Address: 0x1134	Effective: At once
Min.: -1073741824	Unit: Reference unit
Max.: 1073741824	Data Type: Int32
Default: 10000	Change: At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.54 Maximum speed of displacement 9**

Address: 0x1136	Effective: At once
Min.: 1	Unit: rpm
Max.: 9999	Data Type: UInt16
Default: 200	Change: At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.55 Acceleration/Deceleration time of displacement 9**

Address: 0x1137	Effective: At once
Min.: 0	Unit: ms
Max.: 65535	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.56 Interval time after displacement 9**

Address: 0x1138	Effective: At once
Min.: 0	Unit: ms (s)
Max.: 10000	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

**H11.57 Displacement 10**

Address:	0x1139	Effective:	At once
Min.:	-1073741824	Unit:	Reference unit
Max.:	1073741824	Data Type:	Int32
Default:	10000	Change:	At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.59 Maximum speed of displacement 10**

Address:	0x113B	Effective:	At once
Min.:	1	Unit:	rpm
Max.:	9999	Data Type:	UInt16
Default:	200	Change:	At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.60 Acceleration/Deceleration time of displacement 10**

Address:	0x113C	Effective:	At once
Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.61 Interval time after displacement 10**

Address:	0x113D	Effective:	At once
Min.:	0	Unit:	ms (s)
Max.:	10000	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

**H11.62 Displacement 11**

Address: 0x113E	Effective: At once
Min.: -1073741824	Unit: Reference unit
Max.: 1073741824	Data Type: Int32
Default: 10000	Change: At once

**Value Range:**  
-1073741824 to +1073741824

**Description**

-

**H11.64 Maximum speed of displacement 11**

Address: 0x1140	Effective: At once
Min.: 1	Unit: rpm
Max.: 9999	Data Type: UInt16
Default: 200	Change: At once

**Value Range:**  
1 rpm to 9999 rpm

**Description**

-

**H11.65 Acceleration/Deceleration time of displacement 11**

Address: 0x1141	Effective: At once
Min.: 0	Unit: ms
Max.: 65535	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**  
0 ms to 65535 ms

**Description**

-

**H11.66 Interval time after displacement 11**

Address: 0x1142	Effective: At once
Min.: 0	Unit: ms (s)
Max.: 10000	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**  
0 ms(s) to 10000 ms(s)

**Description**

-

**H11.67 Displacement 12**

Address:	0x1143	Effective:	At once
Min.:	-1073741824	Unit:	Reference unit
Max.:	1073741824	Data Type:	Int32
Default:	10000	Change:	At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.69 Maximum speed of displacement 12**

Address:	0x1145	Effective:	At once
Min.:	1	Unit:	rpm
Max.:	9999	Data Type:	UInt16
Default:	200	Change:	At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.70 Acceleration/Deceleration time of displacement 12**

Address:	0x1146	Effective:	At once
Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.71 Interval time after displacement 12**

Address:	0x1147	Effective:	At once
Min.:	0	Unit:	ms (s)
Max.:	10000	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

**H11.72 Displacement 13**

Address: 0x1148	Effective: At once
Min.: -1073741824	Unit: Reference unit
Max.: 1073741824	Data Type: Int32
Default: 10000	Change: At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.74 Maximum speed of displacement 13**

Address: 0x114A	Effective: At once
Min.: 1	Unit: rpm
Max.: 9999	Data Type: UInt16
Default: 200	Change: At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.75 Acceleration/Deceleration time of displacement 13**

Address: 0x114B	Effective: At once
Min.: 0	Unit: ms
Max.: 65535	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.76 Interval time after displacement 13**

Address: 0x114C	Effective: At once
Min.: 0	Unit: ms (s)
Max.: 10000	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

**H11.77 Displacement 14**

Address: 0x114D	Effective: At once
Min.: -1073741824	Unit: Reference unit
Max.: 1073741824	Data Type: Int32
Default: 10000	Change: At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.79 Maximum speed of displacement 14**

Address: 0x114F	Effective: At once
Min.: 1	Unit: rpm
Max.: 9999	Data Type: UInt16
Default: 200	Change: At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.80 Acceleration/Deceleration time of displacement 14**

Address: 0x1150	Effective: At once
Min.: 0	Unit: ms
Max.: 65535	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.81 Interval time after displacement 14**

Address: 0x1151	Effective: At once
Min.: 0	Unit: ms (s)
Max.: 10000	Data Type: UInt16
Default: 10	Change: At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-



**H11.82 Displacement 15**

Address:	0x1152	Effective:	At once
Min.:	-1073741824	Unit:	Reference unit
Max.:	1073741824	Data Type:	Int32
Default:	10000	Change:	At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.84 Maximum speed of displacement 15**

Address:	0x1154	Effective:	At once
Min.:	1	Unit:	rpm
Max.:	9999	Data Type:	UInt16
Default:	200	Change:	At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.85 Acceleration/Deceleration time of displacement 15**

Address:	0x1155	Effective:	At once
Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.86 Interval time after displacement 15**

Address:	0x1156	Effective:	At once
Min.:	0	Unit:	ms (s)
Max.:	10000	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

**H11.87 Displacement 16**

Address:	0x1157	Effective:	At once
Min.:	-1073741824	Unit:	Reference unit
Max.:	1073741824	Data Type:	Int32
Default:	10000	Change:	At once

**Value Range:**

-1073741824 to +1073741824

**Description**

-

**H11.89 Maximum speed of displacement 16**

Address:	0x1159	Effective:	At once
Min.:	1	Unit:	rpm
Max.:	9999	Data Type:	UInt16
Default:	200	Change:	At once

**Value Range:**

1 rpm to 9999 rpm

**Description**

-

**H11.90 Acceleration/Deceleration time of displacement 16**

Address:	0x115A	Effective:	At once
Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

-

**H11.91 Interval time after displacement 16**

Address:	0x115B	Effective:	At once
Min.:	0	Unit:	ms (s)
Max.:	10000	Data Type:	UInt16
Default:	10	Change:	At once

**Value Range:**

0 ms(s) to 10000 ms(s)

**Description**

-

## 5.17 H12: Multi-speed Parameters

### H12.00 Multi-speed operation mode

Address: 0x1200

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 1

Change: At stop

#### Value Range:

0: Individual operation (number of speeds defined by H12.01)

1: Cyclic operation (number of speeds defined by H12.01)

2: DI-based operation

#### Description

Defines the multi-speed operation mode when the speed reference source is multi-speed reference (H06.01 = 5, H06.02 = 1/2/3) in the speed control mode.

0: The drive stops after one cycle of operation and switches to the next speed automatically.

1: The drive operates cyclically as long as the S-ON signal is active. In cyclic operation, the drive starts from speed 1 again after each cycle of operation.

2: The drive operates continuously as long as the S-ON signal is active. The operating time of each speed is determined only by the time interval of speed switchover. The operating direction can be switched by FunIN.5 (DIR-SEL).

The S-ON signal must remain active during operation of each speed. Otherwise, the drive stops immediately based on the stop mode defined by H02.05.

Speed arrival (FunOUT.19: V-Arr) signal is activated every time a certain speed reaches the set value.

### H12.01 Number of speed references in multi-speed mode

Address: 0x1201

Min.: 1

Unit: -

Max.: 16

Data Type: UInt16

Default: 16

Change: At stop

#### Value Range:

1 to 16

#### Description

Defines the total number of speed references in the multi-speed mode. Different speed references, operating time, and acceleration/deceleration time (four groups available) can be set for each speed.

H12.00 ≠ 2: Speeds are switched automatically in a sequence from 1, 2...H12.01.

H12.00 = 2: Assign four DIs (hardware DI or VDI) with DI functions 6 to 9 (FunIN.6: CMD1 to FunIN.9: CMD4) and control the DI logic through the host controller to switch between different speeds. The displacement No. is a 4-bit binary value. Bit 0...bit 3 correspond to CMD1...CMD4.

**H12.02 Operating time unit**

Address: 0x1202

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: s

1: min

**Description**

Defines the time unit in multi-speed operation.

0: s

1: min

**H12.03 Acceleration time 1**

Address: 0x1203

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 10

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Four groups of acceleration/deceleration time can be set for each speed reference.

Acceleration time: time for the motor to accelerate from 0 rpm to 1000 rpm at a constant speed

**H12.04 Deceleration time 1**

Address: 0x1204

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 10

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Four groups of acceleration/deceleration time can be set for each speed reference.

Deceleration time: time for the motor to decelerate from 1000 rpm to 0 rpm at a constant speed

**H12.05 Acceleration time 2**

Address: 0x1205

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 50

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Four groups of acceleration/deceleration time can be set for each speed reference.

Acceleration time: time for the motor to accelerate from 0 rpm to 1000 rpm at a constant speed

**H12.06 Deceleration time 2**

Address: 0x1206

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 50

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Four groups of acceleration/deceleration time can be set for each speed reference.

Deceleration time: time for the motor to decelerate from 1000 rpm to 0 rpm at a constant speed

**H12.07 Acceleration time 3**

Address: 0x1207

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 100

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Four groups of acceleration/deceleration time can be set for each speed reference.

Acceleration time: time for the motor to accelerate from 0 rpm to 1000 rpm at a constant speed

**H12.08 Deceleration time 3**

Address: 0x1208

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 100

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Four groups of acceleration/deceleration time can be set for each speed reference.

Deceleration time: time for the motor to decelerate from 1000 rpm to 0 rpm at a constant speed

**H12.09 Acceleration time 4**

Address: 0x1209

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 150

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Four groups of acceleration/deceleration time can be set for each speed reference.

Acceleration time: time for the motor to accelerate from 0 rpm to 1000 rpm at a constant speed

**H12.10 Deceleration time 4**

Address: 0x120A

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 150

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Four groups of acceleration/deceleration time can be set for each speed reference.

Deceleration time: time for the motor to decelerate from 1000 rpm to 0 rpm at a constant speed

**H12.20 Speed reference for speed 1**

Address: 0x1214

Min.: -9999

Unit: rpm

Max.: 9999

Data Type: Int16

Default: 0

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.21 Operating time of speed 1**

Address: 0x1215

Min.: 0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

Defines the operating time of speed 1.

The operating time is the sum of the speed variation time from previous speed reference to present speed reference plus the average operating time of present speed reference.

If the operating time is set to 0, the drive skips this speed automatically.

As long as H12.00 (Multi-speed operation mode) is set to 2 (DI-based operation) and the speed No. determined by the external DI does not change, the drive continues operating at the speed defined by this speed reference, without being affected by the reference operating time.

**H12.22 Acceleration/Deceleration time of speed 1**

Address: 0x1216

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Defines the acceleration/deceleration time of speed 1.

0: Zero acceleration/deceleration time (acceleration time: 0; deceleration time: 0)

1: Acceleration/Deceleration time 1 (acceleration time: H12.03; deceleration time: H12.04)

2: Acceleration/Deceleration time 2 (acceleration time: H12.05; deceleration time: H12.06)

3: Acceleration/Deceleration time 3 (acceleration time: H12.07; deceleration time: H12.08)

4: Acceleration/Deceleration time 4 (acceleration time: H12.09; deceleration time (H12.10)

**H12.23 Speed reference for speed 2**

Address: 0x1217

Min.: -9999

Max.: 9999

Default: 100

Unit: rpm

Data Type: Int16

Change: At once

**Value Range:**

-9999 to 9999

**Description**

-

**H12.24 Operating time of speed 2**

Address: 0x1218

Min.: 0

Max.: 6553.5

Default: 5

Unit: s (m)

Data Type: UInt16

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.25 Acceleration/Deceleration time of speed 2**

Address: 0x1219

Min.: 0

Max.: 4

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.26 Speed reference for speed 3**

Address: 0x121A

Min.: -9999

Max.: 9999

Default: 300

Unit: rpm

Data Type: Int16

Change: At once

**Value Range:**

-9999 to +9999



**Description**

-

**H12.27 Operating time of speed 3**

Address: 0x121B

Min.: 0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.28 Acceleration/Deceleration time of speed 3**

Address: 0x121C

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.29 Speed reference for speed 4**

Address: 0x121D

Min.: -9999

Unit: rpm

Max.: 9999

Data Type: Int16

Default: 500

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.30 Operating time of speed 4**

Address: 0x121E

Min.: 0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16



**H12.34 Acceleration/Deceleration time of speed 5**

Address: 0x1222

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.35 Speed reference for speed 6**

Address: 0x1223

Min.: -9999

Unit: rpm

Max.: 9999

Data Type: Int16

Default: 900

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.36 Operating time of speed 6**

Address: 0x1224

Min.: 0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.37 Acceleration/Deceleration time of speed 6**

Address: 0x1225

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time  
 1: Acceleration/Deceleration time 1  
 2: Acceleration/Deceleration time 2  
 3: Acceleration/Deceleration time 3  
 4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.38 Speed reference for speed 7**

Address: 0x1226

Min.: -9999

Unit: rpm

Max.: 9999

Data Type: Int16

Default: 600

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.39 Operating time of speed 7**

Address: 0x1227

Min.: 0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.40 Acceleration/Deceleration time of speed 7**

Address: 0x1228

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time  
 1: Acceleration/Deceleration time 1  
 2: Acceleration/Deceleration time 2  
 3: Acceleration/Deceleration time 3  
 4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.41 Speed reference for speed 8**

Address: 0x1229

Min.: -9999

Max.: 9999

Default: 300

Unit: rpm

Data Type: Int16

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.42 Operating time of speed 8**

Address: 0x122A

Min.: 0

Max.: 6553.5

Default: 5

Unit: s (m)

Data Type: UInt16

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.43 Acceleration/Deceleration time of speed 8**

Address: 0x122B

Min.: 0

Max.: 4

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.44 Speed reference for speed 9**

Address: 0x122C

Min.: -9999

Max.: 9999

Default: 100

Unit: rpm

Data Type: Int16

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.45 Operating time of speed 9**

Address: 0x122D

Min.: 0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.46 Acceleration/Deceleration time of speed 9**

Address: 0x122E

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.47 Speed reference for speed 10**

Address: 0x122F

Min.: -9999

Unit: rpm

Max.: 9999

Data Type: Int16

Default: -100

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.48 Operating time of speed 10**

Address: 0x1230

Min.: 0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16



**H12.52 Acceleration/Deceleration time of speed 11**

Address: 0x1234

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.53 Speed reference for speed 12**

Address: 0x1235

Min.: -9999

Unit: rpm

Max.: 9999

Data Type: Int16

Default: -500

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.54 Operating time of speed 12**

Address: 0x1236

Min.: 0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.55 Acceleration/Deceleration time of speed 12**

Address: 0x1237

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**



- 0: Zero acceleration/deceleration time
- 1: Acceleration/Deceleration time 1
- 2: Acceleration/Deceleration time 2
- 3: Acceleration/Deceleration time 3
- 4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.56 Speed reference for speed 13**

Address: 0x1238

Min.: -9999

Max.: 9999

Default: -700

Unit: rpm

Data Type: Int16

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.57 Operating time of speed 13**

Address: 0x1239

Min.: 0

Max.: 6553.5

Default: 5

Unit: s (m)

Data Type: UInt16

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.58 Acceleration/Deceleration time of speed 13**

Address: 0x123A

Min.: 0

Max.: 4

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.59 Speed reference for speed 14**

Address: 0x123B

Min.: -9999

Max.: 9999

Default: -900

Unit: rpm

Data Type: Int16

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.60 Operating time of speed 14**

Address: 0x123C

Min.: 0

Max.: 6553.5

Default: 5

Unit: s (m)

Data Type: UInt16

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.61 Acceleration/Deceleration time of speed 14**

Address: 0x123D

Min.: 0

Max.: 4

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.62 Speed reference for speed 15**

Address: 0x123E

Min.: -9999

Max.: 9999

Default: -600

Unit: rpm

Data Type: Int16

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.63 Operating time of speed 15**

Address: 0x123F

Min.: 0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16

Default: 5

Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.64 Acceleration/Deceleration time of speed 15**

Address: 0x1240

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**H12.65 Speed reference for speed 16**

Address: 0x1241

Min.: -9999

Unit: rpm

Max.: 9999

Data Type: Int16

Default: -300

Change: At once

**Value Range:**

-9999 to +9999

**Description**

-

**H12.66 Operating time of speed 16**

Address: 0x1242

Min.: 0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16

Default: 5 Change: At once

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.67 Acceleration/Deceleration time of speed 16**

Address: 0x1243

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

Same as H12.22

**5.18 H17: VDI/VDO Parameters****H17.90 Communication VDI enable**

Address: 0x175A

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Disable

1: Enable

**Description**

To use the VDI function:

1. Set H17.90 to enable VDI.
2. Set the default level after power-on in H17.91.
3. Set the DI function of the VDI through parameters in group H17.
4. Set the VDI output in H31.00.

**H17.91 VDI default value upon power-on**

Address: 0x175B

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: 0x0: No default

1: 0x01: VDI1 default value

2: 0x02: VDI2 default value

4: 0x04: VDI3 default value

8: 0x08: VDI4 default value

16: 0x10: VDI5 default value

32: 0x20: VDI6 default value

64: 0x40: VDI7 default value

128: 0x80: VDI8 default value

256: 0x100: VDI9 default value

512: 0x200: VDI10 default value

1024: 0x400: VDI11 default value

2048: 0x800: VDI12 default value

4096: 0x1000: VDI13 default value

8092: 0x2000: VDI14 default value

16384: 0x4000: VDI15 default value

32768: 0x8000: VDI16 default value

**Description**

Used to configure the initial values of VDI upon power-on.

Bit 0 corresponds to VDI1.

Bit 1 corresponds to VDI2.

...

Bit15 corresponds to VDI16.

**H17.00 VDI1 function**

Address: 0x1700

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment  
 1: Servo ON  
 2: Alarm reset signal  
 5: Multi-reference direction  
 6: Multi-reference switchover CMD1  
 7: Multi-reference switchover CMD2  
 8: Multi-reference switchover CMD3  
 9: Multi-reference switchover CMD4  
 14: Positive limit switch  
 15: Negative limit switch  
 18: Forward jog  
 19: Reverse jog  
 24: Electronic gear ratio selection  
 28: Multi-position reference enable  
 31: Home switch  
 34: Emergency stop  
 40: Multi-speed enable

**Description**

-

**H17.01 VDI1 logic level**

Address: 0x1701

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.02 VDI2 function**

Address: 0x1702

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- 0: No assignment
- 1: Servo ON
- 2: Alarm reset signal
- 5: Multi-reference direction
- 6: Multi-reference switchover CMD1
- 7: Multi-reference switchover CMD2
- 8: Multi-reference switchover CMD3
- 9: Multi-reference switchover CMD4
- 14: Positive limit switch
- 15: Negative limit switch
- 18: Forward jog
- 19: Reverse jog
- 24: Electronic gear ratio selection
- 28: Multi-position reference enable
- 31: Home switch
- 34: Emergency stop
- 40: Multi-speed enable

**Description**

-

**H17.03 VDI2 logic level selection**

Address: 0x1703

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.04 VDI3 function**

Address: 0x1704

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment  
 1: Servo ON  
 2: Alarm reset signal  
 5: Multi-reference direction  
 6: Multi-reference switchover CMD1  
 7: Multi-reference switchover CMD2  
 8: Multi-reference switchover CMD3  
 9: Multi-reference switchover CMD4  
 14: Positive limit switch  
 15: Negative limit switch  
 18: Forward jog  
 19: Reverse jog  
 24: Electronic gear ratio selection  
 28: Multi-position reference enable  
 31: Home switch  
 34: Emergency stop  
 40: Multi-speed enable

**Description**

-

**H17.05 VDI3 logic level selection**

Address: 0x1705

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.06 VDI4 function**

Address: 0x1706

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**



- 0: No assignment
- 1: Servo ON
- 2: Alarm reset signal
- 5: Multi-reference direction
- 6: Multi-reference switchover CMD1
- 7: Multi-reference switchover CMD2
- 8: Multi-reference switchover CMD3
- 9: Multi-reference switchover CMD4
- 14: Positive limit switch
- 15: Negative limit switch
- 18: Forward jog
- 19: Reverse jot
- 24: Electronic gear ratio selection
- 28: Multi-position reference enable
- 31: Home switch
- 34: Emergency stop
- 40: Multi-speed enable

**Description**

-

**H17.07 VDI4 logic level selection**

Address: 0x1707

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.08 VDI5 function**

Address: 0x1708

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment  
 1: Servo ON  
 2: Alarm reset signal  
 5: Multi-reference direction  
 6: Multi-reference switchover CMD1  
 7: Multi-reference switchover CMD2  
 8: Multi-reference switchover CMD3  
 9: Multi-reference switchover CMD4  
 14: Positive limit switch  
 15: Negative limit switch  
 18: Forward jog  
 19: Reverse jog  
 24: Electronic gear ratio selection  
 28: Multi-position reference enable  
 31: Home switch  
 34: Emergency stop  
 40: Multi-speed enable

**Description**

-

**H17.09 VDI5 logic level selection**

Address: 0x1709

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.10 VDI6 function**

Address: 0x170A

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ON2: Alarm reset signal5: Multi-reference direction6: Multi-reference switchover CMD17: Multi-reference switchover CMD28: Multi-reference switchover CMD39: Multi-reference switchover CMD414: Positive limit switch15: Negative limit switch18: Forward jog19: Reverse jot24: Electronic gear ratio selection28: Multi-position reference enable31: Home switch34: Emergency stop40: Multi-speed enable

**Description**

-

**H17.11 VDI6 logic level selection**

Address: 0x170B

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.12 VDI7 function**

Address: 0x170C

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ON2: Alarm reset signal5: Multi-reference direction6: Multi-reference switchover CMD17: Multi-reference switchover CMD28: Multi-reference switchover CMD39: Multi-reference switchover CMD414: Positive limit switch15: Negative limit switch18: Forward jog19: Reverse jot24: Electronic gear ratio selection28: Multi-position reference enable31: Home switch34: Emergency stop40: Multi-speed enable

**Description**

-

**H17.13 VDI7 logic level selection**

Address: 0x170D

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.14 VDI8 function**

Address: 0x170E

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ON

2: Alarm reset signal

5: Multi-reference direction

6: Multi-reference switchover CMD1

7: Multi-reference switchover CMD2

8: Multi-reference switchover CMD3

9: Multi-reference switchover CMD4

14: Positive limit switch

15: Negative limit switch

18: Forward jog

19: Reverse jog

24: Electronic gear ratio selection

28: Multi-position reference enable

31: Home switch

34: Emergency stop

40: Multi-speed enable

**Description**

-

**H17.15 VDI8 logic level selection**

Address: 0x170F

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.16 VDI9 function**

Address: 0x1710

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ON2: Alarm reset signal5: Multi-reference direction6: Multi-reference switchover CMD17: Multi-reference switchover CMD28: Multi-reference switchover CMD39: Multi-reference switchover CMD414: Positive limit switch15: Negative limit switch18: Forward jog19: Reverse jot24: Electronic gear ratio selection28: Multi-position reference enable31: Home switch34: Emergency stop40: Multi-speed enable

**Description**

-

**H17.17 VDI9 logic level selection**

Address: 0x1711

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.18 VDI10 function**

Address: 0x1712

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ON2: Alarm reset signal5: Multi-reference direction6: Multi-reference switchover CMD17: Multi-reference switchover CMD28: Multi-reference switchover CMD39: Multi-reference switchover CMD414: Positive limit switch15: Negative limit switch18: Forward jog19: Reverse jot24: Electronic gear ratio selection28: Multi-position reference enable31: Home switch34: Emergency stop40: Multi-speed enable

**Description**

-

**H17.19 VDI10 logic level selection**

Address: 0x1713

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.20 VDI11 function**

Address: 0x1714

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ON

2: Alarm reset signal

5: Multi-reference direction

6: Multi-reference switchover CMD1

7: Multi-reference switchover CMD2

8: Multi-reference switchover CMD3

9: Multi-reference switchover CMD4

14: Positive limit switch

15: Negative limit switch

18: Forward jog

19: Reverse jog

24: Electronic gear ratio selection

28: Multi-position reference enable

31: Home switch

34: Emergency stop

40: Multi-speed enable

**Description**

-

**H17.21 VDI11 logic level selection**

Address: 0x1715

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

- 0: Active when the written value is 1
- 1: Active when the written value changes from 0 to 1

**Description**

-

**H17.22 VDI12 function**

Address: 0x1716

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- 0: No assignment
- 1: Servo ON
- 2: Alarm reset signal
- 5: Multi-reference direction
- 6: Multi-reference switchover CMD1
- 7: Multi-reference switchover CMD2
- 8: Multi-reference switchover CMD3
- 9: Multi-reference switchover CMD4
- 14: Positive limit switch
- 15: Negative limit switch
- 18: Forward jog
- 19: Reverse jot
- 24: Electronic gear ratio selection
- 28: Multi-position reference enable
- 31: Home switch
- 34: Emergency stop
- 40: Multi-speed enable

**Description**

-

**H17.23 VDI12 logic level selection**

Address: 0x1717

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

- 0: Active when the written value is 1
- 1: Active when the written value changes from 0 to 1

**Description**

-

**H17.24 VDI13 function**

Address: 0x1718

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ON

2: Alarm reset signal

5: Multi-reference direction

6: Multi-reference switchover CMD1

7: Multi-reference switchover CMD2

8: Multi-reference switchover CMD3

9: Multi-reference switchover CMD4

14: Positive limit switch

15: Negative limit switch

18: Forward jog

19: Reverse jog

24: Electronic gear ratio selection

28: Multi-position reference enable

31: Home switch

34: Emergency stop

40: Multi-speed enable

**Description**

-

**H17.25 VDI13 logic level selection**

Address: 0x1719

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.26 VDI14 function**

Address: 0x171A

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once



**Value Range:**

- 0: No assignment
- 1: Servo ON
- 2: Alarm reset signal
- 5: Multi-reference direction
- 6: Multi-reference switchover CMD1
- 7: Multi-reference switchover CMD2
- 8: Multi-reference switchover CMD3
- 9: Multi-reference switchover CMD4
- 14: Positive limit switch
- 15: Negative limit switch
- 18: Forward jog
- 19: Reverse jot
- 24: Electronic gear ratio selection
- 28: Multi-position reference enable
- 31: Home switch
- 34: Emergency stop
- 40: Multi-speed enable

**Description**

-

**H17.27 VDI14 logic level selection**

Address: 0x171B

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

- 0: Active when the written value is 1
- 1: Active when the written value changes from 0 to 1

**Description**

-

**H17.28 VDI15 function**

Address: 0x171C

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment  
 1: Servo ON  
 2: Alarm reset signal  
 5: Multi-reference direction  
 6: Multi-reference switchover CMD1  
 7: Multi-reference switchover CMD2  
 8: Multi-reference switchover CMD3  
 9: Multi-reference switchover CMD4  
 14: Positive limit switch  
 15: Negative limit switch  
 18: Forward jog  
 19: Reverse jog  
 24: Electronic gear ratio selection  
 28: Multi-position reference enable  
 31: Home switch  
 34: Emergency stop  
 40: Multi-speed enable

**Description**

-

**H17.29 VDI15 logic level selection**

Address: 0x171D

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.30 VDI16 function**

Address: 0x171E

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ON2: Alarm reset signal5: Multi-reference direction6: Multi-reference switchover CMD17: Multi-reference switchover CMD28: Multi-reference switchover CMD39: Multi-reference switchover CMD414: Positive limit switch15: Negative limit switch18: Forward jog19: Reverse jog24: Electronic gear ratio selection28: Multi-position reference enable31: Home switch34: Emergency stop40: Multi-speed enable

**Description**

-

**H17.31 VDI16 logic level selection**

Address: 0x171F

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 11: Active when the written value changes from 0 to 1

**Description**

-

**H17.92 Communication VDO enable**

Address: 0x175C

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Disable

1: Enable

**Description**

To use the VDO function:

1. Set H17.92 to enable VDO.
2. Set the default level after power-on in H17.93.
3. Set the DO function of the VDO through parameters in group H17.
4. Read the output level of the VDO in H17.32.

**H17.93 VDO default value after power-on**

Address: 0x175D

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: 0x0: No default  
 1: 0x01: VDI1 default value  
 2: 0x02: VDI2 default value  
 4: 0x04: VDI3 default value  
 8: 0x08: VDI4 default value  
 16: 0x10: VDI5 default value  
 32: 0x20: VDI6 default value  
 64: 0x40:VDI7 default value  
 128: 0x80: VDI8 default value  
 256: 0x100: VDI9 default value  
 512: 0x200: VDI10 default value  
 1024: 0x400: VDI11 default value  
 2048: 0x800: VDI12 default value  
 4096: 0x1000: VDI13 default value  
 8192: 0x2000: VDI14 default value  
 16384: 0x4000: VDI15 default value  
 32768: 0x8000: VDI16 default value

**Description**

Used to configure the initial value of VDO upon power-on.

Bit 0 corresponds to VDO1.

Bit 1 corresponds to VDO2.

...

Bit15 corresponds to VDO16.

**H17.32 VDO virtual level**

Address: 0x1720

Min.: 0

Max.: 65535

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0 to 65535

**Description**

-

**H17.33 VDO1 function**

Address: 0x1721

Min.: 0

Max.: 32

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0: No assignment  
 1: Servo ready  
 2: Motor rotating  
 10: Warning  
 11: Fault  
 31: Communication-forced DO  
 32: EDM output

**Description**

-

**H17.34 VDO1 logic level**

Address: 0x1722

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.35 VDO2 function**

Address: 0x1723

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

10: Warning

11: Fault

31: Communication-forced DO

32: EDM output

**Description**

-

**H17.36 VDO2 logic level**

Address: 0x1724

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.37 VDO3 function**

Address: 0x1725

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

10: Warning

11: Fault

31: Communication-forced DO

32: EDM output

**Description**

-

**H17.38 VDO3 logic level**

Address: 0x1726

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.39 VDO4 function**

Address: 0x1727

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment  
 1: Servo ready  
 2: Motor rotating  
 10: Warning  
 11: Fault  
 31: Communication-forced DO  
 32: EDM output

**Description**

-

**H17.40 VDO4 logic level**

Address: 0x1728

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.41 VDO5 function**

Address: 0x1729

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

10: Warning

11: Fault

31: Communication-forced DO

32: EDM output

**Description**

-

**H17.42 VDO5 logic level**

Address: 0x172A

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.43 VDO6 function**

Address: 0x172B

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

10: Warning

11: Fault

31: Communication-forced DO

32: EDM output

**Description**

-

**H17.44 VDO6 logic level**

Address: 0x172C

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.45 VDO7 function**

Address: 0x172D

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**



0: No assignment  
 1: Servo ready  
 2: Motor rotating  
 10: Warning  
 11: Fault  
 31: Communication-forced DO  
 32: EDM output

**Description**

-

**H17.46 VDO7 logic level**

Address: 0x172E

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.47 VDO8 function**

Address: 0x172F

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

10: Warning

11: Fault

31: Communication-forced DO

32: EDM output

**Description**

-

**H17.48 VDO8 logic level**

Address: 0x1730

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.49 VDO9 function**

Address: 0x1731

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

10: Warning

11: Fault

31: Communication-forced DO

32: EDM output

**Description**

-

**H17.50 VDO9 logic level**

Address: 0x1732

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.51 VDO10 function**

Address: 0x1733

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment  
 1: Servo ready  
 2: Motor rotating  
 10: Warning  
 11: Fault  
 31: Communication-forced DO  
 32: EDM output

**Description**

-

**H17.52 VDO10 logic level**

Address: 0x1734

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.53 VDO11 function**

Address: 0x1735

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

10: Warning

11: Fault

31: Communication-forced DO

32: EDM output

**Description**

-

**H17.54 VDO11 logic level**

Address: 0x1736

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.55 VDO12 function**

Address: 0x1737

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

10: Warning

11: Fault

31: Communication-forced DO

32: EDM output

**Description**

-

**H17.56 VDO12 logic level**

Address: 0x1738

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.57 VDO13 function**

Address: 0x1739

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment  
 1: Servo ready  
 2: Motor rotating  
 10: Warning  
 11: Fault  
 31: Communication-forced DO  
 32: EDM output

**Description**

-

**H17.58 VDO13 logic level**

Address: 0x173A

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.59 VDO14 function**

Address: 0x173B

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

10: Warning

11: Fault

31: Communication-forced DO

32: EDM output

**Description**

-

**H17.60 VDO14 logic level**

Address: 0x173C

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.61 VDO15 function**

Address: 0x173D

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

10: Warning

11: Fault

31: Communication-forced DO

32: EDM output

**Description**

-

**H17.62 VDO15 logic level**

Address: 0x173E

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.63 VDO16 function**

Address: 0x173F

Min.: 0

Unit: -

Max.: 32

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- 0: No assignment
- 1: Servo ready
- 2: Motor rotating
- 10: Warning
- 11: Fault
- 31: Communication-forced DO
- 32: EDM output

**Description**

-

**H17.64 VDO16 logic level**

Address: 0x1740

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

## 5.19 H18: Position Comparison Output Parameters

**H18.00 Position comparison output selection**

Address: 0x1800

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Disable

1: Enable (rising edge-triggered)

**Description**

-

**H18.01 Position comparison output feedback source**

Address: 0x1801

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Motor encoder feedback  
 1: Fully closed-loop position feedback

**Description**

-

**H18.02 Position comparison resolution**

Address: 0x1802

Min.: 0

Unit: -

Max.: 7

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

0: 24-bit

1: 23-bit

2: 22-bit

3: 21-bit

4: 20-bit

5: 19-bit

6: 18-bit

7: 17-bit

**Description**

-

**H18.03 Position comparison mode**

Address: 0x1803

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Individual comparison mode

1: Cyclic comparison mode

2: Fixed cyclic comparison mode

**Description**

-

**H18.04 Current position as zero**

Address: 0x1804

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0: Disable

1: Enable (rising edge-triggered)



**Description**

-

**H18.05 Position comparison output width**

Address: 0x1805

Min.: 0.1

Unit: ms

Max.: 204.7

Data Type: UInt16

Default: 0.1

Change: At once

**Value Range:**

0.1 ms to 204.7 ms

**Description**

Defines the effective pulse width of the DO when the comparison point is reached. The value range is 0 to 204.7 (unit: 0.1 ms).

**H18.06 Position comparison output ABZ port polarity**

Address: 0x1806

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: OCZ output logic

0: Positive, output high level upon active logic

1: Negative, output low level upon active logic

bit 1: Z port output logic

0: Positive, output high level upon active logic

1: Negative, output low level upon active logic

bit 2: A/B output logic

0: Positive, output high level upon active logic

1: Negative, output low level upon active logic

**Description**

0: Positive, output high level upon active logic; 1: Negative, output low level upon active logic

bit 0: OCZ output logic

bit 1: Z port output logic

bit 2: A/B output logic

**H18.07 Start point of position comparison**

Address: 0x1807

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 40

**Description**

-

**H18.08 End point of position comparison**

Address: 0x1808

Min.: 0

Unit: -

Max.: 40

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 40

**Description**

-

**H18.09 Current status of position comparison**

Address: 0x1809

Min.: 0

Unit: -

Max.: 1024

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 1024

**Description**

-

**H18.10 Real-time position of position comparison**

Address: 0x180A

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H18.12 Zero offset of position comparison**

Address: 0x180C

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H18.14 Position comparison output delay compensation**

Address: 0x180E

Min.: -12

Unit: us

Max.: 12

Data Type: Int16

Default: 0

Change: At once

**Value Range:**

-12.00 us to +12.00 us

**Description**

Used to compensate for the delay caused by hardware signal output.

**H18.15 Cycles of fixed mode**

Address: 0x180F

Min.: 1

Unit: -

Max.: 65535

Data Type: UInt16

Default: 1

Change: At once

**Value Range:**

1 to 65535

**Description**

-

**H18.16 ABZ output function setting**

Address: 0x1810

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: OCZ output function0: Frequency-division output

1: Position comparison

bit 1: Z port output function

0: Frequency-division output

1: Position comparison

bit 2: A/B port output function

0: Frequency-division output

1: Position comparison

**Description**

0: Frequency-division output; 1: Position comparison

bit 0: OCZ port function setting

bit 1: Z port function setting

bit 2: A/B function setting

### **H18.17 Number of fixed modes completed**

Address: 0x1811

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

#### **Value Range:**

0 to 65535

#### **Description**

-

## **5.20 H19: Target Position Parameters**

### **H19.00 Target value of position comparison 1**

Address: 0x1900

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

#### **Value Range:**

-2147483648 to +2147483647

#### **Description**

-

### **H19.02 Attribute value of position comparison 1**

Address: 0x1902

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

#### **Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Attribute of position comparison point 1

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2 to bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9 to bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**H19.03 Target value of position comparison 2**

Address: 0x1903

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.05 Attribute value of position comparison 2**

Address: 0x1905

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point

bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point

bit 2: N/A

bit 3: N/A

bit 4: N/A

bit 5: N/A

bit 6: N/A

bit 7: DO1 output

bit 8: DO2 output

bit 9: N/A

bit 10: N/A

bit 11: N/A

bit 12: Frequency-division A output

bit 13: Frequency-division B output

bit 14: Frequency-division Z output

bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.06 Target value of position comparison 3**

Address: 0x1906

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.08 Attribute value of position comparison 3**

Address: 0x1908

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point

bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point

bit 2: N/A

bit 3: N/A

bit 4: N/A

bit 5: N/A

bit 6: N/A

bit 7: DO1 output

bit 8: DO2 output

bit 9: N/A

bit 10: N/A

bit 11: N/A

bit 12: Frequency-division A output

bit 13: Frequency-division B output

bit 14: Frequency-division Z output

bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.09 Target value of position comparison 4**

Address: 0x1909

Min.:	-2147483648	Unit:	-
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.11 Attribute value of position comparison 4**

Address: 0x190B

Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.12 Target value of position comparison 5**

Address: 0x190C

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.14 Attribute value of position comparison 5**

Address: 0x190E

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**



- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.15 Target value of position comparison 6**

Address: 0x190F

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.17 Attribute value of position comparison 6**

Address: 0x1911

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.18 Target value of position comparison 7**

Address: 0x1911

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.20 Attribute value of position comparison 7**

Address: 0x1914

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.21 Target value of position comparison 8**

Address: 0x1915

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.23 Attribute value of position comparison 8**

Address: 0x1917

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.24 Target value of position comparison 9**

Address: 0x1918

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.26 Attribute value of position comparison 9**

Address: 0x191A

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.27 Target value of position comparison 10**

Address: 0x191B

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.29 Attribute value of position comparison 10**

Address: 0x191D

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.30 Target value of position comparison 11**

Address: 0x191E

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.32 Attribute value of position comparison 11**

Address: 0x1920

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.33 Target value of position comparison 12**

Address: 0x1921

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.35 Attribute value of position comparison 12**

Address: 0x1923

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.36 Target value of position comparison 13**

Address: 0x1924

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.38 Attribute value of position comparison 13**

Address: 0x1926

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**



- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.39 Target value of position comparison 14**

Address: 0x1927

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.41 Attribute value of position comparison 14**

Address: 0x1929

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.42 Target value of position comparison 15**

Address: 0x192A

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.44 Attribute value of position comparison 15**

Address: 0x192C

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.45 Target value of position comparison 16**

Address: 0x192D

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.47 Attribute value of position comparison 16**

Address: 0x192F

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.48 Target value of position comparison 17**

Address: 0x1930

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.50 Attribute value of position comparison 17**

Address: 0x1932

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.51 Target value of position comparison 18**

Address: 0x1933

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.53 Attribute value of position comparison 18**

Address: 0x1935

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.54 Target value of position comparison 19**

Address: 0x1936

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.56 Attribute value of position comparison 19**

Address: 0x1938

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.57 Target value of position comparison 20**

Address: 0x1939

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.59 Attribute value of position comparison 20**

Address: 0x193B

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.60 Target value of position comparison 21**

Address: 0x193C

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.62 Attribute value of position comparison 21**

Address: 0x193E

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**



- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.63 Target value of position comparison 22**

Address: 0x193F

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.65 Attribute value of position comparison 22**

Address: 0x1941

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.66 Target value of position comparison 23**

Address: 0x1942

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.68 Attribute value of position comparison 23**

Address: 0x1944

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.69 Target value of position comparison 24**

Address: 0x1945

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.71 Attribute value of position comparison 24**

Address: 0x1947

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.72 Target value of position comparison 25**

Address: 0x1948

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.74 Attribute value of position comparison 25**

Address: 0x194A

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.75 Target value of position comparison 26**

Address: 0x194B

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.77 Attribute value of position comparison 26**

Address: 0x194D

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.78 Target value of position comparison 27**

Address: 0x194E

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.80 Attribute value of position comparison 27**

Address: 0x1950

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.81 Target value of position comparison 28**

Address: 0x1951

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.83 Attribute value of position comparison 28**

Address: 0x1953

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.84 Target value of position comparison 29**

Address: 0x1954

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.86 Attribute value of position comparison 29**

Address: 0x1956

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**



- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.87 Target value of position comparison 30**

Address: 0x1957

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.89 Attribute value of position comparison 30**

Address: 0x1959

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.90 Target value of position comparison 31**

Address: 0x195A

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.92 Attribute value of position comparison 31**

Address: 0x195C

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.93 Target value of position comparison 32**

Address: 0x195D

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.95 Attribute value of position comparison 32**

Address: 0x195F

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.96 Target value of position comparison 33**

Address: 0x1960

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.98 Attribute value of position comparison 33**

Address: 0x1962

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.99 Target value of position comparison 34**

Address: 0x1963

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.101 Attribute value of position comparison 34**

Address: 0x1965

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.102 Target value of position comparison 35**

Address: 0x1966

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.104 Attribute value of position comparison 35**

Address: 0x1968

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.105 Target value of position comparison 36**

Address: 0x1969

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.107 Attribute value of position comparison 36**

Address: 0x196B

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.108 Target value of position comparison 37**

Address: 0x196C

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.110 Attribute value of position comparison 37**

Address: 0x196E

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**



- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.111 Target value of position comparison 38**

Address: 0x196F

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.113 Attribute value of position comparison 38**

Address: 0x1971

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.114 Target value of position comparison 39**

Address: 0x1972

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.116 Attribute value of position comparison 39**

Address: 0x1974

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point
- bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point
- bit 2: N/A
- bit 3: N/A
- bit 4: N/A
- bit 5: N/A
- bit 6: N/A
- bit 7: DO1 output
- bit 8: DO2 output
- bit 9: N/A
- bit 10: N/A
- bit 11: N/A
- bit 12: Frequency-division A output
- bit 13: Frequency-division B output
- bit 14: Frequency-division Z output
- bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

**H19.117 Target value of position comparison 40**

Address: 0x1975

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**H19.119 Attribute value of position comparison 40**

Address: 0x1977

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

bit 0: Output DO active signal if current position changes from "less than" to "more than" the comparison point  
bit 1: Output DO active signal if current position changes from "more than" to "less than" the comparison point  
bit 2: N/A  
bit 3: N/A  
bit 4: N/A  
bit 5: N/A  
bit 6: N/A  
bit 7: DO1 output  
bit 8: DO2 output  
bit 9: N/A  
bit 10: N/A  
bit 11: N/A  
bit 12: Frequency-division A output  
bit 13: Frequency-division B output  
bit 14: Frequency-division Z output  
bit 15: Frequency-division OCZ output

**Description**

Same as H19.02

## 5.21 H1F: Software Tool Parameters

### H1F.90 DI function state 1 read through communication

Address:	0x1F5A	Effective:	At once
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

Bit 0 corresponds to DI function 1.

Bit 1 corresponds to DI function 2.

Bit 2 corresponds to DI function 3.

...

By analogy

### H1F.91 DI function state 2 read through communication

Address:	0x1F5B	Effective:	At once
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

Bit 0 corresponds to DI function 17.

Bit 1 corresponds to DI function 18.

Bit 2 corresponds to DI function 19.

...

By analogy

**H1F.92 DI function state 3 read through communication**

Address: 0x1F5C

Effective: At once

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

Bit 0 corresponds to DI function 33.

Bit 1 corresponds to DI function 34.

Bit 2 corresponds to DI function 35.

...

By analogy

**H1F.93 DI function state 4 read through communication**

Address: 0x1F5D

Effective: At once

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

Bit 0 corresponds to DI function 49.

Bit 1 corresponds to DI function 50.

Bit 2 corresponds to DI function 51.

...

By analogy

**H1F.94 DO function state 1 read through communication**

Address: 0x1F5E

Effective: At once

Min.: 0

Unit: -



Max.: 65535	Data Type: UInt16
Default: 0	Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

Bit 0 corresponds to DO function 1.  
 Bit 1 corresponds to DO function 2.  
 Bit 2 corresponds to DO function 3.  
 ...  
 By analogy

**H30.02 DO function state 2 read through communication**

Address: 0x3002

Min.: 0	Unit: -
Max.: 65535	Data Type: UInt16
Default: 0	Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

Bit 0 corresponds to DO function 17.  
 Bit 1 corresponds to DO function 18.  
 Bit 2 corresponds to DO function 19.  
 ...  
 By analogy

**5.23 H31: Communication Setting**

**H31.00 VDI virtual level set through communication**

Address: 0x3100

Min.: 0	Unit: -
Max.: 65535	Data Type: UInt16
Default: 0	Change: At once

**Value Range:**

0 to 65535

**Description**

When H17.90 is set to 1, the VDI state is defined by H31.00.  
 The VDI logic is determined by H17.91 (Default VDI virtual level value upon power-on) upon initial power-on. Thereafter, the VDI logic is determined by H31.00.  
 "bit(n) = 1" of H31.00 indicates the logic of VDI (n+1) is "1". "bit(n)=0" indicates the logic of VDI (n+1) is "0".

**H31.04 DO status set through communication**

Address: 0x3104

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 65535

**Description**

Set H04.22 to define H31.04 as the source of DO state.

**H31.05 AO set through communication**

Address: 0x3105

Min.: -10000

Unit: mV

Max.: 10000

Data Type: Int16

Default: 0

Change: At once

**Value Range:**

-10000 mV to +10000 mV

**Description**

Set H04.50 to 10 to define H31.05 as the source of AO (unit: mV).

**H31.09 Speed reference set through communication**

Address: 0x3109

Min.: -9999.000

Unit: rpm

Max.: 9999.000

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-9999.000 to +9999.000

**Description**

Set H06.02 to 4 to define H31.09 as the source of the speed reference in the speed control mode (unit: rpm).

**H31.11 Torque reference set through communication**

Address: 0x310B

Min.: -100

Unit: %

Max.: 100

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-100.000% to +100.000%

**Description**

Set H07.02 to 4 to define H31.11 as the source of the torque reference in the torque control mode. The setpoint 100.000% corresponds to the rated torque of the motor.



## 5.24 1000h Object Dictionaries

### 1000.00h Device type

Address: 0x5405

Min.: 0

Max.: 65535

Default: 0

Unit: -

Data Type: UInt16

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

### 1001.00h Error register

Address: 0x5406

Min.: 0

Max.: 255

Default: 0

Unit: -

Data Type: UInt16

Change: Unchangeable

**Value Range:**

0 to 255

**Description**

-

### 1018.01h Vendor ID

Address: 0x5401

Min.: 0

Max.: 65535

Default: 0

Unit: -

Data Type: UInt32

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

### 1018.02h Product code

Address: 0x5402

Min.: 0

Max.: 65535

Default: 0

Unit: -

Data Type: UInt32

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**1018.03h Revision number**

Address: 0x5403

Min.: 0

Max.: 65535

Default: 0

Unit: -

Data Type: UInt32

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**1600.00h Number of valid mapped objects in RPDO1**

Address: 0x3900

Min.: 0

Max.: 20

Default: 3

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0 to 20

**Description**

The object can be modified only when the PDO is invalid. When 0 is written, the mapped objects of other sub-indexes are cleared.

**1600.01h 1st mapped object in RPDO1**

Address: 0x3901

Min.: 0

Max.: 2147483647

Default: 1614807040

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

The total length of a mapped object cannot exceed 64 bits. Mapping based on bytes instead of bits is supported. The indexes and sub-indexes of mapped objects must exist in the object dictionary list and are readable and mappable. Sub-indexes are written in the following format:

bit 0 to bit 7: Object length

bit 8 to bit 15: Sub-index

bit 16 to bit 31: Index

**1600.02h 2nd mapped object in RPDO1**

Address: 0x3902

Min.: 0

Max.: 2147483647

Default: 1618608128

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.03h 3rd mapped object in RPDO1**

Address: 0x3903

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 1622671360

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.04h 4th mapped object in RPDO1**

Address: 0x3904

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.05h 5th mapped object in RPDO1**

Address: 0x3905

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.06h 6th mapped object in RPDO1**

Address: 0x3906

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.07h 7th mapped object in RPDO1**

Address: 0x3907

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.08h 8th mapped object in RPDO1**

Address: 0x3908

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.09h 9th mapped object in RPDO1**

Address: 0x3909

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.0Ah 10th mapped object in RPDO1**

Address: 0x390A

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.0Bh 11th mapped object in RPDO1**

Address: 0x390B

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.0Ch 12th mapped object in RPDO1**

Address: 0x390C

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.0Dh 13th mapped object in RPDO1**

Address: 0x390D

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.0Eh 14th mapped object in RPDO1**

Address: 0x390E

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.0Fh 15th mapped object in RPDO1**

Address: 0x390F

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.10h 16th mapped object in RPDO1**

Address: 0x3910

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.11h 17th mapped object in RPDO1**

Address: 0x3911

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.12h 18th mapped object in RPDO1**

Address: 0x3912

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.13h 19th mapped object in RPDO1**

Address: 0x3913

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1600.14h 20th mapped object in RPDO1**

Address: 0x3914

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1600.01h

**1A00.00h Number of valid mapped objects in TPDO1**

Address: 0x4000

Min.: 0

Unit: -

Max.: 20

Data Type: UInt16

Default: 7

Change: At once

**Value Range:**

0 to 20

**Description**

The object can be modified only when the PDO is invalid. When 0 is written, the mapped objects of other sub-indexes are cleared.

**1A00.01h 1st mapped object in TPDO1**

Address: 0x4001

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 1614872576

Change: At once

**Value Range:**

0 to 2147483647

**Description**

The total length of a mapped object cannot exceed 64 bits. Mapping based on bytes instead of bits is supported. The indexes and sub-indexes of mapped objects must exist in the object dictionary list and are readable and mappable.

Sub-indexes are written in the following format:

bit 0 to bit 7: Object length

bit 8 to bit 15: Sub-index

bit 16 to bit 31: Index

**1A00.02h 2nd mapped object in TPDO1**

Address: 0x4002

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 1617166336

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.03h 3rd mapped object in TPDO1**

Address: 0x4003

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 1622736896

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.04h 4th mapped object in TPDO1**

Address: 0x4004

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 1622802432

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.05h 5th mapped object in TPDO1**

Address: 0x4005



Min.: 0  
Max.: 2147483647  
Default: 1622933504

Unit: -  
Data Type: UInt32  
Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.06h 6th mapped object in TPDO1**

Address: 0x4006

Min.: 0  
Max.: 2147483647  
Default: 1614741504

Unit: -  
Data Type: UInt32  
Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.07h 7th mapped object in TPDO1**

Address: 0x4007

Min.: 0  
Max.: 2147483647  
Default: 1627193344

Unit: -  
Data Type: UInt32  
Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.08h 8th mapped object in TPDO1**

Address: 0x4008

Min.: 0  
Max.: 2147483647  
Default: 0

Unit: -  
Data Type: UInt32  
Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.09h 9th mapped object in TPDO1**

Address: 0x4009

Min.: 0  
Max.: 2147483647

Unit: -  
Data Type: UInt32

Default: 0  
**Value Range:**  
 0 to 2147483647  
**Description**  
 Same as 1A00.01h

Change: At once

**1A00.0Ah 10th mapped object in TPDO1**

Address: 0x400A  
 Min.: 0  
 Max.: 2147483647  
 Default: 0  
**Value Range:**  
 0 to 2147483647  
**Description**  
 Same as 1A00.01h

Unit: -  
 Data Type: UInt32  
 Change: At once

**1A00.0Bh 11th mapped object in TPDO1**

Address: 0x400B  
 Min.: 0  
 Max.: 2147483647  
 Default: 0  
**Value Range:**  
 0 to 2147483647  
**Description**  
 Same as 1A00.01h

Unit: -  
 Data Type: UInt32  
 Change: At once

**1A00.0Ch 12th mapped object in TPDO1**

Address: 0x400C  
 Min.: 0  
 Max.: 2147483647  
 Default: 0  
**Value Range:**  
 0 to 2147483647  
**Description**  
 Same as 1A00.01h

Unit: -  
 Data Type: UInt32  
 Change: At once

**1A00.0Dh 13th mapped object in TPDO1**

Address: 0x400D  
 Min.: 0  
 Max.: 2147483647  
 Default: 0

Unit: -  
 Data Type: UInt32  
 Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.0Eh 14th mapped object in TPDO1**

Address: 0x400E

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.0Fh 15th mapped object in TPDO1**

Address: 0x400F

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.10h 16th mapped object in TPDO1**

Address: 0x4010

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.11h 17th mapped object in TPDO1**

Address: 0x4011

Min.: 0

Unit: -

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.12h 18th mapped object in TPDO1**

Address: 0x4012

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.13h 19th mapped object in TPDO1**

Address: 0x4013

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1A00.14h 20th mapped object in TPDO1**

Address: 0x4014

Min.: 0

Max.: 2147483647

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 2147483647

**Description**

Same as 1A00.01h

**1C12.00h Number of assigned PDOs**

Address: 0x5000

Min.: 0

Max.: 2

Default: 1

Unit: -

Data Type: UInt8

Change: At once

**Value Range:**

0 to 2

**Description**

-

**1C12.01h Index of assigned RPDO1**

Address: 0x5001

Min.: 5632

Max.: 5898

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

5632 to 5898

**Description**

-

**1C12.02h Index of assigned RPDO2**

Address: 0x5002

Min.: 5632

Max.: 5898

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

5632 to 5898

**Description**

-

**1C13.00h Number of assigned PDOs**

Address: 0x5100

Min.: 0

Max.: 2

Default: 0

Unit: -

Data Type: UInt8

Change: At once

**Value Range:**

0 to 2

**Description**

-

**1C13.01h Index of assigned TPDO1**

Address: 0x5101

Min.: 6656

Max.: 6922

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

6656 to 6922

**Description**

-

**1C13.02h Index of assigned TPDO2**

Address: 0x5102

Min.: 6656

Unit: -

Max.: 6922

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

6656 to 6922

**Description**

-

**1C32.01h Synchronization type**

Address: 0x5201

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 65535

**Description**

-

**1C32.02h Cycle time**

Address: 0x5202

Min.: 0

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 4294967295

**Description**

-

**1C32.04h Synchronization types supported**

Address: 0x5204

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 65535

**Description**

-

**1C32.05h Minimum cycle time**

Address: 0x5205

Min.: 0

Max.: 4294967295

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 4294967295

**Description**

-

**1C33.01h Synchronization type**

Address: 0x5301

Min.: 0

Max.: 65535

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0 to 65535

**Description**

-

**1C33.02h Cycle time**

Address: 0x5302

Min.: 0

Max.: 4294967295

Default: 0

Unit: -

Data Type: UInt32

Change: At once

**Value Range:**

0 to 4294967295

**Description**

-

**1C33.04h Synchronization types supported**

Address: 0x5304

Min.: 0

Max.: 65535

Default: 0

Unit: -

Data Type: UInt16

Change: At once

**Value Range:**

0 to 65535

**Description**

-

**1C33.05h Minimum cycle time**

Address: 0x5305

Min.: 0

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 4294967295

**Description**

-

**5.25 6000h Object Dictionaries****603Fh Error code**

Address: 0x3500

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

When an error described in the DSP402 profile occurs on the servo drive, 603Fh is as described in DSP402.

When an error specified by the user occurs on the servo drive, 603Fh is 0xFF00.

The value of 603Fh is in hexadecimal.

In addition, the object dictionary 203Fh displays auxiliary bytes of fault codes in hexadecimal.

203Fh is a UInt32 value, in which the high 16 bits indicate the internal fault code of the manufacturer, and the low 16 bits indicate the external fault code of the manufacturer.

**6040h Control word**

Address: 0x3502

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 65535



**Description**

-

**6041h Status word**

Address: 0x3504

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**605Ah Quick stop option code**

Address: 0x3536

Min.: 0

Unit: -

Max.: 7

Data Type: Int16

Default: 2

Change: At stop

**Value Range:**

0: Coast to stop, keeping de-energized state

1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state

2: Ramp to stop as defined by 6085h, keeping de-energized state

3: Stop at emergency stop torque, keeping de-energized state

5: Ramp to stop as defined by 6084h/609Ah (HM), keeping position lock state

6: Ramp to stop as defined by 6085h, keeping position lock state

7: Stop at emergency stop torque, keeping position lock state

**Description**

0: Coast to stop, keeping de-energized state

1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state

2: Ramp to stop as defined by 6085h, keeping de-energized state

3: Stop at emergency stop torque, keeping de-energized state

5: Ramp to stop as defined by 6084h/609Ah (HM), keeping position lock state

6: Ramp to stop as defined by 6085h, keeping position lock state

7: Stop at emergency stop torque, keeping position lock state

**605Ch Disable operation option code**

Address: 0x353A

Min.: -4

Unit: -

Max.: 2

Data Type: Int16

Default: 0

Change: At stop

**Value Range:**

- 4: Ramp to stop as defined by 6085h, keeping dynamic braking state
- 3: Stop at zero speed, keeping dynamic braking state
- 2: Ramp to stop as defined by 6084h/609Ah (HM), keeping dynamic braking state
- 1: Dynamic braking stop, keeping dynamic braking state
- 0: Coast to stop, keeping de-energized state
- 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state
- 2: Dynamic braking stop, keeping de-energized state

**Description**

- 4: Ramp to stop as defined by 6085h, keeping dynamic braking state
- 3: Stop at zero speed, keeping dynamic braking state
- 2: Ramp to stop as defined by 6084h/609Ah (HM), keeping dynamic braking state
- 1: Dynamic braking stop, keeping dynamic braking state
- 0: Coast to stop, keeping de-energized state
- 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized status
- 2: Dynamic braking stop, keeping de-energized state

**605Dh Stop option code**

Address: 0x353C

Min.: 1

Unit: -

Max.: 3

Data Type: Int16

Default: 1

Change: At stop

**Value Range:**

- 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping position lock state
- 2: Ramp to stop as defined by 6085h, keeping position lock state
- 3: Stop at emergency stop torque, keeping position lock state

**Description**

Defines the halt mode.

- 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping position lock state
- 2: Ramp to stop as defined by 6085h, keeping position lock state
- 3: Stop at emergency stop torque, keeping position lock state

**605Eh Fault reaction option code**

Address: 0x353C

Min.: -5

Unit: -

Max.: 4

Data Type: Int16

Default: 2

Change: At stop

**Value Range:**

- 5: Stop at zero speed, keeping dynamic braking state
- 4: Stop at emergency stop torque, keeping dynamic braking state
- 3: Ramp to stop as defined by 6085h, keeping dynamic braking state
- 2: Ramp to stop as defined by 6084h/609Ah (HM), keeping dynamic braking state
- 1: Dynamic braking stop, keeping dynamic braking state
- 0: Coast to stop, keeping de-energized state
- 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state
- 2: Ramp to stop as defined by 6085h, keeping de-energized state
- 3: Stop at emergency stop torque, keeping de-energized state
- 4: Dynamic braking stop, keeping de-energized state

**Description**

- 5: Stop at zero speed, keeping dynamic braking state
- 4: Stop at the emergency stop torque, keeping dynamic braking state
- 3: Ramp to stop as defined by 6085h, keeping dynamic braking state
- 2: Ramp to stop as defined by 6084h/609Ah (HM), keeping dynamic braking state
- 1: Dynamic braking stop, keeping dynamic braking state
- 0: Coast to stop, keeping de-energized state
- 1: Ramp to stop as defined by 6084h/609Ah (HM), keeping de-energized state
- 2: Ramp to stop as defined by 6085h, keeping de-energized state
- 3: Stop at emergency stop torque, keeping de-energized state
- 4: Dynamic braking stop, keeping de-energized state

**6060h Modes of operation**

Address: 0x353E

Min.: 0

Unit: -

Max.: 10

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

- 1: Profile position (PP) mode
- 3: Profile velocity (PV) mode
- 4: Profile torque (PT) mode
- 6: Homing (HM) mode
- 8: Cyclic synchronous position (CSP) mode
- 9: Cyclic synchronous velocity (CSV) mode
- 10: Cyclic synchronous torque (CST) mode

**Description**

Defines the servo drive operation mode.

- 1: Profile position (PP) mode
- 3: Profile velocity (PV) mode
- 4: Profile torque (PT) mode
- 6: Homing (HM) mode
- 8: Cyclic synchronous position (CSP) mode
- 9: Cyclic synchronous velocity (CSV) mode
- 10: Cyclic synchronous torque (CST) mode
- Others: N/A

If an unsupported operation mode is selected through an SDO, an SDO error will be returned.

If an unsupported operation mode is selected through a PDO, the change of the operation mode will be invalid.

### 6061h Modes of operation display

Address: 0x3544

Min.: 0

Unit: -

Max.: 10

Data Type: UInt16

Default: 0

Change: Unchangeable

#### Value Range:

- 1: Profile position (PP) mode
- 3: Profile velocity (PV) mode
- 4: Profile torque (PT) mode
- 6: Homing (HM) mode
- 8: Cyclic synchronous position (CSP) mode
- 9: Cyclic synchronous velocity (CSV) mode
- 10: Cyclic synchronous torque (CST) mode

#### Description

Indicates the actual operation mode.

- 1: Profile position (PP) mode
- 3: Profile velocity (PV) mode
- 4: Profile torque (PT) mode
- 6: Homing (HM) mode
- 8: Cyclic synchronous position (CSP) mode
- 9: Cyclic synchronous velocity (CSV) mode
- 10: Cyclic synchronous torque (CST) mode

### 6062h Position demand value

Address: 0x3546

Min.: -2147483648

Unit: Reference unit

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

#### Value Range:

-2147483648 to +2147483647

**Description**

Indicates the real-time position reference (reference unit).

**6063h Position actual value\***

Address: 0x3548

Min.: -2147483648

Unit: Pulse

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Indicates the absolute position feedback (encoder unit) of the motor in real time.

**6064h Position actual value**

Address: 0x354A

Min.: -2147483648

Unit: Reference unit

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Indicates the absolute position feedback (reference unit) in real time.

Position actual value in user-defined unit (6064h) x Gear ratio (6091h) = Position actual value in encoder unit (6063h)

**6065h Following error window**

Address: 0x354C

Min.: 0

Unit: Reference unit

Max.: 4294967295

Data Type: UInt32

Default: 219895608

Change: At once

**Value Range:**

0 to 4294967295

**Description**

Defines the threshold of excessive position deviation (reference unit).

When the difference value between position demand value (6062h) and position actual value (6064h) keeps exceeding  $\pm 6065h$  after the time defined by 6066h elapses, EB00.0 (Position deviation too large) occurs.

**6066h Following error time out**

Address: 0x354E

Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the time lapse to trigger excessive position deviation (EB00.0), which must be used together with 6065h.

**6067h Position window**

Address: 0x3550

Min.:	0	Unit:	Reference unit
Max.:	4294967295	Data Type:	UInt32
Default:	46976	Change:	At once

**Value Range:**

0 to 4294967295

**Description**

Defines the threshold for position reach.

If the difference value between 6062h and 6064h is within  $\pm 6067h$  and the time reaches 6068h, the position is reached. In this case, bit10 of 6041h is set to 1 in the profile position mode.

This flag bit is meaningful only when the S-ON signal is active in the profile position mode.

**6068h Position window time**

Address: 0x3552

Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	At once

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the window time for position reach, which must be used together with 6067h.

**606Ch Velocity actual value**

Address: 0x355A

Min.:	-2147483648	Unit:	Reference unit/s
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Indicates the actual speed feedback in user-defined unit.

**606Dh Velocity window**

Address: 0x355C

Min.: 0

Unit: rpm

Max.: 65535

Data Type: UInt16

Default: 10

Change: At once

**Value Range:**

0 rpm to 65535 rpm

**Description**

Defines the threshold for speed reach.

If the difference value between 60FFh and 606Ch is within  $\pm 606Dh$  and the time reaches 606Eh, the speed is reached and bit10 of 6041h is set to 1 in the profile velocity mode.

This flag bit is meaningful only when the S-ON signal is active in the PV mode.

**606Eh Velocity window time**

Address: 0x355E

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the time window for speed reach, which must be used together with 606Dh.

**606Fh Velocity threshold**

Address: 0x3560

Min.: 0

Unit: rpm

Max.: 65535

Data Type: UInt16

Default: 10

Change: At once

**Value Range:**

0 rpm to 65535 rpm

**Description**

Defines the threshold for determining whether the user velocity is 0.

When 606Ch is within  $\pm 606Fh$  and the time reaches the value set by 6070h, the user velocity is 0. When either condition is not met, the user velocity is not 0.

This flag bit is meaningful only in the profile velocity mode is not related to the S-ON state.

#### 6070h Velocity threshold time

Address: 0x3562

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 0

Change: At once

##### **Value Range:**

0 ms to 65535 ms

##### **Description**

Defines the time window for determining whether the user velocity is 0, which must be used together with 606Fh.

#### 6071h Target torque

Address: 0x3564

Min.: -4000

Unit: 0.001

Max.: 4000

Data Type: Int16

Default: 0

Change: At once

##### **Value Range:**

-4000 to +4000

##### **Description**

Defines the target torque in the profile torque mode.

The value 1000 corresponds to the rated torque of the motor.

#### 6072h Max. torque value

Address: 0x3566

Min.: 0

Unit: 0.001

Max.: 4000

Data Type: UInt16

Default: 3500

Change: At once

##### **Value Range:**

0 to 4000

##### **Description**

Defines the maximum torque reference limit.

The value 1000 corresponds to the rated torque of the motor.

#### 6074h Torque demand value

Address: 0x356A

Min.: -4000

Unit: 0.001

Max.: 4000

Data Type: Int16



Default: 0 Change: Unchangeable

**Value Range:**

-4000 to +4000

**Description**

Defines the target torque value.

The value 1000 corresponds to the rated torque of the motor.

**6077h Torque actual value**

Address: 0x3570

Min.: -4000

Unit: 0.001

Max.: 4000

Data Type: Int16

Default: 0

Change: Unchangeable

**Value Range:**

-4000 to +4000

**Description**

Indicates the internal torque feedback of the servo drive.

The value 1000 corresponds to the rated torque of the motor.

**607Ah Target position**

Address: 0x3576

Min.: -2147483648

Unit: Reference unit

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

Defines the target position of the servo drive in the profile position mode.

Table 5-1 Description of bit 6 of 6040h

Value of Bit 6	Description	Remarks
0	607Ah indicates the absolute target position of current segment.	After positioning of current segment is done, the value of 6064h will be the same as the value of 607Ah.
1	607Ah indicates the target increment displacement of current segment.	After positioning of current segment is done, user displacement increment will be the same as the value of 607Ah.

**607Ch Home offset**

Address: 0x357A

Min.: -2147483648

Unit: Reference unit

Max.: 2147483647                      Data Type: Int32  
 Default: 0                              Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

Defines the physical location of mechanical zero that deviates from the home of the motor in position control modes (profile position mode, interpolation mode, and homing mode).

The home offset is active under the following conditions: The device is powered on, the homing operation is complete, and bit 15 of 6041h is set to 1.

After homing is done, the position actual value (6064h) will be the same as the value of 607Ch.

If 607Ch is outside the value of 607Dh (Software position limit), EE09.1 occurs (Home setting error).

**607D.01h Min. position limit**

Address: 0x3700

Min.: -2147483648                      Unit: Reference unit  
 Max.: 2147483647                      Data Type: Int32  
 Default: -2147483648                  Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

Defines the minimum software position limit relative to the mechanical zero point.

Minimum software position limit = (607D.01h)

The software position limit is used to judge the absolute position. When homing is not performed, the internal software position limit is invalid.

The condition for activating the software position limit is set in H0A.01 (object dictionary 0x200A.02h).

**607D.02h Max. position limit**

Address: 0x3800

Min.: -2147483648                      Unit: Reference unit  
 Max.: 2147483647                      Data Type: Int32  
 Default: 2147483647                    Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

Defines the maximum software position limit relative to the mechanical zero.

Maximum software position limit = (607D.02h)

**607Eh Polarity**

Address: 0x357E

Min.: 0

Unit: -

Max.: 255

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 255

**Description**

Defines the polarity of position or speed references.

When bit 7 is 1, it indicates the position reference is multiplied by "-1" and the motor direction is reversed in the standard position mode or interpolation mode.

When bit 6 is 1, it indicates the speed reference (60FFh) is multiplied by "-1" and the motor direction is reversed in the velocity mode.

When bit 5 is 1, it indicates the torque demand value (6071h) is multiplied by "-1" and the motor direction is reversed in the torque mode.

Other bits are meaningless.

**607Fh Max. profile velocity**

Address: 0x3580

Min.: 0

Unit: Reference unit/s

Max.: 4294967295

Data Type: UInt32

Default: 4294967295

Change: At once

**Value Range:**

0 to 4294967295

**Description**

Defines the maximum operating speed in user-defined unit.

Set a proper gear ratio (8/1 recommended) when using a 26-bit encoder.

Otherwise, the motor speed will be limited to 3840 rpm.

**6081h Profile velocity**

Address: 0x3584

Min.: 0

Unit: Reference unit/s

Max.: 4294967295

Data Type: UInt32

Default: 111848106

Change: At once

**Value Range:**

0 to 4294967295

**Description**

Defines the constant running speed of the displacement reference in the profile position mode.

The setpoint takes effect after the slave receives the displacement reference.

**6083h Profile acceleration**

Address: 0x3588

Min.: 0

Max.: 4294967295

Default: 4294967295

Unit: Reference unit/s<sup>2</sup>

Data Type: UInt32

Change: At once

**Value Range:**

0 to 4294967295

**Description**

Defines the acceleration of the displacement reference in the profile position mode.

The following formula applies if a motor equipped with 23-bit encoder needs to run at 400 rpm (6081h:  $400 \times 8388608/60$ ) with acceleration rate being 400 rpm/s (6083h:  $400 \times 8388608/60$ ) and deceleration rate being 200 rpm/s (6084h:  $200 \times 8388608/60$ ) under a gear ratio of 1:1:

Acceleration time  $t_{up} = \Delta 6081h / \Delta 6083h = 1$  (s); Deceleration time  $t_{down} = \Delta 6081h / \Delta 6084h = 2$  (s)

The setpoint 0 will be forcibly changed to 1.

**6084h Profile deceleration**

Address: 0x358A

Min.: 0

Max.: 4294967295

Default: 4294967295

Unit: Reference unit/s<sup>2</sup>

Data Type: UInt32

Change: At once

**Value Range:**

0 to 4294967295

**Description**

Defines the deceleration rate in the deceleration stage of the displacement reference in the profile position mode.

The following formula applies if a motor equipped with 23-bit encoder needs to run at 400 rpm (6081h:  $400 \times 8388608/60$ ) with acceleration rate being 400 rpm/s (6083h:  $400 \times 8388608/60$ ) and deceleration rate being 200 rpm/s (6084h:  $200 \times 8388608/60$ ) under a gear ratio of 1:1:

Acceleration time  $t_{up} = \Delta 6081h / \Delta 6083h = 1$  (s); Deceleration time  $t_{down} = \Delta 6081h / \Delta 6084h = 2$  (s)

The setpoint 0 will be forcibly changed to 1.

**6085h Quick stop deceleration**

Address:

Min.: 0

Max.: 4294967295

Default: 2147483648

Unit: Reference unit/s<sup>2</sup>

Data Type: UInt32

Change: At once

**Value Range:**

0 to 4294967295

**Description**

Defines the deceleration rate when the quick stop command (6040h = 0x0002) is active and 605Ah (Quick stop option code) is set to 2 or 5.

The setpoint 0 will be forcibly changed to 1.

**6087h Torque slope**

Address: 0x3590

Min.: 0

Unit: 0.1%/s

Max.: 4294967295

Data Type: UInt32

Default: 4294967295

Change: At once

**Value Range:**

0 to 4294967295

**Description**

Defines the acceleration rate (torque increment per second) of the torque reference in profile torque mode, indicating the torque reference increment per second.

In the profile torque mode, if 605Ah is set to 1, 2, 5, or 6, or 605Dh is set to 1 or 2, the servo drive decelerates to stop as defined by 6087h.

If the setpoint exceeds the torque reference limit, the limit value will be used.

The setpoint 0 will be forcibly changed to 1.

**6091.01h Motor revolutions**

Address: 0x3714

Min.: 1

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 1

Change: At stop

**Value Range:**

1 to 4294967295

**Description**

Defines the numerator of the gear ratio.

The gear ratio is used to establish the proportional relationship between the load shaft displacement designated by the user and the motor shaft displacement.

The relationship between motor position feedback (encoder unit) and load shaft position feedback (reference unit) is as follows.

Motor position feedback = Load shaft position feedback x Gear ratio

The relationship between the motor speed (rpm) and the load shaft speed (reference unit/s) is as follows.

Motor speed (rpm) = Load shaft speed x 6091h x 60/Encoder resolution

The relationship between the motor acceleration (rpm/ms) and the load shaft acceleration (reference unit/s<sup>2</sup>) is as follows.

Motor acceleration (rpm/ms) = Load shaft acceleration x 6091h x 1000/Encoder resolution/60

### 6091.02h Shaft revolutions

Address: 0x3814

Min.: 1

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 1

Change: At stop

#### Value Range:

1 to 4294967295

#### Description

Defines the denominator of the gear ratio.

### 6098h Homing method

Address: 0x35B2

Min.: -2

Unit: -

Max.: 35

Data Type: Int16

Default: 1

Change: At once

#### Value Range:

-2 to +35

#### Description

Table 5–2 Defines the homing method.

Setpoint	Description
-2	Forward, positive mechanical limit as deceleration point and Z signal as home
-1	Reverse, negative mechanical limit as deceleration point and Z signal as home
1	Reverse, negative limit switch as deceleration point and Z signal as home, falling edge of the negative limit switch signal must be reached before Z signal
2	Forward, positive limit switch as deceleration point and Z signal as home, falling edge of positive limit switch signal must be reached before Z signal
3	Forward, home switch as deceleration point and Z signal as home, falling edge on the same side of the home switch signal must be reached before Z signal
4	Forward, home switch as deceleration point and Z signal as home, rising edge on the same side of the home switch signal must be reached before Z signal
5	Reverse, home switch as deceleration point and Z signal as home, falling edge on the same side of the home switch signal must be reached before Z signal
6	Reverse, home switch as deceleration point and Z signal as home, rising edge on the same side of the home switch signal must be reached before Z signal

Setpoint	Description
7	Forward, home switch as deceleration point and Z signal as home, falling edge on the same side of the home switch signal must be reached before Z signal
8	Forward, home switch as deceleration point and Z signal as home, rising edge on the same side of the home switch signal must be reached before Z signal
9	Forward, home switch as deceleration point and Z signal as home, rising edge on the other side of the home switch signal must be reached before Z signal
10	Forward, home switch as deceleration point and Z signal as home, falling edge on the other side of the home switch signal must be reached before Z signal
11	Reverse, home switch as deceleration point and Z signal as home, falling edge on the same side of the home switch signal must be reached before Z signal
12	Reverse, home switch as deceleration point and Z signal as home, rising edge on the same side of the home switch signal must be reached before Z signal
13	Reverse, home switch as deceleration point and Z signal on the other side of the home switch signal as home, rising edge on the other side of the home switch signal must be reached before Z signal
14	Reverse, home switch as deceleration point and Z signal on the other side of the home switch signal as home, falling edge on the other side of the home switch signal must be reached before Z signal
15 to 16	The servo drive does not perform the homing operation.
17 to 30	Similar to setpoints 1...14 except that the deceleration point coincide with the home
31 to 32	The servo drive does not perform the homing operation.
33	Reverse, Z signal as home
34	Forward, Z signal as home
35	Current position as home

### 6099.01h Speed during search for switch

Address: 0x371C

Min.: 0

Unit: Reference unit/s

Max.: 4294967295

Data Type: UInt32

Default: 111848106

Change: At stop

#### Value Range:

0 to 4294967295

#### Description

Defines the speed during search for the deceleration point signal. A large setpoint helps prevent E601.0 (Homing timeout).

### 6099.02h Speed during search for zero

Address: 0x381C

Min.: 0

Unit: Reference unit/s

Max.: 4294967295                      Data Type: UInt32  
 Default: 11184810                    Change:     At stop

**Value Range:**

0 to 4294967295

**Description**

Defines the speed in searching for the home signal. Setting this speed to a low value prevents overshoot during stop at high speed, avoiding excessive deviation between the stop position and the set mechanical home.

**609Ah Homing acceleration**

Address: 0x35B6

Min.: 0                                      Unit:            Reference unit/s<sup>2</sup>

Max.: 4294967295                      Data Type: UInt32

Default: 4294967295                    Change:     At once

**Value Range:**

0 to 4294967295

**Description**

Defines the acceleration rate in the homing mode.

**60B0h Position offset**

Address: 0x35E2

Min.: -2147483648                      Unit:            Reference unit

Max.: 2147483647                      Data Type: Int32

Default: 0                                Change:     At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**60B1h Velocity offset**

Address: 0x35E4

Min.: -2147483648                      Unit:            Reference unit/s

Max.: 2147483647                      Data Type: Int32

Default: 0                                Change:     At once

**Value Range:**

-2147483648 to +2147483647

**Description**

-

**60B2h Torque offset**

Address: 0x35E6





bit	Name	Description
8	Touch probe 2 function selection 0: Disable touch probe 2 1: Enable touch probe 2	bit 8 to bit 13: settings related to touch probe 2
9	Touch probe 2 trigger mode 0: Single trigger mode (Latches the position at the first trigger event.) 1: Continuous trigger mode	
10	Touch probe 2 trigger signal selection 0: DI signal 1: Z signal	
11	N/A	
12	Touch probe 2 positive edge 0: Switch off latching at positive edge 1: Enable latching at positive edge	
13	Touch probe 2 negative edge 0: Switch off latching at negative edge 1: Enable latching at negative edge	
14 to 15	N/A	-

**60B9h Touch probe status**

Address: 0x35F4

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

Defines the functions of touch probe 1 and touch probe 2.

See the following table for descriptions of each bit of 60B9h.

bit	Name	Description
0	Touch probe 1 function selection 0: Disable touch probe 1 1: Enable touch probe 1	bit 0 to bit 2: status of touch probe 1
1	Touch probe 1 positive edge value 0: No positive edge value latched 1: Positive edge value latched	
2	Touch probe 1 negative edge value 0: No negative edge value latched 1: Negative edge value latched	
3 to 5	N/A	-

bit	Name	Description
6 to 7	Number of touch probe trigger events when touch probe 1 is assigned with the function of continuous sampling	Indicates the number of touch probe trigger events (0 to 3) when touch probe 1 is assigned with the function of continuous sampling.
8	Touch probe 2 function selection 0: Disable touch probe 2 1: Enable touch probe 2	bit 8 to bit 10: status of touch probe 2
9	Touch probe 2 positive edge value 0: No positive edge value latched 1: Positive edge value latched	
10	Touch probe 2 negative edge value 0: No negative edge value latched 1: Negative edge value latched	
11 to 13	N/A	-
14 to 15	Number of touch probe trigger events when touch probe 2 is assigned with the function of continuous sampling	Indicates the number of touch probe trigger events (0 to 3) when touch probe 2 is assigned with the function of continuous sampling.

**60BAh Touch probe 1 positive edge**

Address: 0x35F4

Min.: -2147483648

Unit: Reference unit

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Indicates the position feedback value (reference unit) latched at positive edge of touch probe 1 signal.

**60BBh Touch probe 1 negative edge**

Address: 0x35F8

Min.: -2147483648

Unit: Reference unit

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Indicates the position feedback value (reference unit) latched at negative edge of touch probe 1 signal.

**60BCh Touch probe 2 positive edge**

Address: 0x35FA

Min.: -2147483648

Max.: 2147483647

Default: 0

Unit: Reference unit

Data Type: Int32

Change: Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Indicates the position feedback value (reference unit) latched at positive edge of touch probe 2 signal.

**60BDh Touch probe 2 negative edge**

Address:

Min.: -2147483648

Max.: 2147483647

Default: 0

Unit: Reference unit

Data Type: Int32

Change: Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Indicates the position feedback value (reference unit) latched at negative edge of touch probe 2 signal.

**60C5h Max. acceleration**

Address: 0x360C

Min.: 0

Max.: 4294967295

Default: 4294967295

Unit: Reference unit/s<sup>2</sup>

Data Type: UInt32

Change: At once

**Value Range:**

0 to 4294967295

**Description**

Defines the maximum permissible deceleration in the profile position mode, profile velocity mode, and homing mode.

The setpoint 0 will be forcibly changed to 1.

**60C6h Max. deceleration**

Address: 0x360E

Min.: 0

Max.: 4294967295

Default: 4294967295

Unit: Reference unit/s<sup>2</sup>

Data Type: UInt32

Change: At once

**Value Range:**

0 to 4294967295

**Description**

Defines the maximum allowable deceleration in the profile position mode, profile velocity mode, and homing mode.

The setpoint 0 will be forcibly changed to 1.

**60D5h Touch probe 1 positive edge counter**

Address: 0x362C

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

The counting value is added by "1" each time this object is triggered.

**60D6h Touch probe 1 negative edge counter**

Address: 0x362E

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

The counting value is added by "1" each time this object is triggered.

**60D7h Touch probe 2 positive edge counter**

Address: 0x3630

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

The counting value is added by "1" each time this object is triggered.

**60D8h Touch probe 2 negative edge counter**

Address: 0x3632

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

The counting value is added by "1" each time this object is triggered.

**60E0h Positive torque limit value**

Address: 0x3642

Min.: 0

Unit: 0.001

Max.: 4000

Data Type: UInt16

Default: 3500

Change: At once

**Value Range:**

0 to 4000

**Description**

Defines the maximum torque limit of the servo drive in the forward direction.

**60E1h Negative torque limit value**

Address: 0x3644

Min.: 0

Unit: 0.001

Max.: 4000

Data Type: UInt16

Default: 3500

Change: At once

**Value Range:**

0 to 4000

**Description**

Defines the maximum torque limit of the servo drive in the reverse direction.

**60E6h Actual position calculation method**

Address: 0x364E

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At once

**Value Range:**

0 to 1

**Description**

Defines the method for calculating the mechanical position after homing is done.

0: Absolute homing

After homing is done, the value of position feedback (6064h) will be the same as the value of home offset (607Ch).

1: Relative homing

After homing is done, the value of position feedback (6064h) will be the sum of current position feedback plus the position offset (607Ch).

**60F4h Following error actual value**

Address: 0x366A

Min.: -2147483648

Max.: 2147483647

Default: 0

Unit: Reference unit

Data Type: Int32

Change: Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Indicates the position deviation (reference unit).

**60FCh Position demand value\***

Address:

Min.: -2147483648

Max.: 2147483647

Default: 0

Unit: pulse

Data Type: Int32

Change: Unchangeable

**Value Range:**

-2147483648 to +2147483647

**Description**

Indicates the position reference (encoder unit).

If no warning is detected when the S-ON signal is active, the relationship between the position reference in reference unit and that in encoder unit is as follows:

 $60FCh \text{ (in encoder unit)} = 6062h \text{ (in reference unit)} \times 6091h$ **60FDh Digital inputs**

Address: 0x367C

Min.: 0

Max.: 4294967295

Default: 0

Unit: -

Data Type: UInt32

Change: Unchangeable

**Value Range:**

0 to 4294967295

**Description**

Indicates current DI logic of the drive.

0: Inactive

1: Active

Table 5-3 The DI signal indicated by each bit is described as follows:

bit	Description
0	Reverse overtravel active
1	Forward overtravel active
2	Home signal active
3 to 15	N/A
16	DI1 input active
17	DI2 input active
18	DI3 input active
19	DI4 input active
20	DI5 input active
21 to 26	N/A
27	STO1 signal input
28	STO2 signal input
29	EDM output active
30	Z signal active
31	N/A

**60FFh Target velocity**

Address:

Min.: -2147483648

Unit: Reference unit/s

Max.: 2147483647

Data Type: Int32

Default: 0

Change: At once

**Value Range:**

-2147483648 to +2147483647

**Description**

Defines the target velocity in the cyclic synchronous velocity mode and profile velocity mode.

**60FE.01h Physical outputs**

Address: 0x3781

Min.: 0

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 4294967295

**Description**



Indicates the DO logic.

The signal indicated by each bit is described as follows:

bit	Description
0 to 15	N/A
16	Forced DO1 output (0: OFF; 1: ON) when bit 16 of 60FE.02 = 1
17	Forced DO2 output (0: OFF; 1: ON) when bit 17 of 60FE.02 = 1
18 to 25	N/A
26	Switched between P and PI for gain switchover when bit 26 of 60FE.02 = 1
27 to 31	N/A

**60FE.02h Bitmask**

Address:

Min.: 0

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 0

Change: At once

**Value Range:**

0 to 4294967295

**Description**

0 to 15: N/A

16: Forced DO1 output enable

17: Forced DO2 output enable

18 to 25: N/A

26: P/PI switchover enable

27 to 31: N/A

## 6 Application Cases

### 6.1 AM600 Series Controller as the Host Controller

This section describes how to configure the SV680N series servo drive for working with AM600 series controller.






Figure 6-1 Configuration flowchart

#### Opening the software and creating an AM600 project


Select **AM600-CPU1608TP**, as shown in the following interface.






### Adding the SV680N servo drive as slave



Open the network configuration and import the ECT file of SV680N (This step can be skipped in later versions). Add an SV680N servo drive as a slave, as shown in the following interface.






## Configuring PDO

Select **Enable Expert Settings** and configure PDOs in the process data as needed. In this case, CSP is used as the operation mode and the default values of 1600 and 1A00 are used for PDO parameters.




## Configuring axis parameters


1. Set the software position limit and the operation mode in basic axis settings.



2. Select **16#4000000** for the 26-bit encoder, **16#800000** for the 23-bit encoder, and **16#100000** for the 20-bit encoder during unit conversion. In this case, the single-turn travel distance is set to 60 mm and 1 mm/s equals to 1 rpm of the motor.




3. Select the homing mode according to actual needs. For details, see section "Homing mode" in SV680N Series Servo Drive Function Guide for details.




## Adding a program

Add a program to control the servo axis position, as shown by the following interface.



- Implement basic functions such as enabling, homing and positioning through adding function blocks.





- To implement directed motion through the logic program, some variables may need to be called to different POUs. Therefore, define these variables as global variables.

**CASE iStatus OP**

```


10:|
gb_powerOn:=TRUE;
IF gb_powerok THEN
iStatus:=20;
END_IF
20:
gd_MoveAbsPos:=1000;gd_MoveAbsVel:=200;gd_MoveAbsVelacc:=200;gd_MoveAbsVeldec:=200;gb_moveAbs:=TRUE;
IF gb_moveAbsOK THEN
gb_moveAbs:=FALSE;iStatus:=30;
END_IF
30:
gd_MoveAbsPos:=2000;gd_MoveAbsVel:=400;gd_MoveAbsVelacc:=400;gd_MoveAbsVeldec:=400;gb_moveAbs:=TRUE;
IF gb_moveAbsOK THEN
gb_moveAbs:=FALSE;iStatus:=40;
END_IF
40:
gd_MoveAbsPos:=0;gd_MoveAbsVel:=1000;gd_MoveAbsVelacc:=1000;gd_MoveAbsVeldec:=1000;gb_moveAbs:=TRUE;
IF gb_moveAbsOK THEN
gb_moveAbs:=FALSE;iStatus:=50;
END_IF
50:
gb_powerOn:=FALSE;
iStatus:=0;
END_CASE
    
```

**END\_CASE**




## Compiling

After compiling the program, click the icon indicated by the red square box to check whether the program is correct.




## Downloading and commissioning

1. After checking that the program is correct, download the program to PLC. The program can be activated after running. Before downloading, scan the PLCs first to select the PLC to be downloaded, and then click the download icon, as shown in the following interface.



2. After log-in, ensure the servo drive and the axis are in normal state.





3. Monitor critical parameters through the monitoring function. Start the testing program to perform basic tests such as enabling, homing and positioning.

Expression	Type	Value	Prepared value	Address	Comment
# MC_Power_0	MC_Power				
# MC_Power_1	MC_Power				

Expression	Application	Type	Value	Prepared value	Execution point
Axis.FactPosition	Device.Application	REAL	881.408793926239		Cyclic Monitoring
Axis.nAxisState	Device.Application	SMC_AXIS_STATE	continuous_motion		Cyclic Monitoring
Axis.FactVelocity	Device.Application	REAL	99.334723949432373		Cyclic Monitoring

4. After the test is done, perform directed motion program.

```

1 CASE iStatus[20] OF
2   10:
3     gb_powerOn TRUE :=TRUE;
4     IF gb_powerOk TRUE THEN
5       iStatus[20] :=20;
6     END_IF
7     20:
8     gd_MoveAbsPos[1E+03] :=1000;gd_MoveAbsVel[200] :=200;gd_MoveAbsVelacc[200] :=200;gd_MoveAbsVeldec[200] :=200;
9     IF gb_moveAbsOk FALSE THEN
10      gb_moveAbs TRUE :=FALSE;iStatus[20] :=30;
11    END_IF
12    30:
13    gd_MoveAbsPos[1E+03] :=2000;gd_MoveAbsVel[200] :=400;gd_MoveAbsVelacc[200] :=400;gd_MoveAbsVeldec[200] :=400;
14    IF gb_moveAbsOk FALSE THEN
15      gb_moveAbs TRUE :=FALSE;iStatus[20] :=40;
16    END_IF
17    40:
18    gd_MoveAbsPos[1E+03] :=0;gd_MoveAbsVel[200] :=1000;gd_MoveAbsVelacc[200] :=1000;gd_MoveAbsVeldec[200] :=1000;
19    IF gb_moveAbsOk FALSE THEN
20      gb_moveAbs TRUE :=FALSE;iStatus[20] :=50;
21    END_IF
22    50:
23    gb_powerOn TRUE :=FALSE;
24    iStatus[20] :=0;
25  END_CASERETURN

```

## 6.2 Omron NX1P2 Controller as the Host Controller

This section describes how to configure the SV680N series servo drive for working with an Omron NX1P2 controller.




Figure 6-2 Configuration flowchart

## Installing the Sysmac Studio software

It is recommended to install the Sysmac Studio software of V1.10 or later.

## Importing the xml device description file


Import the device description file (V2.5 or later recommended).

Use the device description file of "SV680\_1Axis\_V0.04-0506.xml" or later version. The file path is as follows: OMRON\Sysmac Studio\IODeviceProfiles\EsiFiles\UserEsiFiles.

If the xml file is saved under this path for the first time, the Sysmac Studio software must be restarted.

## Setting the network connection property

- If the PC is connected to the controller through an USB, skip this step.
- If the PC is connected to the controller through Ethernet, set the TCP/IP property of the PC, as shown below.



### Configuring the servo drive

Recommended version for pilot run:

Use MCU software version of 0900.0 (H01.00 = 0900.1) or later for SV680N series servo drives.

Use FPGA software version of 0902.1 (H01.01 = 0902.1) or later for SV680N series servo drives.

Pay attention to the setting of H0E.21.


Param. No.	Name	Value Range	Unit	Initial Value	Related Mode	Change	Effective	Value
H0E.21	EtherCAT slave alias	0 to 65535	-	0	-	At stop	At once	Non-zero

When an Omron controller is used, set the EtherCAT communication station number in H0E.21. It is recommended to set the station number according to the actual connection sequence for the convenience of configuration management.

### Creating a project

Device: Select the device according to the actual controller model.


Version: Use V1.09 or later versions. NX1P2-1140DT supports V1.13 only.



### Communication setting

After entering the main interface, set the connection mode between the PC and the controller in **Controller > Connection type**.


- Select **Remote connection via USB** to perform **USB Communication Test** directly. If the test is succeeded, proceed to the next step.
- Select **Ethernet connection via a hub**, in this case, set the IP address to 192.168.250.1 (controlled by NX), and then perform **Ethernet Communication Test**. If the test is succeeded, proceed to the next step.



## Scanning the device

Switch the controller status to **ONLINE** and **RUN** mode.



1. Observe the controller status in the lower right corner, which is **ONLINE** and **RUN** mode.




2. A prompt window appears if it is a new controller.
3. Click **Yes** in the window. The name shown in the window is the project name.

Scan the devices and add slaves.

Right click **Configurations and Setup**→**EtherCAT**→**Master**, and select **Compare and Merge with Actual Network Configuration**. The controller scans all the slaves in the network (an error will be reported if the station number is 0). After scanning, click **Apply actual network configuration** in the window displayed to add the slave. You can view the slaves added in the main page.






## Parameter setting

Switch the controller to the offline mode and set PDO mapping, axis parameters, and distributed clock.


### Setting PDO mapping

1. Set the PDO mapping.



2. Select the editable RPDO and TPDO provided by SV680N for configuration.






3. Modify the PDO mapping object through **Add PDO Entry** and **Delete PDO Entry**. The commonly used mapping parameters are shown in the following interface.

Index	Size	Data type	PDO entry name
0x603F:00	16 [bit]	UINT	Error code
0x6041:00	16 [bit]	UINT	Statusword
0x6064:00	32 [bit]	DINT	Position actual value
0x6077:00	16 [bit]	INT	Torque actual value
0x60F4:00	32 [bit]	DINT	Following error actual value
0x60B9:00	16 [bit]	UINT	Touch Probe Status
0x60BA:00	32 [bit]	DINT	Touch Probe pos 1 pos value
0x60BC:00	32 [bit]	DINT	Touch Probe pos 2 pos value
0x60FD:00	32 [bit]	UDINT	Digital inputs


### Setting axis parameters

1. Right click **Motion Control Setup** > **Axis settings** > **Add** > **Motion Control Axis**, as shown in the following interface.



2. You can rename MC\_Axis000 through a simple click. For example, if it is named as "Rewind axis", the axis variable "Rewind axis" used in the NX program represents control on this SV680N servo axis.
3. Double-click **MC\_Axis000** and configure the SV680N device of the corresponding station in the corresponding basic axis setting interface.

a. Axis assignment



- **Axis number:** Represents the Ethernet communication station No. of the servo drive, which is also the value of H0E.21.
  - **Axis use:** Represents the axis in use.
  - **Axis type:** Represents the servo axis.
  - **Output device 1:** Select the SV680N servo drive.
- b. Detailed settings
- Select the PDO mapping objects according to step 8, which is to assign the output parameters (controller to device) and input parameters (device to controller). Note that the object name, node number, and index number must

be set correctly. Each mapping object selected in step 8 must be assigned correctly. Otherwise, an error will be reported.

Function Name	Device	Process Data
- Output (Controller to Device)		
★ 1. Controlword	Node : 1 InoSV660N(E001)	6040h-00.0(259th rece
★ 3. Target position	Node : 1 InoSV660N(E001)	607Ah-00.0(259th rece
5. Target velocity	<Not assigned>	<Not assigned>
7. Target torque	<Not assigned>	<Not assigned>
9. Max profile Velocity	<Not assigned>	<Not assigned>
11. Modes of operation	Node : 1 InoSV660N(E001)	6060h-00.0(259th rece
15. Positive torque limit value	<Not assigned>	<Not assigned>
16. Negative torque limit value	<Not assigned>	<Not assigned>
21. Touch probe function	Node : 1 InoSV660N(E001)	6088h-00.0(259th rece
44. Software Switch of Encoder's Input	<Not assigned>	<Not assigned>
+ Input (Device to Controller)		
+ Digital inputs		

⚠ The combinations of MC Function Module functions and process data are changed. When changing the combinations, please confirm that they behave as intended. Invalid combinations may cause unexpected operations of the equipment and machines.

- 60FDh must be mapped by bits in accordance with that in the Omron controller, as shown in the following interface. Bit 0 to bit 2 of SV680N represent the negative position limit, positive position limit, and the home respectively. Bit 16 to bit 20 represent the status of DI1 to DI5.


28. Positive limit switch	Node : 1 InoSV660N(E001)	60FDh-00.1(Inputs_Digital inputs_60FD_00)
29. Negative limit switch	Node : 1 InoSV660N(E001)	60FDh-00.0(Inputs_Digital inputs_60FD_00)
30. Immediate Stop Input	<Not assigned>	<未分配>
32. Encoder Phase Z Detection	<Not assigned>	<未分配>
33. Home switch	<Not assigned>	60FDh-00.2(Inputs_Digital inputs_60FD_00)
37. External Latch Input 1	Node : 1 InoSV660N(E001)	<未分配>
38. External Latch Input 2	<Not assigned>	<未分配>

## Note

As restricted by configurations of Omron software tool, axis configuration for SV680N series servo drives needs to be performed manually.

## Unit conversion setting

Set **Command pulse count per motor rotation** based on the resolution of the motor encoder (example: 67108864 PPR for motor equipped with 26-bit encoder). For the convenience of commissioning, set the **Work travel distance per motor rotation** to 60 mm/rev, indicating 1 mm/s equals to 1 rpm of the motor.



Select the **Unit of display** based on the actual operating unit when setting the gear ratio. All the position-type parameters in the host controller will be displayed in this unit.


### Operation settings

The screenshot shows the 'Operation Settings' window with the following parameters:

Velocity/Acceleration/Deceleration				
Maximum velocity	600	mm/s	Velocity warning value	0 %
Start velocity	0	mm/s		
Maximum jog velocity	600	mm/s		
Maximum acceleration	0	mm/s <sup>2</sup>	Acceleration warning value	0 %
Maximum deceleration	0	mm/s <sup>2</sup>	Deceleration warning value	0 %
Acceleration/deceleration over	Use rapid acceleration/deceleration (Blending is changed to Buffered)			
Operation selection at Reversing	Deceleration stop			
Torque				
Positive torque warning value	0	%	Negative torque warning value	0 %
Monitor				
In-position range	10	mm	In-position check time	0 ms
Actual velocity filter time constant	0	ms	Zero position range	10 mm


- **Velocity/Acceleration/Deceleration:** Set the maximum speed of the load (if the converted motor speed exceeds 6000 rpm, a parameter setting error, which is marked by a red box, will be reported by the host controller software) according to actual conditions. If the acceleration/deceleration rate is 0, the motion profile will be generated based on the maximum acceleration/deceleration rate (there is no need to set the acceleration/deceleration rate in general cases).
- **Torque:** If the warning value is 0, no warning will be reported. There is no need to set the warning value in general cases
- **Monitor:** Set **In-position range** and **Zero position range** based on actual motor and mechanical conditions. If the set value is too low, positioning or homing may not be completed.

### Limit settings



You can use the function of software position limit. The software position limit will be activated after homing.

### Homing settings



The homing mode involves cooperation between the servo drive and host controller. Set the homing mode according to the following table.

Description of NX Software	Servo Drive Function	Terminal Configuration
Home proximity signal	Home switch (FunIN.31)	-
Positive limit input	P-OT (FunIN.14)	DI1
Negative limit input	N-OT (FunIN.15)	DI2

Select the homing mode of the host controller and set the homing speed, acceleration, and home offset based on actual mechanical conditions.

- Introduction to homing  
Function block: MC\_Home and MC\_HomeWithParameter
  1. Set MC\_Home in the preceding figure and MC\_HomeWithParameter in the function block.
  2. The two function blocks both include 10 types of homing modes.

MC_Home	MC_HomeWithParameter
Proximity reverse turn/home proximity input OFF Proximity reverse turn/home proximity input ON Home proximity input OFF Home proximity input ON Limit input OFF Proximity reverse turn/home input mask distance Limit inputs only Proximity reverse turn/holding time No home proximity input/holding home input Zero position preset	Designate the homing action to be modified. 0: Proximity reverse turn/home proximity input OFF 1: Proximity reverse turn/home proximity input ON 4: Home proximity input OFF 5: Home proximity input ON 8: Limit input OFF 9: Proximity reverse turn/home input mask distance 11: Limit inputs only 12: Proximity reverse turn/holding time 13: No home proximity input/holding home input 14: Zero position preset


- Home proximity input OFF: The search for the home signal starts after the falling edge of the home proximity switch is reached.
- Home proximity input ON: The search for the home signal starts after the rising edge of the home proximity switch is reached.
- Proximity reverse turn: The home proximity signal is ON when homing starts, and reverse running applies after the falling edge of the home proximity signal is reached.
- Home input mask distance: The home signal is masked by the host controller within the set distance after receiving the homing signal (for example, edge change of home proximity signal), and the home signal is received only after the set distance passes.
- Holding time: The home signal is masked by the host controller within the set period of time after receiving the homing signal (for example, edge change of home proximity signal), and home signal is received only after the set period of time elapses.
- Zero position preset: The home offset is being written to the position reference/ position feedback in the host controller with current position as the home and motor at a standstill.

## Note

In all the homing modes, the home signal is searched at low speed. In case of operations at high speed, the home signal is hidden during decelerating from high speed to low speed.

## Distributed clock


The default clock is 1 ms. The synchronization clock (cycle of primary fixed-cycle tasks) named "PDO communication cycle" can be modified in **Task Settings**. The modification will be activated after switching to the online status at next power-on.




## Program-controlled servo operations



1. After configurations are done, you can control the servo operations through the PLC program.

If the MC\_POWER module is used, it is recommended to add the servo status bit "MC\_Axis000.DrvStatus. Ready" (MC\_Axis000 is the axis name). This is to prevent the situation where the PLC program is running but communication configuration is not done.




2. After all the settings and programming are done, switch to the online state, and

click  to download the program to the controller.

Click  to use the synchronization function. This function serves to compare the difference between the current program and the program in the controller, allowing users to determine whether to download the program to the controller, upload it from the controller  or leave it unchanged.

You can monitor the data through the monitoring list or collect the data waveform by using the data tracking function during operation.



### 6.3 Beckhoff TwinCAT3 as the Host Controller

This section describes how to configure the SV680N servo drive for working with Beckhoff TwinCAT3.






Figure 6-3 Configuration flowchart

### Installing the TwinCAT software

The TwinCAT3 software, which supports Windows7 32-bit or 64-bit systems, can be downloaded from the official website of Beckhoff.



---

### Note

The Ethernet card must be 100 M Ethernet card equipped with Intel chip. If other brands are used, the EtherCAT operation may fail.

---


1. Copy the SV680N EtherCAT configuration file (SV680\_1Axis\_V0.04-0506) to the TwinCAT installation directory: TwinCAT\3.1\Config\Io\EtherCAT.
2. Open TwinCAT3 and create a **New Twincat3 Project**.




## Installing the network adapter driver

Install the TwinCAT network adapter driver.



1. Open **Show Real Time Ethernet Compatible Devices...** in the menu shown in the preceding figure to display the following dialog box. Select local connection under **Incompatible devices**, and click **Install**.




2. After installation is done, the network adapter installed will be displayed under **Installed and ready to use devices(realtime capable)**.




### Searching for devices

1. Create a project and start searching for devices. Select  **Devices**, and click  as shown below.


The settings are shown as follows.




2. Click **OK**.




3. Click **OK**.




4. Click **OK**.




5. Click **OK**.



6. Click **Cancel**.




7. The search for the device is done, as shown below.



### Configuring servo drive parameters

Configure parameters through SDO communication in CoE - Online interface. When 200E-01h is set to 3, parameter values modified through SDO communication will be saved upon power failure. To modify 6060h to the CSP mode (8), follow the procedure shown in the following figure.



### Note

This operation is available only when H02.00 (Control mode) is set to 9 (EtherCAT mode).

### Configuring PDO

Select 0x1600 and 0x1A00 as shown in the following figure. Change the current PDO only if it does not fulfill your needs. To modify the PDO, right-click on the **PDO**

**Content** window, click **Delete** to delete the redundant PDO or click **Insert** to add the PDO needed.

The screenshot shows the TwinCAT software interface with the following data:

**Sync Manager:**

SM	Size	Type	Flags
0	256	MbaOut	
1	256	MbaIn	
2	8	Out...	
3	22	Inputs	

**Process Data:** Startup | CoE - Online | Online | NC: Online | NC: Functions

**PDO List:**

Index	Size	Name	Flags	SM	SU
0x1A00	22.0	Inputs		3	0
0x1B01	28.0	Inputs	F	0	0
0x1B02	25.0	Inputs	F	0	0
0x1B03	29.0	Inputs	F	0	0
0x1B04	29.0	Inputs	F	0	0
0x1B00	8.0	Outputs		2	0
0x1701	12.0	Outputs	F	0	0

**PDO Assignment (0x1C12):**

- 0x1B00
- 0x1701 (excluded by 0x1B00)
- 0x1702 (excluded by 0x1B00)
- 0x1703 (excluded by 0x1B00)
- 0x1704 (excluded by 0x1B00)
- 0x1705 (excluded by 0x1B00)

**Download:**

- PDO Assignment
- PDO Configuration

**PDO Content (0x1B00):**

Index	Size	Offs	Name	Type	Default
0x604...	2.0	0.0	Controlword	UINT	
0x607...	4.0	2.0	Target position	DINT	
0x60B...	2.0	0.0	Touch probe function	BOOL	
		8.0			

**Context Menu:**

- Insert...
- Delete...
- Edit...
- Move Up
- Move Down

The screenshot shows the TwinCAT software interface with the following data:

**Sync Manager:**

SM	Size	Type	Flags
0	256	MbaOut	
1	256	MbaIn	
2	8	Out...	
3	22	Inputs	

**Process Data:** Startup | CoE - Online | Online | NC: Online | NC: Functions

**PDO List:**

Index	Size	Name	Flags	SM	SU
0x1A00	22.0	Inputs		3	0
0x1B01	28.0	Inputs	F	0	0
0x1B02	25.0	Inputs	F	0	0
0x1B03	29.0	Inputs	F	0	0
0x1B04	29.0	Inputs	F	0	0
0x1B00	8.0	Outputs		2	0
0x1701	12.0	Outputs	F	0	0

**PDO Assignment (0x1C13):**

- 0x1A00
- 0x1B01 (excluded by 0x1A00)
- 0x1B02 (excluded by 0x1A00)
- 0x1B03 (excluded by 0x1A00)
- 0x1B04 (excluded by 0x1A00)

**Download:**

- PDO Assignment
- PDO Configuration

**PDO Content (0x1A00):**

Index	Size	Offs	Name	Type	Default
0x604...	2.0	0.0	Statusword	UINT	
0x608...	4.0	2.0	Position actual value	DINT	
0x60B...	2.0	8.0	Touch probe status	UINT	
0x60B...	4.0	9.0	Touch probe pos value	DINT	


**Context Menu:**

- Insert...
- Delete...
- Edit...
- Move Up
- Move Down


## Activating the configuration and switching to the operation mode

1. Click 






2. Click **OK**.



3. After you click **OK**, the device enters OP status as shown in the Online interface. Meanwhile, the 3rd LED on the keypad displays "8", and the keypad displays "\_\_88RY".




## Controlling servo drive operations

Control the servo drive through NC or PLC programs.


### 1. Operating in the CSP mode

- a. Set the unit.

Set the unit to **mm** during the test.




- b. Set the scaling factor.



Scaling factor: Indicates the distance corresponding to the encoder pulses per position feedback.

For example, 67108864 PPR correspond to a distance of 60 mm, then the scaling factor is:  $60/67108864 = 0.00000089406967163$  mm/Inc.

- c. Set the encoder feedback mode to **PosVelo**.




Descriptions for **Other Settings**:


**Encoder mode: POS, POSVELO, and POSVELOACC.**

- **POS**: The encoder only calculates the position, which is used when the position loop is in the servo drive.
- **POSVELO**: The encoder only calculates the position and speed, which is used when the position loop is in TWINCAT NC.
- **POSVELOACC**: The TWINCAT NC uses the encoder to determine the position, speed, and acceleration.


- d. Jogging test

Hide the system deviation temporarily.







Click **Set** to display a dialog box and then click **All** to enable the servo drive. Perform jogging through F1 to F4. The jog speed is set as follows.




2. Controlling the servo drive operations through the PLC
  - a. Create a PLC program.







b. Add a motion control library for calling the motion control function blocks.




c. Create a POU program.





d. Call the motion module to implement some simple actions and input the final program to **PlcTask**.




e. Link the axis to the variable defined in the PLC.




f. Compile the program. If there is not fault, activate the configuration and log onto the PLC.



g. Click **Start** to make the servo drive run.





3. Controlling the servo drive operations through the HMI  
Add the HMI interface to control the servo drive through the HMI interface.




## Using the scope view function

1. Add a scope view project as shown in the following figure.





2. Add parameters to be monitored and monitor these parameters during operation of the PLC.



## 6.4 KEYENCE KV7500 Controller as the Host Controller

### 6.4.1 Configuring the Servo Drive

- Servo drive versions  
It is recommended to use the device description file of "SV680N-Ecat\_v0.09.xml" or later for trial run of SV680N series servo drives. It is recommended to use the MCU software version of 901.4 (H01.00 = 901.4) or later for SV680N series servo drives.
- Description of 60FDh  
bit 0: negative limit switch bit 1: positive limit switch bit 2: home switch bit 16...bit 20 correspond to DI1...DI5 respectively.

### 6.4.2 Configuring KEYENCE KV7500 Software Tool

As software tool versions earlier than KV STUDIO 9.45 do not support extension of KEYENCE EtherCAT module "KV-XH16EC", the version of the KEYENCE software tool used must be KV STUDIO 9.45 or later.





Figure 6-4 Configuration flowchart


#### Unit configuration setting

Create a project and click **OK** to display the following window.




Click **Yes**, **No**, or **Read unit setting** as needed.

- Click **Read unit setting** when the physical PLC unit is connected properly and able to communicate with the software tool. The software tool obtains unit configurations automatically according to the physical connection.
- If you click **Yes**, the **Unit Editor** window opens, allowing you to select units for configuration through dragging or double-clicking.




- If you click **No**, you can click **Tool > Unit editor** or double-click **[0] KV7500** under **Unit configuration**.



## Axis configuration setting


1. Open **Axis configuration setting** and double-click **Register ESI file**.




2. Find the storage directory of the device description file ".xml" and open it to import the ".xml" file.

<input type="checkbox"/> 03023980-SV820N-3Axis-V3.03.xml	2019/8/30 20:34	XML
<input type="checkbox"/> 03024278-IS620N-Ecat_v2.6.8.xml	2019/9/16 9:18	XML
<input checked="" type="checkbox"/> SV680_1Axis_V0.09.xml	2019/12/30 15:04	XML
<input type="checkbox"/> SV820N_ECAT.xml	2018/3/21 8:47	XML


- After the device description file is imported, you can start to add axes and set the control cycle in **Axis configuration setting**. The default control cycle is 1 ms and the minimum control cycle is 250 us.
- You can add the axes needed through dragging or double-clicking. Select the corresponding axis and set critical information such as the **Encoder resolution**, **Max. motor speed**, and **Max. motor torque** for this axis.




- You can add **PDO mapping** in **Slave detailed setting**.




- If extension setting is needed, set **Extension setting** to **Enable**.




7. For **Motion function setting**, you can double-click or click on the combo box (small triangle icon) to select the PDO configuration needed from the dropdown list, or you can right-click > **Automatic assignment > Yes**, in this way the assigned contents will match preceding PDO contents automatically. During manual assignment, do not neglect any contents in the PDO mapping. Otherwise, a prompt window displays to remind you of the missing contents when you click **OK**. For **Communication command at initialization**, **DC setting**, and **Advanced settings**, use the default values. After settings are done, click **OK**.




8. After settings in **Slave detailed setting** are done, the exclamation symbol disappears.




9. After adding the axes, click **OK**, and the following dialog box opens, asking you whether to set up coordinate (namely electronic gear ratio) transformation.



- Click **Yes** and the coordinate transformation dialog box opens. Set mechanical parameters and the coordinate unit based on actual conditions and click **Execute calculation**. The software calculates the denominator and numerator for coordinate transformation automatically and writes parameters to **Axis control setting** automatically.




- If you click **No**, you can click **Tool > Coordinate transformation calculation > KV-XH setting > Coordinate transformation calculation**.



## Axis control setting

1. To open axis control setting, click **Tool > Axis configuration setting > KV-XH setting > Axis control setting**, or click **Axis control setting** under **Project**.
2. In axis control setting, you can set items including **Unit coordinate transformation**, **Software limit coord**, **Axis error**, **Axis control function**, **Common in position control**, **Operation speed**, and **JOG**.






## Operation settings

### Homing

Before homing, assign **(+) limit switch**, **(-) limit switch**, and **Origin sensor** in **Motion function setting** under **Axis configuration setting** to each bit of 60FDh. 60FDh is defined as follows:

bit 0: negative limit switch; bit 1: positive limit switch; bit 2: home switch; bit 16...bit 20: DI1...DI5

In automatic assignment, you need to assign **(+) limit switch**, **(-) limit switch**, and **Origin sensor** manually, you can assign them to corresponding bits of 60FDh based on the relationship shown in the following figure or to bit 16...bit 20, in this case, you also need to assign them to corresponding DI5 of the servo drive.



Set the limit parameters for homing in **Axis control setting > Origin return**. The following homing methods are available. For detailed trajectories, see KEYENCE instruction manual for positioning/motion control unit KV-XH16EC.

Default	Value Range	Description
DOG type (with phase Z)	DOG type (with phase Z)	Decelerating upon DOG signal input and homing through phase Z signal
	DOG type (without phase Z)	Decelerating upon DOG signal input and homing through falling edge of DOG signal
	DOG-type inching (with phase Z)	Pausing after moving based on Dog ON upon DOG signal input, then moving to the homing direction through position-type speed control and homing with phase Z signal
	DOG-type inching (without phase Z)	Moving based on Dog ON upon DOG signal input before homing
	DOG type (contact)	Homing executed when the ON duration of the torque limit signal keeps longer than the compression torque time upon DOG signal input
	Origin sensor and phase Z	Homing executed in the initial phase Z position after the origin sensor is ON
	Rising edge of origin sensor	Homing executed through the rising edge of the origin sensor
	Middle point of origin sensor (without phase Z)	Taking the middle point of the ON range of origin sensor as the origin and comparing it with that in "Rising edge of origin sensor". Even if the light-receptive performance of the origin sensor degrades, the homing position can hardly change with the time.
	Rising edge of limit switch	Homing executed with the limit switch in the negative direction (direction where the current coordinate decreases) as the origin sensor
	Immediate homing of phase Z	Homing executed with phase Z signal
	Data setting type	Taking current coordinate as the origin coordinate

The following homing methods are available in IS620N and SV680N series servo drives.

No.	Homing Mode	IS620N	SV680N
1	DOG-type (with phase Z)	OK	OK
2	DOG-type (without phase Z)	OK	OK
3	DOG-type inching (with phase Z)	No	No
4	DOG-type inching (without phase Z)	No	No


No.	Homing Mode	IS620N	SV680N
5	DOG-type (contact)	OK	Homing is available, but the reference coordinate after homing is not 0. Updating to the xml coordinate of IS620N clears the reference coordinate.
6	Origin sensor and phase Z	OK	OK
7	Rising edge of origin sensor	OK	OK
8	Middle point of origin sensor	No	No
9	Rising edge of limit switch	Homing is available, but the reference coordinate after homing is not 0	Homing is available, but the reference coordinate after homing is not 0
10	Immediate homing of phase Z	OK	OK

### Positioning


Set the unit coordinate transformation properly before positioning. The unit coordinate transformation is "PLS" by default, which allows no modification on the numerator or denominator. Assume N revolutions are required by the servo drive, in this case, the number of commands that need to be sent by the host controller is N x Pulses per revolution. If coordinate transformation calculation has been executed, the unit coordinate transformation parameters will match the unit transformation results automatically.

1. Set the motion profile of the servo drive in **Tool > Point parameter > KV-XH setting**.






- b. Move the mouse to the point target parameter, such as "No.1-Axis1", and wait until the mouse icon to change from an arrow to a small hand. Then drag towards the program edit interface with the right mouse button, and the following short-cut displays.



- c. Select the function needed, such as Operation enable, and click it to generate a DEMO program automatically. Then designate the part in red as the relay needed. After these actions are done, this function is done compiling.




#### 4. Unit monitor


The unit monitor supports monitoring on the operating state of KV-XH16EC or the internal data.

a. You can open **Unit monitor** in the following three ways:

- Select the unit to be monitored and right-click to select **Unit monitor** in the short-cut menu.




- Double-click with left mouse button to open the **Unit monitor**.
- Right-click the blank section in the **Main** program to select **Unit monitor** in the menu displayed.



b. The unit monitor displays the operating state of each axis.

- 1). To change the operating state of the monitor item, click **Monitor item setting** on the top right corner.



- 2). To check whether I/O signals such as limit switch signals and origin sensor signals are normal, open **Unit monitor** and find the corresponding monitoring position.

If corresponding message is received, a small black circle will be displayed.

The error state of the unit can also be displayed in the **Unit monitor**. The axis error can be cleared using the **Error clear** button in the bottom right.



### 6.4.3 Trial Run


In trial run, actions can be acknowledged directly, without the need for programming ladder diagrams.

1. You can find the trial run button at the bottom right of the unit monitor interface.
2. Select the control mode from positioning control, speed control, and torque control.
3. Then, select the object axis for trial run.

### Note

If trial run is executed in the speed control mode or torque control mode, a warning will be reported. To execute trial run, set the control mode to position control.

The following introduces **Trial run > Positioning control**.



1. OP enable/Servo ON

Unrelated to the status of the ladder diagram program. "OP enable" and "Servo ON" can be executed through **Commissioning**. After operations are done, the **Operation ready** and **Servo ready** indicators turn green. To ensure safety, set the CPU unit to PROG mode and execute operations again after stopping ladder diagram program.

Confirm the following items when the **Servo ready** indicator is not in green.

- No error occurs on the axis.
- No warning occurs on the servo drive.
- The main circuit power supply of the servo drive is switched on.
- The Ethernet cable is connected.

## 2. Axis error/Error clear

Check the error details and clear the error. After rectifying the error cause, click **Error clear** button to clear the error.

## 3. JOG

Click - **direction** or + **direction** buttons to execute forward or reverse jog, which operates with the speed multiplied by a certain ratio (settable with an increment of 1%) between 10% to 100% based on the setpoint in **Axis control setting > Jog at high speed**.

## 4. Inching

Click - **direction** or + **direction** buttons to execute forward or reverse inching based on **Axis control setting > JOG starting speed** and the movement value defined in **Axis control setting > Inching movement**.

## 5. Origin return

Click the **Origin return** button to execute homing.

## 6. Teaching


Click the **Acquire** button to save current command coordinate value to the buffer memory of the target coordinate of the designated point number. The teaching function is available only in the online edit mode. The teaching value will also be reflected to the buffer memory and the point parameter.

## 7. Trial run

Designate a point number and click the **Start** button to execute point positioning. To stop operation, click **Decel Stop** or **Force Stop** button to stop smoothly with speed reduced to zero gradually or stop immediately with shock being incurred. Clicking the **1 point operation** button makes the servo drive execute positioning of one point. Clicking the **Cont. operation** button makes the servo drive execute positioning of ten points at most. Clicking the **Repeat** button makes the servo drive return to the point in the first row and execute positioning repeatedly after positioning of the point in the last row is done. The time interval between points can be set to a value from 0.1s to 20.0s.

## 8. Changing current coordinate

Click **Command coordinate** and the **Changing current coordinate** dialog box opens. Enter the coordinate needing to be changed and click the **Change** button to change the current coordinate of the axis in trial run, and then close the **Changing current coordinate** dialog box. If you click the **Close** button after changing current coordinate, the **Changing current coordinate** dialog box will be closed with current coordinate unchanged.





19011537A00

---

Copyright © Shenzhen Inovance Technology Co., Ltd.

---

**Shenzhen Inovance Technology Co., Ltd.**

[www.inovance.com](http://www.inovance.com)

---

**Add.:** Inovance Headquarters Tower, High-tech Industrial Park,  
Guanlan Street, Longhua New District, Shenzhen

**Tel:** (0755) 2979 9595

**Fax:** (0755) 2961 9897

---

**Suzhou Inovance Technology Co., Ltd.**

[www.inovance.com](http://www.inovance.com)

---

**Add.:** No. 16 Youxiang Road, Yuexi Town,  
Wuzhong District, Suzhou 215104, P.R. China

**Tel:** (0512) 6637 6666

**Fax:** (0512) 6285 6720