



PS00007054A03

## GL20-0808ETN Series Digital Input and Output Module User Guide

---

**Suzhou Inovance Technology Co., Ltd.**

Add.: No.52, Tian E Dang Road, Wuzhong District,  
Suzhou 215104, P.R. China  
Tel: (0512) 6637 6666 Fax: (0512) 6285 6720  
[www.inovance.com](http://www.inovance.com)

>>>



# Preface

## ■ Introduction

GL20-0808ETN expansion module features 8-channel digital input and 8-channel NPN transistor output. It can be used with Easy series PLCs and GL20 series communication interface modules, such as GL20-RTU-ECT module.

This guide describes the mechanical installation, electrical installation, program commissioning, troubleshooting, and version matching information of the product.

## ■ Standards Compliance

The following table lists the certifications, directives, and standards that the product may comply with. For details about the acquired certificates, see the certification marks on the product nameplate.

| Certifica-tion        | Directive      |                                    | Standard  |
|-----------------------|----------------|------------------------------------|---|
| CE Certifica-tion     | EMC Directive  | 2014/30/EU                         | <b>24 VDC products:</b><br>EN 61131-2<br><b>220 VAC products:</b><br>EN 61131-2<br>EN 61000-3-2<br>EN 61000-3-3 |
|                       | LVD Directive  | 2014/35/EU                         | EN 61010-1<br>EN 61010-2-201  |
|                       | RoHS Directive | 2011/65/EU amended by (EU)2015/863 | EN IEC 63000  |
| UL/cUL Certifica-tion | -              |                                    | UL 61010-1<br>UL 61010-2-201<br>CAN/CSA-C22.2 No. 61010-1<br>CSA C22.2 NO. 61010-2-201                          |
| KCC Certifica-tion    | -              |                                    | -   |
| EAC Certifica-tion    | -              |                                    | -   |

| Certification      | Directive          |  | Standard  |
|--------------------|--------------------|--|---|
| UKCA Certification | Safety Regulations | Electrical Equipment (Safety) Regulations 2016 | EN 61010-1<br>EN 61010-2-201  |
|                    | EMC Regulations    | Electromagnetic Compatibility Regulations 2016 | <b>24 VDC products:</b><br>EN 61131-2<br><b>220 VAC products:</b><br>EN 61131-2<br>EN 61000-3-2<br>EN 61000-3-3 |
|                    | RoHS Regulations   | Directive (RoHS) Regulations 2012              | EN IEC 63000  |

## ■ More Data

| Name  | Code       | Description   |
|---|------------|---|
| GL20-RTU-ECT Series Communication Interface Module User Guide               | PS00004985 |   |
| GL20-RTU-ECT32 Series Communication Interface Module User Guide             | PS00013434 |   |
| GL20-RTU-PN Series Communication Interface Module User Guide                | PS00007594 |   |
| GL20-RTU-EIP Series Communication Interface Module User Guide               | PS00014402 | Introduces the mechanical installation, electrical installation, program commissioning, troubleshooting, and version matching information of the product. |
| GL20-0808ETN Series Digital Input and Output Module User Guide (This guide) | PS00007054 |   |

## ■ Revision History

| Date         | Version | Revision  |
|--------------|---------|---|
| March 2025   | A03     | <p><b>Added:</b></p> <p>Added "<a href="#">2.1 Installation Precautions</a>" on <a href="#">page 17</a>.</p> <p><b>Modified:</b></p> <ul style="list-style-type: none"><li>• Modified "<a href="#">1.2 Components</a>" on <a href="#">page 10</a>.</li><li>• Modified the output PDO data volume in "<a href="#">1.3 Technical Specifications</a>" on <a href="#">page 12</a>.</li><li>• Modified "<a href="#">2.2 Installation Dimensions</a>" on <a href="#">page 17</a>.</li><li>• Modified the wiring diagram in "<a href="#">3.3 Terminal Wiring</a>" on <a href="#">page 23</a>.</li><li>• Modified the operation steps in "<a href="#">Program Commissioning</a>" on <a href="#">page 25</a>.</li><li>• Modified "<a href="#">Troubleshooting</a>" on <a href="#">page 33</a>.</li><li>• Modified "<a href="#">Appendix: Version Matching Information</a>" on <a href="#">page 35</a>.</li></ul> |
| August 2023  | A02     | Made minor corrections.   |
| June 2023    | A01     | Modified the wiring diagram. Added "Troubleshooting" and "Version Matching Information" sections.   |
| October 2022 | A00     | Initial release.  |

## ■ Access to the Guide

This guide is not delivered with the product. You can obtain the PDF version in the following ways

- Do keyword search under Service and Support at [www.inovance.com](http://www.inovance.com).
- Scan the QR code on the product with your smart phone.
- Scan the QR code below to install My Inovance app, where you can search for and download user guides.



## ■ **Warranty Disclaimer**

Inovance provides warranty service within the warranty period (as specified in your order) for any fault or damage that is not caused by improper operation of the user. You will be charged for any repair work after the warranty period expires.

Within the warranty period, maintenance fee will be charged for the following damage:

- Damage caused by operations not following the instructions in the user guide
- Damage caused by fire, flood, or unusual voltage
- Damage caused by unintended use of the product
- Damage caused by use beyond the specified scope of application of the product
- Damage or secondary damage caused by force majeure (natural disaster, earthquake, and lightning strike)

The maintenance is charged according to the latest Price List of Inovance. If otherwise agreed upon, the terms and conditions in the agreement shall prevail.

For details, see Product Warranty Card.

# Safety Precautions

## ■ Safety Disclaimer

1. Read and follow the safety instructions when installing, operating, and maintaining the equipment.
2. To ensure your safety and prevent damage to the equipment, follow the marks on the equipment and all the safety instructions in this guide.
3. "CAUTION", "WARNING", and "DANGER" items in the guide do not indicate all safety precautions that need to be followed; instead, they just supplement the safety precautions.
4. Use this equipment according to the designated environment requirements; otherwise, a fault may occur. Malfunction or damage caused by improper use is not covered by warranty.
5. Inovance shall take no responsibility for any personal injury or property damage caused by improper use.

## ■ Safety Levels and Definitions



"DANGER" indicates that failure to comply with the notice can result in death or severe personal injuries.



"WARNING" indicates that failure to comply with the notice may result in death or severe personal injuries.



"CAUTION" indicates that failure to comply with the notice may result in minor or moderate personal injuries or equipment damage. Keep this guide properly for future use and deliver it to the end user.

## Control System Design



- Provide a safety circuit outside the PLC so that the control system can still work safely once external power failure or controller fault occurs.
- Add a fuse or circuit breaker because the module may smoke or catch fire due to long-time overcurrent caused by operation above rated current or load short-circuit.

 **WARNING**

- An emergency stop circuit, a protection circuit, a forward/reverse operation interlocked circuit, and an upper position limit and lower position limit interlocked circuit must be set in the external circuits of PLC to prevent damage to the equipment.
- To ensure safe operation, for the output signals that may cause critical accidents, use external protection circuits and safety mechanism.
- Once the CPU of the PLC detects an exception in the system, all outputs may be closed; however, when a fault occurs in the controller circuit, the output may not be under control. Therefore, it is necessary to design an appropriate external control circuit to ensure normal operation.
- If the output units such as relays or transistors are damaged, the output may fail to switch between ON and OFF states according to the commands.
- The PLC is designed to be used in an indoor electrical environment (overvoltage category II). The power supply must have a system-level surge protector, assuring that overvoltage due to lightning shock cannot be applied to the PLC's power supply input terminals, signal input terminals, and output terminals, to prevent damage to the equipment.

## **Installation**

 **WARNING**

- Installation must be carried out by skilled personal who have undergone specialized electrical training and possess comprehensive electrical expertise.
- Disconnect all external power supplies of the system before removing/installing the module. Failure to do so may result in electric shock, module fault, or malfunction.
- Do not use the PLC in environments with dust, greasy smoke, conductive dust, corrosive or combustible gases, exposed to high temperature, condensation, wind & rain, or subject to vibration and shock. Electric shock, fire, and malfunction may also result in damage or deterioration to the product.
- The PLC is open-type equipment that must be installed in a control cabinet with lock (cabinet housing protection > IP20). Only the skilled personnel who have undergone specialized electrical training and possess comprehensive electrical expertise can open the cabinet.

 **CAUTION**

- Prevent metal filings and wire ends from dropping into ventilation holes of the PLC during installation. Failure to comply may result in fire, fault, and malfunction.
- Ensure there are no unwanted matters on ventilation surface. Failure to comply may result in poor ventilation, which may cause fire, fault, and malfunction.
- Ensure the module is connected to the respective connector securely and hook the module firmly. Improper installation may result in malfunction, fault, or fall-off.

## Wiring



- Wiring must be carried out by skilled personnel who have undergone specialized electrical training and possess comprehensive electrical expertise.
- Disconnect all external power supplies of the system before wiring. Failure to comply may result in electric shock, module fault, or malfunction.
- Insulate the cable terminals properly to ensure the insulation distance between cables will not be shortened after cables are connected to the terminal block. Failure to comply may result in electric shock or damage to the equipment.



- To avoid electric shock, cut off the power supply before connecting the product to the power supply.
- The input power of the product must meet the specifications listed in this guide. If the power input does not meet the specifications, the equipment may be damaged. Thus, check regularly that the DC power provided by the switching-mode power supply unit is stable.

## Operation and Maintenance



- Operation and maintenance must be carried out by skilled personnel who have undergone specialized electrical training and possess comprehensive electrical expertise.
- Do not touch the terminals while the power is on. Failure to comply may result in electric shock or malfunction.
- Disconnect all external power supplies of the system before cleaning the module. Failure to comply may result in electric shock.
- Disconnect all external power supplies of the system before assembling/disassembling the module or connecting/removing the communication cables. Failure to comply may result in electric shock or malfunction.

## **Safety Recommendations**

- In the position where the operator directly touches the machinery part, for example, where a machinery tool is loaded/unloaded, or where a machine runs automatically, the on-site manual operating devices and any other alternative means must be carefully arranged and designed so that they are independent of the PLC and can start or terminate the automatic running of the system.
- If modification on the program is needed during system operation, use the lock function or other protective measures. Ensure that only authorized personnel can make the necessary modifications.

## **Disposal**



- Treat the scrapped equipment as industrial waste. Dispose of the battery according to local laws and regulations.
- Recycle retired equipment in accordance with industry waste disposal standards to avoid environmental pollution.


# 1 Product Information

## 1.1 Naming Rules and Nameplate

GL 20 -08 08 E TN

①      ②      ③      ④      ⑤      ⑥


|   |   |   |
|---|---|---|
| ① <b>Product Information</b><br>GL: Inovance general local module | ③ <b>Number of Input Channels</b><br>8 inputs   | ⑤ <b>Module Type</b><br>Logic I/O expansion module    |
| ② <b>Series Number</b><br>20: 20 series module                    | ④ <b>Number of Output Channels</b><br>8 outputs | ⑥ <b>Output Type</b><br>Transistor output (sink type) |



The data for ordering the product is shown below.

| Model        | Description   | Material Code | Applicable Model   |
|--------------|---|---------------|--|
| GL20-0808ETN | GL20 series module with 8-channel digital inputs and 8-channel NPN transistor outputs | 01440339      | GL20 series communication interface modules and Easy series PLCs |

## 1.2 Components



| No. | Name                 | Description  |   |              |  |
|-----|----------------------|--|---|--------------|--|
| ①   | Signal indicator     | PR<br>(POWER +RUN)   | Power/Run indicator   | Yellow-green | <ul style="list-style-type: none"> <li>• Steady ON: The module is operating normally.</li> <li>• Flashing quickly: The module is addressed successfully.</li> <li>• Flashing slowly: The module is powered on but not addressed.</li> <li>• OFF: The module is not powered on or is faulty.</li> </ul> |
|     |                      | ERR  | Fault indicator   | Red          | ON when the module is faulty. For details, see " <a href="#">"Troubleshooting" on page 33</a>  |
| ②   | I/O signal indicator | 00 to 07   | I/O signal indicator  | Yellow-green | <ul style="list-style-type: none"> <li>• Steady ON: The input/output is active.</li> <li>• OFF: The input/output is inactive.</li> </ul>   |
| ③   | Color identification |  Red: Digital output  |  Orange: Analog output |              |  |
|     |                      |  Gray: Digital input  |  Green: Analog input   |              |  |
|     |                      |  White: Communication |  Blue: Other modules   |              |  |
| ④   | I/O terminals        | /  | 8 input and 8 outputs   | /            | For details, see " <a href="#">"3.2 Terminal Definition" on page 23</a>  |

## Note

- Quick flashing: The indicator is on for 200 ms and off for 50 ms, repeating this cycle.
- Slow flashing: The indicator is on for 200 ms and off for 1 s, repeating this cycle.

## 1.3 Technical Specifications

### ■ General specifications

| Item                   | Specification          |
|------------------------|------------------------|
| IP rating              | IP20                   |
| Dimensions (W x H x D) | 12 mm x 100 mm x 75 mm |
| Weight                 | About 60 g             |

### ■ Power supply specifications

| Item  | Specification                 |
|---|-------------------------------|
| Rated voltage of bus input power supply       | 5 VDC (4.75 VDC to 5.25 VDC)  |
| Rated current of bus input power supply       | 130 mA (typical value @5 V)   |
| Rated voltage of terminal input power supply  | 24 VDC (20.4 VDC to 28.8 VDC) |
| Rated current of terminal input power supply  | 100 mA (typical @24 V)        |
| Rated voltage of terminal output power supply | /                             |
| Rated current of terminal output power supply | /                             |
| Hot swap                                      | Not supported                 |

### ■ Input specifications

| Item                          | Specification                           |
|-------------------------------|---|
| Input type                    | Digital input                           |
| Input mode                    | Sink mode                               |
| Number of input channels      | 8                                       |
| Input voltage class           | 24 VDC $\pm$ 10% (21.6 VDC to 26.4 VDC) |
| Input current (typical value) | 4 mA (typical @24 V)                    |

| Item                                   | Specification  |
|--|--|
| ON voltage                             | 15 VDC   |
| OFF voltage                            | < 5 VDC  |
| Hardware response time upon ON/<br>OFF | 100 us/100 us  |
| Software filter time                   | Supported  |
| Input impedance                        | Reference value: 5.3 k to 5.6 k  |
| Isolation                              | Isolated   |
| Input indicator                        | The input indicator turns on (controlled by software) when the input is in drive state.  |
| Input derating                         | The module operates at full load at 45°C (with the number of simultaneously ON input channels not exceeding 8) and operates at 50% of full load at 55°C (with the number of simultaneously ON input channels not exceeding 4). |

## ■ Output specifications

| Item                                   | Specification  |
|--|--|
| Output type                            | Digital output/transistor output                                 |
| Output mode                            | Sink mode  |
| Number of output channels              | 8  |
| Output voltage class                   | 24 VDC $\pm$ 10% (21.6 VDC to 26.4 VDC)                          |
| Resistive output load                  | 0.5 A/channel; 2 A/module  |
| Inductive output load                  | 7.2 W/channel; 12 W/module                                       |
| Lamp output load                       | 5 W/channel; 9 W/module  |
| Hardware response time upon ON/<br>OFF | 100 us/100 us  |
| Leakage current upon OFF               | 10 $\mu$ A   |
| Switching frequency                    | Resistive load: 100 Hz; inductive load: 0.5 Hz; lamp load: 10 Hz |
| Isolation                              | Isolated   |

| Item                 | Specification  |
|----------------------|--|
| Output indicator     | The output indicator turns on (controlled by software) when the output is in drive state.  |
| Output derating      | The module operates at full load (with the output current of all simultaneously ON output channels not exceeding 2 A) at 45°C, and operates at 50% of full load at 55°C (with the output current not exceeding 1 A). |
| Protective functions | Short circuit protection and overcurrent protection  |

## ■ Software specifications

| Item   | Specification   |
|--|---|
| Input PDO data volume                          | Max. 1 byte   |
| Output PDO data volume                         | Max. 1 byte   |
| Output state mode during fault stop            | Output zero, last value, or preset value                                      |
| Preset value output during fault stop          | 0 or 1  |
| Output terminal fault detection and indication | Not supported   |
| Output channel logic level configuration       | Not supported   |
| Independent channel enable configuration       | Not supported   |
| Diagnostic report function configuration       | Not supported   |
| Output in the stop mode                        | Outputted based on fault stop state mode and preset value (no longer updated) |

## Note

Stop at fault refers to:

- Background start/stop;
- The bus of GL20 communication interface module is out of communication due to disconnection of the network cable or manual state switching;
- The local bus stops operation.

## 1.4 Environmental Specifications

| Item  | Specification  |
|---|--|
| Installation/<br>application<br>environment | Free from conductive dust, conductive fibers, explosive dust, flammable gases, water mist/greasy dirt, corrosive dusts/gases, strong vibration, and repetitive shock   |
| Altitude                                    | ≤ 2,000 m  |
| Pollution degree                            | 2  |
| Immunity                                    | 2 kV on power supply cable (compliant with IEC 61000-4-4)  |
| Overvoltage category                        | I  |
| EMC immunity level                          | Zone B, IEC61131-2   |
| Anti-static rating                          | Contact discharge +/- 6 kV and air discharge +/- 8 kV  |
| Vibration resistance                        | <ul style="list-style-type: none"><li>• Application scenario: Tested according to IEC60068-2-6, 3.5 mm amplitude from 5 Hz to 8.4 Hz; 1 g acceleration from 8.4 Hz to 200 Hz; 10 cycles per axial direction</li><li>• Transportation scenario: Tested according to IEC60068-2-64, 0.01 g<sup>2</sup>/Hz power spectral density from 5 Hz to 100 Hz; 0.001 g<sup>2</sup>/Hz power spectral density at 200 Hz; 1.14 g Grms</li></ul> |
| Shock resistance                            | Application/Transportation scenario: Tested according to IEC60068-2-27; 15 g peak acceleration, 11 ms pulse width, 18 cycles in total in X, Y and Z axial directions   |
| Operating<br>temperature/humidity           | <ul style="list-style-type: none"><li>• Temperature: -20°C to +55°C</li><li>• Humidity: &lt; 95% RH (30°C), without condensation</li></ul>   |

| Item                                   | Specification  |
|--|--|
| Storage temperature/<br>humidity       | <ul style="list-style-type: none"><li>• Temperature: -20°C to +60°C</li><li>• Humidity: &lt; 95% RH (30°C), without condensation</li></ul> |
| Transportation<br>temperature/humidity | <ul style="list-style-type: none"><li>• Temperature: -40°C to +70°C</li><li>• Humidity: &lt; 95% RH (40°C), without condensation</li></ul> |

## 2 Mechanical Installation


### 2.1 Installation Precautions

- Make sure the module is powered off before installing or removing.
- Do not hot swap the modules. Otherwise, the modules may be damaged by overcurrent or overvoltage, and the communication interface module or PLC may be subject to restart, user data loss or corruption.
- Do not drop or shock the housing or terminals of the module to avoid damage.


### 2.2 Installation Dimensions

#### ■ Module

The installation dimensions (in mm) are shown in the figure below.




## ■ Cable connection



### 2.3 Installation Method

The module is mounted onto a DIN rail according to IEC 60715 (width: 35 mm, thickness: 1 mm). The dimensions (in mm) are shown below.






## Caution

If the thickness of the DIN rail is not as required, the product cannot fit in or function properly as the DIN rail mounting hook does not work.


### ■ **Installing modules side by side**

Install modules side by side by sliding them along the top and bottom guide rails of the module, as shown below.




### ■ **Installing modules onto DIN Rail**

1. Align the module with the DIN rail and push the module in the direction indicated by the arrow until you hear a click, as shown below.



2. Make sure the DIN rail mounting hook of the module is locked. The locked and unlocked states of the mounting hook are shown below.



- If the mounting hook is pressed down, it is locked.
- If the mounting hook is lifted up, it is unlocked.


To lock the module to the DIN rail, press down the mounting hook.



When the module is not installed on the DIN rail, keep the rail hook in locked state. A hook that kept in unlocked state for a long period of time may fail to function properly.


3. Install a DIN rail end plate on both sides of the PLC or the module.

To install the end plate, hook the bottom of it to the bottom of the DIN rail, rotate the end plate to hook the top of it to the top of the DIN rail, and then tighten the screw to lock the end plate in place.



## ■ Removing modules

Pry the DIN rail mounting hook upwards with a tool such as a slotted screwdriver, hold the protrusions and pull the module out straight forward. Then, press down the top of the mounting hook.




### 3 Electrical Installation

#### 3.1 Cable Selection

The cable lug and cable diameter included in the following table are only for reference.

| Material Name | Cable Diameter  |     | KST   |               | Suzhou Yuanli |               |
|---------------|-----------------|-----|-------|---------------|---------------|---------------|
|               | mm <sup>2</sup> | AWG | Model | Crimping Tool | Model         | Crimping Tool |
| Tubular lug   | 0.3             | 22  | E0308 | KST2000L      | 0308          | YAC-5         |
|               | 0.5             | 20  | E0508 |               | 0508          |               |
|               | 0.75            | 18  | E7508 |               | 7508          |               |
|               | 1.0             | 18  | E1008 |               | 1008          |               |
|               | 1.5             | 16  | E1508 |               | 1508          |               |

To use other types of tubular lugs, crimp the lug to the cables according to the shape and dimension requirements shown below.



### 3.2 Terminal Definition



| Left Indicator | Left Signal | Left Terminal | Right Terminal | Right Signal | Right Indicator |
|----------------|-------------|---------------|----------------|--------------|-----------------|
| 00             | DI0         | A1            | B1             | DO0          | 08              |
| 01             | DI1         | A2            | B2             | DO1          | 09              |
| 02             | DI2         | A3            | B3             | DO2          | 10              |
| 03             | DI3         | A4            | B4             | DO3          | 11              |
| 04             | DI4         | A5            | B4             | DO4          | 12              |
| 05             | DI5         | A6            | B6             | DO5          | 13              |
| 06             | DI6         | A7            | B7             | DO6          | 14              |
| 07             | DI7         | A8            | B8             | DO7          | 15              |
| /              | 24V         | A9            | B9             | COM          | /               |


### 3.3 Terminal Wiring

This section introduces the wiring precautions and circuit block diagram of the GL20-0808ETN module.

## ■ Wiring precautions

- Do not bundle the expansion cable together with power cables (with high voltage and large current) that produce strong interference signals; otherwise, the expansion cable may be influenced by noise, surge, or induction. Separate it from other cables and avoid cabling in parallel.
- Use recommended cables and adapter boards for connection. It is recommended that shielded cables be used as expansion cables to enhance anti-interference capacity.
- Apply single-point grounding for the shielding of shielded cable and solder sealed cable.

## ■ Circuit block diagram and wiring diagram




# 4 Program Commissioning

The following is an example where AM600 is used as the master control module along with the GL20-0808ETN module.


1. Enable the AM600 series PLC as the EtherCAT master and add the GL20-RTU-ECT communication interface module.

- In the left **Devices** pane, double-click **Network Configuration** and click the AM600 figure in the upper left corner of the interface. Check the "EtherCAT Master" to enable the PLC as an EtherCAT master.




- Add the GL20-RTU-ECT communication interface module.

- Method 1: In the right **Network Devices List**, double-click "GL20-RTU-ECT" to add the module.



- Method 2: In the left **Devices** pane, right-click **ETHERCAT(EtherCAT Master SoftMotion)** ① and select **Add Device**. Select "GL20\_RTU\_ECT \_x.x.x.x" ② in the pop-up dialog box and click **Add Device** ③.



Method 3: In the left **Devices** pane, right click **ETHERCAT(EtherCAT Master SoftMotion)** and select **Scan For Devices**. Click **Scan Devices**, select the GL20-RTU-ECT module, and click **Copy Scan Device**.




2. Add the GL20-0808ETN module.

- Method 1: Open the **Hardware Configuration** pane by double-clicking **EtherCAT Config** ① in the left **Devices** pane, or double-clicking the GL20-RTU-ECT figure in the **Network Configuration** pane. In the right **In\Output Module List**, double-click "GL20-0808ETN" ② or drag the GL20-0808ETN module and place it after the GL20-RTU-ECT module.




- Method 2: In the left **Devices** pane, right click "GL20\_RTU\_ECT" ① and select **Add Device**. Select "GL20-0808ETN" ② in the pop-up dialog box and click **Add Device** ③.



- Method 3: In the left **Devices** pane, right-click **ETHERCAT(EtherCAT Master SoftMotion)** and select **Scan For Devices**. Click **Scan Devices**, select the GL20-0808ETN module, and click **Copy Scan Device**.

3. Double-click the GL20-0808ETN module ① to set the **Channels Config** ②.




The parameters for channel configuration are shown in the following table.


| Name                                   | Description   | Configuration   |
|--|---|---|
| Filter time                            | Debounce filter time of the digital input channel   | <p>The following parameter values are supported:</p> <ul style="list-style-type: none"> <li>• No filter</li> <li>• 0.25 ms</li> <li>• 0.5 ms</li> <li>• 1 ms (default value)</li> <li>• 2 ms</li> <li>• 4 ms</li> <li>• 8 ms</li> <li>• 16 ms</li> <li>• 32 ms</li> </ul>   |
| Out status after stop or disconnection | Output mode of the output channel of the module in non-OP state (when the module is stopped or the coupler is disconnected) | <p>The following options are supported:</p> <ul style="list-style-type: none"> <li>• <b>Output last value:</b> All channels in the corresponding group retain the output state before module stop or network disconnection.</li> <li>• <b>Output preset value:</b> The output mode of each channel in the corresponding group matches the preset values. The preset value is matched by bit, with one bit representing one channel. For example, if bit0 is set to FALSE, the output state of channel 0 is 0; if bit0 is set to TRUE, the output state of channel 0 is 1.</li> <li>• <b>Bitwise setting:</b> The output mode of each channel in the corresponding group is matched by bit, with one bit representing one channel. For example, bit0 represents channel 0. If bit0 is set to TRUE, channel 0 outputs according to its preset value. If bit0 is set to FALSE, channel 0 retains the last output state.</li> </ul> |

#### 4. Create input/output variables.

a. In the left **Devices** pane, double-click **PLC\_PRG** ① and click  ② in the upper right corner to switch to table mode.




b. Add the custom input variable "CHI0" and output variable "CHO0". Set the scope of these variables to "VAR" and data type to "INT", as shown below.




#### 5. Map the input/output variable to the corresponding input/output channel.


a. In the left **Devices** pane, double-click **GL20\_RTU\_ECT** ① and click the **EtherCAT I/O Mapping** tab ②.



b. On the **EtherCAT I/O Mapping** tab, double-click a variable entry and click ① to open the **Input Assistant** dialog box. Choose **Application > PLC\_PRG** > specific variables ② and click **OK** ③.



Map the input variable "CH10" to the input channel of the configuration module, and map the output variable "CH00" to the output channel, as shown below.




- Double-click **PLC\_PRG** in the left **Devices** pane and complete the programming on the **PLC\_PRG** page.
- Check, compile, log in, download, and run the program.

- a. Click  on the toolbar at the top of the interface to check whether the program is correct.
- b. Click  on the toolbar to compile all the code into PLC executable code.
- c. Click  on the toolbar, and follow the interface prompts to log in to the PLC and download the program.
- d. Click  on the toolbar to execute the program.

# 5 Troubleshooting

When the ERR indicator is ON, the module is faulty. The module reports a fault code. You can get the fault code through the diagnostic data object dictionary value displayed on the **CoE Online** interface, as shown below. For the module installed in slot n (n = 0 to 31), the object dictionary definition for index 0xA000+0x40\*n is shown in the table below.



| GL20_RTU_ECT                    |                |   |       |                                      |  |  |
|---------------------------------|----------------|---|-------|--------------------------------------|--|--|
| General                         |                | Read this page                                |       | <input type="checkbox"/> Auto Update | <input checked="" type="radio"/> Offline from ESI file | <input type="radio"/> Online from device |
| Process Data(PDO Setting)       | Index:Subindex | Name  | Flags | Type                                 | Value  |  |
| Startup parameters(SDO Setting) | 16#1008:16#00  | Device Name                                   | RO    | STRING(16)                           |  |  |
| Online                          | 16#1009:16#00  | Hardware version                              | RO    | STRING(16)                           |  |  |
| CoE Online                      | 16#100A:16#00  | Software version                              | RO    | STRING(16)                           |  |  |
| Device Diagnosis                | 16#1018:16#00  | Identity                                      | RO    | USINT                                |  |  |
| EtherCAT I/O Mapping            | 16#1C00:16#00  | Sync manager type                             | RO    | USINT                                |  |  |
| EtherCAT IEC Objects            | 16#1C12:16#00  | RxPDO assign                                  | RO    | USINT                                |  |  |
| Status                          | 16#1C13:16#00  | TxDPO assign                                  | RO    | USINT                                |  |  |
| Information                     | 16#1C32:16#00  | SM output parameter                           | RO    | USINT                                |  |  |
|                                 | 16#1C33:16#00  | SM input parameter                            | RO    | USINT                                |  |  |
|                                 | 16#3010:16#00  | Port 0 error counter                          | RO    | USINT                                |  |  |
|                                 | 16#3011:16#00  | Port 1 error counter                          | RO    | USINT                                |  |  |
|                                 | 16#3012:16#00  | ESC error counter                             | RO    | USINT                                |  |  |
|                                 | 16#3016:16#00  | Station address                               | RO    | USINT                                |  |  |
|                                 | 16#3020:16#00  | Fpga soft version                             | RO    | UDINT                                |  |  |
|                                 | 16#3021:16#00  | Module software version                       | RO    | USINT                                |  |  |
|                                 | 16#6000:16#00  | 0808ETN input                                 | RO    | USINT                                |  |  |
|                                 | 16#7000:16#00  | 0808ETN output                                | RO    | USINT                                |  |  |
|                                 | 16#8000:16#00  | 0808ETN DI-CHO Filter time parameters         | RW    | USINT                                |  |  |
|                                 | 16#8001:16#00  | 0808ETN module configure stopmode parameters  | RW    | USINT                                |  |  |
|                                 | 16#8002:16#00  | 0808ETN module configure stopvalue parameters | RW    | USINT                                |  |  |
|                                 | 16#A000:16#00  | 0808ETN Diagnosis information                 | RO    | USINT                                |  |  |
|                                 | 16#01          | 0808ETN Moudle Diagnosis information          | RO    | UINT                                 |  |  |
|                                 | 16#02          | 0808ETN DI-CHO Diagnosis information          | RO    | UINT                                 |  |  |
|                                 | 16#03          | 0808ETN DO-CHO Diagnosis information          | RO    | UINT                                 |  |  |
|                                 | 16#F000:16#00  | Modular device profile                        | RO    | USINT                                |  |  |
|                                 | 16#F030:16#00  | Configured Module Ident List                  | RO    | USINT                                |  |  |
|                                 | 16#F050:16#00  | Detected Module Ident List                    | RO    | USINT                                |  |  |
|                                 | 16#F100:16#00  | Device Status                                 | RO    | USINT                                |  |  |
|                                 | 16#F110:16#00  | Module Error Flag                             | RO    | USINT                                |  |  |
|                                 | 16#F120:16#00  | LBus Count                                    | RO    | USINT                                |  |  |
|                                 | 16#F800:16#00  | Device configuration data                     | RO    | USINT                                |  |  |
|                                 | 16#FB00:16#00  | Control word                                  | RW    | UINT                                 |  |  |

| Index    | 0xA000+0x40*n: 0808ETN Diagnostic Information |           |             |         |               |
|----------|---|-----------|-------------|---------|---------------|
| Subindex | Name  | Data Type | Access Mode | Mapping | Default Value |
| 0        | 0808ETN fault code                            | USINT     | RW          | NO      | 3             |
| 1        | 0808ETN module fault information              | UINT      | RO          | NO      | 0             |
| 2        | 0808ETN module input fault information        | UINT      | RO          | NO      | 0             |
| 3        | 0808ETN module output fault information       | UINT      | RO          | NO      | 0             |

## ■ Module fault code

| Code   | Description                 | Solution                                       |
|--------|-----------------------------|--|
| 0x5003 | External 24 V power failure | Check the isolated power supply of the module. |

## 6 Appendix: Version Matching Information

Contact Inovance technical support to obtain the firmware of GL20-0008ETN module and the firmware of communication interface module. XML files and the AutoShop/InoProShop software can be downloaded from the software and debugging tools tab on the GL20 series product page at <https://www.inovance.com>. The following table describes the version matching information.

| Module Firmware Version | Communication Interface Module Firmware Version  | XML/GSD File Version   | AutoShop/InoProShop Version   |
|-------------------------|--|--|---|
| Logic software: 1.1.0.0 | <ul style="list-style-type: none"><li>• GL20-RTU-ECT: Board software 2.4.18.0 and later</li><li>• GL20-RTU-ECT32: Board software 2.5.10.0 and later</li><li>• GL20-RTU-PN: Board software 2.1.1.0 and later</li><li>• GL20-RTU-EIP: Board software 1.1.6.0 and later</li></ul> | <ul style="list-style-type: none"><li>• GL20-RTU-ECT: 1.3.9.0 and later</li><li>• GL20-RTU-ECT32: 3.0.1.0 and later</li><li>• GL20-RTU-PN: 20230523 and later</li><li>• GL20-RTU-EIP: V00.01 and later</li></ul> | <ul style="list-style-type: none"><li>• AutoShop: V4.6.5.0 and later</li><li>• InoProShop: V1.7.3 SP5 and later</li></ul> |